

## A Word to Mazda Owners

---

Thank you for choosing a Mazda. We at Mazda design and build vehicles with complete customer satisfaction in mind.

To help ensure enjoyable and trouble-free operation of your Mazda, read this manual carefully and follow its recommendations.

Regular servicing of your vehicle by an expert repairer helps maintain both its roadworthiness and its resale value. A world-wide network of Authorised Mazda Repairers can help you with their professional servicing expertise.

Their specially trained personnel are best qualified to service your Mazda vehicle properly and exactly. Also, they are supported by a wide range of highly specialized tools and equipment specially developed for servicing Mazda vehicles. When maintenance or service is necessary, consult an Authorised Mazda Repairer.

We assure you that all of us at Mazda have an ongoing interest in your motoring pleasure and in your full satisfaction with your Mazda product.

**Mazda Motor Corporation  
HIROSHIMA, JAPAN**

### **Important Notes About This Manual**

Keep this manual in the glove compartment as a handy reference for the safe and enjoyable use of your Mazda. Should you resell the vehicle, leave this manual with it for the next owner.

All specifications and descriptions are accurate at the time of printing. Because improvement is a constant goal at Mazda, we reserve the right to make changes in specifications at any time without notice and without obligation.

**Please be aware that this manual applies to all models, equipment and options. As a result, you may find some explanations for equipment not installed on your vehicle.**

©2019 Mazda Motor Corporation  
July 2020 (Print2)


## How to Use This Manual

---

We want to help you get the most driving pleasure from your vehicle. Your owner's manual, when read from cover to cover, can do that in many ways.

Illustrations complement the words of the manual to best explain how to enjoy your Mazda. By reading your manual, you can find out about the features, important safety information, and driving under various road conditions.

The symbol below in this manual means “Do not do this” or “Do not let this happen”.



**Index:** A good place to start is the Index, an alphabetical listing of all information in your manual.

You'll find several WARNINGS, CAUTIONs, and NOTEs in the manual.



*A WARNING indicates a situation in which serious injury or death could result if the warning is ignored.*



*A CAUTION indicates a situation in which bodily injury or damage to your vehicle, or both, could result if the caution is ignored.*

### **NOTE**

*A NOTE provides information and sometimes suggests how to make better use of your vehicle.*

The following symbol, located on some parts of the vehicle, indicates that this manual contains information related to the part.







Please refer to the manual for a detailed explanation.





## Table of Contents

|                                                                                                                                                                 |           |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------|
| <b>Pictorial Index</b><br>Interior, exterior views and part identification of your Mazda.                                                                       | <b>1</b>  |
| <b>Essential Safety Equipment</b><br>Important information about safety equipment, including seats, seat belt system, child-restraint systems and SRS air bags. | <b>2</b>  |
| <b>Before Driving</b><br>Use of various features, including keys, doors, mirrors and windows.                                                                   | <b>3</b>  |
| <b>When Driving</b><br>Information concerning safe driving and stopping.                                                                                        | <b>4</b>  |
| <b>Interior Features</b><br>Use of various features for ride comfort, including air-conditioning and audio system.                                              | <b>5</b>  |
| <b>Maintenance and Care</b><br>How to keep your Mazda in top condition.                                                                                         | <b>6</b>  |
| <b>If Trouble Arises</b><br>Helpful information on what to do if a problem arises with the vehicle.                                                             | <b>7</b>  |
| <b>Customer Information</b><br>Important consumer information including warranties and add-on equipment.                                                        | <b>8</b>  |
| <b>Specifications</b><br>Technical information about your Mazda.                                                                                                | <b>9</b>  |
| <b>Index</b>                                                                                                                                                    | <b>10</b> |



# 1

## Pictorial Index

Interior, exterior views and part identification of your Mazda.

### Interior Overview..... 1-2

Interior Equipment (View A)..... 1-2

Interior Equipment (View B)..... 1-3

Interior Equipment (View C)..... 1-4

Interior Equipment (View D)..... 1-5


### Exterior Overview..... 1-6

Saloon..... 1-6

Hatchback..... 1-7

## Interior Overview


### Interior Equipment (View A)



|                                                        |            |
|--------------------------------------------------------|------------|
| ① Wiper and washer lever.....                          | page 4-53  |
| ② Turn and lane-change signal.....                     | page 4-52  |
| ③ Lighting control.....                                | page 4-47  |
| ④ Door-lock knob.....                                  | page 3-12  |
| ⑤ Power window switches.....                           | page 3-26  |
| ⑥ Power window lock switch.....                        | page 3-27  |
| ⑦ Power folding mirror switch.....                     | page 3-23  |
| ⑧ Outside mirror switch.....                           | page 3-23  |
| ⑨ DSC OFF switch.....                                  | page 4-68  |
| ⑩ i-stop OFF switch.....                               | page 4-16  |
| ⑪ Lane Departure Warning System (LDWS) OFF switch..... | page 4-84  |
| ⑫ Smart City Brake Support (SCBS) OFF switch.....      | page 4-138 |

**1-2** The equipment and installation position varies by vehicle

## Interior Equipment (View B)




- ① Hazard warning flasher switch.....page 4-58
- ② Audio control switches.....page 5-14
- ③ Instrument cluster.....page 4-19
- ④ Instrument panel illumination knob..... page 4-22
- ⑤ Cruise control switches..... page 4-110, 4-186
- ⑥ Remote fuel-filler flap release.....page 3-21
- ⑦ Bonnet release handle.....page 6-11
- ⑧ Lock release lever..... page 2-5
- ⑨ Push button start.....page 4-4

The equipment and installation position varies by vehicle

**1-3**


## Interior Overview

### Interior Equipment (View C)



|                                    |                 |
|------------------------------------|-----------------|
| ① SRS air bags.....                | page 2-43       |
| ② Audio system.....                | page 5-20, 5-67 |
| ③ Air-conditioning system.....     | page 5-4        |
| ④ Rear window defogger switch..... | page 4-57       |
| ⑤ Active driving display.....      | page 4-26       |
| ⑥ CD player.....                   | page 5-25, 5-79 |
| ⑦ Accessory sockets.....           | page 5-143      |
| ⑧ External input terminal.....     | page 5-15       |
| ⑨ Drive selection switch.....      | page 4-72       |
| ⑩ Shift lever/Selector lever.....  | page 4-36, 4-38 |
| ⑪ Fuse block (Left side).....      | page 6-37       |

**Interior Equipment (View D)**




|                          |            |
|--------------------------|------------|
| ① Rearview mirror.....   | page 3-24  |
| ② Sunvisor.....          | page 5-141 |
| ③ Vanity mirror.....     | page 5-141 |
| ④ Overhead lights.....   | page 5-141 |
| ⑤ Bottle holder.....     | page 5-145 |
| ⑥ SRS air bag.....       | page 2-43  |
| ⑦ Seat belts.....        | page 2-16  |
| ⑧ Rear seat.....         | page 2-11  |
| ⑨ Front seat.....        | page 2-5   |
| ⑩ Cup holders.....       | page 5-144 |
| ⑪ Parking brake.....     | page 4-61  |
| ⑫ Commander switch.....  | page 5-67  |
| ⑬ Glove compartment..... | page 5-145 |

The equipment and installation position varies by vehicle **1-5**

## Exterior Overview

### Saloon




|                                |           |
|--------------------------------|-----------|
| ① Bonnet.....                  | page 6-11 |
| ② Windscreen wiper blades..... | page 6-19 |
| ③ Door and key.....            | page 3-10 |
| ④ Fuel-filler flap.....        | page 3-21 |
| ⑤ Wheels and Tyres.....        | page 6-27 |
| ⑥ Exterior lights.....         | page 6-30 |
| ⑦ Boot lid.....                | page 3-14 |
| ⑧ Child safety lock.....       | page 3-12 |
| ⑨ Outside mirror.....          | page 3-23 |

### 1-6

The equipment and installation position varies by vehicle






**Hatchback**





|                                |           |
|--------------------------------|-----------|
| ① Bonnet.....                  | page 6-11 |
| ② Windscreen wiper blades..... | page 6-19 |
| ③ Door and key.....            | page 3-10 |
| ④ Fuel-filler flap.....        | page 3-21 |
| ⑤ Wheels and Tyres.....        | page 6-27 |
| ⑥ Exterior lights.....         | page 6-30 |
| ⑦ Rear window wiper blade..... | page 6-20 |
| ⑧ Liftgate.....                | page 3-14 |
| ⑨ Aerial.....                  | page 5-19 |
| ⑩ Child safety lock.....       | page 3-12 |
| ⑪ Outside mirror.....          | page 3-23 |

The equipment and installation position varies by vehicle **1-7**



# MEMO



## 2

## Essential Safety Equipment

Important information about safety equipment, including seats, seat belt system, child-restraint systems and SRS air bags.

|                                                          |                 |                                                                                         |                 |
|----------------------------------------------------------|-----------------|-----------------------------------------------------------------------------------------|-----------------|
| <b>Seats.....</b>                                        | <b>2-2</b>      | <b>Child-Restraint System Suitability<br/>for Various Seat Positions<br/>Table.....</b> | <b>2-32</b>     |
| Seat Precautions.....                                    | 2-2             | Installing Child-Restraint<br>Systems.....                                              | 2-35            |
| Front Seat.....                                          | 2-5             |                                                                                         |                 |
| Rear Seat.....                                           | 2-11            |                                                                                         |                 |
| Head Restraints.....                                     | 2-14            |                                                                                         |                 |
| <br><b>Seat Belt Systems.....</b>                        | <br><b>2-16</b> | <br><b>SRS Air Bags.....</b>                                                            | <br><b>2-43</b> |
| Seat Belt Precautions.....                               | 2-16            | Supplementary Restraint System<br>(SRS) Precautions.....                                | 2-43            |
| Seat Belt.....                                           | 2-20            | Supplementary Restraint System<br>Components.....                                       | 2-48            |
| Seat Belt Warning Systems.....                           | 2-21            | How the SRS Air Bags Work.....                                                          | 2-49            |
| Seat Belt Pretensioner and Load<br>Limiting Systems..... | 2-22            | SRS Air Bag Deployment<br>Criteria.....                                                 | 2-52            |
| <br><b>Child Restraint.....</b>                          | <br><b>2-24</b> | Limitations to SRS Air Bag.....                                                         | 2-53            |
| Child-Restraint Precautions.....                         | 2-24            | Constant Monitoring.....                                                                | 2-55            |
| Child-Restraint System<br>Installation.....              | 2-28            |                                                                                         |                 |

## Seats

### Seat Precautions

#### **WARNING**

***Make sure the adjustable components of a seat are locked in place:***

*Adjustable seats and seatbacks that are not securely locked are dangerous. In a sudden stop or collision, the seat or seatback could move, causing injury. Make sure the adjustable components of the seat are locked in place by attempting to slide the seat forward and backward and rocking the seatback.*

***Never allow children to adjust a seat:***

*Allowing children to adjust a seat is dangerous as it could result in serious injury if a child's hands or feet become caught in the seat.*

***Do not drive with the seatback unlocked:***

*All of the seatbacks play an important role in your protection in a vehicle. Leaving the seatback unlocked is dangerous as it can allow passengers to be ejected or thrown around and baggage to strike occupants in a sudden stop or collision, resulting in severe injury. After adjusting the seatback at any time, even when there are no other passengers, rock the seatback to make sure it is locked in place.*

***Adjust a seat only when the vehicle is stopped:***

*If the seat is adjusted while the vehicle is being driven, the seating posture may become unstable and the seat could move unexpectedly resulting in injury.*

***Do not modify or replace the front seats:***

*Modifying or replacing the front seats such as replacing the upholstery or loosening any bolts is dangerous. The front seats contain air bag components essential to the supplementary restraint system. Such modifications could damage the supplementary restraint system and result in serious injury. Consult an expert repairer (we recommend an Authorised Mazda Repairer) if there is any need to remove or reinstall the front seats.*

***Do not drive with damaged front seats:***

*Driving with damaged front seats, such as seat cushions torn or damaged down to the urethane, is dangerous. A collision, even one not strong enough to inflate the air bags, could damage the front seats which contain essential air bag components. If there was a subsequent collision, an air bag may not deploy which could lead to injuries. Always have an expert repairer (we recommend an Authorised Mazda Repairer) inspect the front seats, front seat belt pretensioners and air bags after a collision.*

***Do not drive with either front seats reclined:***

*Sitting in a reclined position while the vehicle is moving is dangerous because you do not get the full protection from seat belts. During sudden braking or a collision, you can slide under the lap belt and suffer serious internal injuries. For maximum protection, sit well back and upright.*

***Do not place an object such as a cushion between the seatback and your back:***

*Putting an object such as a cushion between the seatback and your back is dangerous because you will be unable to maintain a safe driving posture and the seat belt cannot function at its full capacity in a collision, which could result in a serious accident, injury or death.*

***Do not place objects under the seat:***

*The object could get stuck and cause the seat to not be fixed securely, and result in an accident.*

***Do not stack cargo higher than the seatbacks:***

*Stacking luggage or other cargo higher than the seatbacks is dangerous. During sudden braking or a collision, objects can fly around and become projectiles that may hit and injure passengers.*

***Make sure luggage and cargo is secured before driving:***

*Not securing cargo while driving is dangerous as it could move or be crushed during sudden braking or a collision and cause injury.*

***Never allow a passenger to sit or stand on the folded seatback while the vehicle is moving:***

*Driving with a passenger on the folded seatback is dangerous. Allowing a child to sit up on the folded seatback while the vehicle is moving is particularly dangerous. In a sudden stop or even a minor collision, a child not in a proper seat or child-restraint system and seat belt could be thrown forward, back or even out of the vehicle resulting in serious injuries or death. The child in the baggage area could be thrown into other occupants and cause serious injury.*

***Never give the car keys to children and do not allow them to play in the vehicle (Saloon):***

*Playing with the folding rear seats is dangerous. Once the seatbacks are back up, a child in the boot would not be able to get out the way they had entered. If you have small children, keep the seatbacks locked.*

## Seats

---

***Always leave your car locked and keep the car keys safely away from children (Saloon):***

*Leaving your car unlocked or the keys in reach of children is dangerous. Children who find their way into the boot through an unlocked rear seatback or an open boot can become accidentally locked in the boot. This could result in death or brain damage from heat prostration, particularly in the summer. Always lock the doors and the boot, and as an added measure, keep the rear seatbacks locked, whether you have children in your home or not.*

 **CAUTION**

- *When operating a seat, be careful not to put your hands or fingers near the moving parts of the seat or on the side trim to prevent injury.*
- *When moving the seats, make sure there is no cargo in the surrounding area. If the cargo gets caught it could damage the cargo.*
- *When moving the seats forward and rearward or returning a rear-reclined seatback to its upright position, make sure you hold onto the seatback with your hand while operating. If the seatback is not held, the seat will move suddenly and could cause injury.*
- *When inserting your hand under the seat to clean the cabin or pick up something you dropped under the seat, be careful not to hurt yourself. If you contact the moving parts of the seat rail or seat frame, it could result in injury.*

**NOTE**

- *When returning a rear seat to its original position, place the seat belt in its normal position. Verify that the seat belt pulls out and retracts.*

## Front Seat



### ▼ Adjusting the Driver's Seat

Using the driving position set up procedure recommended by Mazda allows you to maintain a relaxed posture, drive the vehicle for longer periods without feeling tired, and make quick operations naturally.

Also, you can be assured of a clear view in the forward direction to help you drive more safely and comfortably.

The adjustments for the driving position recommended by Mazda are done using the following procedures.

1. Moving the steering wheel and seat to their default positions.
2. Adjusting the seatback angle.
3. Adjusting the seat position forward and back.
4. Adjusting the seat height.
5. Adjusting the steering wheel position.
6. Adjusting the head restraint position.



#### ① Seat Slide

To move a seat forward or backward, raise the lever and slide the seat to the desired position and release the lever.

Make sure the lever returns to its original position and the seat is locked in place by attempting to push it forward and backward.

#### ② Height Adjustment

To adjust the seat height, move the lever up or down.

## Seats

---

### ③ Seat Recline

To change the seatback angle, lean forward slightly while raising the lever. Then lean back to the desired position and release the lever.

Make sure the lever returns to its original position and the seatback is locked in place by attempting to push it forward and backward.

#### **Before making adjustments to the driving position recommended by Mazda**

Before making adjustments, move the steering wheel and seat to their default positions.

#### **How to move the steering wheel to its default position**




#### ***Never adjust the steering wheel while the vehicle is moving:***

*Adjusting the steering wheel while the vehicle is moving is dangerous. Moving it can very easily cause the driver to abruptly turn to the left or right. This can lead to loss of control or an accident.*

#### ***After adjusting the steering wheel position, make sure it is securely locked by trying to move it up and down:***

*Driving with the steering wheel not securely locked in position is dangerous. If the steering wheel moves unexpectedly while driving, you could lose control of the steering resulting in an accident.*

Lower the lever, move the steering wheel to the lowest position, and then push it down and all the way back.



#### **How to move a driver's seat to its default position**


1. Slide the seat all the way back.
2. Lower the seat to its lowest height.
3. Sit squarely in the seat and rest your back against the seatback.





**Seat adjustment procedure for the driving position recommended by Mazda****Adjusting the seatback angle (reclining)**

Adjust the seatback to the angle providing a comfortable seated posture.

1. With your posture slightly slouched, move the seatback forward to the angle where your waist feels slightly cramped.



2. Move the seatback backward to a comfortable seated posture without any feeling of cramping in your waist.

**Adjusting the seat position forward and back (sliding)**


Adjust the seat to the position best for operating the accelerator and brake pedals.

1. Place your left foot on the footrest, your right foot between the accelerator and brake pedals, and position your heel to the position allowing easy switching between the pedals.


## Seats

---

2. With your heel set on the floor, set your right foot on the brake pedal and move the seat forward as far as possible until you feel a slight cramping in your ankle.



3. With your right foot set on the brake pedal, move the seat back until you no longer feel cramping in your ankle.
4. With your heel set on the floor, make sure you can move your foot between the brake pedal and accelerator pedal smoothly.
5. Depress the accelerator pedal completely with your heel set on the floor and make sure that your ankle does not feel over-stretched.




### Adjusting the seat height

Adjust the seat height to a position where you have a clear forward view and you can drive the vehicle easily.

1. With your back resting against the seatback, raise the seat to the height where you can see the rear edge area of the bonnet surface from the windscreen.


If you raise the seat height, the seat moves forward. Adjust the seat forward or back again.




### **Adjusting the steering wheel position**

Adjust the steering wheel to the position where it can be operated easily and the gauges can be viewed easily.

1. With your back resting against the seatback, extend both arms, place them on the top of the steering wheel, and pull the steering wheel towards you to the position of your wrists.



2. Adjust the steering wheel height so that the gauges can be viewed easily.
3. Raise the lever to securely lock the steering wheel.




## Seats

### Adjusting the head restraint position

To prevent shock to the head and neck, adjust the head restraints to their correct positions. Refer to Height Adjustment on page 2-14.

### ▼ Adjusting the Front Passenger's Seat



#### ① Seat Slide

To move a seat forward or backward, raise the lever and slide the seat to the desired position and release the lever.

Make sure the lever returns to its original position and the seat is locked in place by attempting to push it forward and backward.

#### ② Height Adjustment\*

To adjust the seat height, move the lever up or down.

#### ③ Seat Recline

To change the seatback angle, lean forward slightly while raising the lever. Then lean back to the desired position and release the lever.

Make sure the lever returns to its original position and the seatback is locked in place by attempting to push it forward and backward.

## Rear Seat

### ▼ Split Folding the Seatbacks

By lowering the rear seatbacks the luggage compartment space can be expanded.

### WARNING

**Do not drive the vehicle with occupants on folded down seatbacks or in the luggage compartment.**

Putting occupants in the luggage compartment is dangerous because seat belts cannot be fastened which could lead to serious injury or death during sudden braking or a collision.

**Do not allow children to play inside the vehicle with the seatbacks lowered.**

Allowing children to play in the vehicle with the seatbacks folded down is dangerous. If a child enters the luggage compartment and the seatbacks were raised back up, the child may become trapped in the luggage compartment which could lead to an accident.

**Tightly secure cargo in the luggage compartment when it is transported with the seatbacks folded down.**

Driving without tightly securing cargo and luggage is dangerous as it could move and become an obstruction to driving during emergency braking or a collision resulting in an unexpected accident.

**When transporting cargo, do not allow the cargo to exceed the height of the seatbacks.**

Transporting cargo stacked higher than the seatbacks is dangerous as visibility to the rear and sides of the vehicle is reduced which could interfere with driving operations and lead to an accident.

### Lowering the seatbacks

### CAUTION

#### ➤ (Hatchback)

When folding the seatback forward, always support the seatback with your hand. If it is not supported by a hand, fingers or the hand pressing the push knob could be injured.

#### ➤ Check the position of a front seat before folding a rear seatback.


Depending on the position of a front seat, it may not be possible to fold a rear seatback all the way down because it may hit the seatback of the front seat which could scratch or damage the front seat or its pocket. Lower or remove the head restraint on the rear outboard seat if necessary.

#### (Saloon)

1. Lower the head restraint all the way down.  
Refer to Head Restraints on page 2-14.

## Seats


2. Open the boot lid and pull the lever of the seatback you want to fold down.




3. Open a rear door and fold the rear seat forward.

### (Hatchback)

1. Lower the head restraint all the way down.  
Refer to Head Restraints on page 2-14.
2. Press the push knob to fold down the seatback you want to fold down.



3. Secure the rear seat belt in the belt clip.



### To return the seatback to its upright position:


#### **WARNING**

***When returning a seatback to its upright position, make sure the 3-point seat belt is not caught in the seatback and the 3-point seat belt is not twisted.***

*If the seat belt is used while it is twisted and caught in the seatback, the seat belt cannot function at its full capacity, which could cause serious injury or death.*


**When returning a seatback to its upright position, make sure that it is firmly locked and the red indication is not visible (Hatchback).**

*If the red indication is visible behind the push knob, it means the seatback is not locked. If the vehicle is driven without the seatback locked, it could fold down suddenly and cause an accident.*



#### (Saloon)


1. Make sure that the seat belt passes through the seat belt guide correctly and it is not twisted, then raise the seatback while preventing the seat belt from being caught in the seatback.



2. Press the seatback rearward and lock it in place. After returning the seatback to its upright position, make sure it is securely locked.

#### (Hatchback)

1. Verify that the seat belt is secured in the belt clip.



2. Lift the seatback upright.
3. Press the seatback rearward and lock it in place. After returning the seatback to its upright position, make sure it is securely locked.
4. Make sure that the seat belt is neither stuck in the rear seat nor twisted, then remove the seat belt from the belt clip.

## Seats

### Head Restraints

Your vehicle is equipped with head restraints on all outboard seats and the rear centre seat. The head restraints are intended to help protect you and the passengers from neck injury.


#### **WARNING**

***Always drive with the head restraints installed when seats are being used and make sure they are properly adjusted. In addition, always raise the head restraints on all rear seats when they are being used:***

*Driving with the head restraints adjusted too low or removed is dangerous. With no support behind your head, your neck could be seriously injured in a collision.*

#### ▼ **Height Adjustment**


Adjust the head restraint so that the centre is even with the top of the passenger's ears.




To raise a head restraint, pull it up to the desired position.

To lower the head restraint, press the stop-catch release, then push the head restraint down.


#### **Front seats**



#### **Rear outboard seats**



#### **Rear centre seat**



#### ▼ **Removal/Installation**

To remove the head restraint, pull it up while pressing the stop-catch.

To install the head restraint, insert the legs into the holes while pressing the stop-catch.



 **WARNING**

***Always drive with the head restraints installed when seats are being used and make sure they are properly installed:***

*Driving with the head restraints not installed is dangerous. With no support behind your head, your neck could be seriously injured in a collision.*

***After installing a head restraint, try lifting it to make sure that it does not pull out:***

*Driving with an unsecured head restraint is dangerous as the effectiveness of the head restraint will be compromised which could cause it to unexpectedly detach from the seat.*

 **CAUTION**

- *When installing a head restraint, make sure that it is installed correctly with the front of the head restraint facing forward. If the head restraint is installed incorrectly, it could detach from the seat during a collision and result in injury.*
- *The head restraints on each of the front and rear seats are specialized to each seat. Do not switch around the head restraint positions. If a head restraint is not installed to its correct seat position, the effectiveness of the head restraint during a collision will be compromised which could cause injury.*

## Seat Belt Systems

---

### Seat Belt Precautions

Seat belts help to decrease the possibility of severe injury during accidents and sudden stops. Mazda recommends that the driver and all passengers always wear seat belts.

All the seats have lap/shoulder belts. These belts also have retractors with inertia locks that keep them out of the way when not in use. The locks allow the belts to remain comfortable on users, but they will lock in position during a collision.

The rear outboard seat belt retractors operate in two modes, emergency locking mode and, for child-restraint systems, automatic locking mode.

#### **WARNING**

***Always wear your seat belt and make sure all occupants are properly restrained:***

*Not wearing a seat belt is extremely dangerous. During a collision, occupants not wearing seat belts could hit someone or things inside the vehicle or even be thrown out of the vehicle. They could be seriously injured or even killed. In the same collision, occupants wearing seat belts would be much safer.*

***Do not wear twisted seat belts:***

*Twisted seat belts are dangerous. In a collision, the full width of the belt is not available to absorb the impact. This puts more force on the bones beneath the belt, which could cause serious injury or death. So, if your seat belt is twisted, you must straighten the seat belt to remove any twists and to allow the full width of the belt to be used.*

***Never use one seat belt on more than one person at a time:***

*Using one seat belt for more than one person at a time is dangerous. A seat belt used in this way cannot spread the impact forces properly and the two passengers could be crushed together and seriously injured or even killed. Never use one belt for more than one person at a time and always operate the vehicle with each occupant properly restrained.*

***Do not operate a vehicle with a damaged seat belt:***

*Using a damaged seat belt is dangerous. An accident could damage the belt webbing of the seat belt in use. A damaged seat belt cannot provide adequate protection in a collision. Have an expert repairer (we recommend an Authorised Mazda Repairer) inspect all seat belt systems in use during an accident before they are used again.*

Essential Safety Equipment

## Seat Belt Systems

---

***Have your seat belts changed immediately if the pretensioner or load limiter has been expended:***

*Always have an expert repairer (we recommend an Authorised Mazda Repairer) immediately inspect the seat belt pretensioners and air bags after any collision. Like the air bags, the seat belt pretensioners and load limiters will only function once and must be replaced after any collision that caused them to deploy. If the seat belt pretensioners and load limiters are not replaced, the risk of injury in a collision will increase.*

***Positioning the Shoulder Portion of the Seat Belt:***

*Improper positioning of the shoulder portion of the seat belt is dangerous. Always make sure the shoulder portion of the seat belt is positioned across your shoulder and near your neck, but never under your arm, on your neck, or on your upper arm.*

***Positioning the Lap Portion of the Seat Belt:***

*The lap portion of the seat belt worn too high is dangerous. In a collision, this would concentrate the impact force directly on the abdominal area, causing serious injury. Wear the lap portion of the belt snugly and as low as possible.*

***Instructions for Use of Seat Belt Assemblies:***

*Seatbelts are designed to bear upon the bony structure of the body, and should be worn low across the front of the pelvis or the pelvis, chest and shoulders, as applicable; wearing the lap section of the belt across the abdominal area must be avoided.*

*Seatbelts should be adjusted as firmly as possible, consistent with comfort, to provide the protection for which they have been designed. A slack belt will greatly reduce the protection afforded to the wearer.*

*Care should be taken to avoid contamination of the webbing with polishes, oils and chemicals, and particularly battery acid. Cleaning may safely be carried out using mild soap and water. The belt should be replaced if webbing becomes frayed, contaminated or damaged.*

*It is essential to replace the entire assembly after it has been worn in a severe impact even if damage to the assembly is not obvious.*

*Belts should not be worn with straps twisted.*

*Each belt assembly must only be used by one occupant; it is dangerous to put a belt around a child being carried on the occupant's lap.*

*No modifications or additions should be made by the user which will either prevent the seat belt adjusting devices from operating to remove slack, or prevent the seat belt assembly from being adjusted to remove slack.*


## Essential Safety Equipment

# Seat Belt Systems

---

### CAUTION

*Belt retraction may become difficult if the belts and rings are soiled, so try to keep them clean. For more details about cleaning the seat belts, refer to "Seat Belt Maintenance" (page 6-50).*



### ▼ Pregnant Women and Persons with Serious Medical Conditions

Pregnant women should always wear seat belts. Ask your doctor for specific recommendations.

The lap belt should be worn **SNUGLY AND AS LOW AS POSSIBLE OVER THE HIPS**.

The shoulder belt should be worn across your shoulder properly, but never across the stomach area.

Persons with serious medical conditions also should wear seat belts. Check with your doctor for any special instructions regarding specific medical conditions.



### ▼ Emergency Locking Mode

When the seat belt is fastened, it will always be in the emergency locking mode.

In the emergency locking mode, the belt remains comfortable on the occupant and the retractor will lock in position during a collision.

If the belt is locked and cannot be pulled out, retract the belt once, and then try pulling it out slowly. If this fails, pull the belt strongly 1 time and loosen, then pull it out again slowly.

#### **(Seat Belt with Automatic Locking Mode)**

When the seat belt is fastened, it will always be in the emergency locking mode until it is switched to automatic locking mode by pulling it all the way out to its full length. If the belt feels tight and hinders comfortable movement while the vehicle is stopped or in motion, it may be in the automatic locking mode because the belt has been pulled too far out. To return the belt to the more comfortable emergency locking mode, wait until the vehicle has stopped in a safe, level area, retract the belt fully to convert it back to emergency locking mode and then extend it around you again.


### ▼ Automatic Locking Mode

Always use the automatic locking mode to keep the child-restraint system from shifting to an unsafe position in the event of an accident. To enable seat belt automatic locking mode, pull it all the way out and connect it as instructed on the child-restraint system. It will retract down to the child-restraint system and stay locked on it. See the section on child restraint (page 2-24).


## Essential Safety Equipment Seat Belt Systems

### Seat Belt

#### ▼ Fastening the Seat Belt




Position the lap belt as low as possible, not on the abdominal area, then adjust the shoulder belt so that it fits snugly against your body.




#### (Saloon)

Before fastening the rear seat belt, make sure that the seat belt passes through the seat belt guide correctly and it is not twisted.



### ▼ Unfastening the Seat Belt


Depress the button on the seat belt buckle. If the belt does not fully retract, pull it out and check for kinks or twists. Then make sure it remains untwisted as it retracts.



#### **NOTE**

*If a belt does not fully retract, inspect it for kinks and twists. If it is still not retracting properly, have it inspected at an expert repairer (we recommend an Authorised Mazda Repairer).*

### ▼ Front Shoulder Belt Adjuster



Make sure the adjuster is locked.

## Seat Belt Warning Systems

If it detects that the occupant seat belt is unfastened, the warning light or beep alerts the occupant.

Refer to Taking Action on page 7-31.

Refer to Seat Belt Warning Beep on page 7-37.

### Seat belt indicator light (rear seat) (green)

# REAR



The light turns on when the ignition is switched ON and a rear seat belt is fastened, and then it turns off after about 30 seconds.

## Seat Belt Systems

### Seat Belt Pretensioner and Load Limiting Systems

For optimum protection, the front seat belts and rear outboard seat belts are equipped with pretensioner and load limiting systems. For both these systems to work properly you must wear the seat belt properly.

#### **Pretensioners:**

When a collision is detected, the pretensioners deploy simultaneously with the air bags.

For deployment details, refer to the SRS Air Bag Deployment Criteria (page 2-52).

The seat belt retractors remove slack quickly as the air bags are expanding. Any time the air bags and seat belt pretensioners have fired they must be replaced.

A system malfunction or operation conditions are indicated by a warning. Refer to Taking Action on page 7-31. Refer to Air Bag/Seat Belt Pretensioner System Warning Beep on page 7-37.

#### **Load limiter:**

The load limiting system releases belt webbing in a controlled manner to reduce belt force on the occupant's chest. While the most severe load on a seat belt occurs in frontal collisions, the load limiter has an automatic mechanical function and can activate in any accident mode with sufficient occupant movement.

Even if the pretensioners have not fired, the load limiting function must be checked by an expert repairer (we recommend an Authorised Mazda Repairer).



#### ***Wear seat belts only as recommended in this owner's manual:***

*Incorrect positioning of the seat belts is dangerous. Without proper positioning, the pretensioner and load limiting systems cannot provide adequate protection in an accident and this could result in serious injury. For more details about wearing seat belts, refer to "Fastening the Seat Belt" (page 2-20).*

#### ***Have your seat belts changed immediately if the pretensioner or load limiter has been expended:***

*Always have an expert repairer (we recommend an Authorised Mazda Repairer) immediately inspect the seat belt pretensioners and air bags after any collision. Like the air bags, the seat belt pretensioners and load limiters will only function once and must be replaced after any collision that caused them to deploy. If the seat belt pretensioners and load limiters are not replaced, the risk of injury in a collision will increase.*



***Do not modify the components or wiring, or use electronic testing devices on the pretensioner system:***

*Modifying the components or wiring of the pretensioner system, including the use of electronic testing devices is dangerous. You could accidentally activate it or make it inoperable which would prevent it from activating in an accident. The occupants or repairers could be seriously injured.*

***Properly dispose of the pretensioner system:***

*Improper disposal of the pretensioner system or a vehicle with non-deactivated pretensioners is dangerous. Unless all safety procedures are followed, injury could result. Have an expert repairer (we recommend an Authorised Mazda Repairer) safely dispose of the pretensioner system or scrap a pretensioner system equipped vehicle.*

***NOTE***

- The pretensioner system may not operate depending on the type of the collision. For details, refer to the SRS Air Bag Deployment Criteria (page 2-52).*
- Some smoke (non-toxic gas) will be released when the air bags and pretensioners deploy. This does not indicate a fire. This gas normally has no effect on occupants, however, those with sensitive skin may experience light skin irritation. If residue from the deployment of the air bags or the pretensioner system gets on the skin or in the eyes, wash it off as soon as possible.*

## Child Restraint

### Child-Restraint Precautions

Mazda strongly urges the use of child-restraint systems for children small enough to use them.

Check your local and state or provincial laws for specific requirements regarding the safety of children riding in your vehicle.

Whatever child-restraint system you consider, please pick the appropriate one for the age and size of the child, obey the law and follow the instructions that come with the individual child-restraint system.

A child who has outgrown child-restraint systems should sit in the rear and use seat belts.

The child-restraint system should be installed on the rear seat.

Statistics confirm that the rear seat is the best place for all children up to 12 years of age-the more so with a supplementary restraint system (air bags).

A rear-facing child-restraint system should **NEVER** be used in the front passenger seat with the air bag system activated. The front passenger's seat is also the least preferred seat for other child-restraint systems.

#### **WARNING**

***Use the correct size child-restraint system:***

*For effective protection in vehicle accidents and sudden stops, a child must be properly restrained using a seat belt or child-restraint system depending on age and size. If not, the child could be seriously injured or even killed in an accident.*

***Follow the manufacturer's instructions and always keep the child-restraint system buckled down:***

*An unsecured child-restraint system is dangerous. In a sudden stop or a collision it could move causing serious injury or death to the child or other occupants. Make sure any child-restraint system is properly secured in place according to the child-restraint system manufacturer's instructions. When not in use, remove it from the vehicle or fasten it with a seat belt, or latch it down to BOTH ISOFIX anchors, and attach the corresponding tether anchor.*

## Essential Safety Equipment Child Restraint

### ***Always secure a child in a proper child-restraint system:***

*Holding a child in your arms while the vehicle is moving is extremely dangerous. No matter how strong the person may be, he or she cannot hold onto a child in a sudden stop or collision and it could result in serious injury or death to the child or other occupants. Even in a moderate accident, the child may be exposed to air bag forces that could result in serious injury or death to the child, or the child may be slammed into an adult, causing injury to both child and adult.*


### ***Extreme Hazard! Never use a rear-facing child-restraint system on the front passenger seat with an air bag that could deploy:***

*NEVER use a rearward facing child restraint on a seat protected by an ACTIVE AIRBAG in front of it, DEATH or SERIOUS INJURY to the CHILD can occur.*

*Vehicles with a front passenger air bag have a warning label attached as shown below. The warning label reminds you not to put a rear-facing child-restraint system on the front passenger seat at any time.*



*Even in a moderate collision, the child-restraint system can be hit by a deploying air bag and moved violently backward resulting in serious injury or death to the child.*



## Child Restraint

---

***Do not install a front-facing child-restraint system on the front passenger seat unless it is unavoidable:***

*In a collision, the force of a deploying air bag could cause serious injury or death to the child. If installing a front-facing child-restraint system on the front passenger seat is unavoidable, move the front passenger seat as far back as possible and adjust the seat bottom (height adjustable seat bottom) to the highest position at which the seat belt fastening the child-restraint system is securely tightened.*



***Do not allow a child or anyone to lean over or against the side window of a vehicle with side and curtain air bags:***

*It is dangerous to allow anyone to lean over or against the side window, the area of the front passenger seat, the front and rear window pillars and the roof edge along both sides from which the side and curtain air bags deploy, even if a child-restraint system is used. The impact of inflation from a side or curtain air bag could cause serious injury or death to an out of position child. Furthermore, leaning over or against the front door could block the side and curtain air bags and eliminate the advantages of supplementary protection. With the front air bag and the additional side air bag that comes out of the front seat, the rear seat is always a better location for children. Take special care not to allow a child to lean over or against the side window, even if the child is seated in a child-restraint system.*

***Never use one seat belt on more than one person at a time:***

*Using one seat belt for more than one person at a time is dangerous. A seat belt used in this way cannot spread the impact forces properly and the two passengers could be crushed together and seriously injured or even killed. Never use one belt for more than one person at a time and always operate the vehicle with each occupant properly restrained.*

**WARNING:** *child restraint anchorages are designed to withstand only those loads imposed by correctly fitted child restraints. Under no circumstances are they to be used for adult seat belts, harnesses or for attaching other items or equipment to the vehicle.*

***Always remove the head restraint and install child-restraint system (except when installing a backless booster seat):***

*Installing a child-restraint system without removing the head restraint is dangerous. The child-restraint system cannot be installed correctly which may result in death or injury to the child in a collision.*

Essential Safety Equipment  
**Child Restraint**

---

 **CAUTION**

*A seat belt or child-restraint system can become very hot in a closed vehicle during warm weather. To avoid burning yourself or a child, check them before you or your child touches them.*

**NOTE**

*Your Mazda is equipped with ISOFIX anchors for attachment of ISOFIX child-restraint systems on the rear seats. When using these anchors to secure a child-restraint system, refer to “Using ISOFIX Anchor” (page 2-39).*

## Child Restraint

### Child-Restraint System Installation

#### ▼ Categories of Child-Restraint Systems

##### **NOTE**

*When purchasing, ask the manufacturer of the child-restraint system which type of child-restraint system is appropriate for your child and vehicle.*

##### **(Countries conforming to the UN-R 44 and UN-R 129 regulation)**

Child-restraint systems are classified into the following 5 groups according to the UN-R 44 and UN-R 129 regulation.

| Group | Age                           | Weight                        | Size Classification/<br>Fixture (CRF) |
|-------|-------------------------------|-------------------------------|---------------------------------------|
| 0     | Up to about 9 months old      | Up to 10 kg (up to 22 lb)     | ISO/L1                                |
|       |                               |                               | ISO/L2                                |
|       |                               |                               | ISO/R1                                |
| 0+    | Up to about 2 years old       | Up to 13 kg (up to 29 lb)     | ISO/R1                                |
|       |                               |                               | ISO/R2                                |
|       |                               |                               | ISO/R3                                |
| 1     | About 8 months to 4 years old | 9 kg — 18 kg (20 lb — 40 lb)  | ISO/R2                                |
|       |                               |                               | ISO/R3                                |
|       |                               |                               | ISO/F2                                |
|       |                               |                               | ISO/F2X                               |
| 2     | About 3 to 7 years old        | 15 kg — 25 kg (33 lb — 55 lb) | —                                     |
| 3     | About 6 to 12 years old       | 22 kg — 36 kg (48 lb — 79 lb) | —                                     |

##### **(Australia)**

Child-restraint systems for Australia must conform to Australian Standard AS 1754/91 or later. Refer to your local state authority for the latest specification.

##### **(Other countries)**

Please comply with the legal regulations concerning the use of child-restraint systems in your country.

## Essential Safety Equipment Child Restraint

### ▼ Child-Restraint System Types


In this owner's manual, explanation of child-restraint systems secured with seat belts is provided for the following 3 types of popular child-restraint systems: baby seat, child seat, booster seat.

#### NOTE

- Installation position is determined by the type of child-restraint system. Always read the manufacturer's instructions and this owner's manual carefully.
- Due to variations in the design of child-restraint systems, vehicle seats and seat belts, all child-restraint systems may not fit all seating positions. Before purchasing a child-restraint system, it should be tested in the specific vehicle seating position (or positions) where it is intended to be used. If a previously purchased child-restraint system does not fit, you may need to purchase a different one that will.

#### Baby seat

A baby seat provides restraint by bracing the baby's head, neck and back against the seating surface.




#### Child seat

A child seat restrains a child's body using the harness.



#### Booster seat

A booster seat is a child restraint accessory designed to improve the fit of the seat belt system around the child's body.



\*1 When using a backless booster seat, always install the vehicle head restraint to the seat where the backless booster seat is installed.

#### (Australia)

Child-restraint systems for Australia must conform to Australian Standard AS 1754/91 or later.


#### (Other countries)

Please comply with the legal regulations concerning the use of child-restraint systems in your country.

## Child Restraint

### ▼ Baby Seat Installation Position

A baby seat is used in the rear-facing position only.




#### WARNING

***Never use a rear-facing child-restraint system on the front passenger seat protected by an air bag:***

*NEVER use a rearward facing child restraint on a seat protected by an ACTIVE AIRBAG in front of it, DEATH or SERIOUS INJURY to the CHILD can occur.*

*The child-restraint system can be hit by the deploying air bag and knocked out of position. A child in the child-restraint system could be seriously injured or killed.*



### ▼ Child Seat Installation Position

A child seat is used in front-facing and rear-facing positions depending on the age and size of the child. When installing, follow the manufacturer's instructions in accordance with the appropriate age and size of the child as well as the directions for installing the child-restraint system.


#### Rear-facing type

#### WARNING

***Never use a rear-facing child-restraint system on the front passenger seat protected by an air bag:***

*NEVER use a rearward facing child restraint on a seat protected by an ACTIVE AIRBAG in front of it, DEATH or SERIOUS INJURY to the CHILD can occur.*

*The child-restraint system can be hit by the deploying air bag and knocked out of position. A child in the child-restraint system could be seriously injured or killed.*





### Front-facing type

#### **WARNING**


***Do not install a front-facing child-restraint system on the front passenger seat unless it is unavoidable:***

*In a collision, the force of a deploying air bag could cause serious injury or death to the child. If installing a front-facing child-restraint system on the front passenger seat is unavoidable, move the front passenger seat as far back as possible and adjust the seat bottom (height adjustable seat bottom) to the highest position at which the seat belt fastening the child-restraint system is securely tightened.*



#### **▼ Booster Seat Installation Position**

A booster seat is used in the front-facing position only.



#### **WARNING**

***Do not install a front-facing child-restraint system on the front passenger seat unless it is unavoidable:***

*In a collision, the force of a deploying air bag could cause serious injury or death to the child. If installing a front-facing child-restraint system on the front passenger seat is unavoidable, move the front passenger seat as far back as possible and adjust the seat bottom (height adjustable seat bottom) to the highest position at which the seat belt fastening the child-restraint system is securely tightened.*



## Child Restraint

### Child-Restraint System Suitability for Various Seat Positions Table

Provided information in the table shows your child-restraint system suitability for various seating position. For installation suitability of other manufacturer child-restraint system, carefully consult the manufacturer's instructions which accompany the child-restraint system.

When installing a child-restraint system, the following points must be observed:

- Always remove the head restraint before installing a child-restraint system. However, when installing a booster seat, always install the vehicle head restraint to the seat where the booster seat is installed. In addition, always use a tether strap and attach it securely. Refer to Head Restraints on page 2-14.
- When installing a child-restraint system to the front passenger seat, adjust the seat slide position as far back as possible. Adjust the seat bottom (height adjustable seat bottom) to the highest position so that the seat belt can securely fasten the child-restraint system. Refer to Adjusting the Front Passenger's Seat on page 2-10.
- When it is difficult to install a child-restraint system to the front passenger seat, or the seat belt cannot be secured to the child-restraint system, perform the following operations to adjust the seat holding the child-restraint system so that the seat belt can be secured completely to it.
  - Move the seat forward or back.
  - Move the seatback forward or back.
  - Move the seat bottom up or down. (Vehicles with height adjustment function)
- When installing a child-restraint system to the rear seat, adjust the front seat position so that the front seat does not contact the child-restraint system. Refer to Adjusting the Driver's Seat on page 2-5. Refer to Adjusting the Front Passenger's Seat on page 2-10.
- A child-restraint system with a support leg cannot be installed on the rear centre seat position.
- When installing a child-restraint system came equipped with a tether, remove the head restraint. Refer to Head Restraints on page 2-14.

When installing a child-restraint system to the rear seat, refer to the child-restraint system manufacturer's instructions and the Using ISOFIX Anchor on page 2-39.

| Seating position                                        | Passenger | Rear (Left) | Rear (Centre) | Rear (Right) |
|---------------------------------------------------------|-----------|-------------|---------------|--------------|
| Seating position suitable for universal belted (Yes/No) | Yes (UF)  | Yes (U)     | No            | Yes (U)      |

Essential Safety Equipment  
**Child Restraint**

| Seating position                                        | Passenger | Rear (Left) | Rear (Centre) | Rear (Right) |
|---------------------------------------------------------|-----------|-------------|---------------|--------------|
| i-Size seating position (Yes/No)                        | No        | No          | No            | No           |
| Largest suitable rearward facing fixture (R1)           | No        | Yes (IL)    | No            | Yes (IL)     |
| Largest suitable rearward facing fixture (R2)           | No        | Yes (IL)    | No            | Yes (IL)     |
| Largest suitable rearward facing fixture (R2X)          | No        | Yes (IL)    | No            | Yes (IL)     |
| Largest suitable rearward facing fixture (R3)           | No        | Yes (IL)    | No            | Yes (IL)     |
| Largest suitable forward facing fixture (F2)            | No        | Yes (IUF)   | No            | Yes (IUF)    |
| Largest suitable forward facing fixture (F2X)           | No        | Yes (IUF)   | No            | Yes (IUF)    |
| Largest suitable forward facing fixture (F3)            | No        | Yes (IUF)   | No            | Yes (IUF)    |
| Largest suitable lateral facing fixture (L1)            | No        | No          | No            | No           |
| Largest suitable lateral facing fixture (L2)            | No        | No          | No            | No           |
| Largest suitable booster fixture (B2)                   | No        | Yes (IUF)   | No            | Yes (IUF)    |
| Largest suitable booster fixture (B3)                   | No        | Yes (IUF)   | No            | Yes (IUF)    |
| Non i-size compatible with a support leg (Yes/No)       | No        | Yes         | No            | Yes          |
| Lower ISOFIX anchorages but without Top Tether (Yes/No) | No        | No          | No            | No           |

U = Suitable for “universal” category restraints approved for use in this mass group.

UF = Suitable for forward-facing “universal” category restraints approved for use in this mass group.

IUF = Suitable for ISOFIX forward child restraints systems of universal category approved for use in the mass group.

## Essential Safety Equipment

# Child Restraint

---

L = Suitable for particular child restraints given on attached list. These restraints may be of the “specific vehicle”, “restricted” or “semi-universal” categories.

IL = Suitable for particular ISOFIX child restraint systems (CRS) given in the attached list. These ISOFIX CRS are those of the “specific vehicle”, “restricted” or “semi-universal” categories.

i-U = Suitable for i-Size “universal” Child Restraint Systems forward and rearward facing.

i-UF = Suitable for forward-facing i-Size “universal” Child Restraint Systems only.

Yes = Child-restraint system can be secured on the seat.

No = Child-restraint system cannot be secured on the seat, or there is no fixture.

X = Child-restraint system cannot be installed.

A Mazda genuine child-restraint system can be installed. Regarding child-restraint systems which can be installed, refer to the accessories catalog.

## Installing Child-Restraint Systems


### ▼ Anchor Bracket

Anchor brackets for securing child-restraint systems are equipped in the vehicle. Locate each anchor position using the illustration.

To install a child-restraint system, remove the head restraint. Always follow the instruction manual accompanying the child-restraint system.

#### Anchor bracket location

Use the indicated anchor bracket locations when installing a child-restraint system equipped with a tether.



### **WARNING**

*WARNING: child restraint anchorages are designed to withstand only those loads imposed by correctly fitted child restraints. Under no circumstances are they to be used for adult seat belts, harnesses or for attaching other items or equipment to the vehicle.*

#### **Always attach the tether strap to the correct tether anchor position:**


*Attaching the tether strap to the incorrect tether anchor position is dangerous. In a collision, the tether strap could come off and loosen the child-restraint system. If the child-restraint system moves it could result in death or injury to the child.*

## Child Restraint


### **Always remove the head restraint and install child-restraint system:**

*Installing a child-restraint system without removing the head restraint is dangerous. The child-restraint system cannot be installed correctly which may result in death or injury to the child in a collision.*


**(Saloon)**




**(Saloon)**



**(Hatchback)**



**(Hatchback)**



### **Always install the head restraint and adjust it to the appropriate position after removing the child-restraint system:**

*Driving with the head restraint removed is dangerous as impact to the occupant's head cannot be prevented during emergency braking or in a collision, which could result in a serious accident, injury or death.*

*Refer to Head Restraints on page 2-14.*


### **▼ Using Automatic Locking Mode**

Follow these instructions when using the automatic locking mode for a child-restraint system.


1. Make sure the seatback is securely latched by pushing it back until it is fully locked.
2. Remove the head restraint. However, when installing a backless booster seat, always install the vehicle head restraint to the seat where the backless booster seat is installed.  
Refer to Head Restraints on page 2-14.
3. Secure the child-restraint system with the lap portion of the lap/shoulder belt. See the manufacturer's instructions on the child-restraint system for belt routing instructions.

Essential Safety Equipment  
**Child Restraint**

4. To get the retractor into the automatic locking mode, pull the shoulder belt portion of the seat belt until the entire length of the belt is out of the retractor.



5. Push the child-restraint system firmly into the vehicle seat. Be sure the belt retracts as snugly as possible. A clicking noise from the retractor will be heard during retraction if the system is in the automatic locking mode. If the belt does not lock the seat down tight, repeat this step.



**NOTE**

- *Inspect this function before each use of the child-restraint system. You should not be able to pull the shoulder belt out of the retractor while the system is in the automatic locking mode. When you remove the child-restraint system, be sure the belt fully retracts to return the system to emergency locking mode before occupants use the seat belts.*
6. If your child-restraint system requires the use of a tether strap, refer to the manufacturer's instructions to hook and tighten the tether strap.

**⚠ WARNING**


**WARNING:** child restraint anchorages are designed to withstand only those loads imposed by correctly fitted child restraints. Under no circumstances are they to be used for adult seat belts, harnesses or for attaching other items or equipment to the vehicle.

## Child Restraint


**Always remove the head restraint and install child-restraint system (except when installing a backless booster seat):**

Installing a child-restraint system without removing the head restraint is dangerous. The child-restraint system cannot be installed correctly which may result in death or injury to the child in a collision.

**(Saloon)**



**(Hatchback)**



**Always attach the tether strap to the correct tether anchor position:**

Attaching the tether strap to the incorrect tether anchor position is dangerous. In a collision, the tether strap could come off and loosen the child-restraint system. If the child-restraint system moves it could result in death or injury to the child.

**Always install the head restraint and adjust it to the appropriate position after removing the child-restraint system:**

Driving with the head restraint removed is dangerous as impact to the occupant's head cannot be prevented during emergency braking or in a collision, which could result in a serious accident, injury or death.

Refer to Head Restraints on page 2-14.

### ▼ Centre-Rear Seat Child-Restraint System Installation

1. Make sure the seatback is securely latched by pushing it back until it is fully locked.
2. Remove the head restraint. However, when installing a backless booster seat, always install the vehicle head restraint to the seat where the backless booster seat is installed.  
Refer to Head Restraints on page 2-14.
3. Secure the child-restraint system with the seat belt, according to the manufacturer's instructions.
4. Secure the tether strap according to the child-restraint system manufacturer's instruction.

### ⚠ WARNING

**WARNING:** child restraint anchorages are designed to withstand only those loads imposed by correctly fitted child restraints. Under no circumstances are they to be used for adult seat belts, harnesses or for attaching other items or equipment to the vehicle.




Essential Safety Equipment  
**Child Restraint**


**Always remove the head restraint and install child-restraint system (except when installing a backless booster seat):**

Installing a child-restraint system without removing the head restraint is dangerous. The child-restraint system cannot be installed correctly which may result in death or injury to the child in a collision.

**(Saloon)**



**(Hatchback)**



**Always attach the tether strap to the correct tether anchor position:**

Attaching the tether strap to the incorrect tether anchor position is dangerous. In a collision, the tether strap could come off and loosen the child-restraint system. If the child-restraint system moves it could result in death or injury to the child.

**Always install the head restraint and adjust it to the appropriate position after removing the child-restraint system:**

Driving with the head restraint removed is dangerous as impact to the occupant's head cannot be prevented during emergency braking or in a collision, which could result in a serious accident, injury or death.

Refer to Head Restraints on page 2-14.

**▼ Using ISOFIX Anchor**

**⚠ WARNING**

**Follow the manufacturer's instructions for the use of the child-restraint system:**

An unsecured child-restraint system is dangerous. In a sudden stop or a collision it could move causing serious injury or death to the child or other occupants. Make sure any child-restraint system is properly secured in place according to the manufacturer's instructions.

**Make sure the child-restraint system is properly secured:**

A child-restraint system that is not secured is dangerous. In a sudden stop or collision, it can become a projectile and hit someone, causing serious injury. When not in use, remove it from the vehicle, put it in the luggage compartment or at least make sure it is securely fastened to the ISOFIX anchors.


## Child Restraint

***Make sure there are no seat belts or foreign objects near or around the ISOFIX anchor-secured child-restraint system:***

*Not following the child-restraint system manufacturer's instructions when installing the child-restraint system is dangerous. If seat belts or a foreign object prevent the child-restraint system from being securely attached to the ISOFIX anchors and the child-restraint system is installed improperly, the child-restraint system could move in a sudden stop or collision causing serious injury or death to the child or other occupants. When installing the child-restraint system, make sure there are no seat belts or foreign objects near or around the ISOFIX anchors. Always follow the child-restraint system manufacturer's instructions.*

1. First, adjust the front seat to allow clearance between the child-restraint system and the front seat.  
Refer to Adjusting the Driver's Seat on page 2-5.  
Refer to Adjusting the Front Passenger's Seat on page 2-10.
2. Make sure the seatback is securely latched by pushing it back until it is fully locked.

3. Expand the seams on the rear of the seat bottom slightly to verify the locations of the ISOFIX anchor.



**NOTE**

- The markings above the ISOFIX anchors indicate the locations of the ISOFIX anchors for the attachment of a child-restraint system.
4. Remove the head restraint. However, when installing a backless booster seat, always install the vehicle head restraint to the seat where the backless booster seat is installed.  
Refer to Head Restraints on page 2-14.
  5. Secure the child-restraint system using the ISOFIX anchor, following the child-restraint system manufacturer's instruction.
  6. If your child-restraint system came equipped with a tether, that probably means it is very important to properly secure the tether for child safety. Please carefully follow the child-restraint system manufacturer's instructions when installing tethers (page 2-35).

Essential Safety Equipment  
**Child Restraint**

**⚠ WARNING**

*WARNING: child restraint anchorages are designed to withstand only those loads imposed by correctly fitted child restraints. Under no circumstances are they to be used for adult seat belts, harnesses or for attaching other items or equipment to the vehicle.*


**Always attach the tether strap to the correct tether anchor position:**

*Attaching the tether strap to the incorrect tether anchor position is dangerous. In a collision, the tether strap could come off and loosen the child-restraint system. If the child-restraint system moves it could result in death or injury to the child.*


**Always remove the head restraint and install child-restraint system (except when installing a backless booster seat):**

*Installing a child-restraint system without removing the head restraint is dangerous. The child-restraint system cannot be installed correctly which may result in death or injury to the child in a collision.*

**(Saloon)**



**(Hatchback)**



## Child Restraint

---

***Always install the head restraint and adjust it to the appropriate position after removing the child-restraint system:***

*Driving with the head restraint removed is dangerous as impact to the occupant's head cannot be prevented during emergency braking or in a collision, which could result in a serious accident, injury or death.*

*Refer to Head Restraints on page 2-14.*

## Supplementary Restraint System (SRS) Precautions

The front and side supplementary restraint systems (SRS) include different types of air bags. **Please verify the different types of air bags which are equipped on your vehicle by locating the “SRS AIRBAG” location indicators.** These indicators are visible in the area where the air bags are installed.

The air bags are installed in the following locations:

- The steering wheel hub (driver air bag)
- The front passenger instrument panel (front passenger air bag)
- The outboard sides of the front seatbacks (side air bags)
- The front and rear window pillars, and the roof edge along both sides (curtain air bags)

The air bag supplementary restraint systems are designed to provide supplementary protection in certain situations so seat belts are always important in the following ways:

Without seat belt usage, the air bags cannot provide adequate protection during an accident. Seat belt usage is necessary to:

- Keep the occupant from being thrown into an inflating air bag.
- Reduce the possibility of injuries during an accident that is not designed for air bag inflation, such as roll-over or rear impact.
- Reduce the possibility of injuries in frontal, near frontal or side collisions that are not severe enough to activate the air bags.
- Reduce the possibility of being thrown from your vehicle.
- Reduce the possibility of injuries to lower body and legs during an accident because the air bags provide no protection to these parts of the body.
- Hold the driver in a position which allows better control of the vehicle.

A child who is too small to use a seat belt must be properly secured using a child-restraint system (page 2-24).

Carefully consider which child-restraint system is necessary for your child and follow the installation directions in this Owner's Manual as well as the child-restraint system manufacturer's instructions.

## SRS Air Bags

---

### **WARNING**

**Seat belts must be worn in air bag equipped vehicles:**

Depending only on the air bags for protection during an accident is dangerous. Alone, air bags may not prevent serious injuries. The appropriate air bags can be expected to inflate only in the first accident, such as frontal, near frontal or side collisions that are at least moderate. Vehicle occupants should always wear seat belts.


**Children should not ride in the front passenger seat:**

Placing a child, 12 years or under, in the front seat is dangerous. The child could be hit by a deploying air bag and be seriously injured or even killed. A sleeping child is more likely to lean against the door and be hit by the side air bag in moderate collision to the front-passenger side of the vehicle. Whenever possible, always secure a child 12 years and under on the rear seats with an appropriate child-restraint system for the child's age and size.

**Extreme Hazard! Never use a rear-facing child-restraint system on the front passenger seat with an air bag that could deploy:**

NEVER use a rearward facing child restraint on a seat protected by an ACTIVE AIRBAG in front of it, DEATH or SERIOUS INJURY to the CHILD can occur.

Even in a moderate collision, the child-restraint system can be hit by a deploying air bag and moved violently backward resulting in serious injury or death to the child.



**Do not sit too close to the driver and front passenger air bags:**

Sitting too close to the driver and front passenger air bag modules or placing hands or feet on them is extremely dangerous. The driver and front passenger air bags inflate with great force and speed. Serious injuries could occur if someone is too close. The driver should always hold onto only the rim of the steering wheel. The front seat passenger should keep both feet on the floor. Front seat occupants should adjust their seats as far back as possible and always sit upright against the seatbacks with seat belts worn properly.

***Sit in the centre of the seat and wear seat belts properly:***

*Sitting too close to the side air bag modules or placing hands on them, or sleeping up against the door or hanging out the windows is extremely dangerous. The side and curtain air bags inflate with great force and speed directly expanding along the door on the side the car is hit. Serious injury could occur if someone is sitting too close to the door or leaning against a window, or if rear seat occupants grab the sides of the front seatbacks. Give the side and curtain air bags room to work by sitting in the centre of the seat while the vehicle is moving with seat belts worn properly.*

***Do not attach objects on or around the area where driver and front passenger air bags deploy:***

*Attaching an object to the driver and front passenger air bag modules or placing something in front of them is dangerous. In an accident, an object could interfere with air bag inflation and injure the occupants.*

***Do not attach objects on or around the area where a side air bag deploys:***

*Attaching objects to the front seat in such a way as to cover the outboard side of the seat in any way is dangerous. In an accident the object could interfere with the side air bag, which inflates from the outboard side of the front seats, impeding the added protection of the side air bag system or redirecting the air bag in a way that is dangerous. Furthermore, the bag could be cut open releasing the gas.*

*Do not hang net bags, map pouches or backpacks with side straps on the front seats. Never use seat covers on the front seats. Always keep the side air bag modules in your front seats free to deploy in the event of a side collision.*

***Do not attach objects on or around the area where a curtain air bag deploys:***

*Attaching objects to the areas where the curtain air bag activates such as on the windscreen glass, side door glass, front and rear window pillars and along the roof edge and assist grips is dangerous. In an accident the object could interfere with the curtain air bag, which inflates from the front and rear window pillars and along the roof edge, impeding the added protection of the curtain air bag system or redirecting the air bag in a way that is dangerous. Furthermore, the bag could be cut open releasing the gas.*

*Do not place hangers or any other objects on the assist grips. When hanging clothes, hang them on the coat hook directly. Always keep the curtain air bag modules free to deploy in the event of a side collision.*

***Do not touch the components of the supplementary restraint system after the air bags have inflated:***

*Touching the components of the supplementary restraint system after the air bags have inflated is dangerous. Immediately after inflation, they are very hot. You could get burned.*

## SRS Air Bags

---

**Never install any front-end equipment to your vehicle:**

Installation of front-end equipment, such as frontal protection bar (kangaroo bar, bull bar, push bar, or other similar devices), snowplow, or winches, is dangerous. The air bag crash sensor system could be affected. This could cause air bags to inflate unexpectedly, or it could prevent the air bags from inflating during an accident. Front occupants could be seriously injured.

**Do not modify the suspension:**

Modifying the vehicle suspension is dangerous. If the vehicle's height or the suspension is modified, the vehicle will be unable to accurately detect a collision resulting in incorrect or unexpected air bag deployment and the possibility of serious injuries.

**Do not modify a front door or leave any damage unrepaired. Always have an expert repairer (we recommend an Authorised Mazda Repairer) inspect a damaged front door:**

Modifying a front door or leaving any damage unrepaired is dangerous. Each front door has a side crash sensor as a component of the supplementary restraint system. If holes are drilled in a front door, a door speaker is left removed, or a damaged door is left unrepaired, the sensor could be adversely affected causing it to not detect the pressure of an impact correctly during a side collision. If a sensor does not detect a side impact correctly, the side and curtain air bags and the front seat belt pretensioner may not operate normally which could result in serious injury to occupants.

**Do not modify the supplementary restraint system:**

Modifying the components or wiring of the supplementary restraint system is dangerous. You could accidentally activate it or make it inoperable. Do not make any modifications to the supplementary restraint system. This includes installing trim, badges, or anything else over the air bag modules. It also includes installing extra electrical equipment on or near system components or wiring. An expert repairer (we recommend an Authorised Mazda Repairer) can provide the special care needed in the removal and installation of front seats. It is important to protect the air bag wiring and connections to assure that the bags do not accidentally deploy, and that the driver seat slide position sensor is not damaged and the seats retain an undamaged air bag connection.

**Do not place luggage or other objects under the front seats:**

Placing luggage or other objects under the front seats is dangerous. The components essential to the supplementary restraint system could be damaged, and in the event of a side collision, the appropriate air bags may not deploy, which could result in death or serious injury. To prevent damage to the components essential to the supplementary restraint system, do not place luggage or other objects under the front seats.



**Do not operate a vehicle with damaged air bag/seat belt pretensioner system components:**

Expended or damaged air bag/seat belt pretensioner system components must be replaced after any collision which caused them to deploy or damage them. Only a trained expert repairer (we recommend an Authorised Mazda Repairer) can fully evaluate these systems to see that they will work in any subsequent accident. Driving with an expended or damaged air bag or pretensioner unit will not afford you the necessary protection in the event of any subsequent accident which could result in serious injury or death.

**Do not remove interior air bag parts:**

Removing any components such as the front seats, front instrument panel, the steering wheel or parts on the front and rear window pillars and along the roof edge, containing air bag parts or sensors is dangerous. These parts contain essential air bag components. The air bag could accidentally activate and cause serious injuries. Always have an Authorised Mazda Repairer remove these parts.

**Properly dispose of the air bag system:**


Improper disposal of an air bag or a vehicle with live air bags in it can be extremely dangerous. Unless all safety procedures are followed, injury could result. Have an expert repairer (we recommend an Authorised Mazda Repairer) safely dispose of the air bag system or scrap an air bag equipped vehicle.

**NOTE**

- When an air bag deploys, a loud inflation noise can be heard and some smoke will be released. Neither is likely to cause injury, however, the texture of the air bags may cause light skin injuries on body parts not covered with clothing through friction.
- Should you sell your Mazda, we urge you to tell the new owner of its air bag systems and that familiarization with all instructions about them, from the Owner's Manual, is important.
- This highly-visible label warns against the use of a rear-facing child-restraint system on the front passenger seat.



### Supplementary Restraint System Components



\* Some models

- ① Driver/Front passenger inflators and air bags
- ② Crash sensors, and diagnostic module (SAS unit)
- ③ Seat belt pretensioners (page 2-22)
- ④ Front air bag sensor
- ⑤ Side crash sensors
- ⑥ Air bag/seat belt pretensioner system warning light (page 4-29)
- ⑦ Side and curtain inflators and air bags
- ⑧ Driver seat slide position sensor (page 2-49)

## How the SRS Air Bags Work

Your Mazda is equipped with the following types of SRS air bags. SRS air bags are designed to work together with the seat belts to help to reduce injuries during an accident. The SRS air bags are designed to provide further protection for passengers in addition to the seat belt functions. Be sure to wear seat belts properly.

### ▼ Seat Belt Pretensioners

The pretensioners operate differently depending on what types of air bags are equipped. For more details about seat belt pretensioner operation, refer to the SRS Air Bag Deployment Criteria (page 2-52).

#### Front

The front seat belt pretensioners are designed to deploy in moderate or severe frontal, near frontal collisions. In addition, during a side collision, the pretensioner operates.

#### Rear Outboard

The rear outboard seat belt pretensioners are designed to deploy in moderate or severe frontal, near frontal collisions.

### ▼ Driver Air Bag

The driver's air bag is mounted in the steering wheel.

When air bag crash sensors detect a frontal impact of greater than moderate force, the driver's air bag inflates quickly helping to reduce injury mainly to the driver's head or chest caused by directly hitting the steering wheel.


For more details about air bag deployment, refer to "SRS Air Bag Deployment Criteria" (page 2-52).

The inflation of the driver's dual-stage air bag is controlled in two energy stages depending on the driver's seat position. The driver's seat slide position sensor is located under the driver's seat. The sensor determines whether the driver's seat is forward of or behind a reference position and sends the seat position to the diagnostic module (SAS unit). The SAS unit is designed to control the deployment of the driver's air bag depending on how close the driver's seat is to the steering wheel.

## SRS Air Bags

---

During an impact of moderate severity, the driver's air bag deploys with lesser energy, whereas during more severe impacts and when the driver's seat is behind the reference position, it deploys with more energy.



### ▼ Front Passenger Air Bag


The front passenger air bag is mounted in the front passenger instrument panel. The inflation mechanism for the front passenger air bag is the same as the driver's air bag. For more details about air bag deployment, refer to "SRS Air Bag Deployment Criteria" (page 2-52).



### ▼ Side Air Bags

The side air bags are mounted in the outboard sides of the front seatbacks. When the air bag crash sensors detect a side impact of greater than moderate force, the system inflates the side air bag only on the side in which the vehicle was hit. The side air bag inflates quickly to reduce injury to the driver or front passenger's chest caused by directly hitting interior parts such as a door or window.

For more details about air bag deployment, refer to "SRS Air Bag Deployment Criteria" (page 2-52).




#### ▼ Curtain Air Bags

The curtain air bags are mounted in the front and rear window pillars, and the roof edge along both sides.

When the air bag crash sensors detect a side impact of greater than moderate force, the curtain air bag inflates quickly and helps to reduce injury mainly to the rear outboard passenger's head caused by directly hitting interior parts such as a door or window.

For more details about air bag deployment, refer to "SRS Air Bag Deployment Criteria" (page 2-52).



Only one side curtain air bag will deploy on the side of the vehicle that receives the force of an impact.

#### ▼ Warning Light/Beep

A system malfunction or operation conditions are indicated by a warning.

Refer to Warning/Indicator Lights on page 4-29.

Refer to Warning Sound is Activated on page 7-37.



## Essential Safety Equipment

# SRS Air Bags

## SRS Air Bag Deployment Criteria

This chart indicates the applicable SRS equipment that will deploy depending on the type of collision.

(The illustrations are the representative cases of collisions.)

|                                       | Types of collision                                                                |                                                                                   |                                                                                     |
|---------------------------------------|-----------------------------------------------------------------------------------|-----------------------------------------------------------------------------------|-------------------------------------------------------------------------------------|
|                                       | A severe frontal/near frontal collision                                           | A severe side collision                                                           | A rear collision                                                                    |
| SRS equipment                         |  |  |  |
| Front seat belt pretensioner          | X                                                                                 | X                                                                                 | No air bag and seat belt pretensioner will be activated in a rear collision.        |
| Rear out-board seat belt pretensioner | X                                                                                 |                                                                                   |                                                                                     |
| Driver air bag                        | X                                                                                 |                                                                                   |                                                                                     |
| Front passenger air bag               | X                                                                                 |                                                                                   |                                                                                     |
| Side air bag                          |                                                                                   | X (impact side only)                                                              |                                                                                     |
| Curtain air bag                       |                                                                                   | X (impact side only)                                                              |                                                                                     |

X : The SRS air bag equipment is designed to deploy in a collision.

### NOTE

*In a frontal offset collision, the equipped air bags and pretensioners may all deploy depending on the direction, angle, and rate of impact.*


## Limitations to SRS Air Bag

In severe collisions such as those described previously in "SRS Air Bag Deployment Criteria", the applicable SRS air bag equipment will deploy. However, in some accidents, the equipment may not deploy depending on the type of collision and its severity.


### **Limitations to front/near front collision detection:**

The following illustrations are examples of front/near front collisions that may not be detected as severe enough to deploy the SRS air bag equipment.


Impacts involving trees or poles



Frontal offset impact to the vehicle



Rear-ending or running under a truck's tail gate




## SRS Air Bags

---


### Limitations to side collision detection:

The following illustrations are examples of side collisions that may not be detected as severe enough to deploy the SRS air bag equipment.

Side impacts involving trees or poles



Side impacts with two-wheeled vehicles



Roll-over








## Constant Monitoring



The following components of the air bag systems are monitored by a diagnostic system:

- Front air bag sensors
- Crash sensors, and diagnostic module (SAS unit)
- Side crash sensors
- Driver seat slide position sensor
- Air bag modules
- Seat belt pretensioners
- Air bag/Seat belt pretensioner system warning light
- Related wiring

The diagnostic module continuously monitors the system's readiness. This begins when the ignition is switched ON and continues while the vehicle is being driven.



# MEMO



## 3 Before Driving

Use of various features, including keys, doors, mirrors and windows.

|                                      |             |                                   |             |
|--------------------------------------|-------------|-----------------------------------|-------------|
| <b>Keys.....</b>                     | <b>3-2</b>  | <b>Windows.....</b>               | <b>3-26</b> |
| Keys.....                            | 3-2         | Power Windows.....                | 3-26        |
| Keyless Entry System.....            | 3-3         |                                   |             |
| <b>Advanced Keyless Entry</b>        |             | <b>Security System.....</b>       | <b>3-29</b> |
| <b>System.....</b>                   | <b>3-7</b>  | Modification and Add-On           |             |
| Advanced Keyless Entry System* ..... | 3-7         | Equipment.....                    | 3-29        |
| .....                                | 3-7         | Immobilizer System.....           | 3-29        |
| Operational Range.....               | 3-8         |                                   |             |
| <b>Doors and Locks.....</b>          | <b>3-9</b>  | <b>Driving Tips.....</b>          | <b>3-31</b> |
| Door Locks.....                      | 3-9         | Running-In Period.....            | 3-31        |
| Liftgate/Boot Lid.....               | 3-13        | Saving Fuel and Protection of the |             |
|                                      |             | Environment.....                  | 3-31        |
| <b>Fuel and Emission.....</b>        | <b>3-17</b> | Hazardous Driving.....            | 3-32        |
| Fuel and Engine Exhaust              |             | Floor Mat.....                    | 3-32        |
| Precautions.....                     | 3-17        | Rocking the Vehicle.....          | 3-33        |
| Fuel-Filler Flap and Cap.....        | 3-21        | Winter Driving.....               | 3-34        |
|                                      |             | Driving In Flooded Area.....      | 3-35        |
| <b>Mirrors.....</b>                  | <b>3-23</b> | <b>Towing.....</b>                | <b>3-36</b> |
| Mirrors.....                         | 3-23        | Towing Caravans and               |             |
|                                      |             | Trailers.....                     | 3-36        |

\*Some models. **3-1**

## Keys

### Keys

#### **WARNING**

**Do not leave the key in your vehicle with children and keep them in a place where your children will not find or play with them:**

Leaving children in a vehicle with the key is dangerous. This could result in someone being badly injured or even killed. Children may find these keys to be an interesting toy to play with and could cause the power windows or other controls to operate, or even make the vehicle move.

#### **CAUTION**

- *Because the key (transmitter) uses low-intensity radio waves, it may not function correctly under the following conditions:*
  - *The key is carried with communication devices such as cellular phones.*
  - *The key contacts or is covered by a metal object.*
  - *The key is near electronic devices such as personal computers.*
  - *Non-Mazda genuine electronic equipment is installed in the vehicle.*
  - *There is equipment which discharges radio waves near the vehicle.*
- *The key (transmitter) may consume battery power excessively if it receives high-intensity radio waves. Do not place the key near electronic devices such as televisions or personal computers.*


- *To avoid damage to the key (transmitter), DO NOT:*
  - *Drop the key.*
  - *Get the key wet.*
  - *Disassemble the key.*
  - *Expose the key to high temperatures on places such as the instrument panel or bonnet, under direct sunlight.*
  - *Expose the key to any kind of magnetic field.*
  - *Place heavy objects on the key.*
  - *Put the key in an ultrasonic cleaner.*
  - *Put any magnetized objects close to the key.*

A code number is stamped on the plate attached to the key set; detach this plate and store it in a safe place (not in the vehicle) for use if you need to make a replacement key (auxiliary key). Also write down the code number and keep it in a separate safe and convenient place, but not in the vehicle.

If your key (auxiliary key) is lost, consult an expert repairer (we recommend an Authorised Mazda Repairer), and have your code number ready.


**NOTE**

*The driver must carry the key to ensure the system functions properly.*



 Key code number plate

To use the auxiliary key, pull out the auxiliary key from the transmitter while pressing the knob.

**Keyless Entry System**

This system uses the key buttons to remotely lock and unlock the doors and the liftgate/boot lid, and opens the boot lid.

The system can start the engine without having to take the key out of your purse or pocket.

System malfunctions or warnings are indicated by the following warning lights or beeps.

- KEY Warning Light (Red)  
Refer to Contact Authorised Mazda Repairer and Have Vehicle Inspected on page 7-25.  
Refer to Taking Action on page 7-31.
- Ignition Not Switched Off (STOP) Warning Beep  
Refer to Ignition Not Switched Off (STOP) Warning Beep on page 7-38.
- Key Removed from Vehicle Warning Beep  
Refer to Key Removed from Vehicle Warning Beep on page 7-38.

If you have a problem with the key, consult an expert repairer (we recommend an Authorised Mazda Repairer).

If your key is lost or stolen, consult an expert repairer (we recommend an Authorised Mazda Repairer) as soon as possible for a replacement and to make the lost or stolen key inoperative.

## Keys

### CAUTION

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

### NOTE

- The keyless entry system operation may vary due to local conditions.
- The keyless entry system is fully operational (door/liftgate/boot lid lock/unlock) when the ignition is switched off. The system does not operate if the ignition is switched to any position other than off.
- If the key does not operate when pressing a button or the operational range becomes too small, the battery may be weak. To install a new battery, refer to Key Battery Replacement (page 6-25).
- Battery life is about 1 year. Replace the battery with a new one if the KEY indicator light (green) flashes in the instrument cluster. Replacing the battery about once a year is recommended because the KEY warning light/indicator light may not illuminate or flash depending on the rate of battery depletion.




- Additional keys can be obtained at an Authorised Mazda Repairer. Up to 6 keys can be used with the keyless functions per vehicle. Bring all keys to the Authorised Mazda Repairer when additional keys are required.

### ▼ Transmitter

Operation indicator light

Operation buttons



### NOTE

- The headlights turn on/off by operating the transmitter. Refer to Leaving Home Light on page 4-51.
- **(With the advanced keyless function)**  
A beep sound can be heard for confirmation when the doors and the liftgate/boot lid are locked/unlocked using the key. If you prefer, the beep sound can be turned off.  
The volume of the beep sound can also be changed.  
Refer to Personalisation Features on page 9-8.  
Use the following procedure to change the setting.
  1. Switch the ignition off and close all of the doors and the liftgate/boot lid.
  2. Open the driver's door.
  3. Within 30 seconds of opening the driver's door, press and hold the LOCK button on the key for 5 seconds or longer.

*The beep sound activates at the currently set volume. The setting changes each time the LOCK button on the key is pressed and the beep sound activates at the set volume. (If the beep sound has been set to not activate, it will not activate.)*

4. *The setting change is completed by doing any one of the following:*
  - *Switching the ignition to ACC or ON.*
  - *Closing the driver's door.*
  - *Opening the liftgate/boot lid.*
  - *Not operating the key for 10 seconds.*
  - *Pressing any button except the LOCK button on the key.*
  - *Pressing a request switch.*

The operation indicator light flashes when the buttons are pressed.

### **Lock button**

To lock the doors and the liftgate/boot lid, press the lock button and the hazard warning lights will flash once.

**(With the advanced keyless function)**

A beep sound will be heard once.



### **NOTE**

- *The doors and the liftgate/boot lid cannot be locked by pressing the lock button while any other door or the liftgate is open. The hazard warning lights will also not flash.*
- *Make sure all doors and the liftgate/boot lid are locked after pressing the button.*

### **Unlock button**

To unlock the doors and the liftgate/boot lid, press the unlock button and the hazard warning lights will flash twice.

**(With the advanced keyless function)**

A beep sound will be heard twice.



### **NOTE**

#### **• (Auto re-lock function)**

*After unlocking with the key, all doors and the liftgate/boot lid will automatically lock if any of the following operations are not performed within about 30 seconds.*

*The time required for the doors to lock automatically can be changed.*

*Refer to Personalisation Features on page 9-8.*

- *A door or the liftgate/boot lid is opened.*
- *The ignition is switched to any position other than off.*

### **Boot button (Saloon)**

To open the boot lid, press and hold the boot button until the boot lid opens.



### **▼ Operational Range**

The system operates only when the driver is in the vehicle or within operational range while the key is being carried.

## Keys

### Starting the Engine


#### **NOTE**

- Starting the engine may be possible even if the key is outside of the vehicle and extremely close to a door and window, however, always start the engine from the driver's seat.

*If the vehicle is started and the key is not in the vehicle, the vehicle will not restart after it is shut off and the ignition is switched to off.*


- The luggage compartment/boot is out of the assured operational range, however, if the key (transmitter) is operable the engine will start.

#### **With the advanced keyless function**



Operational range

#### **Without the advanced keyless function**



Operational range

#### **NOTE**

*The engine may not start if the key is placed in the following areas:*

- Around the instrument panel
- In the storage compartments such as the glove compartment or the centre console

#### **▼ Key Suspend Function**

If a key is left in the vehicle, the functions of the key left in the vehicle are temporarily suspended to prevent theft of the vehicle.

To restore the functions, press the unlock button on the functions-suspended key in the vehicle.



## Advanced Keyless Entry System

### Advanced Keyless Entry System\*

#### WARNING

**Radio waves from the key may affect medical devices such as pacemakers:**

Before using the key near people who use medical devices, ask the medical device manufacturer or your physician if radio waves from the key will affect the device.

The advanced keyless function allows you to lock/unlock the door and the liftgate/boot lid, or open the liftgate/boot lid while carrying the key.

System malfunctions or warnings are indicated by the following warning lights or beeps.

- KEY Warning Light (Red)  
Refer to Warning/Indicator Lights on page 4-29.
- Ignition Not Switched Off Warning Beep  
Refer to Ignition Not Switched Off (STOP) Warning Beep on page 7-38.
- Key Removed from Vehicle Warning Beep  
Refer to Key Removed from Vehicle Warning Beep on page 7-38.
- Request switch Inoperable Warning Beep  
Refer to Request Switch Inoperable Warning Beep (With the advanced keyless function) on page 7-38.

- Key Left-in-luggage Compartment/Boot Warning Beep  
Refer to Key Left-in-luggage Compartment/Boot Warning Beep (With the advanced keyless function) on page 7-39.
- Key Left-in-vehicle Warning Beep  
Refer to Key Left-in-vehicle Warning Beep (With the advanced keyless function) on page 7-39.

#### NOTE

The advanced keyless entry system functions can be deactivated to prevent any possible adverse effect on a user wearing a pacemaker or other medical device. If the system is deactivated, you will be unable to start the engine by carrying the key. Consult an expert repairer (we recommend an Authorised Mazda Repairer) for details. If the advanced keyless entry system has been deactivated, you can start the engine by following the procedure indicated when the key battery goes dead. Refer to Engine Start Function When Key Battery is Dead on page 4-8.

\*Some models.

## Advanced Keyless Entry System


### Operational Range

The system operates only when the driver is in the vehicle or within operational range while the key is being carried.

#### NOTE

When the battery power is low, or in places where there are high-intensity radio waves or noise, the operational range may become narrower or the system may not operate. For determining battery replacement, Refer to Keyless Entry System on page 3-3.

#### ▼ Locking, Unlocking the Doors and the Liftgate/Boot Lid




#### NOTE

- The system may not operate if you are too close to the windows or door handles, or liftgate/boot lid.

- If the key is left in the following areas and you leave the vehicle, the doors may be locked depending on the radio wave conditions even if the key is left in the vehicle.

- Around the instrument panel
- In the storage compartments such as the glove compartment or the centre console
- On the rear parcel shelf (saloon)
- Next to a communication device such as a mobile phone

#### ▼ Opening the Liftgate/Boot Lid



## Doors and Locks

### Door Locks

#### WARNING

***Always take all children and pets with you or leave a responsible person with them:***

*Leaving a child or a pet unattended in a parked vehicle is dangerous. In hot weather, temperatures inside a vehicle can become high enough to cause brain damage or even death.*

***Do not leave the key in your vehicle with children and keep them in a place where your children will not find or play with them:***

*Leaving children in a vehicle with the key is dangerous. This could result in someone being badly injured or even killed.*

***Keep all doors locked when driving:***

*Unlocked doors in a moving vehicle are dangerous. Passengers can fall out if a door is accidentally opened and can more easily be thrown out in an accident.*

***Always close all the windows, lock the doors and the liftgate/boot lid and take the key with you when leaving your vehicle unattended:***

*Leaving your vehicle unlocked is dangerous as children could lock themselves in a hot vehicle, which could result in death. Also, a vehicle left unlocked becomes an easy target for thieves and intruders.*

***After closing the doors and the liftgate/boot lid, always verify that they are securely closed:***

*Doors and the liftgate/boot lid not securely closed are dangerous, if the vehicle is driven with a door and the liftgate/boot lid not securely closed, the door and the liftgate/boot lid could open unexpectedly resulting in an accident.*

***Always confirm the safety around the vehicle before opening a door and the liftgate/boot lid:***

*Suddenly opening a door and the liftgate/boot lid is dangerous. A passing vehicle or a pedestrian could be hit and cause an accident.*

#### CAUTION

- *Always confirm the conditions around the vehicle before opening/closing the doors and the liftgate/boot lid and use caution during strong winds or when parked on an incline. Not being aware of the conditions around the vehicle is dangerous because fingers could get caught in the door and the liftgate/boot lid or a passing pedestrian could be hit, resulting in an unexpected accident or injury.*

#### NOTE

- *Always stop the engine and lock the doors. In addition, to prevent theft of valuables, do not leave them inside the cabin.*

## Doors and Locks

· If the key is left in the following areas and you leave the vehicle, the doors may be locked depending on the radio wave conditions even if the key is left in the vehicle.


- Around the instrument panel
- In the storage compartments such as the glove compartment or the centre console
- On the rear parcel shelf (saloon)
- Next to a communication device such as a mobile phone
- The vehicle lock-out prevention feature prevents you from locking yourself out of the vehicle.

All doors and the liftgate/boot lid will automatically unlock if they are locked using the power door locks with any door or the liftgate open.

### ▼ Locking, Unlocking with Auxiliary Key


All doors and the liftgate/boot lid lock automatically when the driver's door is locked using the auxiliary key. They all unlock when the driver's door is unlocked using the auxiliary key.

Turn the auxiliary key toward the front to lock, toward the back to unlock.



### ▼ Locking, Unlocking with Request Switch (With the advanced keyless function)

All doors and the liftgate/boot lid can be locked/unlocked by pressing the request switch while the key is being carried.



#### To lock

To lock the doors and the liftgate/boot lid, press the request switch and the hazard warning lights will flash once.

A beep sound will be heard once.

#### To unlock

To unlock the doors and the liftgate/boot lid, press the request switch and the hazard warning lights will flash twice.

A beep sound will be heard twice.

#### **NOTE**

- Confirm that all doors and the liftgate/boot lid are securely locked.  
For the liftgate/boot lid, move it without pressing the electric liftgate/boot lid opener to verify that the liftgate/boot lid has not been left ajar.
- All doors and the liftgate/boot lid cannot be locked when any door or the liftgate is open.

## Doors and Locks

- It may require a few seconds for the doors to unlock after the request switch is pressed.
- A beep sound is heard for confirmation when the doors and the liftgate/boot lid are locked/unlocked using the request switch. If you prefer, the beep sound can be turned off.

The volume of the beep sound can also be changed. Refer to Personalisation Features on page 9-8.

Use the following procedure to change the setting.

1. Switch the ignition off and close all of the doors and the liftgate/boot lid.
2. Open the driver's door.
3. Within 30 seconds of opening the driver's door, press and hold the LOCK button on the key for 5 seconds or longer.

The beep sound activates at the currently set volume. The setting changes each time the LOCK button on the key is pressed and the beep sound activates at the set volume. (If the beep sound has been set to not activate, it will not activate.)

4. The setting change is completed by doing any one of the following:
  - Switching the ignition to ACC or ON.
  - Closing the driver's door.
  - Opening the liftgate/boot lid.
  - Not operating the key for ten seconds.
  - Pressing any button except the LOCK button on the key.
  - Pressing a request switch.

- The setting can be changed so that the doors and the liftgate/boot lid are locked automatically without pressing the request switch.

Refer to Personalisation Features on page 9-8.

### **(Walk-away auto lock function)**

A beep sound is heard when all doors and the liftgate are closed while the advanced key is being carried. All doors and the liftgate/boot lid are locked automatically after about three seconds when the advanced key is out of the operational range. Also, the hazard warning lights flash once. (Even if the driver is in the operational range, all doors and the liftgate/boot lid are locked automatically after about 30 seconds.) If you are out of the operational range before the doors and the liftgate/boot lid are completely closed or another key is left in the vehicle, the walk-away auto lock function will not work. Always make sure that all doors and the liftgate/boot lid are closed and locked before leaving the vehicle. The walk-away auto lock function does not close the power windows.

### • **(Auto re-lock function)**

After unlocking with the request switch, all doors and the liftgate/boot lid will automatically lock if any of the following operations are not performed within about 30 seconds.

The time required for the doors to lock automatically can be changed.

Refer to Personalisation Features on page 9-8.

- Opening a door or the liftgate/boot lid.

## Doors and Locks

- Switching the ignition to any position other than off.


### ▼ Locking, Unlocking with Transmitter

All doors and the liftgate/boot lid can be locked/unlocked by operating the keyless entry system transmitter, refer to Keyless Entry System (page 3-3).

### ▼ Locking, Unlocking with Door-Lock Knob

#### Operation from inside


All doors and the liftgate/boot lid lock automatically when the driver's door-lock knob is pushed. They all unlock when the driver's door-lock knob is pulled out.



#### Operation from outside

To lock the rear and front passenger doors with the door-lock knob from the outside, push the door-lock knob to the lock position and close the door (holding the door handle in the open position is not required).

This does not operate the other door locks.



#### **NOTE**

*When locking the door this way:*

- Be careful not to leave the key inside the vehicle.
- The driver's door lock knob cannot be used while the driver's door is open.


### ▼ Rear Door Child Safety Locks

These locks are intended to help prevent children from accidentally opening the rear doors. Use them on both rear doors whenever a child rides in the rear seat of the vehicle.

If you slide the child safety lock to the lock position before closing that door, the door cannot be opened from the inside.

## Doors and Locks

The door can only be opened by pulling the outside handle.



### Liftgate/Boot Lid

#### **WARNING**

**Never allow a person to ride in the luggage compartment/boot:**

Allowing a person to ride in the luggage compartment/boot is dangerous. The person in the luggage compartment/boot could be seriously injured or killed during sudden braking or a collision.

**Do not drive with the liftgate/boot lid open:**

Exhaust gas in the cabin of a vehicle is dangerous. An open liftgate/boot lid in a moving vehicle will cause exhaust gas to be drawn into the cabin. This gas contains CO (carbon monoxide), which is colourless, odourless, and highly poisonous, and it can cause loss of consciousness and death. Moreover, an open liftgate/boot lid could cause occupants to fall out in an accident.

**Do not stack or leave loaded luggage unsecured in the luggage compartment:**


Otherwise, the luggage may move or collapse, resulting in injury or an accident. In addition, do not load luggage higher than the seatbacks. It may affect the side or rear field of view.

#### **CAUTION**

- Before opening the liftgate/boot lid, remove any snow and ice accumulation on it. Otherwise, the liftgate/boot lid could close under the weight of the snow and ice resulting in injury.

## Doors and Locks

- Be careful when opening/closing the liftgate/boot lid during strong winds. If a strong gust blows against the liftgate/boot lid, it could close suddenly resulting in injury.
- Fully open the liftgate/boot lid and make sure that it stays open. If the liftgate/boot lid is only opened partially, it could slam shut by vibration or wind gusts resulting in injury.
- When loading or unloading luggage in the luggage compartment/boot, turn off the engine. Otherwise, you could get burned by the heat of the exhaust gas.
- Be careful not to apply excessive force to the damper stay on the liftgate such as by putting your hand on the stay. Otherwise, the damper stay may bend and affect the liftgate operation.




- Do not modify or replace the liftgate damper stay. Consult an expert repairer (we recommend an Authorised Mazda Repairer) if a liftgate damper stay is deformed or damaged for reasons such as a collision or if there is some other problem.

### ▼ Opening and Closing the Liftgate/Boot Lid


#### Opening the liftgate/boot lid

##### **Using the electric liftgate/boot lid opener**

Unlock the doors and liftgate/boot lid, then press the electric liftgate/boot lid opener on the liftgate/boot lid and raise the liftgate/boot lid when the latch releases.  
**(Hatchback)**



**(Saloon)**



#### **NOTE**

**(With the advanced keyless function)**

- A locked liftgate/boot lid can also be opened while the key is being carried.



## Doors and Locks

- When opening the liftgate/boot lid with the doors and the liftgate/boot lid locked, it may require a few seconds for the liftgate/boot lid latch to release after the electric liftgate/boot lid opener is pressed.
- The liftgate/boot lid can be closed when the doors are locked with the key left in the vehicle. However, to prevent locking the key in the vehicle, the liftgate/boot lid can be opened by pressing the electric liftgate/boot lid opener. If the liftgate/boot lid cannot be opened despite doing this procedure, first push the liftgate/boot lid completely closed, then press the electric liftgate/boot lid opener to fully open the liftgate/boot lid.

### • (Hatchback)

When the latch is released by pressing the electric liftgate opener, the liftgate raises slightly. If the liftgate is not operated for a certain period of time, the liftgate cannot be raised.

#### **To open**

Press the electric liftgate opener again.

#### **To close**

To close the liftgate from its slightly raised position, open it first by pressing the electric liftgate opener, then close it after waiting at least 1 second.


- If the liftgate is not fully closed, the driver is notified by a warning indicated in the instrument cluster.
- If the vehicle battery is dead or there is a malfunction in the electrical system and the liftgate/boot lid cannot be unlocked, the liftgate/boot lid can be opened by performing the emergency procedure.  
Refer to When Liftgate/Boot Lid Cannot be Opened on page 7-42.

### Closing the liftgate/boot lid

#### **(Hatchback)**

Lower the liftgate slowly using the liftgate grip recess, then push the liftgate closed using both hands.

Do not slam it. Pull up on the liftgate to make sure it is secure.



#### **(Saloon)**

Use both hands to push the boot lid down until the lock snaps shut. Do not slam it. Pull up on the boot lid to make sure it is secure.

## Doors and Locks

### ▼ Luggage Compartment

#### Luggage compartment cover\*

#### **WARNING**

##### ***Do not place anything on top of the cover:***

*Placing luggage or other cargo on top of the luggage compartment cover is dangerous. During sudden braking or a collision, the cargo could become a projectile that could hit and injure someone. The vehicle has a light weight luggage compartment cover to keep the contents of your luggage area out of sight; it will not retain heavy objects that are not tied down in an accident such as a rollover. Tie down all heavy objects, whether luggage or cargo, using the tie down hooks.*


##### ***Make sure luggage and cargo are secured before driving:***

*Not securing cargo while driving is dangerous as it could move or be crushed during sudden braking or a collision and cause injury.*

#### **CAUTION**

*Make sure the luggage compartment cover is firmly secured. If it is not firmly secured, it could unexpectedly disengage resulting in injury.*


The luggage compartment can be accessed by opening the liftgate when the straps are attached to the sides of the liftgate.



#### **Removing the cover**

This cover can be removed for more room.

1. Remove the straps from the hooks.
2. Lift the end of the luggage compartment cover a little, pull it outward, and remove it from the pins.



3. Lift the front end of the luggage compartment cover and remove it.

## Fuel and Emission

### Fuel and Engine Exhaust Precautions

#### ▼ Fuel Requirements (Australia)

Vehicles with catalytic converters or oxygen sensors must use **ONLY UNLEADED FUEL**, which will reduce exhaust emissions and keep spark plug fouling to a minimum.

To achieve maximum engine performance, use the specified fuel.

| Fuel                                                                  | Research Octane Number |
|-----------------------------------------------------------------------|------------------------|
| Regular unleaded fuel (Conforming to Fuel Quality Standards Act 2000) | 90 or above            |

Fuel with a lower rating will negatively affect the emission control system performance and could also cause engine knocking and serious engine damage.

#### CAUTION

##### ➤ **USE ONLY UNLEADED FUEL.**

*Leaded fuel is harmful to the catalytic converter and oxygen sensors and will lead to deterioration of the emission control system and or failures.*

##### ➤ *This vehicle can only use oxygenated fuels containing no more than 10 % ethanol by volume. Damage to the vehicle may occur when ethanol exceeds this recommendation, or if the petrol contains any methanol. Stop using gasohol of any kind if your vehicle engine is performing poorly.*

##### ➤ *Never add fuel system additives other than a Mazda genuine product, otherwise the emission control system could be damaged. Consult an expert repairer (we recommend an Authorised Mazda Repairer) for details.*

Petrol blended with oxygenates such as alcohol or ether compounds are generally referred to as oxygenated fuels. The common petrol blend that can be used with your vehicle is ethanol blended at no more than 10 %. Petrol containing alcohol, such as ethanol or methanol, may be marketed under the name “Gasohol”.

Vehicle damage and drivability problems resulting from the use of the following may not be covered by the Mazda warranty.

- Gasohol containing more than 10 % ethanol.
- Petrol or gasohol containing methanol.
- Leaded fuel or leaded gasohol.

## Fuel and Emission

### ▼ Fuel Requirements (Except Australia)

Vehicles with catalytic converters or oxygen sensors must use **ONLY UNLEADED FUEL**, which will reduce exhaust emissions and keep spark plug fouling to a minimum.

To achieve maximum engine performance, use the specified fuel.

| Fuel                  | Research Octane Number |
|-----------------------|------------------------|
| Regular unleaded fuel | 90 or above            |

Fuel with a lower rating will negatively affect the emission control system performance and could also cause engine knocking and serious engine damage.

### CAUTION

#### ➤ **USE ONLY UNLEADED FUEL.**

*Leaded fuel is harmful to the catalytic converter and oxygen sensors and will lead to deterioration of the emission control system and or failures.*

#### ➤ **This vehicle can only use oxygenated fuels containing no more than 10 % ethanol by volume. Damage to the vehicle may occur when ethanol exceeds this recommendation, or if the petrol contains any methanol. Stop using gasohol of any kind if your vehicle engine is performing poorly.**

#### ➤ **Never add fuel system additives other than a Mazda genuine product, otherwise the emission control system could be damaged. Consult an expert repairer (we recommend an Authorised Mazda Repairer) for details.**

### ▼ Emission Control System

This vehicle is equipped with an emission control system (the catalytic converter is part of this system) that enables the vehicle to comply with existing exhaust emissions requirements.

### WARNING

#### **Never park over or near anything flammable:**

*Parking over or near anything flammable, such as dry grass, is dangerous. Even with the engine turned off, the exhaust system remains very hot after normal use and could ignite anything flammable. A resulting fire could cause serious injury or death.*

## Fuel and Emission

### CAUTION

*Ignoring the following precautions could cause lead to accumulate on the catalyst inside the converter or cause the converter to get very hot. Either condition will damage the converter and cause poor performance.*

- **USE ONLY UNLEADED FUEL.**
- *Do not drive your Mazda with any sign of engine malfunction.*
- *Do not coast with the ignition switched off.*
- *Do not descend steep grades in gear with the ignition switched off.*
- *Do not operate the engine at high idle for more than 2 minutes.*
- *Do not tamper with the emission control system. All inspections and adjustments must be made by a qualified technician.*
- *Do not push-start or pull-start this vehicle.*

### ▼ **Engine Exhaust (Carbon monoxide)**

### WARNING

***Do not drive your vehicle if you smell exhaust gas inside the vehicle:***

*Engine exhaust gas is dangerous. This gas contains carbon monoxide (CO), which is colourless, odourless, and poisonous. When inhaled, it can cause loss of consciousness and death. If you smell exhaust gas inside the vehicle, keep all windows fully open and contact an expert repairer (we recommend an Authorised Mazda Repairer) immediately.*

***Do not run the engine when inside an enclosed area:***

*Running the engine inside an enclosed area, such as a garage, is dangerous. Exhaust gas, which contains poisonous carbon monoxide, could easily enter the cabin. Loss of consciousness or even death could occur.*

***Open the windows or adjust the heating or cooling system to draw fresh air when idling the engine:***

*Exhaust gas is dangerous. When the vehicle is stopped with the windows closed and the engine running for a long time even in an open area, exhaust gas, which contains poisonous carbon monoxide, could enter the cabin. Loss of consciousness or even death could occur.*

Before Driving

## Fuel and Emission

---

***Clear snow from underneath and around your vehicle, particularly the tail pipe, before starting the engine:***

*Running the engine when a vehicle is stopped in deep snow is dangerous. The exhaust pipe could be blocked by the snow, allowing exhaust gas to enter the cabin. Because exhaust gas contains poisonous carbon monoxide, it could cause loss of consciousness or even death to occupants in the cabin.*

**Fuel-Filler Flap and Cap****⚠ WARNING**

**When removing the fuel-filler cap, loosen the cap slightly and wait for any hissing to stop, then remove it:**

*Fuel spray is dangerous. Fuel can burn skin and eyes and cause illness if ingested. Fuel spray is released when there is pressure in the fuel tank and the fuel-filler cap is removed too quickly.*

**Before refuelling, stop the engine, and always keep sparks and flames away from the filler neck:**

*Fuel vapour is dangerous. It could be ignited by sparks or flames causing serious burns and injuries.*

*Additionally, use of the incorrect fuel-filler cap or not using a fuel-filler cap may result in a fuel leak, which could result in serious burns or death in an accident.*

**Do not continue refuelling after the fuel pump nozzle shuts off automatically:**

*Continuing to add fuel after the fuel pump nozzle has shut off automatically is dangerous because overfilling the fuel tank may cause fuel overflow or leakage. Fuel overflow and leakage could damage the vehicle and if the fuel ignites it could cause a fire and explosion resulting in serious injury or death.*


**⚠ CAUTION**

*Always use only a designated Mazda fuel-filler cap or an approved equivalent, available at an expert repairer (we recommend an Authorised Mazda Repairer). The wrong cap can result in a serious malfunction of the fuel and emission control systems.*

**▼ Refuelling**

Before refuelling, close all the doors, windows, and the liftgate/boot lid, and switch the ignition OFF.

1. To open the fuel-filler flap, pull the remote fuel-filler flap release.




2. To remove the fuel-filler cap, turn it anticlockwise.

Before Driving


## Fuel and Emission

---

3. Attach the removed cap to the inner side of the fuel-filler flap.



4. Insert the refuelling nozzle all the way and begin refuelling. Pull out the refuelling nozzle after the refuelling stops automatically.
5. To close the fuel-filler cap, turn it clockwise until a click is heard.
6. To close, press the fuel-filler flap until it locks securely.





## Mirrors

Before driving, adjust the inside and outside mirrors.

### ▼ Outside Mirrors

#### **WARNING**

***Be sure to look over your shoulder before changing lanes:***  
*Changing lanes without taking into account the actual distance of the vehicle in the convex mirror is dangerous. You could have a serious accident. What you see in the convex mirror is closer than it appears.*

#### Mirror type

##### **Flat type (driver's side)**

Flat surface mirror.

##### **Convex type (front passenger side)**

The mirror has single curvature on its surface.


#### Power mirror adjustment

The ignition must be switched to ACC or ON position.

To adjust:

1. Rotate the mirror switch to the left **L** or right **R** to choose the left or right side mirror.

2. Press the mirror switch in the appropriate direction.



After adjusting the mirror, lock the control by rotating the switch to the centre position.

#### Folding outside mirror

#### **WARNING**

***Always return the outside mirrors to the driving position before you start driving:***  
*Driving with the outside mirrors folded in is dangerous. Your rear view will be restricted, and you could have an accident.*

#### ***Do not touch a power folding outside mirror while it is moving:***

*Touching the power folding outside mirror when it is moving is dangerous. Your hand could be pinched and injured or the mirror could be damaged.*

#### ***Use the switch to set the mirror to the on-road position:***

*Setting the power folding outside mirror to the on-road position by hand is dangerous. The mirror will not lock in position and will prevent effective rearview visibility.*

## Mirrors


### **Only operate the power folding outside mirror with the vehicle safely parked:**

Operating the power folding outside mirror while the vehicle is moving is dangerous. Wind blast on the mirror will cause them to collapse and you will be unable to return it to the on-road position, preventing rearview visibility.

The ignition must be switched to ACC or ON position.

To fold the mirrors, press the lower side  of the outside mirror folding switch.

To return the mirrors to their on-road positions, press the upper side  of the outside mirror folding switch.



### **Automatic folding function\***

The automatic folding function operates when the ignition is switched to ACC or OFF.

When the outside mirror automatic folding switch is pressed to the AUTO position (neutral position), the outside mirrors automatically fold in and out when the doors are locked and unlocked.

Also, when the ignition is switched ON or the engine is started, the outside mirrors fold out automatically.

### **NOTE**

The outside mirrors may not fold in and out automatically under cold weather conditions.

If the outside mirrors do not fold in and out automatically, remove any ice or snow, and then press the upper or lower side of the outside mirror automatic folding switch to fold the outside mirrors in or out.

### **Engine-off outside mirror operation**

The outside mirrors can be operated for about 40 seconds after the ignition is switched from ON to off.

### **▼ Rearview Mirror**




### **Do not stack cargo or objects higher than the seatbacks:**

Cargo stacked higher than the seatbacks is dangerous. It can block your view in the rearview mirror, which might cause you to hit another car when changing lanes.

### **Rearview mirror adjustment**

Before driving, adjust the rearview mirror to centre on the scene through the rear window.




**NOTE**

*For the manual antidazzle mirror, perform the adjustment with the antidazzle lever in the day position.*

**Reducing glare from headlights**

**Manual antidazzle mirror**

Push the antidazzle lever forward for day driving. Pull it back to reduce glare of headlights from vehicles at the rear.




**Auto-dimming mirror**

The auto-dimming mirror automatically reduces the glare of headlights from vehicles at the rear when the ignition is switched ON.

**NOTE**

*Do not use glass cleaner or suspend objects on or around the light sensor. Otherwise, light sensor sensitivity will be affected and may not operate normally.*



*The auto-dimming function is cancelled when the ignition is switched ON and the shift/selector lever is in reverse (R).*

Before Driving

## Windows

---

### Power Windows

The windows can be opened/closed by operating the power window switches.

#### **WARNING**

***Make sure the opening is clear before closing a window:***

*Closing a power window is dangerous. A person's hands, head, or even neck could be caught by the window and result in serious injury or even death. This warning applies especially to children.*

***Never allow children to play with power window switches:***

*Power window switches that are not locked with the power window lock switch would allow children to operate power windows unintentionally, which could result in serious injury if a child's hands, head or neck becomes caught by the window.*

***Make sure nothing blocks the window just before it reaches the fully closed position or while holding up the power window switch:***

*Blocking the power window just before it reaches the fully closed position or while holding up the power window switch is dangerous.*

*In this case, the jam-safe function cannot prevent the window from closing all the way. If fingers are caught, serious injuries could occur.*


***NOTE***

*When driving with only 1 of the rear windows open, your ears might experience a resonating sound. However, this does not indicate a problem. The sound can be reduced by slightly opening a front window or by changing the size of the rear window opening.*

### ▼ Opening/Closing Windows

The window opens while the switch is pressed and it closes while the switch is pulled up with the ignition switched ON. Do not open or close three or more windows at the same time.

The front passenger's side and rear windows can be opened/closed when the power window lock switch on the driver's door is in the unlock position. Keep this switch in the locked position while children are in the vehicle.



### NOTE

- A power window may no longer open/close if you continue to press the switch after fully opening/closing the power window. If the power window does not open/close, wait a moment and then operate the switch again.
  - The passenger windows may be opened or closed using the master control switches on the driver's door.
  - The power window can be operated for about 40 seconds after the ignition is switched from ON to ACC or off with all doors closed. If any door is opened, the power window will stop operating.
- For engine-off operation of the power window, the switch must be held up firmly throughout window closure because the auto-closing function will be inoperable.

## Windows

---

### ▼ Auto-opening/Closing

To fully open the window automatically, press the switch completely down, then release. The window will fully open automatically.

To fully close the window automatically, pull the switch completely up, then release. The window will fully close automatically.

To stop the window partway, pull or press the switch in the opposite direction and then release it.

This function is only equipped on the driver's side.

#### **NOTE**

##### ***Power window system initialization procedure***

*If the battery was disconnected during vehicle maintenance, or for other reasons (such as a switch continues to be operated after the window is fully open/closed), the window will not fully open and close automatically.*

*The power window auto function will only resume on a power window that has been reset.*

1. *Switch the ignition ON.*
2. *Make sure that the power window lock switch located on the driver's door is not depressed.*
3. *Press the switch and fully open the window.*
4. *Pull up the switch to fully close the window and continue holding the switch for about 2 seconds after the window fully closed.*
5. *Make sure that the power windows operate correctly using the door switches.*

### ▼ Jam-safe Window

If foreign matter is detected between the window and the window frame while the window is closing automatically (refer to Auto-opening/Closing on page 3-28), the window stops closing and automatically opens partway.

#### **NOTE**

- *The jam-safe function may operate under the following conditions:*
  - *A strong impact is detected while the window is closing automatically.*
  - *Window is closing automatically in very low temperatures.*
- *In the event the jam-safe function activates and the power window cannot be closed automatically, pull and hold the switch and the window will close.*
- *The jam-safe window function does not operate until the system has been reset.*

## Security System

### Modification and Add-On Equipment

Mazda cannot guarantee the immobilizer system's operation if the system has been modified or if any add-on equipment has been installed.

#### CAUTION

*To avoid damage to the vehicle, do not modify the system or install any add-on equipment to the immobilizer system or the vehicle.*

### Immobilizer System

The immobilizer system allows the engine to start only with a key the system recognises.

If someone attempts to start the engine with an unrecognised key, the engine will not start, thereby helping to prevent vehicle theft.

If you have a problem with the immobilizer system or the key, consult an expert repairer (we recommend an Authorised Mazda Repairer).

#### CAUTION

- *Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.*
- *To avoid damage to the key, do not:*
  - *Drop the key.*
  - *Get the key wet.*
  - *Expose the key to any kind of magnetic field.*
  - *Expose the key to high temperatures on places such as the instrument panel or bonnet, under direct sunlight.*
- *If the engine does not start with the correct key, and the security indicator light keeps illuminating or flashing, the system may have a malfunction. Consult an expert repairer (we recommend an Authorised Mazda Repairer).*

## Security System

### NOTE

- The keys carry a unique electronic code. For this reason, and to assure your safety, obtaining a replacement key requires some waiting time. They are only available through an Authorised Mazda Repairer.
- Always keep a spare key in case one is lost. If a key is lost, consult an expert repairer (we recommend an Authorised Mazda Repairer) as soon as possible.
- If you lose a key, an Authorised Mazda Repairer, will reset the electronic codes of your remaining keys and immobilizer system. Bring all the remaining keys to the Authorised Mazda Repairer to reset. Starting the vehicle with a key that has not been reset is not possible.

### ▼ Operation

### NOTE

- The engine may not start and security indicator light may illuminate or flash if the key is placed in an area where it is difficult for the system to detect the signal, such as on the instrument panel or in the glove compartment. Move the key to a location within the signal range, switch the ignition off, and then restart the engine.
- Signals from a TV or radio station, or from a transceiver or mobile telephone could interfere with your immobilizer system. If you are using the proper key and the engine fails to start, check the security indicator light.

### Arming

The system is armed when the ignition is switched from ON to off.

### 3-30

The security indicator light in the instrument cluster flashes every 2 seconds until the system is disarmed.



### Disarming

The system is disarmed when the ignition is switched ON with the correct programmed key. The security indicator light illuminates for about 3 seconds and then turns off. If the engine does not start with the correct key, and the security indicator light remains illuminated or flashing, try the following:

Make sure the key is within the operational range for signal transmission. Switch the ignition off, and then restart the engine. If the engine does not start after 3 or more tries, contact an expert repairer (we recommend an Authorised Mazda Repairer).

### NOTE

- If the security indicator light flashes continuously while you are driving, do not shut off the engine. Go to an expert repairer (we recommend an Authorised Mazda Repairer), and have it checked. If the engine is shut off while the indicator light is flashing, you will not be able to restart it.
- Because the electronic codes are reset when the immobilizer system is repaired, the keys are needed. Make sure to bring all the keys to an expert repairer (we recommend an Authorised Mazda Repairer), so that they can be programmed.



## Running-In Period

No special running-in is necessary, but a few precautions in the first 1,000 km (600 miles) may add to the performance, economy, and life of the vehicle.

- Do not race the engine.
- Do not maintain one constant speed, either slow or fast, for a long period of time.
- Do not drive constantly at full-throttle or high engine rpm for extended periods of time.
- Avoid unnecessary hard stops.
- Avoid full-throttle starts.
- Do not tow a trailer.

## Saving Fuel and Protection of the Environment

How you operate your Mazda determines how far it will travel on a tank of fuel. Use these suggestions to help save fuel and reduce CO<sub>2</sub>.

- Avoid long warm-ups. Once the engine runs smoothly, begin driving.
- Avoid fast starts.
- Drive at lower speeds.
- Anticipate when to apply the brakes (avoid sudden braking).
- Follow the maintenance schedule (page 6-3) and have an expert repairer (we recommend an Authorised Mazda Repairer) perform inspections and servicing.
- Use the air conditioner only when necessary.
- Slow down on rough roads.
- Keep the tyres properly inflated.
- Do not carry unnecessary weight.
- Do not rest your foot on the brake pedal while driving.
- Keep the wheels in correct alignment.
- Keep windows closed at high speeds.
- Slow down when driving in crosswinds and headwinds.

### **WARNING**

***Never stop the engine when going down a hill:***

*Stopping the engine when going down a hill is dangerous. This causes the loss of power steering and power brake control, and may cause damage to the drivetrain. Any loss of steering or braking control could cause an accident.*

## Driving Tips

### Hazardous Driving

#### WARNING

***Be extremely careful if it is necessary to downshift on slippery surfaces:***

*Downshifting into lower gear while driving on slippery surfaces is dangerous. The sudden change in tyre speed could cause the tyres to skid. This could lead to loss of vehicle control and an accident.*

When driving on ice or in water, snow, mud, sand, or similar hazards:

- Be cautious and allow extra distance for braking.
- Avoid sudden braking and sudden manoeuvring.
- Do not pump the brakes. Continue to press down on the brake pedal. Refer to Antilock Brake System (ABS) on page 4-65.
- If you get stuck, select a lower gear and accelerate slowly. Do not spin the front wheels.
- For more traction in starting on slippery surfaces such as ice or packed snow, use sand, rock salt, chains, carpeting, or other nonslip material under the front wheels.

#### **NOTE**

*Use snow chains only on the front wheels.*

### Floor Mat

We recommend the use of Genuine Mazda floor mats.

#### WARNING

***Make sure the floor mats are secured with the grommets or the retainers to prevent them from bunching up under the foot pedals (Driver's side):***

*Using a floor mat that is not secured is dangerous as it will interfere with the accelerator and brake pedal operation (driver's side), which could result in an accident.*

*Only use a floor mat which conforms to the shape of the floor on the driver's side and make sure it is oriented correctly.*

*Secure the floor mat using the grommets or retainers.*

*There are various ways to secure floor mats depending on the type used, therefore secure the mat according to the type.*


*After installing the floor mat, make sure that it does not slide from side to side or back and forth, and that there is sufficient clearance with the accelerator and brake pedals on the driver's side.*

*After removing the floor mat for cleaning or some other reason, always securely reinstall it while paying attention to the precautions just mentioned.*

***Do not install two floor mats, one on top of the other, on the driver's side:***

*Installing two floor mats, one on top of the other, on the driver's side is dangerous as the retention pins can only keep one floor mat from sliding forward.*

*Loose floor mat(s) will interfere with the foot pedals and could result in an accident. If using an all-weather mat for winter use always remove the original floor mat.*



When setting a floor mat, position the floor mat so that its grommets or retainers are inserted over the pointed end of the retention posts.

## Rocking the Vehicle

### **WARNING**

***Do not spin the wheels at high speed, and do not allow anyone to stand behind a wheel when pushing the vehicle:***

*When the vehicle is stuck, spinning the wheels at high speed is dangerous. The spinning tyre could overheat and explode. This could cause serious injuries.*

### **CAUTION**

*Too much rocking may cause engine overheating, transaxle failure, and tyre damage.*

If you must rock the vehicle to free it from snow, sand or mud, depress the accelerator slightly and slowly move the shift lever/selector lever from 1 (D) to R position.

## Driving Tips

### Winter Driving

Carry emergency gear, including tyre chains, window scraper, flares, a small shovel, jumper leads, and a small bag of sand or salt.

Ask an expert repairer (we recommend an Authorised Mazda Repairer) to check the following:

- Have the proper ratio of antifreeze in the radiator.  
Refer to Engine Coolant on page 6-16.
- Inspect the battery and its leads. Cold reduces battery capacity.
- Use an engine oil appropriate for the lowest ambient temperatures that the vehicle will be driven in (page 6-14).
- Inspect the ignition system for damage and loose connections.
- Use washer fluid made with antifreeze—but do not use engine coolant antifreeze for washer fluid (page 6-18).

#### NOTE

- *Do not use the parking brake in freezing weather as it may freeze. Instead, shift to P with an automatic transaxle and to 1 or R with a manual transaxle. Block the rear wheels.*
- *Remove snow before driving. Snow left on the windscreen is dangerous as it could obstruct vision.*
- *Do not apply excessive force to a window scraper when removing ice or frozen snow on the mirror glass and windscreen.*
- *Never use warm or hot water for removing snow or ice from windows and mirrors as it could result in the glass cracking.*

3-34

- *Drive slowly. Braking performance can be adversely affected if snow or ice adheres to the brake components. If this situation occurs, drive the vehicle slowly, releasing the accelerator pedal and lightly applying the brakes several times until the brake performance returns to normal.*

#### ▼ Snow Tyres



**Use only the same size and type tyres (snow, radial, or non-radial) on all 4 wheels:**

*Using tyres different in size or type is dangerous. Your vehicle's handling could be greatly affected and result in an accident.*



*Check local regulations before using studded tyres.*

#### Use snow tyres on all 4 wheels

Do not exceed the maximum permissible speed for your snow tyres or legal speed limits.

#### ▼ Tyre Chains

Check local regulations before using tyre chains.



- *Chains may affect handling.*
- *Do not go faster than 50 km/h (30 mph) or the chain manufacturer's recommended limit, whichever is lower.*

- *Drive carefully and avoid bumps, holes, and sharp turns.*
- *Avoid locked-wheel braking.*
- *Do not use chains on a temporary spare tyre; it may result in damage to the vehicle and to the tyre.*
- *Do not use chains on roads that are free of snow or ice. The tyres and chains could be damaged.*
- *Chains may scratch or chip aluminium wheels.*

Install the chains on the front tyres only.  
Do not use chains on the rear tyres.  
Please consult an expert repairer (we recommend an Authorised Mazda Repairer).

#### **Installing the chains**

1. If your vehicle is equipped with wheel covers remove them, otherwise the chain bands will scratch them.
2. Secure the chains on the front tyres as tightly as possible.  
Always follow the chain manufacturer's instructions.
3. Retighten the chains after driving 1/2—1 km (1/4—1/2 mile).

### **Driving In Flooded Area**

#### **WARNING**

***Dry off brakes that have become wet by driving slowly, releasing the accelerator pedal and lightly applying the brakes several times until the brake performance returns to normal:***

*Driving with wet brakes is dangerous. Increased stopping distance or the vehicle pulling to one side when braking could result in a serious accident. Light braking will indicate whether the brakes have been affected.*

#### **CAUTION**

*Do not drive the vehicle on flooded roads as it could cause short circuiting of electrical/electronic parts, or engine damage or stalling from water absorption. If the vehicle has been immersed in water, consult an expert repairer (we recommend an Authorised Mazda Repairer).*

### Towing Caravans and Trailers

Your Mazda was designed and built primarily to carry passengers and cargo.

If you tow a trailer, follow these instructions because driver and passenger safety depends on proper equipment and safe driving habits. Towing a trailer will affect handling, braking, durability, performance, and economy.

Never overload vehicle or trailer. Consult an Authorised Mazda Dealer if you need further details.

#### CAUTION

- *Towing a trailer during the first 1,000 km (600 miles) of your new Mazda is not recommended. If you do, you may damage the power train components.*
- *Damage caused by towing a trailer/caravan with the saloon model is not covered by the vehicle's warranty.*

#### ▼ Load Limits (Hatchback)

#### CAUTION

*Be aware of the towing load weight differences when towing at high altitudes. For altitudes exceeding 1,000 m, always reduce the towing load by 10% for every 1,000 m increase in altitude from the total weight (gross vehicle weight and load limit). If the determined maximum total towing load weight is exceeded, the engine and other power train parts may be damaged.*

The total weight of a trailer or other towed vehicle must not exceed the following:

Trailer with brakes 900 kg (1,984.1 lb)

Trailer without brakes 500 kg (1,102.3 lb)

The downward load on the tow ball must not exceed 50 kg (110.2 lb).

#### ▼ Towing Instructions

Follow these instructions to make your towing as safe and efficient as possible.

- Use only a Mazda-approved tow bar.
- Never exceed recommended load limits and always refer to the identification plate affixed to the tow bar.
- Before towing, inflate all tyres to the maximum recommended pressures.  
You'll find these specifications on the edge of the driver's door.




- When on a hill or towing with heavy loads, always use a lower gear. This helps maintain speed. It also prevents engine and transaxle overloading when going up hills and reduces the need for braking when going down hills.
- Always allow a greater stopping distance than normal to prevent excessive braking, and avoid sudden stops that could cause loss of control.
- Frequently inspect oil and fluid levels.
- Because of the extra stress on your Mazda from towing, more frequent maintenance than usual is necessary.
- Your Mazda's behaviour changes while towing. Get accustomed to these changes over a short and safe trial distance before starting a long trip.
- Headlights may need re-aiming after a trailer has been attached, especially if a load equalizing hitch is not used.
- Due to the additional stress on the engine cooling system when towing, the airflow to the radiator must not be restricted in any way.
- Make sure the towed vehicle complies with all local regulations, especially in regard to lighting, mirrors, and safety chains. The tow bar should not obscure the rear number plate.
- Whenever you remove the tow bar, seal all mounting holes in the underbody to prevent the entry of exhaust fumes, dust, and water.
- Avoid parking on an incline with a trailer. If this must be done, follow these instructions.

**Parking on an Incline**




1. Set the parking brake and the brakes.
2. Have someone block the wheels of the vehicle and trailer while you apply the brakes.
3. After the wheels are blocked, release the parking brake and the brakes slowly, allowing the blocks to bear the load.
4. Set the parking brake firmly.
5. If the vehicle has an automatic transaxle, put the selector lever in the P position. If it has a manual transaxle, place the gear shift in 1 or R.

**Starting on an Incline**

1. Start the engine (page 4-5).
2. Release the parking brake and slowly pull away a short distance from the wheel blocks.
3. Stop on the nearest level ground, set the parking brake, and pick up the wheel blocks.



# MEMO





## 4 When Driving



Information concerning safe driving and stopping.

|                                             |             |                                    |             |
|---------------------------------------------|-------------|------------------------------------|-------------|
| <b>Start/Stop Engine.....</b>               | <b>4-4</b>  | <b>Hazard Warning Flasher.....</b> | <b>4-58</b> |
| Ignition Switch.....                        | 4-4         |                                    |             |
| Starting the Engine.....                    | 4-5         | <b>Brake.....</b>                  | <b>4-60</b> |
| Turning the Engine Off.....                 | 4-10        | Brake System.....                  | 4-60        |
| i-stop* .....                               | 4-11        | Emergency Stop Signal              |             |
|                                             |             | System.....                        | 4-63        |
| <b>Instrument Cluster and Display .....</b> | <b>4-19</b> | Hill Launch Assist (HLA).....      | 4-63        |
| Meters and Gauges.....                      | 4-19        |                                    |             |
| Active Driving Display* .....               | 4-26        | <b>ABS/TCS/DSC.....</b>            | <b>4-65</b> |
| Warning/Indicator Lights.....               | 4-29        | Antilock Brake System              |             |
|                                             |             | (ABS).....                         | 4-65        |
| <b>Manual Transaxle Operation.....</b>      | <b>4-36</b> | Traction Control System            |             |
| Manual Transaxle Shift                      |             | (TCS).....                         | 4-66        |
| Pattern.....                                | 4-36        | Dynamic Stability Control          |             |
|                                             |             | (DSC).....                         | 4-67        |
| <b>Automatic Transaxle.....</b>             | <b>4-38</b> |                                    |             |
| Automatic Transaxle                         |             | <b>Fuel Economy Monitor.....</b>   | <b>4-69</b> |
| Controls.....                               | 4-38        | Fuel Economy Monitor* .....        | 4-69        |
| Shift-Lock System.....                      | 4-39        |                                    |             |
| Transaxle Ranges.....                       | 4-40        | <b>Drive Selection.....</b>        | <b>4-72</b> |
| Manual Shift Mode.....                      | 4-42        | Drive Selection* .....             | 4-72        |
| Driving Tips.....                           | 4-46        |                                    |             |
| <b>Switches and Controls.....</b>           | <b>4-47</b> | <b>Power Steering.....</b>         | <b>4-73</b> |
| Lighting Control.....                       | 4-47        | Power Steering.....                | 4-73        |
| Turn and Lane-Change                        |             |                                    |             |
| Signals.....                                | 4-52        | <b>i-ACTIVSENSE.....</b>           | <b>4-74</b> |
| Windscreen Wipers and                       |             | i-ACTIVSENSE* .....                | 4-74        |
| Washer.....                                 | 4-53        | High Beam Control System           |             |
| Rear Window Wiper and Washer* .....         | 4-56        | (HBC)* .....                       | 4-77        |
| Rear Window Defogger.....                   | 4-57        | Adaptive LED Headlights            |             |
| Horn.....                                   | 4-58        | (ALH)* .....                       | 4-79        |
|                                             |             | Lane Departure Warning System      |             |
|                                             |             | (LDWS)* .....                      | 4-82        |

\*Some models. **4-1**

|                                                                             |       |
|-----------------------------------------------------------------------------|-------|
| Distance Recognition Support System (DRSS)* .....                           | 4-87  |
| Blind Spot Monitoring (BSM)* .....                                          | 4-89  |
| Traffic Sign Recognition System (TSR)* .....                                | 4-95  |
| Driver Attention Alert (DAA)* .....                                         | 4-101 |
| Rear Cross Traffic Alert (RCTA)* .....                                      | 4-103 |
| Mazda Radar Cruise Control (MRCC)* .....                                    | 4-107 |
| Lane-keep Assist System (LAS) & Lane Departure Warning System (LDWS)* ..... | 4-117 |
| Adjustable Speed Limiter (ASL)* .....                                       | 4-129 |
| Advanced Smart City Brake Support (Advanced SCBS).....                      | 4-136 |
| Smart City Brake Support [Reverse] (SCBS R)* .....                          | 4-140 |
| Smart Brake Support (SBS)* ....                                             | 4-144 |
| 360° View Monitor* .....                                                    | 4-147 |

|                                              |              |
|----------------------------------------------|--------------|
| Forward Sensing Camera (FSC)* .....          | 4-174        |
| Radar Sensor (Front)* .....                  | 4-179        |
| Radar Sensors (Rear)* .....                  | 4-182        |
| Ultrasonic Sensor (Rear)* .....              | 4-184        |
| Front Camera/Side Cameras/Rear Camera* ..... | 4-185        |
| <b>Cruise Control.....</b>                   | <b>4-186</b> |
| Cruise Control* .....                        | 4-186        |
| <b>Tyre Pressure Monitoring System.....</b>  | <b>4-191</b> |
| Tyre Pressure Monitoring System.....         | 4-191        |
| <b>Rear View Monitor.....</b>                | <b>4-194</b> |
| Rear View Monitor* .....                     | 4-194        |
| <b>Parking Sensor System.....</b>            | <b>4-202</b> |
| Parking Sensor System* .....                 | 4-202        |



# MEMO


## Start/Stop Engine

### Ignition Switch

#### ▼ Push Button Start Positions

The system operates only when the key is within operational range.

Each time the push button start is pressed, the ignition switches in the order of off, ACC, and ON. Pressing the push button start again from ON switches the ignition off.



#### NOTE

- The engine starts by pressing the push button start while depressing the clutch pedal (manual transaxle) or the brake pedal (automatic transaxle). To switch the ignition position, press the push button start without depressing the pedal.
- Do not leave the ignition switched ON while the engine is not running. Doing so could result in the battery going dead. If the ignition is left in ACC (For automatic transaxle, the selector lever is in the P position, and the ignition is in ACC), the ignition switches off automatically after about 25 minutes.

#### Off

The power supply to electrical devices turns off and the push button start indicator light (amber) also turns off. In this position the steering wheel is locked.\*

#### WARNING

**Before leaving the driver's seat, always switch the ignition off, set the parking brake, and make sure the selector lever is in P (automatic transaxle) position or in 1st gear or R (manual transaxle):**

Leaving the driver's seat without switching the ignition off, setting the parking brake, and shifting the selector lever to P (automatic transaxle) position or to 1st gear or R (manual transaxle) is dangerous. Unexpected vehicle movement could occur which could result in an accident.

In addition, if your intention is to leave the vehicle for even a short period, it is important to switch the ignition off, as leaving it in another position will disable some of the vehicle's security systems and run the battery down.

#### NOTE

**(Locked steering wheel)\***

If the push button start indicator light (green) is flashing and the beep sound is heard, this indicates that the steering wheel is not unlocked. To unlock the steering wheel, press the push button start while moving the steering wheel left and right.

### ACC (Accessory)

Some electrical accessories will operate and the indicator light (amber) illuminates. In this position the steering wheel is unlocked.\*

#### NOTE

*The keyless entry system does not function while the push button start has been pressed to ACC, and the doors will not lock/unlock even if they have been locked manually.*

### ON

This is the normal running position after the engine is started. The indicator light (amber) turns off. (The indicator light (amber) illuminates when the ignition is switched ON and the engine is not running.)

Some indicator lights/warning lights should be inspected before the engine is started (page 4-29).

#### NOTE

*When the push button start is pressed to ON, the sound of the fuel pump motor operating near the fuel tank can be heard. This does not indicate an abnormality.*

## Starting the Engine

### WARNING

#### **Radio waves from the key may affect medical devices such as pacemakers:**

*Before using the key near people who use medical devices, ask the medical device manufacturer or your physician if radio waves from the key will affect the device.*

#### NOTE

- *The key must be carried because the key carries an immobilizer chip that must communicate with the engine controls at short range.*
- *The engine can be started when the push button start is pressed from off, ACC, or ON.*
- *The push button start system functions (function which can start the engine by only carrying the key) can be deactivated to prevent any possible adverse effect on a user wearing a pacemaker or other medical device. If the system is deactivated, you will be unable to start the engine by carrying the key. Consult an expert repairer (we recommend an Authorised Mazda Repairer) for details. If the push button start system functions have been deactivated, you can start the engine by following the procedure indicated when the key battery goes dead. Refer to Engine Start Function When Key Battery is Dead on page 4-8.*
- *After starting a cold engine, the engine speed increases and a whining sound from the engine compartment can be heard.*

\*Some models.

## Start/Stop Engine

*This is for improved exhaust gas purification and does not indicate any parts defect.*

1. Make sure you are carrying the key.
2. Occupants should fasten their seat belts.
3. Make sure the parking brake is on.
4. Continue to press the brake pedal firmly until the engine has completely started.

5. **(Manual transaxle)**

Continue to press the clutch pedal firmly until the engine has completely started.

**(Automatic transaxle)**

Put the vehicle in park (P). If you must restart the engine while the vehicle is moving, shift into neutral (N).

**NOTE**


**(Manual transaxle)**

*The starter will not operate if the clutch pedal is not depressed sufficiently.*

**(Automatic transaxle)**

*The starter will not operate if the selector lever is not in P or N and the brake pedal is not depressed sufficiently.*

6. Verify that the KEY indicator light (green) in the instrument cluster and the push button start indicator light (green) illuminate.



**NOTE**

- If the push button start indicator light (green) flashes, make sure that the key is being carried.
- If the push button start indicator light (green) flashes with the key being carried, touch the key to the push button start and start the engine. Refer to Engine Start Function When Key Battery is Dead on page 4-8.

## Start/Stop Engine

### CAUTION

If the KEY warning light (red) illuminates, or the push button start indicator light (amber) flashes, this could indicate a problem with the engine starting system. This may prevent the engine from starting or from switching the ignition to ACC or ON. Have your vehicle inspected at an expert repairer (we recommend an Authorised Mazda Repairer) as soon as possible.

### NOTE

- Under the following conditions, the KEY warning light (red) flashes after the push button start is pressed. This informs the driver that the push button start will not switch to ACC even if it is pressed from off.
  - The key battery is dead.
  - The key is out of operational range.
  - The key is placed in areas where it is difficult for the system to detect the signal (page 3-5).
  - A key from another manufacturer similar to the key is in the operational range.

### · (Forced engine starting method)

If the KEY warning light (red) illuminates, or the push button start indicator light (amber) flashes, this could indicate that the engine may not start using the usual starting method. Have your vehicle inspected at an expert repairer (we recommend an Authorised Mazda Repairer) as soon as possible. If this occurs, the engine can be force-started. Press and hold the push button start until the engine starts. Other procedures necessary for starting the engine, such as having the key in the cabin, and depressing the clutch pedal (manual transaxle) or the brake pedal (automatic transaxle) are required.

- When the engine is force-started, the KEY warning light (red) remains illuminated and the push button start indicator light (amber) remains flashing.

### · (Automatic transaxle)

When the selector lever is in the neutral (N) position, the KEY indicator light (green) and the push button start indicator light (green) do not illuminate.

7. Press the push button start after both the KEY indicator light (green) in the instrument cluster and the push button start indicator light (green) illuminate.

### NOTE

- After starting the engine, the push button start indicator light (amber) turns off and the ignition switches to the ON position.

## Start/Stop Engine

- After pressing the push button start and before the engine starts, the operation sound of the fuel pump motor from near the fuel tank can be heard, however, this does not indicate a malfunction.

8. After starting the engine, let it idle for about ten seconds.

### NOTE

- Whether the engine is cold or warm, it should be started without the use of the accelerator.
- If the engine does not start the first time, refer to Starting a Flooded Engine under Emergency Starting. If the engine still does not start, have your vehicle inspected by an Authorised Mazda Repairer (page 7-17).
- **(Manual transaxle vehicle with i-stop function)**  
If the engine has stopped due to stalling, it can be restarted by depressing the clutch pedal within 3 seconds of the engine stopping. The engine cannot be restarted even if the clutch pedal is depressed under the following conditions:
  - The driver's door is open.
  - The driver's seat belt is unfastened.
  - The clutch pedal is not released completely after the engine stalled.
  - The clutch pedal is depressed with the engine not stopped completely.

### ▼ Engine Start Function When Key Battery is Dead

#### ⚠ CAUTION

When starting the engine by holding the transmitter over the push button start due to a dead key battery or a malfunctioning key, be careful not to allow the following, otherwise the signal from the key will not be received correctly and the engine may not start.

- Metal parts of other keys or metal objects touch the key.



- Spare keys or keys for other vehicles equipped with an immobilizer system touch or come near the key.



- Devices for electronic purchases, or security passage touch or come near the key.

If the engine cannot be started due to a dead key battery, the engine can be started using the following procedure:

1. Continue to depress the brake pedal firmly until the engine has completely started.




When Driving

## Start/Stop Engine

### 2. (Manual transaxle)

Continue to depress the clutch pedal firmly until the engine has completely started.

3. Make sure that the push button start indication light (green) flashes.
4. Touch the push button start using the backside of the key (as shown) while the push button start indicator light (green) flashes.



#### NOTE

When touching the push button start using the backside of the key as shown in the illustration, touch the push button start with the lock switch side of the key facing up.

5. Make sure that the push button start indicator light (green) turns on.
6. Press the push button start to start the engine.

#### NOTE

· The engine cannot be started unless the clutch pedal is fully depressed (manual transaxle) or the brake pedal is fully depressed (automatic transaxle).

- If there is a malfunction with the push button start function, the push button start indicator light (amber) flashes. In this case, the engine may start, however, have the vehicle checked at an expert repairer (we recommend an Authorised Mazda Repairer) as soon as possible.
- If the push button start indicator light (green) does not illuminate, perform the operation from the beginning again. If it does not illuminate, have the vehicle checked at an expert repairer (we recommend an Authorised Mazda Repairer).
- To switch the ignition position without starting the engine, perform the following operations after the push button start indicator light (green) turns on.
  1. Release the clutch pedal (manual transaxle) or brake pedal (automatic transaxle).
  2. Press the push button start to switch the ignition position. The ignition switches in the order of ACC, ON, and off each time the push button start is pressed. To switch the ignition position again, perform the operation from the beginning.

## Start/Stop Engine

### ▼ Emergency Operation for Starting the Engine

If the KEY warning light (red) illuminates, or the push button start indicator light (amber) flashes, this could indicate that the engine may not start using the usual starting method. Have your vehicle inspected at an expert repairer (we recommend an Authorised Mazda Repairer) as soon as possible. If this occurs, the engine can be force-started. Press and hold the push button start until the engine starts. Other procedures necessary for starting the engine such as having the key in the cabin, and depressing the clutch pedal (manual transaxle) or the brake pedal (automatic transaxle) are required.

### Turning the Engine Off

#### **WARNING**

#### ***Do not stop the engine while the vehicle is moving:***

*Stopping the engine while the vehicle is moving for any reason other than in an emergency is dangerous. Stopping the engine while the vehicle is moving will result in reduced braking ability due to the loss of power braking, which could cause an accident and serious injury.*

1. Stop the vehicle completely.
2. **(Manual transaxle)**  
Shift into neutral and set the parking brake.  
**(Automatic transaxle)**  
Shift the selector lever to the P position and set the parking brake.
3. Press the push button start to turn off the engine. The ignition position is off.

#### **CAUTION**

➤ *When leaving the vehicle, make sure the push button start is off.*

#### **NOTE**

- *The cooling fan in the engine compartment could turn on for a few minutes after the ignition is switched from ON to OFF, whether or not the A/C is on or off, to cool the engine compartment quickly.*

- When the push button start is pressed from ON to ACC or OFF, the KEY indicator light (green) may flash for approximately 30 seconds indicating that the remaining battery power of the key is low.  
Replace with a new battery before the key becomes unusable.  
Refer to Key Battery Replacement on page 6-25.
- **(Automatic transaxle)**  
If the engine is turned off while the selector lever is in a position other than P, the ignition switches to ACC.

#### ▼ Emergency Engine Stop

Continuously pressing the push button start or quickly pressing it any number of times while the engine is running or the vehicle is being driven will turn the engine off immediately. The ignition switches to ACC.


### i-stop\*

The i-stop function automatically stops the engine when the vehicle is stopped at a traffic light or stuck in traffic, and then restarts the engine automatically to resume driving. The system provides improved fuel economy, reduced exhaust gas emissions, and eliminates idling noise while the engine is stopped.

#### Engine idle stopping and restarting

##### NOTE

- The i-stop indicator light (green) turns on under the following conditions:
  - When engine idling is stopped.



- The i-stop indicator light (green) turns off when the engine is restarted.

#### Manual transaxle

1. Stop the vehicle by depressing the brake pedal and then the clutch pedal.
2. While depressing the clutch pedal, shift the shift lever to the neutral position. Engine idling stops after the clutch pedal is released.
3. The engine restarts automatically when you depress the clutch pedal or start to release it.

\*Some models. **4-11**

## Start/Stop Engine

---

### **NOTE**

*The engine restart timing varies depending on the brake pedal depression force.*

### **(SKYACTIV-D 1.5)**

The engine restarts automatically when the clutch pedal is depressed.

### **Automatic transaxle**

1. Engine idling stops when the brake pedal is depressed while the vehicle is driven (except for driving in the R or M position second gear fixed mode) and the vehicle is stopped.
2. The engine restarts automatically when the brake pedal is released with the selector lever in the D or M position (not in second gear fixed mode).
3. If the selector lever is in the N or P position, the engine does not restart when the brake pedal is released. The engine restarts when the brake pedal is depressed again or the selector lever is shifted to the D, M (not in second gear fixed mode) or the R position. (For the purposes of safety, always keep the brake pedal depressed when shifting the selector lever while engine idling is stopped.)

### **Operation conditions**

#### **When the system is operable**

Under the following conditions, the i-stop indicator light (green) turns on and engine idling stops.

- The engine is warmed up.
- The engine has been started and the vehicle is driven for a certain period.
- The engine is started with the bonnet closed.
- The battery is in good condition.
- All doors, liftgate/boot lid, and bonnet are closed.
- The driver's seat belt is fastened.
- The air conditioner is not operating with the airflow mode in the  position.

#### **• (Automatic air-conditioning)**

- The temperature setting dial of the air conditioner is in a position other than maximum heating or maximum cooling (A/C ON) position.
- The vehicle's interior temperature and the set temperature for the air conditioner are nearly the same.
- The i-stop warning light (amber) is not turned on/flashing.
- The keyless entry & push button start system functions are normal.
- The brake vacuum is sufficiently high.
- The steering wheel is not being operated.

#### **• (Manual transaxle)**

- The vehicle speed is 3 km/h (1.8 mph) or less.
- The shift lever is in the neutral position.
- The clutch pedal is not depressed.

#### **• (Automatic transaxle)**

- The vehicle is stopped.

## Start/Stop Engine

- The selector lever is in the D or M position (not in second gear fixed mode).
- The automatic transaxle fluid has warmed up sufficiently.
- The automatic transaxle fluid temperature is not abnormally high.
- The steering wheel is almost in the straight-ahead position (idling may not stop even with the steering wheel in the straight-ahead position if force is applied to the steering wheel. Release the force applied to the steering wheel to stop engine idling).
- The vehicle is stopped by depressing the brake pedal.
- Emergency braking is not applied.

### When the system is not operable

Engine idling does not stop in the following conditions:

- The vehicle is stopped but the engine is kept idling.
- The air conditioner is operating with the airflow mode in the  position.
- **(Automatic air-conditioning)**
  - The temperature setting dial of the air conditioner is in the maximum heating or maximum cooling (A/C ON) position.
  - There is a large difference between the cabin temperature and the set temperature of the air conditioner.
- The ambient temperature is extremely high or low.
- The atmospheric pressure is low (when driving at high altitudes).
- **(Automatic transaxle)**
  - The vehicle is stopped on a steep incline.

- The steering wheel is not in the straight-ahead position while the vehicle is stopped.

### NOTE

***Under the following conditions, a period of time is required to stop engine idling***

- The battery power is depleted for some reasons such as the vehicle has not been driven for a long period.
- The ambient temperature is high or low.
- After the battery terminals are disconnected for some reasons such as for battery replacement.

### Engine does not restart

*If the following operations are performed while the idling is stopped, the engine will not restart for safety reasons. In such cases, start the engine using the normal method.*

#### • (Manual transaxle)

*With the shift lever in a position other than neutral, the driver's seat belt is unfastened and the driver's door is opened.*

#### • (Automatic transaxle)

*With the selector lever in the D or M (not in second gear fixed mode), the driver's seat belt is unfastened and the driver's door is opened.*

***Engine-stop period is short or time until next engine idle stop is long***

- The ambient temperature is high or low.
- The battery power is depleted.
- Power consumption by the vehicle's electrical parts is high.

## Start/Stop Engine

---

### **Engine restarts automatically while engine idling is stopped**

*Under the following conditions, the engine restarts automatically.*

- The i-stop OFF switch is pressed until the beep sounds.
- The air conditioner is operated with the airflow mode in the  position.
- **(Automatic air-conditioning)**
  - The temperature setting dial of the air conditioner is in the maximum heating or maximum cooling (A/C ON) position.
  - The cabin temperature is largely different from the set temperature of the air conditioner.
- The brakes are released slightly on a slope and the vehicle begins to move.
- Two minutes have elapsed since the idling was stopped.
- The battery power is depleted.
- **(Manual transaxle)**

*With the shift lever in the neutral position, the driver's seat belt is unfastened, the driver's door is opened, or the bonnet is opened.*
- **(Automatic transaxle)**
  - The accelerator pedal is depressed with the selector lever in the D or M (not in second gear fixed mode) position.
  - The selector lever is shifted to the R position.
  - The selector lever is shifted from N or P position to D or M (not in second gear fixed mode) position.
  - The steering wheel is operated with the selector lever in the D or M (not in second gear fixed mode) position.

- The selector lever is in the M position and the second gear fixed mode is selected.
- With the selector lever in the P or N position, or the D/M range, the driver's seat belt is unfastened, the driver's door is opened, or the bonnet is opened.

### **Selector lever is operated while engine idling is stopped (automatic transaxle)**

*If the selector lever is shifted from D or M (not in second gear fixed mode) position to N or P position while engine idling is stopped, the engine does not restart even when the brake pedal is released. The engine will restart if the brake pedal is depressed again or the selector lever is shifted to the D, M (not in second gear fixed mode), or R position. (For the purposes of safety, always keep the brake pedal depressed when shifting the selector lever while engine idling is stopped.)*

*If the selector lever is shifted from the D or M (not in second gear fixed mode) to the N or P position, and the driver's seat belt is unfastened and the driver's door is opened, the engine restarts.*

### **Battery terminals are disconnected**

*Engine idling may not stop right after the battery terminals are disconnected. In addition, if the battery is replaced, the i-stop functions must be verified. Consult an expert repairer (we recommend an Authorised Mazda Repairer).*

▼ **i-stop Warning Light (Amber)/i-stop Indicator Light (Green)**

## i-stop

To ensure safe and comfortable use of the vehicle, the i-stop system constantly monitors the driver's operations, the vehicle's interior and exterior environment, and the operational status of the vehicle, and uses the i-stop warning light (amber) and i-stop indicator light (green) to inform the driver of various cautions and warnings.

**NOTE**

*On vehicles equipped with the centre display, the i-stop operation status is displayed in the fuel monitor control status display.*

*Refer to Control Status Display on page 4-70.*

**i-stop warning light (amber)**

**When the light is turned on**

- The light turns on when the ignition is switched ON and turns off when the engine is started.
- The light turns on when the i-stop OFF switch is pressed and the system is turned off.
- The light turns on if the following operations are performed while engine idling is stopped. In such cases, the engine does not restart automatically to ensure safety. Start the engine using the normal method.
  - The bonnet is opened.
  - **(Manual transaxle)**  
With the shift lever in a position other than neutral, the driver's seat belt is unfastened and the driver's door is opened.
  - **(Automatic transaxle)**  
With the selector lever in the D or M (not in second gear fixed mode) position, the driver's seat belt is unfastened and the driver's door is opened.

**NOTE**

*A problem in the system may be indicated under the following conditions. Have your vehicle inspected at an expert repairer (we recommend an Authorised Mazda Repairer).*

- *The light does not turn on when the ignition is switched ON.*
- *The light continues to remain on even though the i-stop OFF switch has been pressed while the engine is running.*

**When the light is flashing**

The light continues to flash if the system has a malfunction. Have your vehicle inspected at an expert repairer (we recommend an Authorised Mazda Repairer).

When Driving

## Start/Stop Engine


---

### i-stop indicator light (green)

#### When the light is turned on

- The light turns on while engine idling is stopped and turns off when the engine is restarted.

#### ▼ i-stop OFF Switch



By pressing the switch until a beep sounds, the i-stop function is turned off and the i-stop warning light (amber) in the instrument cluster turns on. By pressing the switch again until the beep sounds, the i-stop function becomes operational and the i-stop warning light (amber) turns off.

#### **NOTE**

*If the engine is stopped with the i-stop function cancelled, the i-stop function becomes operational when the engine is started the next time.*




▼ **Vehicle Roll Prevention Function (Automatic transaxle)**


Vehicles with the i-stop function are equipped with a vehicle roll prevention function. This function prevents the vehicle from rolling, such as when releasing the brake pedal while on a slope under the following conditions:

- While engine idling is stopped (prevents the vehicle from rolling back)
  - When starting from a stop (prevents the vehicle's sudden movement due to vehicle creep)
- When the brake pedal is released, the braking force is maintained automatically depending on the grade of the road.


① **Release foot from brake pedal**




② **Vehicle brake force maintained**



③ **Engine restarted**



④ **Acceleration**



**⚠ WARNING**

**Do not rely completely on the vehicle roll prevention function.**

- The vehicle roll prevention function is a supplementary function which operates for a maximum of 4 seconds after releasing the brake pedal and accelerating the vehicle from an engine idling stop condition. Over reliance on the system may result in an unexpected accident if the vehicle were to suddenly accelerate. Before starting to drive the vehicle, always confirm the safety of the surroundings and operate the selector lever, brake pedal, and accelerator pedal appropriately. Note that the vehicle may move suddenly depending on the grade of the road, the vehicle's load, or if it is towing something.

When Driving

## Start/Stop Engine

---

- *Note that the vehicle may move suddenly after the vehicle roll prevention function is released while the vehicle is under the following conditions:*
  - *The selector lever is in the N position.*
  - *If the selector lever is shifted to the N position and the brake pedal is released while the i-stop function is operating, the brake force is gradually released. To accelerate the vehicle, release the brake pedal after the engine restarts and shift the selector lever to a position other than the N position.*


### **NOTE**

- *When the vehicle is stopped on a steep grade, the vehicle roll prevention function does not operate because engine idling is not stopped.*
- *The brake pedal response may change, sound may occur from the brakes, or the brake pedal could vibrate from the operation of the vehicle roll prevention function. However, this does not indicate a malfunction.*


## Instrument Cluster and Display

### Meters and Gauges


**Instrument Cluster**  
**Type A**  
**(Digital Speed Meter Type)**



**Type B**  
**(Analog Speed Meter Type)**



**Steering Switch**



- ① Speedometer..... page 4-20
- ② Odometer, Trip Meter and Trip Meter Selector..... page 4-20
- ③ Tachometer..... page 4-21
- ④ Fuel Gauge..... page 4-21
- ⑤ Instrument Panel Illumination..... page 4-22
- ⑥ Outside Temperature Display..... page 4-23
- ⑦ Cruise Control Set Vehicle Speed Display..... page 4-23
- ⑧ Active Driving Display..... page 4-26
- ⑨ Trip Computer and INFO Switch..... page 4-23

## Instrument Cluster and Display

### ▼ Speedometer

The speedometer indicates the speed of the vehicle.


#### **NOTE**

##### **(Analog speedometer type)**

If a few seconds have elapsed after switching the ignition off, the needle may deviate. However, this does not indicate a problem.

### ▼ Odometer, Trip Meter and Trip Meter Selector

The display mode can be changed from odometer to trip meter A to trip meter B and then back to odometer by pressing the selector while one of them is displayed. The selected mode will be displayed.



#### **NOTE**

When the ignition is switched to ACC or off, the odometer or trip meters cannot be displayed, however, pressing the selector can inadvertently switch the trip meters or reset them during an approximate ten-minute period in the following cases:

- After the ignition is switched to off from ON.
- After the driver's door is opened.

### Odometer

The odometer records the total distance the vehicle has been driven.

### Trip meter

The trip meter can record the total distance of two trips. One is recorded in trip meter A, and the other is recorded in trip meter B.

For instance, trip meter A can record the distance from the point of origin, and trip meter B can record the distance from where the fuel tank is filled.

When trip meter A is selected, pressing the selector again within one second will change to trip meter B mode.

When trip meter A is selected, TRIP A will be displayed. When trip meter B is selected, TRIP B will be displayed.

The trip meter records the total distance the vehicle is driven until the meter is again reset. Return it to "0.0" by depressing and holding the selector for one second or more. Use this meter to measure trip distances and to compute fuel consumption.

## Instrument Cluster and Display

### NOTE

#### · (Vehicles with type B audio)

If the fuel economy data is reset using the fuel economy monitor, or trip A is reset using the trip meter when the function which synchronizes the fuel economy monitor and the trip meter is on, the fuel economy data and trip A are reset simultaneously.

Refer to Fuel Economy Monitor on page 4-69.

- Only the trip meters record tenths of kilometres (miles).
- The trip record will be erased when:
  - The power supply is interrupted (blown fuse or the battery is disconnected).
  - The vehicle is driven over 9999.9 km (mile).

### ▼ Tachometer


The tachometer shows engine speed in thousands of revolutions per minute (rpm).




Do not run the engine with the tachometer needle in the RED ZONE.

This may cause severe engine damage.

#### Type A



#### Type B



### NOTE

When the tachometer needle enters the STRIPED ZONE, this indicates to the driver that the gears should be shifted before entering the RED ZONE.

### ▼ Fuel Gauge

The fuel gauge shows approximately how much fuel is remaining in the tank when the ignition is switched ON. We recommend keeping the tank over 1/4 full.

Full



1/4 Full



Empty



If the low fuel warning light illuminates or the fuel level is very low, refuel as soon as possible.

## Instrument Cluster and Display

If inconsistency in engine performance or stalling occurs due to low fuel level conditions, refuel the vehicle as soon as possible and add at least 10 L (2.7 US gal, 2.2 Imp gal) of fuel.

Refer to Taking Action on page 7-31.

### NOTE

- After refuelling, it may require some time for the indicator to stabilize. In addition, the indicator may deviate while driving on a slope or curve since the fuel moves in the tank.
- The display indicating a quarter or less remaining fuel has more segments to show the remaining fuel level in greater detail.
- The direction of the arrow (➔) indicates that the fuel-filler flap is on the left side of the vehicle.

### ▼ Instrument Panel Illumination

#### (Without auto-light control)

When the position lights are turned on with the ignition switched ON, the brightness of the instrument panel illumination is dimmed.

#### (With auto-light control)

When the position lights are turned on with the ignition switched ON, the brightness of the instrument panel illumination is dimmed. However, when the light sensor detects that the surrounding area is bright such as when the position lights are turned on in the daytime, the instrument panel illumination does not dim.

### NOTE

#### • (With auto-light control)


*When the ignition is switched ON in the early evening or at dusk, the instrument panel illumination is dimmed for several seconds until the light sensor detects the brightness of the surrounding area, however, the dimmer may cancel after the brightness is detected.*

- When the position lights are turned on, the position lights indicator light in the instrument cluster turns on.

*Refer to Headlights on page 4-47.*

The brightness of the instrument cluster and instrument panel illuminations can be adjusted by rotating the knob.

- The brightness decreases by rotating the knob to the left. A beep sound will be heard when the knob has been rotated to the maximum dim position.
- The brightness increases by rotating the knob to the right.



## Instrument Cluster and Display

### **Function for cancelling illumination dimmer**


The illumination dimmer can be cancelled by rotating the instrument panel illumination knob to the right until a beep sound is heard while the instrument cluster is dimmed with the ignition switched ON. If the instrument cluster's visibility is reduced due to glare from surrounding brightness, cancel the illumination dimmer.

#### **NOTE**

- When the illumination dimmer is cancelled, the instrument cluster cannot be dimmed even if the position lights are turned on.
- When the illumination dimmer is cancelled, the screen in the centre display switches to constant display of the daytime screen.

### **▼ Outside Temperature Display**

When the ignition is switched ON, the outside temperature is displayed.




#### **NOTE**

- Under the following conditions, the outside temperature display may differ from the actual outside temperature depending on the surroundings and vehicle conditions:
  - Significantly cold or hot temperatures.
  - Sudden changes in outside temperature.
  - The vehicle is parked.
  - The vehicle is driven at low speeds.

### **▼ Cruise Control Set Vehicle Speed Display\***

The vehicle speed preset using the cruise control is displayed.



### **▼ Trip Computer and INFO Switch**

The following information can be selected by pressing the INFO switch with the ignition switched ON.

- Distance-to-empty mode
- Average fuel economy mode
- Current fuel economy mode
- Average vehicle speed
- Vehicle speed alarm\*

If you have any problems with your trip computer, consult an expert repairer (we recommend an Authorised Mazda Repairer).

\*Some models.

## Instrument Cluster and Display

### Distance-to-empty mode

This mode displays the approximate distance you can travel on the remaining fuel based on the fuel economy.

The distance-to-empty will be calculated and displayed every second.

RANGE  
**160** km

#### **NOTE**

- *Even though the distance-to-empty display may indicate a sufficient amount of remaining driving distance before refuelling is required, refuel as soon as possible if the fuel level is very low or the low fuel warning light illuminates.*
- *The display may not change unless you add more than approximately 9 L (2.3 US gal, 1.9 Imp gal) of fuel.*
- *The distance-to-empty is the approximate remaining distance the vehicle can be driven until all the graduation marks in the fuel gauge (indicating the remaining fuel supply) disappear.*
- *If there is no past fuel economy information such as after first purchasing your vehicle or the information is deleted when the battery leads are disconnected, the actual distance-to empty/range may differ from the amount indicated.*

### Average fuel economy mode

This mode displays the average fuel economy by calculating the total travelled distance and the total fuel consumption since the vehicle was purchased or the past data was reset. The average fuel economy is calculated and displayed every minute.

AVG  
**10.5** L/100km

To clear the data being displayed, press the INFO switch for more than 1.5 seconds or longer.

After resetting the data, - - - L/100 km (- - - mpg) is displayed for one minute before the fuel economy is recalculated and displayed.

#### **NOTE**

##### **(Vehicles with type B audio)**

*If TRIP A is reset using the trip meter when the function which synchronizes (resets) the fuel economy monitor and the trip meter (TRIP A) is on, the displayed past data is reset.*



## Instrument Cluster and Display

### Current fuel economy mode

This mode displays the current fuel economy by calculating the amount of fuel consumption and the distance travelled.

Current fuel economy will be calculated and displayed every 2 seconds.

CURRENT  
7.5 L/100km

When you've slowed to about 5 km/h (3 mph), - - - L/100 km (- - - mpg) will be displayed.

### Average vehicle speed mode

This mode displays the average vehicle speed by calculating the distance and the time travelled since connecting the battery or resetting the data.

Average vehicle speed will be calculated and displayed every 10 seconds.

AVG  
65 km/h

To clear the data being displayed, press the INFO switch for more than 1.5 seconds.

After pressing the INFO switch, - - - km/h (- - - mph) will be displayed for about 1 minute before the vehicle speed is recalculated and displayed.

### Vehicle speed alarm mode\*

In this mode, the current setting for the vehicle speed alarm is displayed. You can change the vehicle speed setting at which the warning is triggered.

#### **NOTE**

*The vehicle speed alarm display is activated at the same time the beep sound is heard. The set vehicle speed flashes several times.*

 100 km/h

The vehicle speed alarm can be set using the centre display.


#### **NOTE**

- Always set the vehicle speed according to the laws and regulations of the country/city in which the vehicle is driven. In addition, always verify the speed of the vehicle using the speedometer.
- The vehicle speed alarm function can be set between 30 and 250 km/h (20 and 150 mph).

When Driving

## Instrument Cluster and Display

### Active Driving Display\*



#### WARNING

**Always adjust the display brightness and position with the vehicle stopped:**

Adjusting the display brightness and position while driving the vehicle is dangerous as doing so could distract your attention from the road ahead and lead to an accident.

#### CAUTION

- Do not try to adjust the angle or open/close the active driving display manually. Fingerprints on the display will make it difficult to view and using excessive force when operating it could cause damage.
- Do not place objects in the vicinity of the active driving display. The active driving display may not operate or any interference with its operation could cause damage.
- Do not place beverages near the active driving display. If water or other liquids are splashed on the active driving display, it could cause damage.
- Do not place objects above the active driving display or apply stickers to the dust-proof sheet/optical receiver as they will cause interference.
- A sensor is integrated to control the display's luminosity. If the optical receiver is covered, the display's luminosity will lower making the display difficult to view.
- Do not allow intense light to hit the optical receiver. Otherwise, it could cause damage.

#### NOTE

- Wearing polarized sunglasses will reduce the visibility of the active driving display due to the characteristics of the display.
- If the battery has been removed and re-installed or the battery voltage is low, the adjusted position may deviate.

## Instrument Cluster and Display

---

- *The display may be difficult to view or temporarily affected by weather conditions such as rain, snow, light, and temperature.*
- *If the audio system is removed, the active driving display cannot be operated.*

The active driving display indicates the following information:

- Blind Spot Monitoring (BSM) Operation Conditions and Warnings  
Refer to Blind Spot Monitoring (BSM) on page 4-89.
- Distance Recognition Support System (DRSS) Warnings  
Refer to Distance Recognition Support System (DRSS) on page 4-87.
- Traffic Sign Recognition System (TSR) traffic signs and Warnings  
Refer to Traffic Sign Recognition System (TSR) on page 4-95.
- Mazda Radar Cruise Control (MRCC) Operation Conditions and Warnings  
Refer to Mazda Radar Cruise Control (MRCC) on page 4-107.
- Lane Departure Warning System (LDWS) Warnings  
Refer to Lane Departure Warning System (LDWS) on page 4-82.
- Lane-keep Assist System (LAS) & Lane Departure Warning System (LDWS) Operation Conditions and Warnings  
Refer to Lane-keep Assist System (LAS) & Lane Departure Warning System (LDWS) on page 4-117.
- Advanced Smart City Brake Support (Advanced SCBS) Warnings  
Refer to Advanced Smart City Brake Support (Advanced SCBS) on page 4-136.
- Smart City Brake Support [Reverse] (SCBS R) Operation Conditions  
Refer to Smart City Brake Support [Reverse] (SCBS R) on page 4-140.
- Smart Brake Support (SBS) Operation Conditions and Warnings  
Refer to Smart Brake Support (SBS) on page 4-144.
- Adjustable Speed Limiter (ASL) Operation Conditions and Warnings  
Refer to Adjustable Speed Limiter (ASL) on page 4-129.
- Driver Attention Alert (DAA) Warnings  
Refer to Driver Attention Alert (DAA) on page 4-101.
- Cruise Control Operation Conditions  
Refer to Cruise Control on page 4-186.
- Navigation Guidance (vehicles with navigation system)
- Speed limit indicator (vehicles with navigation system)
- Vehicle Speed

When Driving

## Instrument Cluster and Display

---

Each setting/adjustment for the active driving display can be performed on the centre display.

1. Select the  icon on the home screen and display the Settings screen.
2. Select the AD-Disp tab.
3. Select the desired item and perform the setting/adjustment.
  - Method for adjusting screen brightness (automatically/manually)
  - Screen brightness initial settings (automatic adjustment is selected)
  - Screen brightness adjustment (manual adjustment is selected)
  - Display position of active driving display (display height)
  - Active driving display ON/OFF (indication)
  - Navigation guidance ON/OFF
  - Reset settings (reset)

### **NOTE**

- The street name may not be displayed depending on the market and region.

## Instrument Cluster and Display


### Warning/Indicator Lights

Instrument Cluster varies depending on model and specifications.

#### Instrument Cluster


##### Type A

(Digital Speed Meter Type)




##### Type B

(Analog Speed Meter Type)



Centre of Instrument panel



Warning/Indicator lights will appear in any of the highlighted areas

#### ▼ Warning Lights


These lights turn on or flash to notify the user of the system operation status or a system malfunction.

| Signal                                                                              | Warning                         | Page                                                    |
|-------------------------------------------------------------------------------------|---------------------------------|---------------------------------------------------------|
|  | Brake System Warning Light*1*2  | 7-23                                                    |
|  | ABS Warning Light*1             | Electronic Brake Force Distribution System Warning 7-23 |
|                                                                                     |                                 | ABS warning 7-25                                        |
|  | Charging System Warning Light*1 | 7-23                                                    |

## Instrument Cluster and Display

| Signal                                                                                         | Warning                                                                                           | Page                       |
|------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------|----------------------------|
|               | Engine Oil Warning Light* <sup>1</sup>                                                            | 7-23                       |
| <br>(Red)     | High Engine Coolant Temperature Warning Light* <sup>1</sup>                                       | 7-23                       |
|               | Power Steering Malfunction Indicator Light* <sup>1</sup>                                          | 7-23                       |
|               | Master Warning Light* <sup>1</sup>                                                                | 7-25                       |
|               | Check Engine Light* <sup>1</sup>                                                                  | 7-25                       |
| <b>i-stop</b><br>(Amber)                                                                       | *i-stop Warning Light* <sup>1</sup>                                                               | 7-25                       |
| <b>AT</b>                                                                                      | *Automatic Transaxle Warning Light* <sup>1</sup>                                                  | 7-25                       |
|               | Air Bag/Seat Belt Pretensioner System Warning Light* <sup>1</sup>                                 | 7-25                       |
|              | Tyre Pressure Monitoring System Warning Light* <sup>1</sup>                                       | Flashing<br>7-25           |
|                                                                                                |                                                                                                   | Turns on<br>7-31           |
| <br>(Red)   | KEY Warning Light* <sup>1</sup>                                                                   | Malfunction<br>7-25        |
|                                                                                                |                                                                                                   | Except malfunction<br>7-31 |
| <br>(Amber) | *High Beam Control System (HBC) Warning Light* <sup>1</sup>                                       | 7-25                       |
| <br>(Amber) | *Adaptive LED Headlights (ALH) Warning Light* <sup>1</sup>                                        | 7-25                       |
|             | *Lane Departure Warning System (LDWS) Warning Light* <sup>1</sup>                                 | Flashing<br>4-85           |
|                                                                                                |                                                                                                   | Turns on<br>7-25           |
|             | *Lane-keep Assist System (LAS) & Lane Departure Warning System (LDWS) Warning Light* <sup>1</sup> | Flashing<br>4-127          |
|                                                                                                |                                                                                                   | Turns on<br>7-25           |
|             | *Lane-keep Assist System(LAS) Hands off Warning Light* <sup>1</sup>                               | 4-120                      |

## Instrument Cluster and Display

| Signal                                                                                                 | Warning                                                                              | Page |
|--------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------|------|
| <br>(Amber)           | *Mazda Radar Cruise Control (MRCC) Warning Light                                     | 7-25 |
|                       | LED Headlight Warning Light* <sup>1</sup>                                            | 7-25 |
|                       | Low Fuel Warning Light                                                               | 7-31 |
| <br>PASSENGER         | Seat Belt Warning Light (Front seat)                                                 | 7-31 |
| <b>REAR</b> <br>(Red) | Seat Belt Warning Light (Rear seat)                                                  | 7-31 |
|                       | Door-Ajar Warning Light                                                              | 7-31 |
| <br>(Amber)           | *Smart Brake Support/Smart City Brake Support (SBS/SCBS) Warning Light* <sup>1</sup> | 7-31 |

\*1 The light turns on when the ignition is switched on for an operation check, and turns off a few seconds later or when the engine is started. If the light does not turn on or remains turned on, have the vehicle inspected at an expert repairer (we recommend an Authorised Mazda Repairer).

\*2 The light turns on continuously when the parking brake is applied.

### ▼ Indicator Lights

These lights turn on or flash to notify the user of the system operation status or a system malfunction.

| Signal                                                                                                     | Indicator Lights                               | Page |
|------------------------------------------------------------------------------------------------------------|------------------------------------------------|------|
| <b>REAR</b> <br>(Green) | Seat Belt Indicator Light (Rear seat)          | 2-21 |
| <br>(Green)             | KEY Indicator Light                            | 4-5  |
|                         | Security Indicator Light* <sup>1</sup>         | 3-30 |
|                         | Wrench Indicator Light* <sup>1</sup>           | 4-35 |
| <br>(Blue)              | Low Engine Coolant Temperature Indicator Light | 4-35 |
| <b>i-stop</b><br>(Green)                                                                                   | *i-stop Indicator Light                        | 4-15 |

\*Some models. **4-31**

## Instrument Cluster and Display

| Signal                                                                              | Indicator Lights                                    | Page                                    |
|-------------------------------------------------------------------------------------|-----------------------------------------------------|-----------------------------------------|
|    | *Vehicle Speed Alarm Indication                     | 4-23                                    |
|    | Shift Position Indication                           | 4-41                                    |
|    | Lights-On Indicator Light                           | 4-47                                    |
|    | Headlight High-Beam Indicator Light                 | Headlight High-Low Beam<br>4-50         |
|                                                                                     |                                                     | Flashing the Headlights<br>4-50         |
|    | Direction Indicator/Hazard Warning Indicator Lights | Turn and Lane-Change Signals<br>4-52    |
|                                                                                     |                                                     | Hazard Warning Flasher<br>4-58          |
|  | TCS/DSC Indicator Light* <sup>1</sup>               | Traction Control System (TCS)<br>4-66   |
|                                                                                     |                                                     | Dynamic Stability Control (DSC)<br>4-67 |
|                                                                                     |                                                     | Turns on<br>7-25                        |



## Instrument Cluster and Display

| Signal                                                                                         | Indicator Lights                                                                      | Page                                                                  |
|------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------|-----------------------------------------------------------------------|
|               | *DSC OFF Indicator Light* <sup>1</sup>                                                | 4-68                                                                  |
| SPORT                                                                                          | *Select Mode Indicator Light                                                          | 4-72                                                                  |
| <br>(Green)   | *High Beam Control System (HBC) Indicator Light                                       | 4-78                                                                  |
| <br>(Green)   | *Adaptive LED Headlights (ALH) Indicator Light                                        | 4-81                                                                  |
|               | *Blind Spot Monitoring (BSM) OFF Indicator Light* <sup>1</sup>                        | Malfunction<br>7-25                                                   |
|                                                                                                |                                                                                       | Except malfunction<br>4-94                                            |
|               | *Lane-keep Assist System (LAS) & Lane Departure Warning System (LDWS) Indicator Light | 4-120                                                                 |
|              | *Lane Departure Warning System (LDWS) OFF Indicator Light* <sup>1</sup>               | 4-85                                                                  |
|             | *Driver Attention Alert (DAA) Indication                                              | 4-102                                                                 |
| <br>(Green) | *Mazda Radar Cruise Control (MRCC) Indicator Light                                    | 4-110                                                                 |
| <br>(Red)   | *Smart Brake Support/Smart City Brake Support (SBS/SCBS) Indicator Light              | Advanced Smart<br>City Brake Sup-<br>port (Advanced<br>SCBS)<br>4-138 |
|                                                                                                |                                                                                       | Smart City<br>Brake Support<br>[Reverse]<br>(SCBS R)<br>4-143         |
|                                                                                                |                                                                                       | Smart Brake<br>Support (SBS)<br>4-146                                 |

\*Some models. **4-33**

## Instrument Cluster and Display

| Signal                                                                                               | Indicator Lights                                                             | Page                                                       |
|------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------|------------------------------------------------------------|
|                     | *Smart Brake Support/Smart City Brake Support (SBS/SCBS) OFF Indicator Light | Advanced Smart City Brake Support (Advanced SCBS)<br>4-138 |
|                                                                                                      |                                                                              | Smart City Brake Support [Reverse] (SCBS R)<br>4-143       |
|                                                                                                      |                                                                              | Smart Brake Support (SBS)<br>4-146                         |
| <br>(White)         | *Adjustable Speed Limiter (ASL) Main Indication                              | 4-131                                                      |
| <br>(Green)         | *Adjustable Speed Limiter (ASL) Set Indication/Indicator Light               | 4-131                                                      |
| <br>(White)        | *Cruise Main Indication                                                      | 4-187                                                      |
| <br>(White/Green) | *Cruise Set Indication/Indicator Light                                       | 4-187                                                      |

\*1 The light turns on when the ignition is switched on for an operation check, and turns off a few seconds later or when the engine is started. If the light does not turn on or remains turned on, have the vehicle inspected at an expert repairer (we recommend an Authorised Mazda Repairer).

## Instrument Cluster and Display

### ▼ Wrench Indicator Light



When the ignition is switched ON, the wrench indicator light turns on and then turns off after a few seconds.

The wrench indicator light turns on when the preset maintenance period arrives. Verify the content and perform maintenance.

Refer to Maintenance Monitor on page 6-8.

### ▼ Low Engine Coolant Temperature Indicator Light (Blue)




The light illuminates continuously when the engine coolant temperature is low and turns off after the engine is warm.

If the low engine coolant temperature indicator light remains illuminated after the engine has been sufficiently warmed up, the temperature sensor could have a malfunction. Consult an expert repairer (we recommend an Authorised Mazda Repairer).

## Manual Transaxle Operation


### Manual Transaxle Shift Pattern



The shift pattern of the transaxle is conventional, as shown.

Depress the clutch pedal all the way down while shifting; then release it slowly.

Your vehicle is equipped with a device to prevent shifting to R (reverse) by mistake. Push the shift lever downward and shift to R.



### **WARNING**

***Do not use sudden engine braking on slippery road surfaces or at high speeds:***

*Shifting down while driving on wet, snowy, or frozen roads, or while driving at high speeds causes sudden engine braking, which is dangerous. The sudden change in tyre speed could cause the tyres to skid. This could lead to loss of vehicle control and an accident.*

***Always leave the shift lever in 1 or R position and set the parking brake when leaving the vehicle unattended:***

*Otherwise the vehicle could move and cause an accident.*

### **CAUTION**

- *Keep your foot off the clutch pedal except when shifting gears. Also, do not use the clutch to hold the vehicle on an upgrade. Riding the clutch will cause needless clutch wear and damage.*
- *Do not apply any excessive lateral force to the shift lever when changing from 5th to 4th gear. This could lead to the accidental selection of 2nd gear, which could result in damage to the transaxle.*
- *Make sure the vehicle comes to a complete stop before shifting to R. Shifting to R while the vehicle is still moving may damage the transaxle.*

### **NOTE**

- *If shifting to R is difficult, shift back into neutral, release the clutch pedal, and try again.*

## Manual Transaxle Operation

### · (With i-stop function)

*If the engine has stopped due to stalling, it can be restarted by depressing the clutch pedal within 3 seconds of the engine stopping.*

*The engine cannot be restarted even if the clutch pedal is depressed under the following conditions:*

- The driver's door is open.
- The driver's seat belt is unfastened.
- The clutch pedal is not released completely after the engine stalled.
- The clutch pedal is depressed with the engine not stopped completely.


### · (With parking sensor system)

*When the shift lever is shifted to the R position with the ignition switched ON, the parking sensor system is activated and a beep sound is heard.*

*Refer to Parking Sensor System on page 4-202.*

### ▼ Gear Shift Indicator (GSI)

The Gear Shift Indicator (GSI) supports you to obtain optimum fuel economy and smooth driving. It displays the selected gear position in the instrument cluster as well as notifies the driver to change to the most suitable gear position corresponding to the actual driving condition.



| Indication    | Condition                                                       |
|---------------|-----------------------------------------------------------------|
| Numeral       | The selected gear position is displayed.                        |
| ➡ and numeral | Shift up or down to the indicated gear position is recommended. |

### ⚠ CAUTION



*Do not rely solely on the shift-up/shift-down recommendations by indications. The actual driving situation might require shift operations different from indication. To avoid the risk of accidents, the road and traffic conditions have to be judged correctly by the driver before shifting.*

### NOTE

*The Gear Shift Indicator (GSI) turns off when the following operations are performed.*

- The vehicle is stopped.
- The vehicle is put in neutral.
- The vehicle is driven in reverse.
- The clutch is not fully engaged when accelerating from a stop.
- The clutch pedal remains depressed for 2 seconds or longer while driving.

### Automatic Transaxle Controls



#### Various Lockouts:

-  Indicates that you must depress the brake pedal and hold in the lock-release button to shift (The ignition must be switched ON).
-  Indicates the selector lever can be shifted freely into any position.
-  Indicates that you must hold in the lock-release button to shift.

#### NOTE

*The Sport AT has an option that is not included in the traditional automatic transaxle that gives the driver the option of selecting each gear instead of leaving it to the transaxle to shift gears. Even if you intend to use the automatic transaxle functions as a traditional automatic, you should also be aware that you can inadvertently shift into manual shift mode and an inappropriate gear may be retained as the vehicle speed increases. If you notice the engine speed going higher or hear the engine racing, confirm you have not accidentally slipped into manual shift mode (page 4-42).*

## Shift-Lock System

The shift-lock system prevents shifting out of P unless the brake pedal is depressed.

To shift from P:

1. Depress and hold the brake pedal.
2. Start the engine.
3. Press and hold the lock-release button.
4. Move the selector lever.


### NOTE

- When the ignition is switched to ACC or the ignition is switched off, the selector lever cannot be shifted from P position.
- The ignition cannot be switched to OFF if the selector lever is not in P position.

### ▼ Shift-Lock Override

If the selector lever will not move from P using the proper shift procedure, continue to hold down the brake pedal.

1. Remove the shift-lock override cover using a cloth-wrapped flat head screwdriver.
2. Insert a screwdriver and push it down.



3. Press and hold the lock-release button.
4. Move the selector lever.

Take the vehicle to an expert repairer (we recommend an Authorised Mazda Repairer) to have the system checked.

## Automatic Transaxle

### Transaxle Ranges

- The shift position indication in the instrument cluster illuminates. Refer to Warning/Indicator Lights on page 4-29.
- The selector lever must be in P or N position to operate the starter.

#### P (Park)

P locks the transaxle and prevents the front wheels from rotating.



#### **WARNING**

**Always set the selector lever to P position and set the parking brake:**

Only setting the selector lever to the P position without using the parking brake to hold the vehicle is dangerous. If P fails to hold, the vehicle could move and cause an accident.



#### **CAUTION**

- Shifting into P, N or R while the vehicle is moving can damage your transaxle.
- Shifting into a driving gear or reverse when the engine is running faster than idle can damage the transaxle.

#### R (Reverse)

In position R, the vehicle moves only backward. You must be at a complete stop before shifting to or from R, except under rare circumstances as explained in Rocking the Vehicle (page 3-33).

#### **NOTE**

**(With parking sensor system)**

When the selector lever is shifted to the R position with the ignition switched ON, the parking sensor system is activated and a beep sound is heard.

Refer to Parking Sensor System on page 4-202.

#### N (Neutral)

In N, the wheels and transaxle are not locked. The vehicle will roll freely even on the slightest incline unless the parking brake or brakes are on.



#### **WARNING**

**If the engine is running faster than idle, do not shift from N or P into a driving gear:**

It's dangerous to shift from N or P into a driving gear when the engine is running faster than idle. If this is done, the vehicle could move suddenly, causing an accident or serious injury.

**Do not shift into N when driving the vehicle:**

Shifting into N while driving is dangerous. Engine braking cannot be applied when decelerating which could lead to an accident or serious injury.



#### **CAUTION**

Do not shift into N when driving the vehicle. Doing so can cause transaxle damage.



## Automatic Transaxle

### **NOTE**

*Apply the parking brake or depress the brake pedal before moving the selector lever from N position to prevent the vehicle from moving unexpectedly.*

### **D (Drive)**

D is the normal driving position. From a stop, the transaxle will automatically shift through a 6-gear sequence.

### **M (Manual)**

M is the manual shift mode position. Gears can be shifted up or down by operating the selector lever. Refer to Manual Shift Mode on page 4-42.

### **▼ Shift Position Indication**



The selector position is indicated when the ignition is switched ON.

### **Gear position indication**

In manual shift mode, the “M” of the shift position indication illuminates and the numeral for the selected gear is displayed.

### **▼ Active Adaptive Shift (AAS)**


Active Adaptive Shift (AAS) automatically controls the transaxle shift points to best suit the road conditions and driver input. This improves driving feel. The transaxle may switch to AAS mode when driving up and down slopes, cornering, driving at high elevations, or depressing the accelerator pedal quickly while the selector lever is in the D position. Depending on the road and driving conditions/vehicle operations, gear shifting could be delayed or not occur, however, this does not indicate a problem because the AAS mode will maintain the optimum gear position.

## Automatic Transaxle

### Manual Shift Mode

The manual shift mode gives you the feel of driving a manual transaxle vehicle by allowing you to operate the selector lever manually. This allows you to control engine rpm and torque to the drive wheels much like a manual transaxle when more control is desired.

To change to manual shift mode, shift the lever from D to M.



#### NOTE

*Changing to manual shift mode while driving will not damage the transaxle.*

To return to automatic shift mode, shift the lever from M to D.

#### NOTE

- If you change to manual shift mode when the vehicle is stopped, the gear will shift to M1.
- If you change to manual shift mode without depressing the accelerator pedal when driving in D range, 5th gear/6th gear, the gear will shift to M4/M5.

#### ▼ Indicators


##### Manual shift mode indication

In manual shift mode, the “M” of the shift position indication in the instrument panel illuminates.


##### Gear position indication

The numeral for the selected gear illuminates.

##### Type A



##### Type B



#### NOTE

- If the gears cannot be shifted down when driving at higher speeds, the gear position indication will flash twice to signal that the gears cannot be shifted down (to protect the transaxle).

## Automatic Transaxle


- If the automatic transaxle fluid (ATF) temperature becomes too high, there is the possibility that the transaxle will switch to automatic shift mode, cancelling manual shift mode and turning off the gear position indication illumination. This is a normal function to protect the AT. After the ATF temperature has decreased, the gear position indication illumination turns back on and driving in manual shift mode is restored.

### ▼ Manually Shifting Up

You can shift gears up by operating the selector lever.

M1 → M2 → M3 → M4 → M5 → M6

To shift up to a higher gear, tap the selector lever back + once.



### NOTE

- When driving slowly, the gears may not shift up.

- Do not drive the vehicle with the tachometer needle in the RED ZONE while in manual shift mode. In addition, manual shift mode switches to automatic shift mode while the accelerator pedal is completely depressed.


This function is cancelled while the DSC is turned off. However, if the vehicle is continuously driven at a high rpm, the gears may automatically shift up to protect the engine.

### ▼ Manually Shifting Down

You can shift gears down by operating the selector lever.

M6 → M5 → M4 → M3 → M2 → M1

To shift down to a lower gear, tap the selector lever forward – once.



### ⚠ WARNING

#### **Do not use engine braking on slippery road surfaces or at high speeds:**

Shifting down while driving on wet, snowy, or frozen roads, or while driving at high speeds causes sudden engine braking, which is dangerous. The sudden change in tyre speed could cause the tyres to skid. This could lead to loss of vehicle control and an accident.

When Driving

## Automatic Transaxle

---

### **NOTE**

- When driving at high speeds, the gear may not shift down.
- During deceleration, the gear may automatically shift down depending on vehicle speed.
- When depressing the accelerator fully, the transaxle will shift to a lower gear, depending on vehicle speed. However, the gears do not kickdown while the DSC is turned off.

### **▼ Second Gear Fixed Mode**


When the selector lever is moved back + while the vehicle speed is about 10 km/h (6.2 mph) or less, the transaxle is set in the second gear fixed mode. The gear is fixed in second while in this mode for easier acceleration from a stop and driving on slippery roads such as snow-covered roads.

If the selector lever is moved back + or forward — while in the second gear fixed mode, the mode will be cancelled.

## When Driving Automatic Transaxle

### ▼ Shift Gear (Shifting) Speed Limit

For each gear position while in the manual mode, the speed limit is set as follows: When the selector lever is operated within the range of the speed limit, the gear is shifted.



#### Shift up

The gear does not shift up while the vehicle speed is lower than the speed limit.

#### Shift down

The gear does not shift down while the vehicle speed exceeds the speed limit.

If the vehicle speed exceeds the speed limit and the gear does not shift down, the gear position indication flashes 2 times to notify the driver that the gear cannot be shifted.

#### Kickdown

When the accelerator pedal is depressed fully while driving, the gear shifts down. However, the gears do not kickdown while the DSC is turned off.

#### **NOTE**

*The gear also shifts down using kickdown while in the second gear fixed mode.*

#### Auto-shift down

The gear shifts down automatically depending on the vehicle speed during deceleration.

#### **NOTE**

*If the vehicle comes to a stop while in the second gear fixed mode, the gear remains in second.*

### Driving Tips

#### **WARNING**

***Do not let the vehicle move in a direction opposite to the direction selected by the selector lever:***

*Do not let the vehicle move backward with the selector lever in a forward position, or do not let the vehicle move forward with the selector lever in the reverse position. Otherwise, the engine may stop, causing the loss of the power brake and power steering functions, and make it difficult to control the vehicle which could result in an accident.*

#### **Passing**

For extra power when passing another vehicle or climbing steep grades, depress the accelerator fully. The transaxle will shift to a lower gear, depending on vehicle speed.

#### **NOTE**

- The accelerator pedal may initially feel heavy as it is being depressed, then feel lighter as it is depressed further. This change in pedal force aids the engine control system in determining how much the accelerator pedal has been depressed for performing kickdown, and functions to control whether or not kickdown should be performed.*
- While the selector lever is in the M position and the DSC is turned off, manual shift mode does not switch to automatic shift mode even if the accelerator pedal is completely depressed. Operate the selector lever.*

#### **Climbing steep grades from a stop**

To climb a steep grade from a stopped position:

1. Depress the brake pedal.
2. Shift to D or M1, depending on the load weight and grade steepness.
3. Release the brake pedal while gradually accelerating.

#### **Descending steep grades**

When descending a steep grade, shift to lower gears, depending on load weight and grade steepness. Descend slowly, using the brakes only occasionally to prevent them from overheating.

**Lighting Control**

**▼ Headlights**


Turn the headlight switch to turn the headlights and other exterior lights on or off.  
When the tail lights, position lights, and the number plate lights are turned on, the lights-on indicator light in the instrument cluster turns on.



**NOTE**

- To prevent discharging the battery, do not leave the lights on while the engine is off unless safety requires them.
- Headlights do not blind drivers approaching in the opposite direction no matter what side of the road you must drive your vehicle (left-hand or right-hand traffic). Therefore, it is not necessary to adjust the optical axis of the headlights when switching temporarily to driving on the opposite side of the road (left-hand or right-hand traffic).

**Without auto-light control**




| Switch Position                                       | OFF  |            | ☞☞☞ |            | ☞☞  |            |
|-------------------------------------------------------|------|------------|-----|------------|-----|------------|
| Ignition Position                                     | ON   | ACC or OFF | ON  | ACC or OFF | ON  | ACC or OFF |
| Headlights                                            | Off  | Off        | Off | Off        | On  | Off        |
| Running lights*                                       | On*1 | Off        | Off | Off        | Off | Off        |
| Tail lights<br>Position lights<br>Number plate lights | Off  | Off        | On  | On         | On  | On*2       |

\*1 The lights are turned on while the vehicle is driven.  
\*2 The lights are turned on continuously if the ignition is switched from ON to any other position with the lights turned on. The lights are turned off when the driver's door is opened or 30 seconds have elapsed since the lights turned on.

## Switches and Controls

### With auto-light control



| Switch Position     | OFF              |            | AUTO               |                  | ☀️  |            | 🌙   |                  |
|---------------------|------------------|------------|--------------------|------------------|-----|------------|-----|------------------|
| Ignition Position   | ON               | ACC or OFF | ON                 | ACC or OFF       | ON  | ACC or OFF | ON  | ACC or OFF       |
| Headlights          | Off              | Off        | Auto* <sup>2</sup> | Off              | Off | Off        | On  | Off              |
| Running lights*     | On* <sup>1</sup> | Off        | On* <sup>3</sup>   | Off              | Off | Off        | Off | Off              |
| Tail lights         |                  |            |                    |                  |     |            |     |                  |
| Position lights     | Off              | Off        | Auto* <sup>2</sup> | On* <sup>4</sup> | On  | On         | On  | On* <sup>4</sup> |
| Number plate lights |                  |            |                    |                  |     |            |     |                  |

\*1 The lights are turned on while the vehicle is driven.

\*2 The lights are turned on by the auto light function.

\*3 The lights are turned on while the vehicle is driven, and turned off when the headlights are turned on by the auto light function.

\*4 The lights are turned on continuously if the ignition is switched from ON to any other position with the lights turned on. The lights are turned off when the driver's door is opened or 30 seconds have elapsed since the lights turned on.

### Auto-light control\*


When the headlight switch is in the AUTO position and the ignition is switched ON, the light sensor senses the surrounding lightness or darkness and automatically turns the headlights and other exterior lights on or off.



## Switches and Controls

### CAUTION

- Do not shade the light sensor by adhering a sticker or a label on the windscreen. Otherwise the light sensor will not operate correctly.



- The light sensor also works as a rain sensor for the auto-wiper control. Keep hands and scrapers clear of the windscreen when the wiper lever is in the AUTO position and the ignition is switched ON as fingers could be pinched or the wipers and wiper blades damaged when the wipers activate automatically. If you are going to clean the windscreen, be sure the wipers are turned off completely — this is particularly important when clearing ice and snow — when it is particularly tempting to leave the engine running.


### NOTE

- The headlights, other exterior lights and instrument panel illumination may not turn off immediately even if the surrounding area becomes well-lit because the light sensor determines that it is night time if the surrounding area is continuously dark for several minutes such as inside long tunnels, traffic jams inside tunnels, or in indoor parking lots. In this case, the lights turn off if the light switch is turned to the OFF position.
- When the headlight switch is in the AUTO position and the ignition is switched to ACC or the ignition is switched off, the headlights and other exterior lights will turn off.
- The instrument panel illumination can be adjusted by rotating the knob in the instrument cluster. Also, the antidazzle mode can be changed by rotating the knob until a beep sound is heard. To adjust the brightness of the instrument panel illumination: Refer to Instrument Panel Illumination on page 4-22.
- The sensitivity of the AUTO lights may be changed by an Authorised Mazda Repairer. Refer to Personalisation Features on page 9-8.

## Switches and Controls

### ▼ Headlight High-Low Beam

The headlights switch between high and low beams by moving the lever forward or backward.




When the headlight high-beams are on, the headlight high-beam indicator light is turned on.



### ▼ Flashing the Headlights

Can be used when the ignition is switched ON.

To flash the headlights, pull the lever fully towards you (the headlight switch does not need to be on).



The headlight high-beam indicator light in the instrument cluster illuminates simultaneously. The lever will return to the normal position when released.




### ▼ Coming Home Light

The coming home light turns on the headlights (low beams) when the lever is operated.

#### To turn on the lights

When the lever is pulled with the ignition switched to ACC or OFF, the low beam headlights turn on.

The headlights turn off after a certain period of time has elapsed after all of the doors are closed.



#### **NOTE**

- The time until the headlights turn off after all of the doors are closed can be changed.  
Refer to Personalisation Features on page 9-8.
- If no operations are done for 3 minutes after the lever is pulled, the headlights turn off.

## Switches and Controls

- The headlights turn off if the lever is pulled again while the headlights are illuminated.


### ▼ Leaving Home Light

The leaving home light turns on the lights when the transmitter unlock button is pressed while away from the vehicle. The following lights turn on when the leaving home light is operated. Low beams, Position lights, Tail lights, Number plate lights.

#### To turn on the lights

When the ignition switch and the headlight switch are in the following conditions, the headlights will illuminate when the transmitter unlock button is pressed and the vehicle receives the transmitter signal. The headlights turn off after a certain period of time has elapsed (30 seconds).

- Ignition switch: off
- Headlight switch: AUTO,  or 



#### **NOTE**

- Operation of the leaving home light can be turned on or off. Refer to Personalisation Features on page 9-8.
- When the transmitter lock button is pressed and the vehicle receives the transmitter signal, the headlights turn off.

- When the headlight switch is turned to the OFF position, the headlights turn off.

### ▼ Headlight Levelling

The number of passengers and weight of cargo in the luggage compartment change the angle of the headlights.

The angle of the headlights will be automatically adjusted when turning on the headlights.

### ▼ Running Lights\*

The running lights turn on automatically when the vehicle starts moving.

They turn off when the parking brake is operated or the selector lever is shifted to the P position (automatic transaxle vehicle).

#### **NOTE**

The running lights can be deactivated. Refer to Personalisation Features on page 9-8.

\*Some models.

## Switches and Controls


### Turn and Lane-Change Signals

The ignition must be switched ON to use the turn and lane-change signals.

#### ▼ Direction Indicators

Move the signal lever down (for a right turn) or up (for a left turn) to the stop position. The signal will self-cancel after the turn is completed.

If the indicator light continues to flash after a turn, manually return the lever to its original position.



The direction indicators in the instrument cluster flash according to the operation of the direction indicator lever to show which signal is working.



#### NOTE

- If an indicator light stays on without flashing or if it flashes abnormally, one of the direction indicator bulbs may be burned out.
- A personalised function is available to change the turn indicator sound volume. (page 9-8)

#### ▼ Lane-Change Signals

Move the lever halfway toward the direction of the lane change—until the indicator flashes— and hold it there. It will return to the off position when released.

#### ▼ Three-Flash Turn Signal

After releasing the direction indicator lever, the direction indicator flashes 3 times. The operation can be cancelled by moving the lever in the direction opposite to which it was operated.

#### NOTE

The three-flash turn signal function can be switched to operable/inoperable using the personalisation function. Refer to Personalisation Features on page 9-8.

## Windscreen Wipers and Washer

The ignition must be switched ON to use the wipers.

### **WARNING**

**Use only windscreen washer fluid or plain water in the reservoir:**

Using radiator antifreeze as washer fluid is dangerous. If sprayed on the windscreen, it will dirty the windscreen, affect your visibility, and could result in an accident.

**Only use windscreen washer fluid mixed with anti-freeze protection in freezing weather conditions:**

Using windscreen washer fluid without anti-freeze protection in freezing weather conditions is dangerous as it could freeze on the windscreen and block your vision which could cause an accident. In addition, make sure the windscreen is sufficiently warmed using the defroster before spraying the washer fluid.


### **NOTE**

*If the windscreen wipers are operated under cold weather conditions or during snowfall, they could stop due to accumulated snow on the windscreen. If the windscreen wipers stop due to accumulated snow on the windscreen, park the vehicle in a safe place, turn the wiper switch off, and then remove the accumulated snow. If the wiper switch is turned to another position other than OFF, the wipers will operate. If the wipers do not operate even though the wiper switch is turned to a position other than OFF, consult an expert repairer (we recommend an Authorised Mazda Repairer) as soon as possible.*

### ▼ Windscreen Wipers

Turn the wipers on by pressing the lever up or down.

**With intermittent wiper**




| Switch Position | Wiper operation                  |
|-----------------|----------------------------------|
| MIST            | Operation while pulling up lever |
| OFF             | Stop                             |
| INT             | Intermittent                     |
| LO              | Low speed                        |
| HI              | High speed                       |


## Switches and Controls

### Variable-speed intermittent wipers

Set the lever to the intermittent position and choose the interval timing by rotating the ring.



### With auto-wiper control




| Switch Position | Wiper operation                  |
|-----------------|----------------------------------|
| MIST            | Operation while pulling up lever |
| OFF             | Stop                             |
| AUTO            | Auto control                     |
| LO              | Low speed                        |
| HI              | High speed                       |

### Auto-wiper control\*

When the wiper lever is in the AUTO position, the rain sensor senses the amount of rainfall on the windscreen and turns the wipers on or off automatically (off—intermittent—low speed—high speed).

The sensitivity of the rain sensor can be adjusted by turning the switch on the wiper lever.


From the centre position (normal), rotate the switch upward for higher sensitivity (faster response) or rotate it downward for less sensitivity (slower response).



## Switches and Controls

### CAUTION

- Do not shade the rain sensor by adhering a sticker or a label on the windscreen. Otherwise the rain sensor will not operate correctly.



- When the wiper lever is in the AUTO position and the ignition is switched ON, the wipers may move automatically in the following cases:
  - If the windscreen above the rain sensor is touched or wiped with a cloth.
  - If the windscreen is struck with a hand or other object from either outside or inside the vehicle.

Keep hands and scrapers clear of the windscreen when the wiper lever is in the AUTO position and the ignition is switched ON as fingers could be pinched or the wipers and wiper blades damaged when the wipers activate automatically. If you are going to clean the windscreen, be sure the wipers are turned off completely (when it is most likely that the engine is left running) this is particularly important when clearing ice and snow.

### NOTE


- Switching the auto-wiper lever from the OFF to the AUTO position while driving activates the windscreen wipers once, after which they operate according to the rainfall amount.
- The auto-wiper control may not operate when the rain sensor temperature is about  $-10^{\circ}\text{C}$  ( $14^{\circ}\text{F}$ ) or lower, or about  $85^{\circ}\text{C}$  ( $185^{\circ}\text{F}$ ) or higher.
- If the windscreen is coated with water repellent, the rain sensor may not be able to sense the amount of rainfall correctly and the auto-wiper control may not operate properly.
- If dirt or foreign matter (such as ice or matter containing salt water) adheres to the windscreen above the rain sensor, or if the windscreen is iced, it could cause the wipers to move automatically. However, if the wipers cannot remove this ice, dirt or foreign matter, the auto-wiper control will stop operation. In this case, set the wiper lever to the low speed position or high speed position for manual operation, or remove the ice, dirt or foreign matter by hand to restore the auto-wiper operation.
- If the auto-wiper lever is left in the AUTO position, the wipers could operate automatically from the effect of strong light sources, electromagnetic waves, or infrared light because the rain sensor uses an optical sensor. It is recommended that the auto-wiper lever be switched to the OFF position other than when driving the vehicle under rainy conditions.

# Switches and Controls

· The auto-wiper control functions can be turned off. Refer to Personalisation Features on page 9-8.

## ▼ Windscreen Washer

Pull the lever toward you and hold it to spray washer fluid.



### NOTE


If the windscreen washer is turned on when the windscreen wipers are not operating, the windscreen wipers operate a few times.

If the washer does not work, inspect the fluid level (page 6-18). If the fluid level is normal, consult an expert repairer (we recommend an Authorised Mazda Repairer).

## Rear Window Wiper and Washer\*

The ignition must be switched ON to use the wiper.

### ▼ Rear Window Wiper



Turn the wiper on by turning the rear wiper/washer switch.

| Switch Position | Wiper operation |
|-----------------|-----------------|
| OFF             | Stop            |
| INT             | Intermittent    |
| ON              | Normal          |

### ▼ Rear Window Washer

To spray washer fluid, turn the rear wiper/washer switch to either of the  position. After the switch is released, the washer will stop.

If the washer does not work, inspect the fluid level (page 6-18). If the fluid level is normal and the washer still does not work, consult an expert repairer (we recommend an Authorised Mazda Repairer).



## Switches and Controls

### Rear Window Defogger


The rear window defogger clears fog from the rear window.

The ignition must be switched ON to use the defogger.


Press the switch to turn on the rear window defogger. The rear window defogger operates for about 15 minutes and then turns off automatically. The indicator light illuminates when the defogger is operating.

To turn off the rear window defogger before the 15 minutes has elapsed, press the switch again.

#### Manual Air-Conditioning



#### Fully Automatic Air-Conditioning



### ⚠ CAUTION

➤ Do not use sharp instruments or window cleaners with abrasives to clean the inside of the rear window surface. They may damage the defogger grid inside the window.

### NOTE

- This defogger is not designed for melting snow. If there is an accumulation of snow on the rear window, remove it before using the defogger.
- The rear window defogger setting can be changed. After changing the setting, the rear window defogger stops automatically after 15 minutes have elapsed and when the ambient temperature is high. When the ambient temperature is low, it continues to operate until the switch is pressed again.  
Refer to Personalisation Features on page 9-8.


## Switches and Controls

### Horn

To sound the horn, press the  mark on the steering wheel.

### Hazard Warning Flasher

The hazard warning lights should always be used when you stop on or near a roadway in an emergency.



The hazard warning lights warn other drivers that your vehicle is a traffic hazard and that they must take extreme caution when near it.



Depress the hazard warning flasher and all the direction indicators will flash. The hazard warning indicator lights in the instrument cluster flash simultaneously.

#### **NOTE**

- The direction indicators do not work when the hazard warning lights are on.
- Check local regulations about the use of hazard warning lights while the vehicle is being towed to verify that it is not in violation of the law.

## Switches and Controls

---

- *If the brake pedal is depressed while driving on slippery roads, the emergency stop signal system could operate causing all the turn and lane change signals to flash. Refer to Emergency Stop Signal System on page 4-63.*
- *While the emergency stop signal system is operating, all the direction indicators automatically flash rapidly to caution the driver of a vehicle following behind your vehicle of a sudden braking situation. Refer to Emergency Stop Signal System on page 4-63.*

### Brake System

#### ▼ Foot Brake

This vehicle has power-assisted brakes that adjust automatically through normal use.

Should power-assist fail, you can stop by applying greater force than normal to the brake pedal. But the distance required to stop will be greater than usual.

#### WARNING

**Do not coast with the engine stalled or turned off, find a safe place to stop:**

*Coasting with the engine stalled or turned off is dangerous. Braking will require more effort, and the brake's power-assist could be depleted if you pump the brake. This will cause longer stopping distances or even an accident.*

**Shift to a lower gear when going down steep hills:**


*Driving with your foot continuously on the brake pedal or steadily applying the brakes for long distances is dangerous. This causes overheated brakes, resulting in longer stopping distances or even total brake failure. This could cause loss of vehicle control and a serious accident. Avoid continuous application of the brakes.*

**Dry off brakes that have become wet by driving slowly, releasing the accelerator pedal and lightly applying the brakes several times until the brake performance returns to normal:**

*Driving with wet brakes is dangerous. Increased stopping distance or the vehicle pulling to one side when braking could result in a serious accident. Light braking will indicate whether the brakes have been affected.*

#### CAUTION

- Do not drive with your foot held on the clutch pedal or brake pedal, or hold the clutch pedal depressed halfway unnecessarily. Doing so could result in the following:
  - The clutch and brake parts will wear out more quickly.
  - The brakes can overheat and adversely affect brake performance.
- Always depress the brake pedal with the right foot. Applying the brakes with the unaccustomed left foot could slow your reaction time to an emergency situation resulting in insufficient braking operation.



- *Wear shoes appropriate for driving in order to avoid your shoe contacting the brake pedal when depressing the accelerator pedal.*

### ▼ Parking Brake




*Driving with the parking brake on will cause excessive wear of the brake parts.*

### NOTE

*For parking in snow, refer to Winter Driving (page 3-34) regarding parking brake use.*


### Setting the parking brake

Depress the brake pedal and then firmly pull the parking brake lever fully upwards with sufficient force to hold the vehicle in a stationary position.



### Releasing the parking brake

Depress the brake pedal and pull the parking brake lever upwards, then press the release button. While holding the button, lower the parking brake lever all the way down to the released position.




### ▼ Warning Light

The warning light turns on when the system has a malfunction. Refer to Contact Authorised Mazda Repairer and Have Vehicle Inspected on page 7-25.

## Brake

### ▼ Brake Pad Wear Indicator

When the disc brake pads become worn, the built-in wear indicators contact the disc plates. This causes a screeching noise to warn that the pads should be replaced.



When you hear this noise, consult an expert repairer (we recommend an Authorised Mazda Repairer) as soon as possible.

### **WARNING**

**Do not drive with worn disc pads:**  
Driving with worn disc pads is dangerous. The brakes could fail and cause a serious accident. As soon as you hear a screeching noise consult an expert repairer (we recommend an Authorised Mazda Repairer).

### **NOTE**

*In high humidity weather conditions, brake noises, such as brake squeak or brake squeal can be heard. It does not indicate a malfunction.*

### ▼ Brake Assist

During emergency braking situations when it is necessary to depress the brake pedal with greater force, the brake assist system provides braking assistance, thus enhancing braking performance.

When the brake pedal is depressed hard or depressed more quickly, the brakes apply more firmly.

### **NOTE**

- *When the brake pedal is depressed hard or depressed more quickly, the pedal will feel softer but the brakes will apply more firmly. This is a normal effect of the brake assist operation and does not indicate a malfunction.*
- *When the brake pedal is depressed hard or depressed more quickly, a motor/pump operation noise may be heard. This is a normal effect of the brake assist and does not indicate a malfunction.*
- *The brake assist equipment does not supersede the functionality of the vehicle's main braking system.*

## Emergency Stop Signal System

If you apply the brakes suddenly while driving at a speed of about 55 km/h (34 mph) or faster, the emergency stop signal system automatically and rapidly flashes all the direction indicator lights to caution drivers behind your vehicle of the sudden braking situation.

### **NOTE**

#### · **Flashing**

*When you bring your vehicle to a complete stop while all the direction indicator lights are flashing rapidly, the rapid flashing of all the direction indicator lights changes back to the normal flashing pattern. When the hazard warning light switch is pressed, all of the direction indicator lights turn off.*

#### · **Operation**

- *When the ABS operates, the emergency stop signal system is more likely to operate. Therefore, if the brake pedal is depressed on a slippery road, all of the direction indicator lights may flash.*
- *The emergency stop signal system does not operate when the hazard warning light switch is pressed.*

## Hill Launch Assist (HLA)

Hill Launch Assist (HLA) is a function which assists the driver in accelerating from a stop while on a slope. When the driver releases the brake pedal and depresses the accelerator pedal while on a slope, the function prevents the vehicle from rolling. The braking force is maintained automatically after the brake pedal is released on a steep grade.

For vehicles with a manual transaxle, Hill Launch Assist (HLA) operates on a downward slope when the shift lever is in the reverse (R) position, and on an upward slope when the shift lever is in a position other than the reverse (R) position.

For vehicles with an automatic transaxle, Hill Launch Assist (HLA) operates on a downward slope when the selector lever is in the reverse (R) position, and on an upward slope when the selector lever is in a forward gear.

### **WARNING**

#### **Do not rely completely on Hill Launch Assist (HLA):**

Hill Launch Assist (HLA) is an auxiliary device for accelerating from a stop on a slope. The system only operates for about 2 seconds and therefore, relying only on the system, when accelerating from a stop is dangerous because the vehicle may move (roll) unexpectedly and cause an accident. The vehicle could roll depending on the vehicle's load or if it is towing something. In addition, for vehicles with a manual transaxle, the vehicle could still roll depending on how the clutch pedal or the accelerator pedal is operated. Always confirm the safety around the vehicle before starting to drive the vehicle.

#### **NOTE**

- Hill Launch Assist (HLA) does not operate on a gentle slope. In addition, the gradient of the slope on which the system will operate changes depending on the vehicle's load.
  - Hill Launch Assist (HLA) does not operate if the parking brake is applied, the vehicle has not stopped completely, or the clutch pedal is released.
  - While Hill Launch Assist (HLA) is operating, the brake pedal may feel stiff and vibrate, however, this does not indicate a malfunction.
  - Hill Launch Assist (HLA) does not operate while the TCS/DSC indicator light is illuminated.
- Refer to Contact Authorised Mazda Repairer and Have Vehicle Inspected on page 7-25.

· Hill Launch Assist (HLA) does not turn off even if the DSC OFF switch is pressed to turn off the TCS/DSC.

#### · (Automatic Transaxle)

Although the Hill Launch Assist (HLA) does not operate during idling stop, the vehicle roll prevention function operates to prevent vehicle roll.



## **Antilock Brake System (ABS)**

The ABS control unit continuously monitors the speed of each wheel. If one wheel is about to lock up, the ABS responds by automatically releasing and reapplying that wheel's brake.

The driver will feel a slight vibration in the brake pedal and may hear a chattering noise from the brake system. This is normal ABS system operation. Continue to depress the brake pedal without pumping the brakes.

The warning light turns on when the system has a malfunction.  
Refer to Contact Authorised Mazda Repairer and Have Vehicle Inspected on page 7-25.

### **WARNING**

***Do not rely on ABS as a substitute for safe driving:***

*The ABS cannot compensate for unsafe and reckless driving, excessive speed, tailgating (following another vehicle too closely), driving on ice and snow, and hydroplaning (reduced tyre friction and road contact because of water on the road surface). You can still have an accident.*

### **NOTE**

- *Braking distances may be longer on loose surfaces (snow or gravel, for example) which usually have a hard foundation. A vehicle with a normal braking system may require less distance to stop under these conditions because the tyres will build up a wedge of surface layer when the wheels skid.*
- *The sound of the ABS operating may be heard when starting the engine or immediately after starting the vehicle, however, it does not indicate a malfunction.*

### Traction Control System (TCS)

The Traction Control System (TCS) enhances traction and safety by controlling engine torque and braking. When the TCS detects driving wheel slippage, it lowers engine torque and operates the brakes to prevent loss of traction.

This means that on a slick surface, the engine adjusts automatically to provide optimum power to the drive wheels, limiting wheel spin and loss of traction.

The warning light turns on when the system has a malfunction.  
Refer to Contact Authorised Mazda Repairer and Have Vehicle Inspected on page 7-25.

#### **WARNING**

#### **Do not rely on the Traction Control System (TCS) as a substitute for safe driving:**

*The Traction Control System (TCS) cannot compensate for unsafe and reckless driving, excessive speed, tailgating (following another vehicle too closely), and hydroplaning (reduced tyre friction and road contact because of water on the road surface). You can still have an accident.*

#### **Use snow tyres or tyre chains and drive at reduced speeds when roads are covered with ice and/or snow:**

*Driving without proper traction devices on snow and/or ice-covered roads is dangerous. The Traction Control System (TCS) alone cannot provide adequate traction and you could still have an accident.*

#### **NOTE**

*To turn off the TCS, press the DSC OFF switch (page 4-68).*

#### **▼ TCS/DSC Indicator Light**



This indicator light stays on for a few seconds when the ignition is switched ON. If the TCS or DSC is operating, the indicator light flashes.

If the light stays on, the TCS, DSC or the brake assist system may have a malfunction and they may not operate correctly. Take your vehicle to an expert repairer (we recommend an Authorised Mazda Repairer).

#### **NOTE**

- *In addition to the indicator light flashing, a slight labouring sound will come from the engine. This indicates that the TCS/DSC is operating properly.*
- *On slippery surfaces, such as fresh snow, it will be impossible to achieve high rpm when the TCS is on.*

## Dynamic Stability Control (DSC)

The Dynamic Stability Control (DSC) automatically controls braking and engine torque in conjunction with systems such as ABS and TCS to help control side slip when driving on slippery surfaces, or during sudden or evasive manoeuvring, enhancing vehicle safety.

Refer to ABS (page 4-65) and TCS (page 4-66).

DSC operation is possible at speeds greater than 20 km/h (12 mph).

The warning light turns on when the system has a malfunction.  
Refer to Contact Authorised Mazda Repairer and Have Vehicle Inspected on page 7-25.

### **WARNING**

***Do not rely on the Dynamic Stability Control as a substitute for safe driving:***  
*The Dynamic Stability Control (DSC) cannot compensate for unsafe and reckless driving, excessive speed, tailgating (following another vehicle too closely), and hydroplaning (reduced tyre friction and road contact because of water on the road surface). You can still have an accident.*

### **CAUTION**

- *The DSC may not operate correctly unless the following are observed:*
  - *Use tyres of the correct size specified for your Mazda on all 4 wheels.*
  - *Use tyres of the same manufacturer, brand and tread pattern on all 4 wheels.*
  - *Do not mix worn tyres.*
- *The DSC may not operate correctly when tyre chains are used or a temporary spare tyre is installed because the tyre diameter changes.*

### **TCS/DSC Indicator Light**



This indicator light stays on for a few seconds when the ignition is switched ON. If the TCS or DSC is operating, the indicator light flashes.

If the light stays on, the TCS, DSC or the brake assist system may have a malfunction and they may not operate correctly. Take your vehicle to an expert repairer (we recommend an Authorised Mazda Repairer).

### ▼ DSC OFF Indicator Light




This indicator light stays on for a few seconds when the ignition is switched ON. It also illuminates when the DSC OFF switch is pressed and TCS/DSC is switched off.

Refer to DSC OFF Switch on page 4-68.

If the light remains illuminated and the TCS/DSC is not switched off, take your vehicle to an expert repairer (we recommend an Authorised Mazda Repairer). The DSC may have a malfunction.

### ▼ DSC OFF Switch

Press the DSC OFF switch to turn off the TCS/DSC. The DSC OFF indicator light in the instrument cluster will illuminate.



Press the switch again to turn the TCS/DSC back on. The DSC OFF indicator light will turn off.

### NOTE

- When DSC is on and you attempt to free the vehicle when it is stuck, or drive it out of freshly fallen snow, the TCS (part of the DSC system) will activate. Depressing the accelerator will not increase engine power and freeing the vehicle may be difficult. When this happens, turn off the TCS/DSC.
- If the TCS/DSC is off when the engine is turned off, it automatically activates when the ignition is switched ON.
- Leaving the TCS/DSC on will provide the best traction.
- If the DSC OFF switch is pressed and held for 10 seconds or more, the DSC OFF switch malfunction detection function operates and the DSC system activates automatically. The DSC OFF indicator light turns off while the DSC system is operative.
- **(Vehicles with Smart City Brake Support (SCBS))**  
If the Smart City Brake Support (SCBS) operates with the TCS/DSC turned off, the TCS/DSC becomes operational automatically.

When Driving


# Fuel Economy Monitor

## Fuel Economy Monitor\*

For vehicles with type B audio, the Control Status, Fuel Consumption, and Effectiveness\*<sup>1</sup> are switched and displayed by operating each icon in the display.

In addition, after completing a trip, the total energy efficiency to date is displayed in the ending display when the ending display is turned on.

1. Select the  icon on the home screen to display the Applications screen.
2. Select the “Fuel Economy Monitor”.
3. Select the  icon at the bottom left of the screen to display the menu in the lower part of the screen.
4. Select the icon in the menu and perform the operation. Each icon operates as follows:

| Indication on display                                                              | Control status                                                                                                                                                                                                                                       |
|------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|  | ① Hides the menu display.                                                                                                                                                                                                                            |
|                                                                                    | ② Displays the Applications screen.                                                                                                                                                                                                                  |
|                                                                                    | ③ Switches the Fuel Economy Monitor in the order of Control Status, Fuel Consumption, and Effectiveness* <sup>1</sup> .                                                                                                                              |
|                                                                                    | ④ Resets the fuel economy data.                                                                                                                                                                                                                      |
|                                                                                    | ⑤ Displays the following setting screen. <ul style="list-style-type: none"> <li>• Ending display on/off switching</li> <li>• On/off switching for function which synchronizes (links) reset of fuel economy data with trip meter (TRIP A)</li> </ul> |


\*<sup>1</sup> With i-stop function.

\*Some models. **4-69**

## Fuel Economy Monitor

### ▼ Fuel Consumption Display

Information regarding the fuel economy is displayed.


| Indication on display                                                                                                                                                                                     | Control status                                                                                                                                                                                                                                                                                                                                                                                                                                                               |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|  <p>① Fuel Economy (This Drive)</p> <p>② Aver. Fuel Economy History</p> <p>③ Average (This Drive)</p> <p>8.0 L/100km</p> | <p>① Displays the fuel economy for the past 60 minutes.</p> <ul style="list-style-type: none"> <li>Displays the fuel economy every minute for the past 1 to 10 minutes.</li> <li>Displays the fuel economy every 10 minutes for the past 10 to 60 minutes.</li> </ul> <p>② Displays the average fuel economy over the past 5 resets and after the current reset.</p> <p>③ Calculates the average fuel economy every minute after vehicle travel begins, and displays it.</p> |

### NOTE

- The fuel economy data is synchronized (linked) with the average fuel economy displayed in the trip computer.
- To reset the fuel economy data, press the  icon in the menu. (The average fuel economy displayed in the trip computer resets at the same time.)
- After resetting the fuel economy data, "--" is displayed while the average fuel economy is being calculated.


### ▼ Control Status Display

The i-stop operation status are displayed.

| Indication on display                                                                                                                                            | Control status                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |
|------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|  <p>① Average (Since Reset)</p> <p>4.2L/100km</p> <p>i-stop ② NOT READY ③</p> | <p>① Displays the accumulated fuel economy.</p> <ul style="list-style-type: none"> <li>Synchronized (linked) with the average fuel economy displayed in the trip computer. Refer to Trip Computer and INFO Switch on page 4-23.</li> <li>To reset, press the  icon in the menu. (The average fuel economy displayed in the trip computer resets at the same time.)</li> </ul> <p>② Displays the readiness status as to whether operation of the i-stop function is available.</p> <p>③ Displays the operation readiness status of the i-stop function on the vehicle side (engine, battery, and A/C) using icon colouring. The blue colour indicates that the i-stop function is ready to operate, and the grey colour indicates that it is not ready for operation.</p> |


When Driving

# Fuel Economy Monitor

| Indication on display                                                                                                                                                                                                                                                                                  | Control status                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |
|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|  <p><b>Fuel Economy Monitor</b> 10:20</p> <p>Average (Since Reset)<br/>4.2L/100km</p> <p>i-stop</p> <p>Can't be activated.<br/>Please turn steering wheel to center.</p> <p>Time Active 1m 50s Total Time 11m 12s</p> | <p>④ Displays the i-stop function status while the vehicle is stopped.</p> <p>⑤ Indicates the operations required by the driver to operate the i-stop function while it is not operating.</p> <p>⑥ Displays the current amount of time that the i-stop function has been operating and the accumulated amount of time that it has been operating.</p> <p>⑦ The i-stop function operation status is indicated by the colour of the engine area. The colour is blue during i-stop function operation, and grey when it is not operating.</p> |

## ▼ Effectiveness Display

The actual performance of the energy efficiency is displayed.

| Indication on display                                                                                                                                                                                                                                       | Control status                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|  <p><b>Fuel Economy Monitor</b> 10:20</p> <p>% i-stop ON (This Drive)</p> <p>60% i-stop ON 12m12s Time Stopped 20m20s</p> <p>Total Range Boosted by i-stop 2000.0 km</p> | <p>① The leaf graphic grows according to the amount of CO2 emissions reduced by the system effects. The cumulative total amount of leaf growth is indicated in terms of the number of tree graphics.</p> <p>② Displays the total driving distance which could be extended by the operation of the i-stop function.</p> <p>③ Displays the percentage of time that the vehicle was stopped by the i-stop function operation out of the total amount of time that the vehicle was stopped.</p> <p>④ Displays the amount of time that the i-stop function has operated.</p> <p>⑤ Displays the total amount of time that the vehicle was stopped.</p> |

## ▼ Ending Screen Display

If the ending display on the fuel economy monitor is on when the ignition is switched from ON to OFF, the actual energy efficiency (with i-stop function) or the information regarding the fuel economy (without i-stop function) is displayed.

## Drive Selection

### Drive Selection\*

Drive selection is a system to switch the vehicle's drive mode. When the sport mode is selected, vehicle's response against accelerator operation is enhanced. Use the sport mode when higher vehicle response is required such as merging onto expressway or accelerating to overtake.

#### CAUTION


*Do not use the sport mode when driving on slippery roads such as wet or snow-covered roads. It may cause tyre slipping.*

#### NOTE

- When the sport mode is selected, driving at higher engine speeds increases and it may increase fuel consumption. Mazda recommends to cancel the sport mode on normal driving.
- Drive mode cannot be switched in the following conditions:
  - ABS/TCS/DSC is operating
  - Steering wheel is being operated abruptly

#### ▼ Drive Selection Switch

Press the drive selection switch forward (“SPORT”) to select the sport mode.  
Pull the drive selection switch back (“—”) to cancel the sport mode.



#### NOTE

- In the following cases, the drive selection is cancelled.

- The ignition is switched OFF.
- Mazda Radar Cruise Control (MRCC) system/cruise control is set.
- Depending on the driving conditions when sport mode is selected, the vehicle may perform shift-down or slightly accelerate.

#### ▼ Select Mode Indicator Light

When the sport mode is selected, the select mode indicator light turns on in the instrument cluster.

# SPORT

#### NOTE

*If the drive selection cannot be switched to sport mode, the select mode indicator light flashes to notify the driver.*



## Power Steering

- Power steering is only operable when the engine is running. If the engine is off or if the power steering system is inoperable, you can still steer, but it requires more physical effort.

If the steering feels stiffer than usual during normal driving or the steering vibrates, consult an expert repairer (we recommend an Authorised Mazda Repairer).

- The warning light notifies the driver of system abnormalities and operation conditions.

In addition, the buzzer may also activate depending on the system abnormality or operation condition.

Refer to Stop Vehicle in Safe Place Immediately on page 7-23.

Refer to Power Steering Warning Buzzer on page 7-39.

### **CAUTION**

*Never hold the steering wheel to the extreme left or right for more than 5 seconds with the engine running. This could damage the power steering system.*

## i-ACTIVSENSE\*

i-ACTIVSENSE is a collective term covering a series of advanced safety and driver support systems which make use of a Forward Sensing Camera (FSC) and radar sensors. These systems consist of active safety and pre-crash safety systems.

These systems are designed to assist the driver in safer driving by reducing the load on the driver and helping to avert collisions or reduce their severity. However, because each system has its limitations, always drive carefully and do not rely solely on the systems.

### ▼ Active Safety Technology

Active Safety Technology supports safer driving by helping the driver to recognise potential hazards and avert accidents.

#### Driver awareness support systems

##### **Nighttime visibility**

Adaptive LED Headlights (ALH)..... page 4-79

High Beam Control System (HBC)..... page 4-77

##### **Left/right side and rear side detection**

Lane Departure Warning System (LDWS).....page 4-82

Blind Spot Monitoring (BSM)..... page 4-89

##### **Road sign recognition**

Traffic Sign Recognition System (TSR)..... page 4-95

##### **Inter-vehicle distance recognition**

Distance Recognition Support System (DRSS)..... page 4-87

##### **Driver fatigue detection**

Driver Attention Alert (DAA)..... page 4-101

##### **Rear obstruction detection when leaving a parking space**

Rear Cross Traffic Alert (RCTA).....page 4-103

##### **Full-surround recognition**

360°View Monitor..... page 4-147

#### Driver support systems

##### **Inter-vehicle distance**

Mazda Radar Cruise Control (MRCC)..... page 4-107

### **Lane departure**

Lane-keep Assist System (LAS).....page 4-117

### **Speed control**

Adjustable Speed Limiter (ASL).....page 4-129

### **▼ Pre-Crash Safety Technology**

Pre-crash safety technology is designed to assist the driver in averting collisions or reduce their severity in situations where they cannot be avoided.

#### **Collision damage reduction in low vehicle speed range**

##### **Forward driving**

Advanced Smart City Brake Support (Advanced SCBS).....page 4-136

##### **Reverse driving**

Smart City Brake Support [Reverse] (SCBS R).....page 4-140

#### **Collision damage reduction in medium/high speed range**

Smart Brake Support (SBS).....page 4-144

### **▼ Camera and Sensors**

#### **Forward Sensing Camera (FSC)**

The Forward Sensing Camera (FSC) detects lane indications and recognises headlights, tail lights and city lights during nighttime driving. In addition, it also detects the vehicle ahead, pedestrians, or obstructions. The following systems also use the Forward Sensing Camera (FSC).

- High Beam Control System (HBC)
- Adaptive LED Headlights (ALH)
- Driver Attention Alert (DAA)
- Lane Departure Warning System (LDWS)
- Lane-keep Assist System (LAS) & Lane Departure Warning System (LDWS)
- Traffic Sign Recognition System (TSR)
- Advanced Smart City Brake Support (Advanced SCBS)
- Smart Brake Support (SBS)

The Forward Sensing Camera (FSC) is installed at the top of the windscreen near the rearview mirror.

Refer to Forward Sensing Camera (FSC) on page 4-174.

### **Radar sensor (front)**

The radar sensor (front) functions by detecting the radio waves reflected off a vehicle ahead sent from the radar sensor. The following systems also use the radar sensor (front).

- Mazda Radar Cruise Control (MRCC)
- Distance Recognition Support System (DRSS)
- Smart Brake Support (SBS)

The radar sensor (front) is mounted behind the radiator grille.  
Refer to Radar Sensor (Front) on page 4-179.

### **Radar sensors (rear)**

The radar sensors (rear) function by detecting the radio waves reflected off a vehicle approaching from the rear or an obstruction sent from the radar sensors. The following systems also use the radar sensors (rear).

- Blind Spot Monitoring (BSM)
- Rear Cross Traffic Alert (RCTA)

The radar sensors (rear) are installed inside the rear bumper, one each on the left and right sides.

Refer to Radar Sensors (Rear) on page 4-182.

### **Ultrasonic sensors (rear)**

The ultrasonic sensors (rear) function by detecting the ultrasonic waves reflected off obstructions at the rear sent from the ultrasonic sensors. The following systems also use the ultrasonic sensors (rear).

- Smart City Brake Support [Reverse] (SCBS R)

The ultrasonic sensors (rear) are mounted in the rear bumper.  
Refer to Ultrasonic Sensors (Rear) on page 4-184.

### **Front camera/side cameras/rear view camera**

The front camera, side cameras, and rear camera shoot images of the area surrounding the vehicle. The 360° View Monitor uses each camera.

Cameras are installed to the front bumper, door mirrors, and rear bumper.

Refer to Front Camera/Side Cameras/Rear Camera on page 4-185.

## High Beam Control System (HBC)\*


The HBC determines the conditions in front of the vehicle using the Forward Sensing Camera (FSC) while driving in darkness to automatically switch the headlights between high and low beams.

Refer to Forward Sensing Camera (FSC) on page 4-174.


While driving the vehicle at a speed of about 30 km/h (19 mph) or more, the headlights are switched to high beams when there are no vehicles ahead or approaching in the opposite direction.

The system switches the headlights to low beams when one of the following occurs:

- The system detects a vehicle or the headlights/lights of a vehicle approaching in the opposite direction.
- The vehicle is driven on roads lined with streetlamps or on roads in well-lit cities and towns.
- The vehicle is driven at less than about 20 km/h (12 mph).



The recognition distance of the Forward Sensing Camera (FSC) varies according to the surrounding conditions.



The warning light turns on when the system has a malfunction.

Refer to Contact Authorised Mazda Repairer and Have Vehicle Inspected on page 7-25.

### **CAUTION**

- Do not adjust the vehicle height, modify the headlight units, or remove the camera, otherwise the system will not operate normally.
- Do not rely excessively on the HBC and drive the vehicle while paying sufficient attention to safety. Switch the headlights between the high beams and low beams manually if necessary.

\*Some models.

### NOTE

*The timing in which the system switches the headlights changes under the following conditions. If the system does not switch the headlights appropriately, manually switch between high and low beams according to the visibility as well as road and traffic conditions.*

- *When there are sources of light in the area such as street lamps, illuminated signboards, and traffic signals.*
- *When there are reflective objects in the surrounding area such as reflective plates and signs.*
- *When visibility is reduced under rain, snow and foggy conditions.*
- *When driving on roads with sharp turn or hilly terrain.*
- *When the headlights/rear lamps of vehicles in front of you or in the opposite lane are dim or not illuminated.*
- *When there is sufficient darkness such as at dawn or dusk.*
- *When the luggage compartment is loaded with heavy objects or the rear passenger seats are occupied.*
- *When visibility is reduced due to a vehicle in front of you spraying water from its tyres onto your windscreen.*

### ▼ To Operate the System

The HBC operates to switch the headlights automatically between high and low beams after the ignition is switched ON and the headlight switch is in the AUTO and high beam position.

The HBC determines that it is dark based on the brightness of the surrounding area. At the same time, the HBC indicator light (green) in the instrument cluster illuminates.



### NOTE

- *When the vehicle speed is about 30 km/h (19 mph) or more, the headlights automatically switch to high beams when there are no vehicles ahead or approaching in the opposite direction. When the vehicle speed is less than about 20 km/h (12 mph), the HBC switches the headlights to low beams.*
- *The low beams may not switch to high beams when cornering.*
- *Operation of the HBC function can be disabled. Refer to Personalisation Features on page 9-8.*

### ▼ Manual Switching

#### Switching to low beams

Shift the lever to the low beam position.  
The HBC indicator light (green) turns off.

#### Switching to high beams

Turn the headlight switch to the  position.  
The HBC indicator light (green) turns off  
and the  is illuminated.

### Adaptive LED Headlights (ALH)\*


The ALH are a system which uses the Forward Sensing Camera (FSC) to determine the situation of a vehicle ahead or a vehicle approaching in the opposite direction while driving at night to automatically switch the illumination range of the headlights, the illuminated area, or the illumination brightness. Refer to Forward Sensing Camera (FSC) on page 4-174.

The ALH are controlled between high and low beams as follows to assure the driver's visibility without dazzling a vehicle ahead or a vehicle approaching in the opposite direction.

#### Glare-Free High Beam

This feature dims only the high-beam light shone on the vehicle ahead.

The high beams will dim while driving at a speed of about 40 km/h (25 mph) or faster. When the vehicle speed is less than about 30 km/h (19 mph), the beams switch to the low beams.




#### **NOTE**

*The headlight high-beam indicator light turns on while the high beams are on.*

\*Some models.


### **Wide-Range Low Beam**

This feature extends the illumination range of the light cast by the low beams while driving at a speed less than about 40 km/h (25 mph).



### **Highway Mode**

This feature shifts the illumination angle of the light cast by the headlights upward while driving on highways.



The distance in which the ALH can detect objects varies depending on the surrounding conditions.



- Do not modify the suspensions or headlight units, or remove the camera. Otherwise, the ALH may not operate normally.
- Do not rely excessively on the ALH and drive the vehicle while paying sufficient attention to safety. Switch the headlights between the high beams and low beams manually if necessary.

### **NOTE**

*Under the following conditions, the ALH may not operate normally. Manually switch between the high and low beams according to the visibility, and the road and traffic conditions.*

- When there are other sources of light in the area such as street lamps, illuminated signboards, and traffic signals.
- When there are reflective objects in the surrounding area such as reflective plates and signs.
- When visibility is reduced under rain, snow and foggy conditions.
- When driving on roads with sharp curves or undulations.
- When the headlights/rear lamps of vehicles ahead or in the opposite lane are dim or not illuminated.
- When there is insufficient darkness such as at dawn or dusk.
- When the luggage compartment is loaded with heavy objects or the rear passenger seats are occupied.
- When visibility is reduced due to a vehicle ahead spraying water from its tyres onto your windscreen.



### ▼ To Operate the System

The system switches the headlights to the high beams after the ignition is switched ON and the headlight switch is in the **AUTO** position. The ALH indicator light (green) in the instrument cluster turns on simultaneously.



The ALH determines that it is nighttime based on the brightness of the surrounding area.

The system cancels operation when the headlight switch is turned to a position other than **AUTO**, the headlights are manually switched to low beams, or the high beams are flashed on and off.

#### **NOTE**

*The system can be changed so that the ALH does not operate.*

*Refer to Personalisation Features on page 9-8.*

### ▼ Manual Switching

#### **Switching to low beams**

Shift the lever to the low beam position.  
The ALH indicator light (green) turns off.

#### **Switching to high beams**

Turn the headlight switch to the  position.

The ALH indicator light (green) turns off and the  is illuminated.


## Lane Departure Warning System (LDWS)\*

The LDWS notifies the driver that the vehicle may be deviating from its lane.

The system detects the white or yellow lines on the traffic lane using the Forward Sensing Camera (FSC) and if it determines that the vehicle may be deviating from its lane, it notifies the driver using the active driving display (vehicles with active driving display), and by flashing the LDWS warning light and activating the LDWS warning beep.

Use the LDWS when you drive the vehicle on roads with white or yellow lines.

Refer to Forward Sensing Camera on page 4-174.



The warning light illuminates when the system has a malfunction.

Refer to Warning Lights on page 4-29.

### **WARNING**

***Do not use the LDWS under the following conditions:***

*The system may not operate adequately according to the actual driving conditions, resulting in an accident.*

- *Driving on roads with tight curves.*
- *Driving under bad weather conditions (rain, fog, and snow).*

**The functions of the LDWS have limitations:**

Always stay on course using the steering wheel and drive with care. The system is not designed to compensate for a driver's lack of caution and if you rely too much on the LDWS it could lead to an accident. The driver is responsible for assuring lane changes and other manoeuvres. Always pay attention to the direction in which the vehicle is travelling and the vehicle's surroundings.



Do not modify the suspension. If the vehicle height or the damping force of the suspensions is changed, the LDWS may not operate correctly.

**NOTE**

- If your vehicle deviates from its traffic lane, the LDWS operates (warning sound and indicator light). Steer the vehicle adequately to drive the vehicle to the centre of the lane.
- When the direction indicator lever is operated for a lane change, the LDWS warning is automatically cancelled. The LDWS warning becomes operable when the direction indicator lever is returned and the system detects the white or yellow lines.
- If the steering wheel, accelerator pedal, or brake pedal is operated abruptly and the vehicle moves close to a white or yellow line, the system determines that the driver is making a lane change and the LDWS warning is automatically cancelled.
- The LDWS may not operate during the period immediately after the vehicle has deviated from its lane and the LDWS has operated, or the vehicle deviates from its lane repeatedly within a short period of time.
- The LDWS does not operate if it does not detect the white or yellow lines of the traffic lane.
- Under the following conditions, the LDWS may not be able to detect white or yellow lines correctly and the LDWS may not operate correctly.
  - If an object placed on the instrument panel is reflected in the windscreen and picked up by the camera.
  - Heavy luggage is loaded in the luggage compartment or on the rear seat and the vehicle is inclined.
  - The tyre pressures are not adjusted to the specified pressure.
  - When the vehicle is driven on the entry and exit to or from the rest area or tollgate of a highway.
  - The white or yellow lines are less visible because of dirt or paint flaking.
  - The vehicle ahead is running near a white or yellow line and the line is less visible.
  - A white or yellow line is less visible because of bad weather (rain, fog, or snow).
  - The vehicle is driven on a temporary lane or section with a closed lane due to construction.

- A misleading line is picked up on the road such as a temporary line for construction, or because of shade, lingering snow, or grooves filled with water.
- The surrounding brightness suddenly changes such as when entering or exiting a tunnel.
- The illumination of the headlights is weakened because of dirt or the optical axis is deviated.
- The windscreen is dirty or foggy.
- Back-light is reflecting from the road surface.
- The road surface is wet and shiny after rain, or there are puddles on the road.
- The shade of a guardrail parallel to a white or yellow line is on the road.
- The width of a lane is excessively narrow or wide.
- The road is excessively uneven.
- The vehicle is shaken after hitting a road bump.
- There are two or more adjacent white or yellow lines.
- There are various road markings or lane markings of various shapes near an intersection.

### ▼ When The System Operates

1. The system goes on operation standby when the LDWS OFF switch is pressed and the LDWS OFF indicator light in the instrument cluster turns off.



2. Drive the vehicle in the centre of the driving lane while the LDWS OFF indicator light is turned off. The system becomes operational when all of the following conditions are met.

- The vehicle is driven in the centre of the driving lane with the white or yellow lines on the left and right sides, or on either side.
- The vehicle speed is about 70 km/h (44 mph) or faster.
- The vehicle is driven on a straight road or road with gentle curves.

The LDWS does not operate in the following cases:

- The system cannot detect white or yellow lines.
- The vehicle speed is less than about 65 km/h (40 mph).
- The vehicle is making a sharp turn.
- The vehicle is making a curve at an inadequate speed.

**NOTE**

- The LDWS does not operate until the system detects a white or yellow line on either the left or right.
- When the system detects a white or yellow line on one side only, the system will activate the warning only when the vehicle deviates on the side where the white or yellow line is being detected.
- The distance and warning sensitivity (likelihood of a warning) which the system uses to determine the possibility of a lane departure can be changed. Refer to Personalisation Features on page 9-8.

**Auto cancel**

In the following cases, the LDWS cancels automatically and the LDWS warning light in the instrument cluster turns on.

- The temperature inside the camera is high or low.
- The windscreen around the camera is foggy.
- The windscreen around the camera is blocked by an obstruction, causing poor forward visibility.

The LDWS is enabled automatically when the operation conditions are met, and the LDWS warning light turns off.

**Auto cancel warning**

When the following operations are performed, the LDWS determines that the driver intends to make a lane change and the LDWS warning is cancelled automatically. The LDWS is enabled automatically after the driver performs the operation.

- The steering wheel is operated abruptly.

- The brake pedal is depressed abruptly.
- The accelerator pedal is depressed abruptly.
- The direction indicator lever is operated (after the direction indicator lever is returned, the LDWS may not operate for about 3 seconds which is the period of time required to make a lane correction).

**NOTE**

After about 60 seconds have elapsed with the direction indicator lever left operating, the LDWS warning may operate if the vehicle is close to a white or yellow line.

**▼ Cancelling The System**


Press the LDWS OFF switch to cancel the LDWS. The LDWS OFF indicator light turns on.

**▼ LDWS Warning**

If the system determines that there is the possibility of a lane departure, the LDWS warning beep activates and the LDWS warning light flashes. Operate the steering wheel appropriately and steer the vehicle to the centre of the lane.

For vehicles equipped with the active driving display, if there is the possibility of a lane departure, the system indicates the direction it determines that the vehicle is deviating in the active driving display.

### Indication on display




#### NOTE

- If the LDWS warning sound is set to rumble<sup>\*1</sup>, the sound will be heard from the vehicle speaker on the side which the system determined the vehicle may be deviating from its lane.
- It may be difficult to hear the LDWS warning beep depending on the surrounding conditions such as outside noise.
- The volume of the LDWS warning sound can be changed.  
Refer to Personalisation Features on page 9-8.
- The type of warning sound (rumble<sup>\*1</sup>/beep) on the LDWS can be changed.  
Refer to Personalisation Features on page 9-8.

<sup>\*1</sup> A rumble strip is a series of grooves in the road pavement surface positioned at specific intervals, and when the vehicle passes over it a vibration and rumble sound is produced which alerts the driver that the vehicle is departing from the lane.

The rumble sound is a reproduction of the sound which occurs when a vehicle passes over a rumble strip.



## Distance Recognition Support System (DRSS)\*

The DRSS measures the distance between your vehicle and a vehicle ahead using a radar sensor (front) while the vehicle speed is about 30 km/h (19 mph) or faster, and if your vehicle approaches a vehicle ahead more closely than what is appropriate for maintaining distance between the vehicles according to the vehicle speed, a notification in the active driving display is indicated to advise you to keep a safe distance from the vehicle ahead.

### **WARNING**

***Do not rely completely on the DRSS and always drive carefully:***

*The ability to detect a vehicle ahead is limited depending on the type of vehicle ahead, the weather conditions, and the traffic conditions. Therefore, if the accelerator and brake pedals are not operated correctly it could lead to an accident. Always verify the safety of the surrounding area and depress the brake pedal or accelerator pedal while keeping a safer distance from vehicles ahead or on-coming vehicles.*

### **NOTE**

- The DRSS operates when all of the following conditions are met:
  - The ignition is switched ON.
  - The DRSS is on.
  - The selector lever is in a position other than reverse (R).
  - The vehicle speed is 30 km/h or faster (19 mph or faster).
- The objects which activate the system are 4-wheeled vehicles.
- The DRSS may also operate in the presence of motorcycles and bicycles.
- The DRSS may not operate normally under the following conditions:
  - The Dynamic Stability Control (DSC) has a malfunction.
  - The vehicle ahead is travelling at an extremely slow speed.
- The system does not operate with the following objects:
  - Vehicles approaching in the opposite direction.
  - Stationary objects (stopped vehicles, obstructions)

### **▼ Indication on Display**


The DRSS operation status is indicated in the active driving display. Regarding malfunctions, check the vehicle conditions or have it inspected by an expert repairer (we recommend an Authorised Mazda Repairer) according to the content of the displayed message.

Refer to Warning/Indicator Lights on page 4-29.

\*Some models.

## NOTE

- When the ignition is switched off, the operation status before the system was turned off is maintained. For example, if the ignition is switched off with the DRSS operable, the system will be operable when the ignition is switched ON the next time.
- The DRSS can be turned on/off and the system's sensitivity can be changed.  
Refer to Personalisation Features on page 9-8.



## Distance-between-vehicles guidelines\*1

| Display                                                                                                                   | Distance between vehicles guidelines<br>(During travel at about 40 km/h<br>(25 mph)) | Distance between vehicles guidelines<br>(During travel at about 80 km/h<br>(50 mph)) |
|---------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------|
| <div> Illuminated in<br/>amber  </div> | About 10 m (32 ft) or less                                                           | About 20 m (65 ft) or less                                                           |

\*1 The distance between vehicles differs depending on vehicle speed.




## Blind Spot Monitoring (BSM)\*

The BSM is designed to assist the driver in checking the area to the rear of the vehicle on both sides during lane changes by notifying the driver of the presence of vehicles approaching from the rear in an adjacent lane.

The BSM detects vehicles approaching from the rear while travelling in the forward direction at a speed of 10 km/h (6.3 mph) or faster and notifies the driver by turning on the BSM warning indicator light and displaying the vehicle detection screen (vehicles with active driving display).

If the direction indicator lever is operated to signal a turn in the direction in which the BSM warning indicator light is illuminated while the approaching vehicle is detected, the BSM notifies the driver of possible danger by turning on the BSM warning indicator light, and by activating the warning sound and the warning screen indicator display (vehicles with active driving display).

The detection area on this system covers the driving lanes on both sides of the vehicle and from the rear part of the front doors to about 50 m (164 ft) behind the vehicle.



### **WARNING**

***Always check the surrounding area visually before making an actual lane change:***

*The system is only designed to assist you in checking for vehicles at your rear when making a lane change. Due to certain limitations with the operation of this system, the BSM warning indicator light, the warning sound and the warning screen indicator display may not activate or they might be delayed even though a vehicle is in an adjacent driving lane. Always make it your responsibility as a driver to check the rear.*

\*Some models. **4-89**


### NOTE

- The BSM will operate when all of the following conditions are met:
  - The ignition is switched ON.
  - The BSM OFF indicator light in the instrument cluster is turned off.
  - The vehicle speed is about 10 km/h (6.3 mph) or faster.
- The BSM will not operate under the following circumstances.
  - The vehicle speed falls below about 10 km/h (6.3 mph) even though the BSM OFF switch indicator light is turned off.
  - The shift lever (manual transaxle)/selector lever (automatic transaxle) is shifted to R position and the vehicle is reversing.
  - The turning radius is small (making a sharp turn, turning at intersections).
- In the following cases, the BSM OFF indicator light turns on and operation of the system is stopped. If the BSM OFF indicator light remains illuminated, have the vehicle inspected at an expert repairer (we recommend an Authorised Mazda Repairer) as soon as possible.
  - Some problem with the system including the BSM warning indicator lights is detected.
  - A large deviation in the installation position of a radar sensor (rear) on the vehicle has occurred.
  - There is a large accumulation of snow or ice on the rear bumper near a radar sensor (rear). Remove any snow, ice or mud on the rear bumper.
  - Driving on snow-covered roads for long periods.
  - The temperature near the radar sensors (rear) becomes extremely hot due to driving for long periods on slopes during the summer.
  - The battery voltage has decreased.
- Under the following conditions, the radar sensors (rear) cannot detect target objects or it may be difficult to detect them.
  - A vehicle is in the detection area at the rear in an adjacent driving lane but it does not approach. The BSM determines the condition based on radar detection data.
  - A vehicle is travelling alongside your vehicle at nearly the same speed for an extended period of time.
  - Vehicles approaching in the opposite direction.
  - A vehicle in an adjacent driving lane is attempting to pass your vehicle.
  - A vehicle is in an adjacent lane on a road with extremely wide driving lanes. The detection area of the radar sensors (rear) is set at the road width of expressways.

- In the following case, the flashing of the BSM warning indicator light, and the activation of the warning sound and the warning screen indicator display may not occur or they may be delayed.
  - A vehicle makes a lane change from a driving lane 2 lanes over to an adjacent lane.
  - Driving on steep slopes.
  - Crossing the summit of a hill or mountain pass.
  - When there is a difference in the height between your driving lane and the adjacent lane.
  - Directly after the BSM system becomes operable by changing the setting.
- If the road width is extremely narrow, vehicles 2 lanes over may be detected. The detection area of the radar sensors (rear) is set according to the road width of expressways.
- The BSM warning indicator light may turn on and the vehicle detection screen may be displayed in the display in reaction to stationary objects (guardrails, tunnels, sidewalks, and parked vehicles) on the road or the roadside.

Objects such as guardrails and concrete walls running alongside the vehicle.

Places where the width between guardrails or walls on each side of the vehicle narrows.



- A BSM warning indicator light may flash or the warning beep and the warning screen indicator display may be activated several times when making a turn at a city intersection.
- Turn off the BSM while pulling a trailer or while an accessory such as a bicycle carrier is installed to the rear of the vehicle. Otherwise, the radar's radio waves will be blocked causing the system to not operate normally.
- In the following cases, it may be difficult to view the illumination/flashing of the BSM warning indicator lights equipped on the door mirrors.
  - Snow or ice is adhering to the door mirrors.
  - The front door glass is fogged or covered in snow, frost or dirt.


- The system switches to the Rear Cross Traffic Alert function when the shift lever (manual transaxle) or the selector lever (automatic transaxle) is shifted to the reverse (R) position. Refer to Rear Cross Traffic Alert (RCTA) on page 4-103.

### ▼ Blind Spot Monitoring (BSM) Warning Indicator Lights/Blind Spot Monitoring (BSM) Warning BEEP

The BSM or Rear Cross Traffic Alert (RCTA) system notifies the driver of the presence of vehicles in adjacent lanes or at the rear of the vehicle using the BSM warning indicator light, the warning sound and the display indicator (vehicles with active driving display) (BSM) while the systems are operational.

#### BSM warning indicator lights

The BSM warning indicator lights are equipped on the left and right door mirrors. The warning indicator lights turn on when a vehicle approaching from the rear in an adjacent lane is detected.



When the ignition is switched ON, the warning indicator light turns on momentarily and then turns off after a few seconds.

#### **Forward driving (BSM operation)**

The BSM detects vehicles approaching from the rear and turns on the BSM warning indicator lights equipped on the door mirrors according to the conditions. Additionally, while a BSM warning indicator light is illuminated, if the direction indicator lever is operated to signal a turn in the direction in which the BSM warning indicator light is illuminated, the BSM warning indicator light flashes.

### **Reverse driving (Rear Cross Traffic Alert (RCTA) system operation)**

The Rear Cross Traffic Alert (RCTA) system detects vehicles approaching from the left and right of your vehicle and flashes the BSM warning indicator lights.

#### **Function for cancelling illumination dimmer**

If the BSM warning indicator lights turn on when the position lights are turned on, the brightness of the BSM warning indicator lights is dimmed.

If the BSM warning indicator lights are difficult to see due to glare from surrounding brightness when travelling on snow-covered roads or under foggy conditions, press the dimmer cancellation button to cancel the dimmer and increase the brightness of BSM warning indicator lights when they turn on.

Refer to Instrument Panel Illumination on page 4-22.

#### **Display indicator (Vehicles with active driving display)**

The detected approaching vehicle and warning are displayed in the active driving display when the vehicle is moving forward (BSM operational).



The detected direction is displayed with a detection indicator (white) when an approaching vehicle is detected. In addition, if the direction indicator lever is operated to signal a lane change while the vehicle is detected, the display changes the colour (amber) of the warning indicator.

#### **BSM warning beep**

The BSM warning beep is activated simultaneously with the flashing of a BSM warning indicator light.


### ▼ Cancelling Operation of Blind Spot Monitoring (BSM)

The Blind Spot Monitoring (BSM) and Rear Cross Traffic Alert (RCTA) systems are turned off and the Blind Spot Monitoring (BSM) OFF indicator light in the instrument cluster turns on.



#### Vehicles with Blind Spot Monitoring (BSM) OFF switch

When the Blind Spot Monitoring (BSM) OFF switch is pressed, the Blind Spot Monitoring (BSM) and Rear Cross Traffic Alert (RCTA) systems are turned off and the Blind Spot Monitoring (BSM) OFF indicator light in the instrument cluster turns on.



If the switch is pressed again, the Blind Spot Monitoring (BSM) and Rear Cross Traffic Alert (RCTA) systems become operable and the Blind Spot Monitoring (BSM) OFF indicator light turns off.

#### **NOTE**

*When the ignition is switched OFF, the system status before it was turned off is maintained. For example, if the ignition is switched OFF while the Blind Spot Monitoring (BSM) and Rear Cross Traffic Alert (RCTA) systems are operable, the Blind Spot Monitoring (BSM) and Rear Cross Traffic Alert (RCTA) systems remain operable the next time the ignition is switched ON.*

#### Vehicles without Blind Spot Monitoring (BSM) OFF switch

The Blind Spot Monitoring (BSM) system can be set to inoperable.

Refer to Personalisation Features on page 9-8.

When the Blind Spot Monitoring (BSM) is set to inoperable, the Blind Spot Monitoring (BSM) and Rear Cross Traffic Alert (RCTA) systems are turned off and the Blind Spot Monitoring (BSM) OFF indicator light in the instrument cluster turns on.

#### **NOTE**

*When the ignition is switched OFF, the system status before it was turned off is maintained. For example, if the ignition is switched OFF while the Blind Spot Monitoring (BSM) and Rear Cross Traffic Alert (RCTA) systems are operational, the Blind Spot Monitoring (BSM) and Rear Cross Traffic Alert (RCTA) systems remain operational the next time the ignition is switched ON.*

## Traffic Sign Recognition System (TSR)\*

The TSR helps prevent the driver from overlooking traffic signs, and provides support for safer driving by displaying traffic signs on the active driving display which are recognised by the Forward Sensing Camera (FSC) or recorded in the navigation system while the vehicle is driven.


The TSR displays the speed limit (including auxiliary signs), do not enter, and traffic stop signs.

If the vehicle speed exceeds the speed limit sign indicated in the active driving display while the vehicle is driven, the system notifies the driver using the indication in the active driving display and a warning sound.

### NOTE


- The TSR is not supported in some countries or regions. For information concerning the supported countries or regions, consult an expert repairer (we recommend an Authorised Mazda Repairer).
- The TSR operates only if the navigation system SD card (Mazda genuine) is inserted in the SD card slot. Consult an expert repairer (we recommend an Authorised Mazda Repairer) for details.

### Speed limit signs (including auxiliary signs) and do not enter signs



\*Some models.

### Stop sign



### WARNING

**Always check the traffic signs visually while driving.**

The TSR helps prevent the driver from overlooking traffic signs and provides support for safer driving. Depending on the weather conditions or problems with traffic signs, a traffic sign may not be recognised or a traffic sign different from the actual traffic sign may be displayed. Always make it your responsibility as a driver to check the actual traffic signs. Otherwise, it could result in an accident.

### NOTE

- The TSR does not operate if there is a malfunction in the Forward Sensing Camera (FSC).
- Under the following conditions, the TSR may not operate normally.
  - An object placed on the instrument panel is reflected in the windscreen and picked up by the camera.
  - Heavy luggage is loaded in the luggage compartment or on the rear seat and the vehicle is tilted.
  - The tyre pressures are not adjusted to the specified pressure.
  - Tyres other than standard tyres are equipped.
  - The vehicle is driven on the ramp and surrounding area to or from a rest area or a tollgate on a highway.
  - When surrounding brightness suddenly changes such as when entering or exiting a tunnel.
  - The illumination of the headlights is weakened because of dirt or the optical axis is deviated.
  - The windscreen is dirty or foggy.
  - The windscreen and camera are fogged (water droplets).



- Strong light is directed at the front of the vehicle (such as backlight or high-beam headlights of on-coming vehicles).
- The vehicle is making a sharp turn.
- Strong light reflects off the road.
- A traffic sign is in a position which makes it difficult to reflect the light from the vehicle's headlights, such as when the vehicle is driven at night or in a tunnel.
- The vehicle is driven under weather conditions such as rain, fog, or snow.
- The stored map data for the navigation system is not current.
- A traffic sign is obscured by mud or snow.
- A traffic sign is concealed by trees or a vehicle.
- A traffic sign is partially shaded.
- A traffic sign is bent or warped.
- A traffic sign is too low or too high.
- A traffic sign is too bright or too dark (including electronic traffic signs).
- A traffic sign is too big or too small.
- There is an object similar to the traffic sign being read (such as another traffic sign or other signs resembling it).
- The TSR does not operate if the active driving display is set to non-display.

#### ▼ Traffic Sign Display Indication

The following traffic signs are displayed on the active driving display.

#### Speed limit signs (including auxiliary signs)

Speed limit signs



Auxiliary sign (example)

If the Forward Sensing Camera (FSC) cannot classify an auxiliary sign (such as time restrictions, turning restrictions, end of section) correctly, the following screen is displayed.



#### Inclement weather speed limit sign



#### Do not enter signs



#### Stop signs



#### NOTE

#### Speed limit signs (including auxiliary signs)

- When the vehicle speed is about 1 km/h (0.6 mph) or faster, the speed limit sign is displayed when any one of the following conditions are met.

- *The Forward Sensing Camera (FSC) recognises a speed limit sign as a sign targeted for your vehicle and the vehicle passes it.*
- *The speed limit sign stored in the navigation system is read.*
- *Inclement weather speed limit signs are displayed when all of the following conditions are met.*
  - *The vehicle speed is about 1 km/h (0.6 mph) or more.*
  - *The Forward Sensing Camera (FSC) recognises an inclement weather speed limit sign as a sign targeted for your vehicle and the vehicle passes it.*
  - *The inclement weather speed limit sign is lower than the currently displayed speed limit sign.*
  - *The windscreen wipers are operated.*
- *In the following cases, display of the speed limit sign stops.*
  - *The Forward Sensing Camera (FSC) recognises a new speed limit sign which differs from the previous one (displays the new speed limit sign).*

**Do not enter signs**

- *A do not enter sign is displayed when all of the following conditions are met.*
  - *The vehicle speed is about 80 km/h (50 mph) or slower.*
  - *The Forward Sensing Camera (FSC) recognises a do not enter sign as a sign targeted for your vehicle and the vehicle passes it.*
  - *A speed limit sign with an auxiliary sign is not recognised.*


- *When the Forward Sensing Camera (FSC) recognises the do not enter sign and a certain period of time has elapsed since the vehicle passed the sign, display of the do not enter sign stops.*

**Stop sign**

- *A stop sign is displayed when all of the following conditions are met:*
  - *The vehicle speed is about 30 km/h (19 mph) or slower.*
  - *The Forward Sensing Camera (FSC) recognises a stop sign as a sign targeted for your vehicle.*
- *When a certain period of time has elapsed since the stop sign was displayed, display of the stop sign stops.*
- *A speed limit sign with an auxiliary sign is not recognised.*

### ▼ Excessive Speed Warning

If the vehicle speed exceeds the speed limit sign displayed in the active driving display, the area around the speed limit sign flashes 10 times in amber and the warning sound is activated 3 times at the same time. If the vehicle speed continues to exceed the displayed speed limit sign, the indication stops flashing and remains on. Check the surrounding conditions and adjust the vehicle speed to the legal speed using the appropriate operation such as depressing the brake pedal.



The warning pattern and the warning activation timing differ depending on the setting contents.

Refer to Personalisation Features on page 9-8.

#### **Warning pattern**

- Off: The excessive speed warning is not activated.
- Visual: The area around the speed limit sign displayed in the display flashes 10 times in amber, and if the vehicle speed continues to exceed the displayed speed limit sign, the indication stops flashing and remains on.
- Audio & Visual: The area around the speed limit sign displayed in the display flashes 10 times in amber and the warning sound is activated 3 times at the same time. If the vehicle speed continues to exceed the displayed speed limit sign, the indication stops flashing and remains on.

### **Warning activation timing**

- **+ 0:** If the vehicle speed exceeds the speed limit sign displayed in the display, the excessive speed warning is activated.
- **+ 5:** If the vehicle speed exceeds the speed limit sign displayed in the display by 5 km/h (3 mph), the excessive speed warning is activated.
- **+ 10:** If the vehicle speed exceeds the speed limit sign displayed in the display by 10 km/h (5 mph), the excessive speed warning is activated.

### **NOTE**

- *In the following cases, the excessive speed warning stops operating.*
  - *The vehicle speed is less than the speed of the displayed speed limit sign. (If the activation timing for the excessive speed warning is changed in the personalisation features, the excessive speed warning stops operating when the vehicle speed is less than the changed vehicle speed.*
  - *A speed limit sign indication has been updated and the vehicle speed is lower than the updated indication.*
  - *Display of the speed limit sign stops.*
- *The warning indication is displayed at the same time the excessive speed warning sound is activated if the vehicle speed exceeds the speed indicated on the speed limit sign. Refer to Warning Sound is Activated on page 7-37.*
- *The TSR can recognise a speed limit sign with an auxiliary sign and display it, but it cannot determine the indication on the auxiliary sign (such as time restrictions, turning restrictions, end of section). Therefore, the excessive speed warning is activated when the vehicle speed exceeds the displayed speed limit sign even if the conditions indicated on the auxiliary sign do not apply to the vehicle.*
- *If the Forward Sensing Camera (FSC) incorrectly recognises the actual speed limit sign at a lower speed, the excessive speed alarm is activated even if the vehicle is driven at the legal speed.*


## Driver Attention Alert (DAA)\*

The DAA is a system which detects driver fatigue and decreased attentiveness, and encourages the driver to take a rest.

When the vehicle is driven inside traffic lane lines at about 65 to 140 km/h (40 to 86 mph), the DAA estimates the amount of accumulated fatigue and decreased attentiveness of the driver based on the information from the Forward Sensing Camera (FSC) and other vehicle information, and encourages the driver to take a rest using an indication on the active driving display and a warning sound.

Use the DAA on expressways or highways.

Refer to Forward Sensing Camera (FSC) on page 4-174.



### **WARNING**

***Do not rely completely on DAA and always drive carefully:***

*The DAA detects driver fatigue and decreased attentiveness and encourages the driver to take a rest, however, it is not designed to prevent the vehicle from straying. If you rely too much on the DAA it could lead to an accident. Drive carefully and operate the steering wheel appropriately.*

*In addition, the system may not be able to detect driver fatigue and decreased attentiveness correctly depending on the traffic and driving conditions. The driver must take sufficient rest in consideration of safer driving.*

### NOTE

- The DAA operates when all of the following conditions are met.
  - The vehicle speed is about 65 to 140 km/h (40 to 86 mph).
  - The system detects white (yellow) lane lines.
  - The system has completed learning of the driver's driving data.
- The DAA does not operate under the following conditions.
  - The vehicle speed is less than about 65 km/h (40 mph).
  - The vehicle speed exceeds about 140 km/h (86 mph)
  - The vehicle is making a sharp turn.
  - The vehicle is changing lanes.
  - The system cannot detect white (yellow) lane lines.
- The DAA may not operate normally under the following conditions.
  - White (yellow) lane lines are less visible because of dirt or fading/patchiness.
  - The vehicle is jolted or swayed continuously by strong winds or rough roads.
  - The vehicle is driven aggressively.
  - When making frequent lane changes.
- The DAA detects driver fatigue and decreased attentiveness based on the driving data when the vehicle is driven at about 65 to 140 km/h (40 to 86 mph) for about 20 minutes. The driving data will be reset under the following conditions.
  - The vehicle is stopped for 15 minutes or longer.
  - The vehicle is driven at less than about 65 km/h (40 mph) for about 30 minutes.
  - The ignition is switched off.
- After the DAA has displayed the first message encouraging rest, it does not display the next one until 45 minutes have passed.

#### ▼ Driver Attention Alert (DAA) Display (White)

When the system detects driver fatigue or decreased attentiveness, it activates the warning sound and displays an alert in the active driving display.



**Time for a break**


#### ▼ Cancelling Driver Attention Alert (DAA)

The DAA can be set to not activate.  
Refer to Personalisation Features on page 9-8.

## Rear Cross Traffic Alert (RCTA)\*

The RCTA system is designed to assist the driver in checking the area to the rear of the vehicle on both sides while the vehicle is reversing by alerting the driver to the presence of vehicles approaching the rear of the vehicle.

The RCTA system detects vehicles approaching from the rear left and right sides of the vehicle, and the rear of the vehicle while the vehicle is being reversed out of a parking space, and notifies the driver of possible danger using the Blind Spot Monitoring (BSM) warning indicator lights and the warning buzzer.



### RCTA operation

1. The RCTA system operates when the shift lever (manual transaxle) or the selector lever (automatic transaxle) is shifted to the reverse (R) position.


2. If there is the possibility of a collision with an approaching vehicle, the Blind Spot Monitoring (BSM) warning indicator lights flashes and the warning beep is activated simultaneously.

**(With rear view monitor)**

The RCTA warning indication in the rearview monitor also synchronizes with the Blind Spot Monitoring (BSM) warning indicator light on the door mirrors.

**(With 360° view monitor)**

The RCTA warning indication in the 360° view monitor also synchronizes with the Blind Spot Monitoring (BSM) warning indicator light on the door mirrors.



### WARNING

**Always check the surrounding area visually before actually putting the vehicle in reverse:**


The system is only designed to assist you in checking for vehicles at the rear when putting the vehicle in reverse. Due to certain limitations with the operation of this system, the Blind Spot Monitoring (BSM) warning indicator lights may not flash or it might be delayed even though a vehicle is behind your vehicle. Always make it your responsibility as a driver to check the rear.

### NOTE


- In the following cases, the Blind Spot Monitoring (BSM) OFF indicator light turns on and operation of the system is stopped. If the Blind Spot Monitoring (BSM) OFF indicator light remains illuminated, have the vehicle inspected at an expert repairer (we recommend an Authorised Mazda Repairer) as soon as possible.




- Some problem with the system including the Blind Spot Monitoring (BSM) warning indicator lights has occurred.
- A large deviation in the installation position of a radar sensor (rear) on the vehicle has occurred.
- There is a large accumulation of snow or ice on the rear bumper near a radar sensor (rear).
- Driving on snow-covered roads for long periods.
- The temperature near the radar sensors becomes extremely hot due to driving for long periods on slopes during the summer.
- The battery voltage has decreased.
- Under the following conditions, the radar sensors (rear) cannot detect target objects or it may be difficult to detect them.
  - The vehicle speed when reversing is about 10 km/h (6.3 mph) or faster.
  - The radar sensor (rear) detection area is obstructed by a nearby wall or parked vehicle. (Reverse the vehicle to a position where the radar sensor detection area is no longer obstructed.)



- A vehicle is approaching directly from the rear of your vehicle.



- The vehicle is parked at an angle.



- Directly after the Blind Spot Monitoring (BSM) system becomes operable using the personalisation feature.
- Radio wave interference from a radar sensor equipped on a nearby parked vehicle.

When Driving

## **i-ACTIVSENSE**

---

- *In the following cases, it may be difficult to view the illumination/flashing of the Blind Spot Monitoring (BSM) warning indicator lights equipped on the door mirrors.*
  - *Snow or ice adheres to the door mirrors.*
  - *The front door glass is fogged or covered in snow, frost or dirt.*
- *Turn off the RCTA system while pulling a trailer or while an accessory such as a bicycle carrier is installed to the rear of the vehicle. Otherwise, the radio waves emitted by the radar will be blocked causing the system to not operate normally.*

## Mazda Radar Cruise Control (MRCC)\*

The MRCC system is designed to maintain headway control\*<sup>1</sup> according to the vehicle speed using a radar sensor (front) to detect the distance to a vehicle ahead, and by presetting the vehicle speed between 30 km/h (19 mph) and 145 km/h (90 mph), the driver is freed from having to constantly use the accelerator or brake pedals.

\*<sup>1</sup> Headway Control: Control of the distance between your vehicle and the vehicle ahead detected by the MRCC system.

Additionally, if your vehicle starts closing in on the vehicle ahead because, for example, the vehicle ahead brakes suddenly, a warning sound and a warning indication in the display are activated simultaneously to alert you to maintain a sufficient distance between the vehicles. Use the MRCC system on expressways and other highways which do not require a lot of repeated acceleration and deceleration.

### **WARNING**

***Do not rely completely on the MRCC system and always drive carefully:***

*The MRCC system is designed to reduce load on the driver, and although it maintains a constant vehicle speed, or specifically, it maintains a constant distance between your vehicle and the detected vehicle ahead according to the vehicle speed, the system has detection limitations depending on the type of vehicle ahead and its conditions, the weather conditions, and the road conditions. Additionally, the system may be unable to decelerate sufficiently to avoid hitting the vehicle ahead if the vehicle ahead applies the brakes suddenly or another vehicle cuts into the driving lane, which could result in an accident. Always verify the safety of the surrounding area and depress the brake pedal or accelerator pedal while keeping a safer distance from vehicles ahead or on-coming vehicles.*

***Do not use the MRCC system in the following locations. Otherwise, it could lead to an accident:***

- *Roads with sharp curves and where vehicle traffic is heavy and there is insufficient space between vehicles. Roads where frequent and repetitive acceleration and deceleration occur (Driving under these conditions using the MRCC system is not possible).*
- *When entering and exiting interchanges, service areas, and parking areas of highways (If you exit a highway while headway control is in use, the vehicle ahead will no longer be tracked and your vehicle may accelerate to the set speed).*
- *Slippery roads such as ice or snow-bound roads (The tyres could spin causing you to lose vehicle control).*
- *Long descending slopes (to maintain distance between vehicles, the system automatically and continuously applies the brakes which could result in the loss of brake power).*

**For the purposes of safety, switch the MRCC system off when it is not being used.**



*If the vehicle is towed or you are towing something, switch the MRCC system off to prevent an incorrect operation.*

### **NOTE**

*• The MRCC system operates when all of the following conditions are met.*

- The vehicle speed is about 30 km/h (19 mph) to 145 km/h (90 mph).*
- The MRCC system is turned on.*
- The parking brake is not applied.*
- The Smart Brake Support (SBS) is not malfunctioning.*
- The Dynamic Stability Control (DSC) is operating normally.*
- All doors are closed.*
- The driver's seat belt is fastened.*

#### **(Manual transaxle)**

- The shift lever is in a position other than reverse (R) or neutral (N).*
- The clutch pedal is not depressed.*


#### **(Automatic transaxle)**

- The selector lever is in the drive (D) position or manual (M) position (manual mode).*
- In the following cases, the warnings may not activate even if your vehicle starts closing in on the vehicle ahead.*
  - You are driving at the same speed as the vehicle ahead.*
  - Directly after the MRCC system has been set.*
  - When the accelerator pedal is depressed or directly after the accelerator pedal is released.*
  - Another vehicle cuts into the driving lane.*
- The following are not detected as physical objects.*
  - Vehicles approaching in the opposite direction*
  - Pedestrians*
  - Stationary objects (stopped vehicles, obstructions)*
- If a vehicle ahead is travelling at an extremely low speed, the system may not detect it correctly.*
- During headway control travel, do not set the system on two-wheeled vehicles such as motorcycles and bicycles.*
- Do not use the MRCC system under conditions in which the close proximity warnings are frequently activated.*

- During headway control travel, the system accelerates and decelerates your vehicle in conjunction with the speed of the vehicle ahead. However, if it is necessary to accelerate for a lane change or if the vehicle ahead brakes suddenly causing you to close in on the vehicle rapidly, accelerate using the accelerator pedal or decelerate using the brake pedal depending on the conditions.
- While the MRCC system is in use, it does not cancel even if the selector lever (automatic transaxle)/shift lever (manual transaxle) is operated and any intended engine braking will not occur. If deceleration is required, lower the vehicle speed setting or depress the brake pedal.
- The brake lights are illuminated while the MRCC automatic braking is operating, however, they may not be illuminated while the vehicle is on a down slope at the set vehicle speed or travelling at a constant speed and following a vehicle ahead.
- The MRCC warning light (amber) illuminates when the system has a malfunction. Refer to Warning Lights on page 4-29.
- The headway control operation can be cancelled and the system can be switched to only cruise control. Refer to Cruise Control Function on page 4-114.

#### ▼ Mazda Radar Cruise Control (MRCC) Display Indication


The setting status and operation conditions of the MRCC system are indicated in the active driving display.



#### ▼ Close Proximity Warning

If your vehicle rapidly closes in on the vehicle ahead because the vehicle applies the brakes suddenly while you are travelling in headway control, the warning sound activates and the brake warning is indicated in the display. Always verify the safety of the surrounding area and depress the brake pedal while keeping a safer distance from the vehicle ahead. Additionally, always keep a safer distance from the vehicles behind you.

**BRAKE !**

**▼ Setting the System**


When the MODE switch is pressed, the MRCC main indication (white) turns on and the vehicle speed and the distance between vehicles while in headway control can be set.

**NOTE**

- When the ignition is switched to ACC or OFF while the MRCC is ON, the MRCC remains ON automatically.

**How to Set the Speed**

1. Adjust the vehicle speed to the desired setting using the accelerator pedal.
2. Headway control begins when the SET+ or SET- switch is pressed. The set speed and the inter-vehicle distance display filled with white lines are displayed. The MRCC set indication (green) is indicated simultaneously.



| Travel status                       | Display                                                                                  |
|-------------------------------------|------------------------------------------------------------------------------------------|
| During travel at constant speed     |  80 |
| During travel under headway control |  80   |

**NOTE**

- If a vehicle ahead is detected while travelling at a constant speed, the vehicle-ahead indication is displayed and headway control is performed. Additionally, when a vehicle ahead is no longer detected, the vehicle-ahead indication turns off and the system switches back to travel at constant speed.

- Headway control is not possible if the vehicle ahead is driving faster than the set speed.  
Adjust the system to the desired vehicle speed using the accelerator pedal.

**How to Set the Distance Between Vehicles During Headway Control**

The distance between vehicles is set to a shorter distance each time the ▼ switch is pressed. The distance between vehicles is set to a longer distance by pressing the ▲ switch. The distance-between-vehicles can be set to 4 levels; Long, medium, short, and extremely short distance.

| Distance-between-vehicles guideline<br>(at 80 km/h (50 mph) vehicle speed) | Display                                                                              |
|----------------------------------------------------------------------------|--------------------------------------------------------------------------------------|
| Long (about 50 m (164 ft))                                                 |    |
| Medium (about 40 m (131 ft))                                               |    |
| Short (about 30 m (98 ft))                                                 |   |
| Extremely short (about 25 m (82 ft))                                       |  |

**NOTE**

- The distance between vehicles differs depending on the vehicle speed, and the slower the vehicle speed, the shorter the distance.
- When the ignition is switched to ACC or OFF and then the engine is started again, the system automatically sets the distance between vehicles to the previous setting.

**Changing the Set Vehicle Speed****Changing the set vehicle speed using the SET switch**

Press the SET+ switch to accelerate.  
 Press the SET- switch to decelerate.  
 The set vehicle speed changes as follows each time the SET switch is pressed.

|             |                 |
|-------------|-----------------|
| Short press | 5 km/h (5 mph)  |
| Long press  | 10 km/h (5 mph) |

**NOTE**

*For example, the set vehicle speed is changed by pressing the SET switch four times as follows:*

*The vehicle speed accelerates or decelerates by 20 km/h (20 mph).*

**To accelerate using the accelerator pedal**

Depress the accelerator pedal and press and release the SET+ or SET- switch at the desired speed. If a switch cannot be operated, the system returns to the set speed when you release your foot from the accelerator pedal.



*The warnings and brake control do not operate while the accelerator pedal is depressed.*

**NOTE**

- When accelerating using the SET+ switch while in headway control, the set vehicle speed can be adjusted but acceleration is not possible. If there is no longer a vehicle ahead, acceleration continues until reaching the set vehicle speed. Check the set vehicle speed by viewing the set vehicle speed display in the active driving display.
- While depressing the accelerator pedal, the colour of the MRCC indication changes from green to white.
- The minimum settable speed is 30 km/h (19 mph). If the set vehicle speed reaches 30 km/h (19 mph) using the switch operation, constant speed travel is maintained at about 30 km/h (19 mph) even if the SET- switch is pressed. The MRCC system is not cancelled.

**To Deactivate**

The MRCC is deactivated when the CANCEL switch is pressed twice.

**When the system is temporarily cancelled**

In the following cases, the MRCC is temporarily cancelled, the MRCC set indication (green) is turned off, and the MRCC main indication (white) is turned on.

- The CANCEL switch is pressed once.
- The brake pedal is depressed.
- The parking brake is applied.
- **(Automatic transaxle)**  
The selector lever is shifted to park (P), neutral (N) or reverse (R).



- **(Manual transaxle)**

The shift lever is in the reverse (R) position.

- In the following cases, the “MRCC cancelled” indication is displayed and the beep sounds one time.
  - The vehicle speed decreases to less than 25 km (16 mph).
  - The DSC has operated.
  - The TCS has operated for a certain period of time.
  - The Advanced Smart City Brake Support (Advanced SCBS) has operated.
  - The Smart Brake Support (SBS) has operated.
  - When travelling on a down slope for a long period of time.
  - There is a problem with the system.
  - Any door is opened.
  - The driver's seat belt is unfastened.

- **(Manual transaxle)**

- The shift lever is shifted to neutral (N) for a certain period of time.
- The clutch is depressed for a certain period of time.
- The engine stalls.

**NOTE**

- *The MRCC system may be cancelled during rain, fog, snow or other inclement weather conditions, or the front surface of the radiator grille is dirty.*
- *If you have temporarily cancelled the MRCC, you can return to your previously set speed by pressing the RES switch and after all of the operation conditions have been met.*

- *If the MRCC system is deactivated, the system does not return to the previously set speed even if the RES switch is pressed.*

**▼ Shift-up/Shift-down Request Display (Manual Transaxle)**

The shift-up or shift-down request display in the active driving display may be indicated while the MRCC is operating. When this occurs, shift gears because the gear position is not appropriate.

| Request    | Display                                                                            |
|------------|------------------------------------------------------------------------------------|
| Shift up   |  |
| Shift down |  |

**NOTE**

*If the gears are not shifted up even though the shift-up request indication is displayed, load will be applied to the engine and the MRCC system may be automatically cancelled or engine damage could occur.*

**▼ Cruise Control Function**

While this function is operating, the headway control operation is cancelled and only the cruise control function operates.

The vehicle speed can be set more than about 25 km/h (16 mph).

Use the cruise control function on expressways and other highways which do not require a lot of repeated acceleration and deceleration.

**⚠ WARNING****Do not use the cruise control function in the following locations:**

*Otherwise, it could lead to an accident.*

- Roads with sharp curves and where vehicle traffic is heavy and there is insufficient space between vehicles. (Driving under these conditions using the cruise control function is not possible)
- Steep down slopes (Set speed may be exceeded because sufficient engine braking cannot be applied)
- Slippery roads such as ice or snow-bound roads (Tyres could spin causing you to lose vehicle control)

**Always drive carefully:**

*The warnings and brake control will not operate after the headway control function is cancelled and the system is switched to only the cruise control function. Depress the brake pedal to decelerate according to the surrounding conditions while keeping a safer distance from the vehicle ahead and always driving carefully.*

**Switching to cruise control function**

When the MODE switch is pressed until the system switches to the cruise main indication (white) while the MRCC system is turned on, the system switches to the cruise control function.

When the system switches to the cruise control function, the cruise main indication (white) is displayed in the instrument cluster and the active driving display to notify the driver as follows:

- The MRCC set indication (green) or the MRCC main indication (white) is turned off, and the cruise main indication (white) is turned on.

 **WARNING**
**Always turn off the cruise control function when it is not in use:**

*Leaving the cruise control function turned on when it is not in use is dangerous as it could operate unexpectedly, resulting in an accident.*

**How to set the speed**

Adjust the system to the desired vehicle speed using the accelerator pedal.

When the SET+ or SET− switch is pressed, the cruise set indication (green) is turned on and headway control begins.

**NOTE**

- *The system may not be able to maintain the set speed constantly depending on driving conditions such as steep up or down slopes.*
- *The speed will continue increasing while the SET+ switch is pressed and held. The speed will continue decreasing while the SET− switch is pressed and held.*

**How to increase the set speed**

The set speed can be increased using the following operations:

**To increase speed using the SET+ switch**

Press and hold the SET+ switch and release the switch at the desired speed.

The set speed can be adjusted incrementally (1 km/h (1 mph) increments) by pressing the switch and releasing it immediately. For example, if the switch is pressed 4 times, the set speed increases by about 4 km/h (4 mph).

**To increase speed using accelerator pedal**

Depress the accelerator pedal and press the SET+ or SET− switch at the desired speed.

If the switch is not operated, the system returns to the set speed after you release your foot from the accelerator pedal.

### **How to Decrease the Set Speed**

Press the SET $\leftarrow$  switch continuously and release the switch at the desired speed. The set speed can be adjusted incrementally (1 km/h (1 mph) increments) by pressing the switch and releasing it immediately. For example, if the switch is pressed 4 times, the set vehicle speed decreases by about 4 km/h (4 mph).

### **Cancelling the function**

When the cruise control function is cancelled and the RES switch is pressed while the vehicle speed is 25 km/h (16 mph) or faster, the speed returns to the original set speed.

### **Cancelling using OFF/CANCEL switch**

When the OFF/CANCEL switch is pressed once, the cruise control function is cancelled.

### **Automatically cancel**

The cruise control function is cancelled automatically in the following cases.

- The brake pedal is depressed.
- The parking brake is applied.

### **(Manual transaxle)**

- The clutch pedal is depressed.
- The shift lever is shifted to neutral position.

### **(Automatic transaxle)**

- The selector lever is shifted to P or N position.

### **NOTE**

- If the vehicle speed decreases by about 15 km/h (9.4 mph) or more than the set speed, the cruise control function may be cancelled.
- When the vehicle speed is less than 21 km/h (13 mph), the cruise control function is cancelled. In this case, the vehicle speed will not return to the original set speed even if the vehicle is accelerated to 25 km/h (16 mph) or faster and the RES switch is pressed. Reset the cruise control function.

## **Lane-keep Assist System (LAS) & Lane Departure Warning System (LDWS)\***

The LAS & LDWS alerts the driver that the vehicle may be deviating from its lane and it provides steering assistance to help the driver stay within the vehicle lanes. The Forward Sensing Camera (FSC) detects the white lines (yellow lines) of the vehicle lane in which the vehicle is travelling and if the system determines that the vehicle may deviate from its lane, it operates the electric power steering to assist the driver's steering operation. The system also alerts the driver by activating a lane departure warning sound, vibrating the steering wheel, and indicating an alert in the display. Use the system when you drive the vehicle on roads with white (yellow) lines such as expressways and highways. Refer to Forward Sensing Camera (FSC) on page 4-174.

The steering wheel operation of the LAS & LDWS has “Late” and “Early” steering assist timing settings.

For the “Late” setting, the system assists the driver's steering operation if there is the possibility of the vehicle deviating from its lane.

For the “Early” setting, the system assists the driver's steering operation constantly so that the vehicle stays near the centre of the vehicle lane.

### **Vehicles with type A audio**

Operates only under the “Late” condition.

“Late” and “Early” cannot be switched (timing at which steering operation assist is provided).

### **Vehicles with type B audio**

“Late” and “Early” timing can be changed (timing at which steering operation assist is provided) by changing the setting.


Refer to Personalisation Features on page 9-8.

When Driving


## i-ACTIVSENSE

The LDWS specification differs depending on whether the LAS is equipped or not. If your vehicle is not equipped with the LAS, refer to the Lane Departure Warning System (LDWS) on page 4-82.

"Late" function



"Early" function



### **WARNING**

#### **Do not rely completely on the LAS & LDWS:**

- The LAS & LDWS is not an automatic driving system. In addition, the system is not designed to compensate for a driver's lack of caution, and over-reliance on the system could lead to an accident.
- The detection ability of the LAS & LDWS is limited. Always stay on course using the steering wheel and drive with care.

#### **Do not use the LAS & LDWS in the following cases:**

The system may not operate adequately according to the actual driving conditions, resulting in an accident.

- Driving on roads with tight curves.
- Driving under bad weather conditions (rain, fog, and snow).
- Slippery roads such as ice or snow-bound roads.
- Roads with heavy traffic and insufficient distance between vehicles.
- Roads with no white (yellow) lane lines.
- Narrow roads resulting from road construction or lane closures.
- The vehicle is driven on a temporary lane or section with a closed lane resulting from road construction where there may be multiple white (yellow) lane lines or they are interrupted.
- Vehicle is driven on roads other than expressways and highways.

4-118

- The tyre pressures are not adjusted to the specified pressure.
- Tyres of a different specified size are used, such as an emergency spare tyre.

 **CAUTION**

Heed the following cautions so that the LAS & LDWS can operate normally.

- Do not modify the suspensions.
- Always use wheels of the specified type and size for the front and rear wheels. Consult an expert repairer (we recommend an Authorised Mazda Repairer) for tyre replacement.

**NOTE**

- When the direction indicator lever is operated for a lane change, the LAS & LDWS is automatically disabled. The LAS & LDWS becomes operational again when the direction indicator lever is returned and the system detects white (yellow) lane lines while the vehicle is being driven normally within its vehicle lane.
- If the steering wheel, accelerator pedal, or brake pedal is operated abruptly and the vehicle moves close to a white (yellow) line, the system determines that the driver is making a lane change and the LAS & LDWS operation is temporarily cancelled. The LAS & LDWS becomes operational again when the system detects white (yellow) lane lines while the vehicle is being driven normally within its vehicle lane.
- If the vehicle deviates from its lane repeatedly within a short period of time, the LAS & LDWS may not operate.
- When white (yellow) lane lines are not detected, the LAS & LDWS does not operate.
- Under the following conditions, the LAS & LDWS may not be able to detect white (yellow) lane lines correctly and it may not operate normally.
  - If an object placed on the instrument panel is reflected in the windscreen and picked up by the camera.
  - Heavy luggage is loaded in the luggage compartment or on the rear seat and the vehicle is tilted.
  - The tyre pressures are not adjusted to the specified pressure.
  - Tyres other than conventional tyres are equipped.
  - Vehicle is driven on an intersection or junction, or on a forked road.
  - The white (yellow) lane lines are less visible because of dirt or fading/patchiness.
  - A vehicle in front of your vehicle is running near a white (yellow) lane line making it less visible.
  - A white (yellow) lane line is less visible because of bad weather (rain, fog, or snow).
  - The vehicle is driven on a temporary lane or section with a closed lane resulting from construction where there may be multiple white (yellow) lane lines or they are interrupted.

- A misleading line is picked up on the road such as a temporary line for construction, or because of shade, lingering snow, or grooves filled with water.
- The surrounding brightness suddenly changes such as when entering or exiting a tunnel.
- The illumination of the headlights is weakened because of dirt or the optical axis is deviated.
- The windscreen is dirty or foggy.
- The windscreen, camera is fogged (water droplets).
- Back-light is reflected off the road surface.
- The road surface is wet and shiny after rain, or there are puddles on the road.
- The shade of a guardrail parallel to a white (yellow) lane line is cast on the road.
- The width of the driving lane is narrow or wide.
- Driving on roads with tight curves.
- The road is excessively uneven.
- The vehicle is shaken after hitting a road bump.
- There are 2 or more adjacent white (yellow) lane lines.
- There are various road markings or lane markings of various shapes near an intersection.

### ▼ System Operation

If the LAS&LDWS OFF indicator light in the instrument cluster turns off when the ignition is switched ON, the system goes on standby.

If the LAS&LDWS OFF indicator light in the instrument cluster turns on when the ignition is switched ON, press the LAS&LDWS OFF switch so that the system goes on standby.



Drive the vehicle in the centre of the vehicle lane while the system is on standby. The system becomes operational when all of the following conditions are met.

- The engine is running.
- The vehicle speed is about 60 km/h (37 mph) or faster.



- The system detects white (yellow) lane lines.  
(If the system only detects a white (yellow) line on either the left or right, the steering wheel operation assist timing is “Late” and the system only operates for a departure in the direction being detected.)
- The driving lane is neither narrow nor wide.

The LAS&LDWS goes on stand-by status in the following cases:

- The system cannot detect white (yellow) lane lines.
- The vehicle speed is less than about 60 km/h (37 mph).
- The ABS/TCS/DSC is operating.
- The DSC is turned off.  
(If the DSC is turned off while the system is operational, a warning beep is heard and the system goes on standby.)
- The vehicle is making a sharp curve.
- The steering wheel is operated abruptly.
- The brake pedal is depressed.
- The width of a lane is excessively narrow or wide.


**NOTE**

- ***(When the timing of the steering assist is set to “Late”)***
  - *The LAS&LDWS does not operate until the system detects white (yellow) lane lines on either the left or right.*
  - *When the system detects a white (yellow) lane line on one side only, the system will not activate warnings for the lane line on the side that is not being detected. The warning is only for a lane deviation on the side that is being detected.*
- ***(When the timing of the steering assist is set to “Early”)***
  - *When the steering assist timing is set to “Early”, the LAS&LDWS does not operate until the system detects white (yellow) lane lines on the left and right. When the system only detects white (yellow) lane lines on either the left or right, the system only operates for a lane deviation on the side being detected.*
  - *The steering wheel operation assist is performed so that the vehicle remains near the centre of the driving lane, however, depending on conditions such as the road curvature, road slope and undulations, and vehicle speed, the system may not be able to keep the vehicle near the centre of the driving lane.*

## i-ACTIVSENSE

- If you take your hands off the steering wheel (not holding the steering wheel), the warning sound is activated and an alert is indicated in the active driving display or the warning light turns on in the instrument cluster.

### With Active Driving Display



### Without Active Driving Display




*If the steering wheel is held lightly, or depending on the road conditions, the system may detect that you have released the steering wheel (not holding the steering wheel) even if you are holding it, and display a message in the active driving display.*

- The timing at which the lane departure warning is activated and the steering wheel operation assist is performed varies.
- The following settings for the LAS&LDWS can be changed. Refer to Personalisation Features on page 9-8.
  - Steering operation assist operational/non-operational
  - Cancel sensitivity (likelihood of steering assist)

### Vehicle lane line display

When the LAS&LDWS detects white (yellow) lines on both the left and right sides and becomes operational, the vehicle lane lines are indicated in the active driving display or the LAS&LDWS indicator light turns on in the instrument cluster.

### With Active Driving Display



### Without Active Driving Display



### Auto cancel

In the following cases, the LAS&LDWS is automatically cancelled and the vehicle lane lines (stand-by) are indicated in the active driving display. In addition, when the LAS&LDWS becomes operational, the system turns back on automatically and the vehicle lane lines (operational) are indicated in the active driving display.

- The temperature inside the camera is high or low.
- The windscreen around the camera is foggy.
- The windscreen around the camera is blocked by an obstruction, causing poor forward visibility.

#### **Auto cancel of warning/steering assist**

When the following operations are performed, the LAS&LDWS operation is automatically cancelled. The LAS&LDWS is automatically re-enabled after the operation.

- The steering wheel is operated abruptly.
- The brake pedal is depressed.
- The accelerator pedal is suddenly depressed.  
(To cancel the automatic sensitivity cancel function, deselect “Cancel sensitivity” in the personalisation features setting.)
- The direction indicator lever is operated.
- The vehicle crosses a lane line.

#### ***NOTE***

- *After the operation, the LAS&LDWS operation may not operate for a period of 5 seconds at the most until the lane lines are detected.*
- *Under the following conditions, the LAS&LDWS cancels the warning/steering assist automatically.*
  - *The driver takes his/her hands off the steering wheel.*  
(The LAS&LDWS is designed to assist the driver's steering operation and it will resume operation automatically when the driver holds the steering wheel.)
  - *The DSC OFF switch is pressed to cancel the DSC.*

#### **Steering operation assist OFF (non-operational)**

The steering operation assist for the LAS&LDWS can be changed to non-operational (OFF). Refer to Setting Change (Personalisation Features) on page 9-8.

When the steering operation assist has been changed to inoperable (OFF), operate the LAS&LDWS as follows:

### System operation

If the LAS&LDWS OFF indicator light in the instrument cluster turns off when the ignition is switched ON, the system goes on standby.

If the LAS&LDWS OFF indicator light in the instrument cluster turns on when the ignition is switched ON, press the LAS&LDWS OFF switch so that the system goes on standby.



Drive the vehicle in the centre of the vehicle lane while the system is on standby. The system becomes operational when all of the following conditions are met.

- The system detects white (yellow) lane lines on both the right and left sides, or on either side.
- The vehicle speed is about 60 km/h (37 mph) or faster.
- The vehicle is driven on a straight road or road with gentle curves.
- The engine is running.

The LAS&LDWS goes on stand-by status in the following cases:

- The system cannot detect white (yellow) lane lines.
- The vehicle speed is less than about 60 km/h (37 mph).
- The vehicle is making a sharp curve.
- The vehicle is making a curve at an inappropriate speed.

### NOTE

- The LAS&LDWS remains on stand-by until it detects white (yellow) lines on both the left and right sides, or on either side.
- When the system detects a white (yellow) lane line on one side only, the system will not activate warnings for the lane line on the side that is not being detected.
- The distance and warning sensitivity (likelihood of a warning) which the system uses to determine the possibility of a lane departure can be changed.  
Refer to Setting Change (Personalisation Features) on page 9-8.

### **Vehicle lane line display**

When the LAS&LDWS detects white (yellow) lines on both the left and right sides and becomes operational, the vehicle lane lines are indicated in the active driving display.



### **Auto cancel**

Under the following conditions, the LAS&LDWS is automatically cancelled. The LAS&LDWS is automatically re-enabled when it becomes operational.

- The temperature inside the camera is high or low.
- The windscreen around the camera is foggy.
- The windscreen around the camera is blocked by an obstruction, causing poor forward visibility.

### **(Auto cancel of warnings)**

When the following operations are performed, the LAS&LDWS determines that the driver intends to make a lane change and the system operation is cancelled automatically. The LAS&LDWS resumes automatically after the operation.

- The steering wheel is operated abruptly.
  - The brake pedal is depressed.
  - The accelerator pedal is depressed.
- (To cancel the automatic sensitivity cancel function, deselect “Warning sensitivity” in the personalisation features setting.)
- The direction indicator lever is operated.
  - The vehicle crosses a lane line.

### ▼ System Cancelling

When the Lane-keep Assist System (LAS) & Lane Departure Warning System (LDWS) is turned off, press the Lane-keep Assist System (LAS) & Lane Departure Warning System (LDWS) OFF switch.



The Lane-keep Assist System (LAS) & Lane Departure Warning System (LDWS) OFF switch indicator light turns on.

#### **NOTE**

- In the following cases, the Lane-keep Assist System (LAS) & Lane Departure Warning System (LDWS) is cancelled automatically and the Lane-keep Assist System (LAS) & Lane Departure Warning System (LDWS) OFF indicator light turns on. Have your vehicle inspected at an expert repairer (we recommend an Authorised Mazda Repairer).
- There is a malfunction in the power steering.
- There is a malfunction in the DSC.
- There is a malfunction in the Forward Sensing Camera (FSC).

- When the ignition is switched OFF, the system status before it was turned off is maintained. For example, if the ignition is switched OFF with the lane-keep system operable, the system will be operable when the ignition is switched ON the next time.

When the Lane-keep Assist System (LAS) & Lane Departure Warning System (LDWS) is cancelled, the vehicle lane lines are no longer indicated in the active driving display.

### ▼ Lane Departure Warning


If the system determines that the vehicle may deviate from its lane, the lane departure warning (beep sound, rumble sound<sup>\*1</sup>, or steering wheel vibration) is activated and the direction in which the system determines that the vehicle may deviate is indicated in the active driving display.

If the system determines that the vehicle may deviate from its lane, the colour of the lane line on the side being detected by the system changes from white to amber, and flashes.

**Warning light (Flashes)**



**Active Driving Display**



#### **NOTE**

- If you have set the lane departure warning sound to the beep sound/rumble sound<sup>\*1</sup> setting, the warning sound may not be heard depending on the surrounding noise conditions.
- If you have set the lane departure warning system to the steering wheel vibrations setting, the vibration may not be felt depending on the road surface conditions.
- When the setting for the steering operation assist is changed to operational, the warnings can be set to activate/not activate. (When the setting for the steering operation assist is changed to non-operational, the warnings cannot be set to not activate.) Refer to Setting Change (Personalisation Features) on page 9-8.
- The LAS & LDWS can be changed to the following settings regardless of whether the steering operation assist has been set to operational/non-operational. Always check the setting status when driving the vehicle and make setting changes if necessary. Refer to Setting Change (Personalisation Features) on page 9-8.

- Steering wheel vibration: Strong/weak
- Warning sound volume
- Types of warnings (steering wheel vibration/beep sound/rumble sound<sup>\*1</sup>)


<sup>\*1</sup> A rumble strip is a series of grooves in the road pavement surface positioned at specific intervals, and when the vehicle passes over it a vibration and rumble sound is produced which alerts the driver that the vehicle is departing from the lane.

When Driving

## i-ACTIVSENSE

---

*The rumble sound is a reproduction of the sound which occurs when a vehicle passes over a rumble strip.*





## Adjustable Speed Limiter (ASL)\*

The ASL is a function to prevent the vehicle from being driven at a vehicle speed faster than a set speed. The vehicle speed is controlled to keep it below the set speed even if the accelerator pedal is depressed.

The ASL can be set between 30 km/h (20 mph) and 200 km/h (125 mph). The vehicle speed may exceed the set speed when the vehicle is driven on a down slope, however, the system notifies the driver by flashing the display and operating a warning sound.


### **WARNING**

**Always turn off the system when changing drivers:**



*If the driver is changed and the new driver is unaware of the ASL function, the vehicle may not accelerate when the driver depresses the accelerator pedal, leading to an accident.*

The system consists of the ASL display and the speed limiter switch on the steering wheel.

#### Active Driving Display



#### Display in the instrument cluster



#### ▼ Adjustable Speed Limiter (ASL) Display

The setting status of the ASL is displayed in the active driving display (Type A instrument cluster\*1) or the display in the instrument cluster (Type B instrument cluster\*1).

\*Some models. **4-129**

When Driving

## i-ACTIVSENSE

\*1 To determine which instrument cluster is equipped on your Mazda, Refer to Meters and Gauges on page 4-19.

### Stand-by display

Displays when the speed limiter switch is operated and the system is turned on.  
Turns off when the system is turned off.

Active Driving Display

Display in the instrument cluster

**85** km/h  ---  **---** km/h

### Setting display

#### **With cruise control**

Displays when the SET/− switch is operated and the speed is set.

#### **With Mazda Rader Cruise Control (MRCC)**

Displays when the SET− or SET+ switch is operated and the speed is set.

Active Driving Display

Display in the instrument cluster

**85** km/h  **100**  **100** km/h

### Cancel display

Displays when any of the following operations is done and the system is temporarily cancelled.

- OFF/CANCEL switch is operated
- Accelerator pedal is strongly depressed

Active Driving Display

Display in the instrument cluster

**80** km/h  **100**  **100** km/h

▼ **Adjustable Speed Limiter (ASL) Main Indication (White), Adjustable Speed Limiter (ASL) Set Indication (White)/Indicator Light (Green)**

**ASL main indication (white)**

The ASL main indication (white) is displayed in the instrument cluster when the ASL is activated.



**ASL set indication (white)/indicator light (green)**

The ASL set indication (white) is displayed in the instrument cluster and the ASL set indicator light (green) turns on when a speed has been set.



▼ **Speed Limiter Warning Beep**

**Indicated in instrument cluster**

If the vehicle speed exceeds the set speed by about 3 km/h (2 mph) or more, a warning sound operates continuously and the ASL display flashes at the same time. The warning sound operates and the display flashes until the vehicle speed decreases to the set speed or less.

**Indicated in active driving display**

If the vehicle speed exceeds the set speed by about 3 km/h (2 mph) or faster, the background of the ASL set speed indication turns amber and flashes 3 times. In addition, a warning sound is activated at the same time. The indication stops flashing and remains on if the vehicle speed continues to exceed the set speed by about 3 km/h (2 mph) or faster, and the indication and warning sound remain on until the vehicle is driven at the set speed or slower.

When Driving

## i-ACTIVSENSE

Verify the safety of the surrounding area and adjust the vehicle speed by applying the brakes. Additionally, keep a safer distance from the vehicles behind you.

Active Driving Display

110 km/h LIM 100

Display in the instrument cluster



### CAUTION

#### **(With cruise control)**

If the set speed is set lower than the current vehicle speed by pressing the SET/- or RES/+ switch, the warning beep is not activated for about 30 seconds even if the vehicle speed is faster than the newly set speed by 3 km/h (2 mph). Be careful not to drive over the set speed.

#### **(With Mazda Radar Cruise Control (MRCC))**

If the set speed is set lower than the current vehicle speed by pressing the SET/- or RES/+ switch, the warning beep is not activated for about 30 seconds even if the vehicle speed is faster than the newly set speed by 3 km/h (2 mph). Be careful not to drive over the set speed.

#### **NOTE**

When the system is temporarily cancelled by depressing the accelerator pedal fully, the ASL display shows the cancel display. Even if the vehicle speed exceeds the set speed by about 3 km/h (2 mph) or more while the cancel display is displayed, the warning sound is not operated.

#### **▼ Activation/Deactivation**

#### **NOTE**

When the ignition is switched off, the system status before it was turned off is maintained. For example, if the ignition is switched off while the ASL is operating, the system will be operable when the ignition is switched ON the next time.

#### **Activation**

Press the MODE switch to operate the system. The ASL screen is displayed, and the ASL main indication (white) turns on.

**NOTE**

*When the cruise control or Mazda Radar Cruise Control (MRCC) system becomes operable after pressing the MODE switch, press the mode switch again to switch to the ASL.*

**Deactivation**

To deactivate the system, do the following operations:

**When a cruising speed has been set (ASL set indication (white)/indicator light (green) turns on)**

Long-press the OFF/CANCEL switch or press the OFF/CANCEL switch 2 times. The ASL screen is no longer displayed and the ASL set indication (white)/indicator light (green) turns off.

**When a cruising speed has not been set (ASL main indication (white) turns on)**

Press the OFF/CANCEL switch. The ASL screen is no longer displayed and the ASL main indication (white) turns off.

**NOTE**

*When the MODE switch is pressed while the ASL is operating, the system switches to the cruise control or Mazda Radar Cruise Control (MRCC) system.*

## ▼ Setting the System



### **WARNING**

***Always verify the safety of the surrounding area when setting the ASL:***

*If the speed is set lower than the current vehicle speed, the vehicle speed is decreased to the set speed. Verify the safety of the surrounding area and keep a safer distance between vehicles ahead and behind you.*

1. Press the MODE switch to turn the system on.
2. **(With cruise control)**  
Press the SET/− to set the speed.  
When the current vehicle speed is 30 km/h (20 mph) or more, the speed is set to the current vehicle speed. When the current vehicle speed is less than 30 km/h (20 mph), the speed is set to 30 km/h (20 mph).  
**(With Mazda Radar Cruise Control (MRCC))**  
Press the SET+ or SET− to set the speed. When the current vehicle speed is 30 km/h (20 mph) or more, the speed is set to the current vehicle speed. When the current vehicle speed is less than 30 km/h (20 mph), the speed is set to 30 km/h (20 mph).

## 3. **(With cruise control)**

To increase the set speed, press the RES/+ switch continuously. The set speed can be adjusted in 10 km/h (5 mph) increments. The set speed can also be adjusted in about 1 km/h (1 mph) increments by pressing the RES/+ switch momentary. For example, the set speed increases about 4 km/h (4 mph) by pressing the RES/+ switch 4 times.

### **(With Mazda Radar Cruise Control (MRCC))**

To increase the set speed, press the SET+ switch continuously. The set speed can be adjusted in 10 km/h (5 mph) increments. The set speed can also be adjusted in about 1 km/h (1 mph) increments by pressing the SET+ switch momentary. For example, the set speed increases about 4 km/h (4 mph) by pressing the SET+ switch 4 times.

## 4. **(With cruise control)**

To decrease the set speed, press the SET/− switch continuously. The set speed can be adjusted in 10 km/h (5 mph) increments. The set speed can also be adjusted in about 1 km/h (1 mph) increments by pressing the SET/− switch momentary. For example, the set speed decreases about 4 km/h (4 mph) by pressing the SET/− switch 4 times.

**(With Mazda Radar Cruise Control (MRCC))**

To decrease the set speed, press the SET $\text{--}$  switch continuously. The set speed can be adjusted in 10 km/h (5 mph) increments. The set speed can also be adjusted in about 1 km/h (1 mph) increments by pressing the SET $\text{--}$  switch momentarily. For example, the set speed decreases about 4 km/h (4 mph) by pressing the SET $\text{--}$  switch 4 times.

**NOTE**

- **(With cruise control)**

*When the vehicle set speed is displayed in the instrument cluster, press the RES/+ switch to set the displayed vehicle speed.*

- **(With Mazda Radar Cruise Control (MRCC))**

*When the vehicle set speed is displayed in the instrument cluster, press the RES switch to set the displayed vehicle speed.*

- The system is temporarily cancelled when the vehicle is accelerated by depressing the accelerator pedal strongly, however, it resumes when the vehicle speed decreases to the set speed or less.
- The vehicle speed may exceed the set speed on a down slope.

**▼ Temporarily Cancelling the System**

The system is temporarily cancelled (stand-by status) when any of the following operations is done while the ASL is displayed.

- OFF/CANCEL switch is pressed
- Accelerator pedal is strongly depressed

**With cruise control**

Press the RES/+ switch to resume the operation at the previous set speed. The ASL display remains displayed.

**With Mazda Radar Cruise Control (MRCC)**

Press the RES switch to resume the operation at the previous set speed. The ASL display remains displayed.

**NOTE**

- **(With cruise control)**

*The set speed can be set by pressing the SET/ $\text{--}$  switch while the system is in stand-by status.*


- **(With Mazda Radar Cruise Control (MRCC))**

*The set speed can be set by pressing the SET+ or SET $\text{--}$  switch while the system is in stand-by status.*

- The ASL is not cancelled by depressing the brake pedal.

## Advanced Smart City Brake Support (Advanced SCBS)

The Advanced SCBS alerts the driver of a possible collision using the display and a warning sound when the Forward Sensing Camera (FSC) detects a vehicle ahead or pedestrian and determines that a collision with the object is unavoidable while the vehicle is driven at a vehicle speed of about 4 to 80 km/h (2 to 50 mph) if the object is a vehicle ahead and about 10 to 80 km/h (6.2 to 50 mph) if the object is a pedestrian. In addition, the system reduces damage in the event of a collision by operating the brake control (Advanced SCBS brake) when the system determines that a collision is unavoidable. In addition, when the driver depresses the brake pedal, the brakes are applied firmly and quickly to assist. (Brake Assist (Advanced SCBS brake assist))



### **WARNING**

***Do not rely completely on the Advanced SCBS system:***

- *The Advanced SCBS system is only designed to reduce damage in the event of a collision. Over reliance on the system leading to the accelerator pedal or brake pedal being mistakenly operated could result in an accident.*
- *The Advanced SCBS system operates in response to a vehicle ahead or a pedestrian. The system does not operate in response to obstructions such as a wall, 2-wheeled vehicles, or animals.*



 **CAUTION**

*In the following cases, turn the system off to prevent a mis-operation:*

- *The vehicle is being towed or when towing another vehicle.*
- *The vehicle is on a chassis roller.*
- *When driving on rough roads such as in areas of dense grass or off-road.*

*Refer to Stopping the Advanced Smart City Brake Support (Advanced SCBS) System Operation on page 4-138 on how to turn off the Advanced SCBS system.*

**NOTE**


- *The Advanced SCBS system will operate under the following conditions.*
  - *The engine is running.*
  - *The Smart City Brake Support (SCBS) warning light(amber) does not illuminate.*
  - **(Object is vehicle ahead)**  
*The vehicle speed is between about 4 to 80 km/h (2 to 50 mph).*
  - **(Object is a pedestrian)**  
*The vehicle speed is between about 10 to 80 km/h (6.2 to 50 mph).*
  - *The Advanced SCBS system is not turned off.*
- *Under the following conditions, the Advanced SCBS system may not operate normally:*
  - *The Advanced SCBS system will not operate if the driver is deliberately performing driving operations (accelerator pedal and steering wheel).*
  - *If there is the possibility of partial contact with a vehicle ahead.*
  - *The vehicle is driven on a slippery road surface such as wet roads or icy or snow-bound roads.*
  - *The braking performance is adversely affected due to cold temperatures or wet brakes.*
  - *The vehicle is driven at the same speed as the vehicle ahead.*
  - *The accelerator pedal is depressed.*
  - *The brake pedal is depressed.*
  - *The steering wheel is being operated.*
  - *The selector lever is being operated.*
- *In the following cases, the Advanced SCBS may operate.*
  - *Objects on the road at the entrance to a curve.*
  - *Vehicles passing in the opposite lane while making a curve.*
  - *When passing through a toll gate.*
  - *When passing through low gates, narrow gates, car washing machines, or tunnels.*
  - *If you suddenly come close to a vehicle ahead.*
  - *2-wheeled vehicles, animals, or standing trees.*

· **(Manual transaxle)**

*If the vehicle is stopped by the SCBS operation and the clutch pedal is not depressed, the engine stops.*

## ▼ Smart City Brake Support (SCBS) Indicator Light (Red)

If the Advanced SCBS is operating, the indicator light (red) flashes.



## ▼ Collision Warning

If there is the possibility of a collision with a vehicle ahead, the beep sounds continuously and a warning is indicated in the active driving display.

**BRAKE!**

### NOTE

· **(Without SCBS OFF switch)**

*The operation distance and volume of the collision warning can be changed. Refer to Personalisation Features on page 9-8.*

· **(With SCBS OFF switch)**

*The operation distance and volume of the collision warning can be changed. Consult an Authorised Mazda Repairer.*

## ▼ Automatic Brake Operation Display

The automatic brake operation display is indicated on the active driving display after the Advanced SCBS is operated.

**SCBS  
Automatic Brake**

### NOTE

- The collision warning beep sounds intermittently while the Advanced SCBS brake or brake assist (Advanced SCBS brake assist) is operating.
- If the vehicle is stopped by the Advanced SCBS operation and the brake pedal is not depressed, the warning beep sounds 1 time after about 2 seconds and the Advanced SCBS brake is automatically released.

## ▼ Stopping the Advanced Smart City Brake Support (Advanced SCBS) System Operation

The Advanced Smart City Brake Support (Advanced SCBS) system can be temporarily deactivated.

When the Advanced Smart City Brake Support (Advanced SCBS) system is turned off, the Smart City Brake Support (SCBS) OFF indicator light turns on.



When the engine is restarted, the system becomes operational.

### Without SCBS OFF switch


Refer to Personalisation Features on page 9-8.

**NOTE**

*When the Advanced Smart City Brake Support (Advanced SCBS) system is set to inoperable, the Smart City Brake Support [Reverse] (SCBS R) system and the Smart Brake Support (SBS) are also set to inoperable.*

**With SCBS OFF switch**


Press the SCBS OFF switch to turn off the system. The Smart City Brake Support (SCBS) OFF indicator light in the instrument cluster will illuminate.



Press the switch again to turn the system back on. The Smart City Brake Support (SCBS) OFF indicator light will turn off.

## Smart City Brake Support [Reverse] (SCBS R)\*

The SCBS R is a system which is designed to reduce damage in the event of a collision by operating the brake control (SCBS brake) when the system's ultrasonic sensors detect an obstruction at the rear of the vehicle while driving at a speed of about 2 to 8 km/h (2 to 4 mph) and the system determines that a collision is unavoidable.



### **⚠ WARNING**

#### **Do not rely completely on the SCBS R system:**

- The SCBS R system is only designed to reduce damage in the event of a collision. Over reliance on the system leading to the accelerator pedal or brake pedal being mistakenly operated could result in an accident.
- To assure the correct operation of the SCBS R, heed the following cautions.
  - Do not apply a sticker to an ultrasonic sensor (rear) (including transparent stickers). Otherwise, the ultrasonic sensor (rear) may not be able to detect vehicles or obstructions which could result in an accident.
  - Do not disassemble an ultrasonic sensor (rear).
  - If cracks or damage caused by flying gravel or debris is visible around an ultrasonic sensor (rear), stop using the SCBS R system immediately and have your vehicle inspected by an expert repairer (we recommend an Authorised Mazda Repairer). If the vehicle continues to be driven with cracks or scratch marks left around an ultrasonic sensor, the system may operate unnecessarily and cause an unexpected accident. Refer to Stopping the Smart City Brake Support [Reverse] (SCBS R) System Operation on page 4-143.
  - Consult an expert repairer (we recommend an Authorised Mazda Repairer) for rear bumper replacement.

#### **Do not modify the suspension:**

If the vehicle height or inclination is changed, the SCBS R system may not operate correctly because it cannot detect obstructions correctly.

***Do not apply a strong force to an ultrasonic sensor (rear):***

*When washing the vehicle, do not spray highly pressurised water against an ultrasonic sensor (rear), or rub it strongly. In addition, do not hit the rear bumper forcefully when loading and unloading cargo. Otherwise, the sensors may not detect obstructions correctly which could cause the SCBS R system to not operate normally, or it could operate unnecessarily.*

**⚠ CAUTION**

- *When driving off-road in areas where there is grass or foliage, it is recommended that the SCBS R system be turned off.*
- *Always use tyres of the specified size and the same manufacturer, brand, and tread pattern on all 4 wheels. In addition, do not use tyres with significantly different wear patterns on the same vehicle. Otherwise, the SCBS R system may not operate normally.*
- *If ice or snow is stuck on the ultrasonic sensors (rear) they may not be able to detect obstructions correctly depending on the conditions. In such cases, the system may not be able to perform controls correctly. Always drive carefully and pay attention to the rear of the vehicle.*

**NOTE**

- *The vehicle posture changes depending on the accelerator pedal, brake pedal and steering wheel operations, which could make it difficult for the system to recognise an obstruction, or it could facilitate unnecessary detection. In such cases, the SCBS R may or may not operate.*
- *The SCBS R system will operate under the following conditions.*
  - *The Smart City Brake Support (SCBS) warning light (amber) does not illuminate.*
  - *The engine is running.*
  - *The change lever (manual transaxle vehicle) or the selector lever (automatic transaxle vehicle) is in the R (reverse) position.*
  - *The vehicle speed is between about 2 to 8 km/h (2 to 4 mph).*
  - *The SCBS R is not turned off.*
  - *The DSC is not malfunctioning.*
- *The SCBS R operates using ultrasonic sensors (rear) which detect obstructions at the rear by emitting ultrasonic waves and then receiving the returning waves reflected off the obstructions.*

- *In the following cases, the ultrasonic sensors (rear) cannot detect obstructions and the SCBS R may not operate.*
  - *The height of the obstruction is low such as low walls or trucks with low loading platforms.*
  - *The height of the obstruction is high such as trucks with high loading platforms.*
  - *The obstruction is small.*
  - *The obstruction is thin such as a signpost.*
  - *The obstruction is positioned away from the centre of the vehicle.*
  - *The surface of the obstruction is not pointed vertically relative to the vehicle.*
  - *The obstruction is soft such as a hanging curtain or snow stuck to a vehicle.*
  - *The obstruction is shaped irregularly.*
  - *The obstruction is extremely close.*
- *In the following cases, the ultrasonic sensors (rear) cannot detect obstructions correctly and the SCBS R may not operate.*
  - *Something is stuck on the bumper near an ultrasonic sensor (rear).*
  - *The steering wheel is turned sharply, or the brake or accelerator pedal is operated.*
  - *There is another obstruction near one obstruction.*
  - *During inclement weather such as rain, fog and snow.*
  - *High or low humidity.*
  - *High or low temperatures*
  - *Strong winds.*
  - *The path of travel is not flat.*
  - *Heavy luggage is loaded in the luggage compartment or on the rear seat.*
  - *Objects such as a wireless aerial, fog light, or illuminated number plate is installed near an ultrasonic sensor (rear).*
  - *The orientation of an ultrasonic sensor (rear) has deviated for reasons such as a collision.*
  - *The vehicle is affected by other sound waves such as the horn, engine noise, ultrasonic sensor of another vehicle.*
- *In the following cases, an ultrasonic sensor (rear) may detect something as a target obstruction which could cause the SCBS R system to operate.*
  - *Driving on a steep slope.*
  - *Wheel blocks.*
  - *Hanging curtains, gate poles such as at toll gates and railroad crossing.*
  - *When travelling near objects such as foliage, barriers, vehicles, walls, and fences along a road.*
  - *When driving off-road in areas where there is grass and forage.*
  - *When passing through low gates, narrow gates, car washing machines, and tunnels.*
  - *A towing bar is installed or a trailer is connected.*

· **(Manual transaxle)**

*If the vehicle is stopped by the Smart City Brake Support (SCBS) operation and the clutch pedal is not depressed, the engine stops.*


· *When the system operates, the user is notified by the active driving display.*

· *The Smart City Brake Support (SCBS) warning indication (amber) turns on when the system has a malfunction.*

*Refer to Warning Lights on page 4-29.*


▼ **Smart City Brake Support (SCBS)  
Indicator Light (Red)**

If the Smart City Brake Support (SCBS) is operating, the indicator light (red) flashes.



▼ **Automatic Brake Operation Display**

“SCBS Automatic Brake” is indicated in the multi-information display after the Smart City Brake Support (SCBS) brakes is operated.



**NOTE**

· *The collision warning beep sounds intermittently while the Smart City Brake Support (SCBS) brake is operating.*

· *If the vehicle is stopped by the Smart City Brake Support (SCBS) operation and the brake pedal is not depressed, the warning beep sounds one time after about 2 seconds and the Smart City Brake Support (SCBS) brake is automatically released.*

▼ **Stopping the Smart City Brake  
Support [Reverse] (SCBS R) System  
Operation**

The SCBS R system can be temporarily deactivated.

When the SCBS R system is turned off, the Smart City Brake Support (SCBS) OFF indicator light turns on.




When the engine is restarted, the system becomes operational.

**Without SCBS OFF switch**

Refer to Personalisation Features on page 9-8.

## With SCBS OFF switch

Press the SCBS OFF switch to turn off the system. The Smart City Brake Support (SCBS) OFF indicator light in the instrument cluster will illuminate.



Press the switch again to turn the system back on. The Smart City Brake Support (SCBS) OFF indicator light will turn off.

## Smart Brake Support (SBS)\*

The SBS system alerts the driver of a possible collision using a display and warning sound if the radar sensor (front) and the Forward Sensing Camera (FSC) determine that there is the possibility of a collision with a vehicle ahead while the vehicle is being driven at about 15 km/h or faster (10 mph or faster). Furthermore, if the radar sensor (front) and the Forward Sensing Camera (FSC) determines that a collision is unavoidable, the automatic brake control is performed to reduce damage in the event of a collision.

In addition, when the driver depresses the brake pedal, the brakes are applied firmly and quickly to assist. (Brake Assist (SBS brake assist))

## WARNING

***Do not rely completely on the SBS system and always drive carefully:***

*The SBS is designed to reduce damage in the event of a collision, not avoid an accident. The ability to detect an obstruction is limited depending on the obstruction, weather conditions, or traffic conditions. Therefore, if the accelerator pedal or brake pedal is mistakenly operated it could result in an accident. Always verify the safety of the surrounding area and depress the brake pedal or accelerator pedal while keeping a safer distance from vehicles ahead or on-coming vehicles.*



**CAUTION**

In the following cases, turn the system off to prevent a mis-operation:

- The vehicle is being towed or when towing another vehicle.
- The vehicle is on a chassis roller.
- When driving on rough roads such as in areas of dense grass or off-road.

**NOTE**


- The SBS system operates when all of the following conditions are met:
  - The ignition is switched ON.
  - The SBS system is on.
  - The vehicle speed is about 15 km/h or faster (10 mph or faster).
  - The relative speed between your vehicle and the vehicle ahead is about 15 km/h or faster (10 mph or faster).
  - The Dynamic Stability Control (DSC) is not operating.
- The SBS system may not operate under the following conditions:
  - If the vehicle is accelerated rapidly and it comes close to a vehicle ahead.
  - The vehicle is driven at the same speed as the vehicle ahead.
  - The accelerator pedal is depressed.
  - The brake pedal is depressed.
  - The steering wheel is being operated.
  - The selector lever is being operated.
  - The direction indicator is being used.
  - When the vehicle ahead is not equipped with tail lights or the tail lights are turned off.

- When warnings and messages, such as a dirty windscreen, related to the Forward Sensing Camera (FSC) are being displayed in the centre display.
- Although the objects which activate the system are four-wheeled vehicles, the radar sensor (front) could detect the following objects, determine them to be an obstruction, and operate the SBS system.
  - Objects on the road at the entrance to a curve (including guardrails and snow banks).
  - A vehicle appears in the opposite lane while cornering or rounding a curve.
  - When crossing a narrow bridge.
  - When passing under a low gate or through a tunnel or narrow gate.
  - When entering an underground parking area.
  - Metal objects, bumps, or protruding objects on the road.
  - If you suddenly come close to a vehicle ahead.
  - When driving in areas where there is high grass or forage.
  - Two-wheeled vehicles such as motorbikes or bicycles.
  - Pedestrians or non-metallic objects such as standing trees.
- When the system operates, the user is notified by the active driving display.
- The SBS warning indication (amber) turns on when the system has a malfunction.

Refer to Taking Action on page 7-31.

▼ **Smart Brake Support (SBS)  
Indicator Light (Red)**

If the SBS is operating, the indicator light (red) flashes.



▼ **Collision Warning**

If there is the possibility of a collision with a vehicle ahead, the beep sounds continuously and a warning is indicated in the active driving display.

**BRAKE !**

▼ **Stopping The Smart Brake Support (SBS) System Operation**

The SBS system can be temporarily deactivated.

Refer to Personalisation Features on page 9-8.

When the SBS system is turned off, the SBS OFF indicator light turns on.



When the engine is restarted, the system becomes operational.

**NOTE**

*If the SBS system operation is turned off, the Smart City Brake Support (SCBS) system operation is turned off simultaneously.*

## 360° View Monitor\*

The 360° View Monitor consists of the following functions which assist the driver in checking the area surrounding the vehicle using various indications in the centre display and a warning sound while the vehicle is being driven at low speeds or while parking.

- **Top view**

The top view displays an image of the vehicle from directly above on the centre display by combining the images taken from the 4 cameras set on all sides of the vehicle. The top view displays on the left side of the screen when the front view or rear view screen is being displayed. The top view assists the driver in checking the area surrounding the vehicle when the vehicle is moving forward or in reverse.

- **Front view/front wide view**

The image from the front of the vehicle is displayed on the centre display.

The view from the front assists the driver in checking the front of the vehicle by displaying guide lines on the displayed image taken from the front of the vehicle.

- **Side view**

The images taken from the front left and right sides of the vehicle are displayed on the centre display.

The side view assists the driver in checking the front sides of the vehicle by displaying guide lines on the displayed image taken from the front left and right sides of the vehicle.

- **Rear view/rear wide view**

The image from the rear of the vehicle is displayed on the centre display.

The image from the rear assists the driver in checking the rear of the vehicle by displaying guide lines on the displayed image taken from the rear of the vehicle.

- **Parking sensor**

If there are any obstructions near the vehicle while the top view/side view is displayed, an obstruction detection indication on the centre display turns on.

The parking sensors use ultrasonic sensors to detect obstructions around the vehicle when the vehicle is driven at low speeds, such as during garage or parallel parking, and notifies the driver of the approximate distance from the vehicle to the surrounding obstruction using sound and an obstruction detection indication.

Refer to Parking Sensor System on page 4-202.

- **Rear Cross Traffic Alert (RCTA)**

If there is the possibility of a collision with an approaching vehicle while the rear view/rear wide view is displayed, a warning is displayed on the centre display.


The Rear Cross Traffic Alert (RCTA) uses radar sensors (rear) to detect vehicles approaching from the rear left and right sides of the vehicle, and it assists the driver in checking the rear of the vehicle while reversing by flashing the Blind Spot Monitoring (BSM) warning lights and activating the warning sound.

Refer to Rear Cross Traffic Alert (RCTA) on page 4-103.

When Driving

## i-ACTIVSENSE

### 360°View Monitor Range



### **⚠ WARNING**

***Always confirm the safety of the area around the vehicle with the mirrors and directly with your eyes when driving.***

*The 360°View Monitor is an auxiliary device which assists the driver in checking the safety of the area around the vehicle.*

*The shooting range of the cameras and detection range of the sensors are limited. For example, the areas in black at the front and rear of the vehicle image and the seams where each of the camera images merge are blind spots where an obstruction may not be visible. In addition, the extended vehicle width lines and projected vehicle path lines are only to be used as references, and the images on the screen may differ from the actual conditions.*

### **⚠ CAUTION**

➤ Do not use the 360°View Monitor under any of the following conditions.

- Icy or snow-covered roads.
- Tyre chains or a temporary spare tyre is installed.

**4-148**

- *The front doors or the boot is not fully closed.*
- *The vehicle is on a road incline.*
- *The door mirrors are retracted.*
- *Do not hit the front/rear camera, front bumper, and door mirrors forcefully. The camera position or installation angle may shift.*
- *The cameras are of a waterproof structure. Do not disassemble, modify, or remove a camera.*
- *The camera cover is made of hard plastic, therefore do not apply oil film remover, organic solvents, wax, or coating agents. If any such agent gets on the camera cover, wipe it off using a soft cloth immediately.*
- *Do not rub the camera lens forcefully, or clean it with an abrasive or hard brush. Otherwise, it could scratch the camera lens and negatively affect the images.*
- *Consult an expert repairer (we recommend an Authorised Mazda Repairer) for repair, painting, or replacement of the front/rear camera, front bumper and door mirrors.*
- *Heed the following cautions to assure that the 360°View Monitor operates normally.*
  - *Do not modify the vehicle suspensions or lower/raise the vehicle body, or both.*
  - *Always use wheels of the specified type and size for the front and rear wheels. Consult an expert repairer (we recommend an Authorised Mazda Repairer) for tyre replacement.*
- *When the display is cold, images may leave trails or the screen might be darker than usual, making it difficult to check the vehicle surroundings. Always confirm the safety at the front and around the vehicle visually when driving.*
- *The method for parking/stopping the vehicle using the 360°View Monitor differs depending on the road circumstances/conditions and the vehicle conditions. When and how much you turn the steering wheel will differ depending on the situation, , therefore always check the vehicle surroundings directly with your eyes while using the system.*

*Also, before using the system, always make sure that the vehicle can be parked/stopped in the parking/stopping space.*

#### **NOTE**

- *If there are water droplets, snow, or mud on the camera lens, wipe it off using a soft cloth. If the camera lens is especially dirty, wash it off with mild detergent.*
- *If the area where the camera is installed, such as the boot (Saloon)/rear bumper (Hatchback) or door mirrors, has been damaged in a vehicle accident, the camera (position, installation angle) may have shifted. Always consult an expert repairer (we recommend an Authorised Mazda Repairer) to have the vehicle inspected.*
- *If the camera is subjected to excessive changes in temperature such as by pouring hot water on the camera during cold weather, the 360°View Monitor may not operate normally.*
- *If the battery voltage is low, the screen might be temporarily difficult to view, however, this does not indicate a problem.*

When Driving

## i-ACTIVSENSE


---

- *The 360°View Monitor has limitations. Objects under the bumper or near both ends of the bumper cannot be displayed.*
- *Obstructions above the upper image range of the camera are not displayed.*
- *Under the following conditions, the screen might be difficult to view, however this does not indicate a problem.*
  - *The temperature near the lens is high/low.*
  - *Rainy conditions, water droplets on the camera, or high humidity.*
  - *Mud or foreign matter near the camera.*
  - *Extremely bright light such as sunlight or headlights hitting the camera lens directly.*
- *Because the 360°View Monitor camera uses a special lens, the distance displayed on the screen differs from the actual distance.*
- *Obstructions displayed on the screen may appear differently than in actuality. (Obstructions may appear fallen, larger, or longer than they actually are.)*
- *Do not apply stickers to a camera or the area around it. In addition, do not install accessories or an illuminated number/character number plate to the area around a camera. Otherwise, the camera may not correctly display the surrounding conditions.*

### ▼ Types of Images Displayed on the Screen


#### Top view/Front view

Displays the image of the area around the vehicle and the vehicle front.




#### Front wide view

Displays the image of the front of the vehicle (wide-area).



#### Side view

Displays the image of the left and right sides of the vehicle.




When Driving

## i-ACTIVSENSE


### Top view/Rear view

Displays the image of the area around the vehicle and the rear of the vehicle.



### Rear wide view

Displays the image of the rear of the vehicle (wide-area).






▼ **How to Use the System**

**Top view/Front view, Front wide view, Side view**

**Indication**


Images are displayed on the screen when the 360°View Monitor switch is pressed with all of the following conditions met.

- The ignition is switched ON.
- The shift lever/selector lever is in a position other than R.



## Display switching

You can change the displayed screen by pressing the commander knob or by touching the switch camera icon on the screen while the top view/front view, front wide view, or the side view is displayed.



## NOTE

- When the shift lever/selector lever is in R position, the displayed screen does not switch to the top view/front view, front wide view, or the side view.
- Display of the top view/front view, front wide view, or the side view stops even with the display conditions met if any of the following conditions occurs.
  - When a switch around the commander knob is pressed.

- **(Manual transaxle)**  
*The parking brake is applied.*
- **(Automatic transaxle)**  
*The selector lever is shifted to P position (displayed when the selector lever is in a position other than P).*
- **(Displayed when vehicle speed is less than 15 km/h (9.3 mph))**
  - *4 minutes and 30 seconds have passed.*
  - *The vehicle speed is about 15 km/h (9.3 mph) or faster.*
- **(Displayed when the vehicle speed is about 15 km/h (9.3 mph) or faster)**
  - *The vehicle speed is about 15 km/h (9.3 mph) or faster after 8 seconds have passed since pressing the 360°View Monitor switch.*
  - *Four minutes and 22 seconds have passed from the point when the vehicle speed was less than 15 km/h (9.3 mph) after 8 seconds have passed since pressing the 360° View Monitor switch.*
- *The 360°View Monitor displays the previously displayed screen.*
- *The 360° View Monitor settings can be changed as follows.*  
*Refer to Personalisation Features on page 9-8.*
  - *Automatic display of the 360°View Monitor when the ultrasonic sensor detects an obstruction.*
  - *Automatic display of the 360°View Monitor when the ignition is switched ON.*

#### **Top view/Rear view, Rear wide view**

The top view/rear view, rear wide view displays when all of the following conditions are met.


- The ignition is switched ON.
- Shift lever/selector lever is in R position.

When Driving


## i-ACTIVSENSE

### Display switching


The displayed screen can be switched by pressing the commander knob or by touching the switch camera icon on the screen while the top view/rear view, rear wide view is displayed.




Top view/Rear view



Switch camera icon



Rear wide view




### NOTE

- The top view/rear view and rear wide view automatically display whether or not the 360° View Monitor switch is turned on or off when shifting the shift lever/selector lever to R position.
- The setting can be changed to display the top view/front view when shifting from reverse to a forward gear without operating the 360° View Monitor switch to check the front of the vehicle while parallel parking.  
Refer to Personalisation Features on page 9-8.

**Screen operation/icon**

**⚠ WARNING**

**Always stop the vehicle when adjusting the 360°View Monitor image quality.**  
Do not adjust the 360°View Monitor image quality while driving. If you adjust the 360° View Monitor image quality (such as brightness, contrast, tone, and colour density) while driving, it could lead to an unexpected accident.




|   | Display/Icon                                | Content                                                                                                     |
|---|---------------------------------------------|-------------------------------------------------------------------------------------------------------------|
| ① | View status icon                            | Indicates which image is displayed among the front view/front wide view/side view/rear view/rear wide view. |
| ② | Parking sensor status icon                  | Indicates that the parking sensor has a problem or it is switched off.                                      |
| ③ | Rear Cross Traffic Alert (RCTA) status icon | Indicates that the radar sensor (rear) has a problem or it is turned off.                                   |
| ④ | Switch camera icon                          | Each time the screen is touched, the display screen switches.                                               |
| ⑤ | Setting icon                                | The image quality for the 360°View Monitor can be adjusted.                                                 |

### ▼ Top View/Front View


Use the top view/front view to assist in checking the safety of the surrounding area when accelerating from a stop, parking, or stopping the vehicle.

#### Display range

(Screen display)




(Actual condition)



#### **NOTE**

- In the top view screen, the areas in black at the front and rear of the vehicle image and the seams where each of the camera images merge are blind spots.
- Because images displayed in the top view screen are processed from each camera, the top view screen may display in the following ways.
  - If an image containing an object with a conspicuous colour is picked up by any of the cameras, the whole screen may be affected and it may display in that colour.
  - Obstructions displayed in the front view may not display on the top view screen.
  - If the position or angle of each camera changes due to tilting of the vehicle, the image may appear distorted.
  - Lines on the road may appear distorted at the seams where each of the camera images merge.
  - The entire screen may appear bright/dark depending on the illumination level around any of the cameras.

### Viewing the screen



|   | Display/Icon                                                     | Content                                                                                                                                                                                                                                                                                                                                                                                          |
|---|------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| ① | Parking sensor view                                              | Displays the parking sensor detection condition when the parking sensor is activated.<br>For details, refer to the parking sensor obstruction detection indication and warning sound.<br>Refer to Parking Sensor System on page 4-202.                                                                                                                                                           |
| ② | Tyre icon                                                        | Indicates the tyre direction. Moves in conjunction with the steering wheel operation.                                                                                                                                                                                                                                                                                                            |
| ③ | Projected vehicle path lines (amber)                             | Indicates the approximate projected path of the vehicle. Moves in conjunction with the steering wheel operation.<br>a) Indicates the path where the edge of the front bumper is expected to travel.<br>b) Indicates the path where the inner side of the vehicle is expected to travel.                                                                                                          |
| ④ | Extended vehicle width lines and distance guide lines (red/blue) | Indicates the approximate width of the vehicle and the distance (from front end of bumper) in front of the vehicle. <ul style="list-style-type: none"> <li>The red lines indicate the points up to about 0.5 m (20 in) from the front end of the bumper.</li> <li>The blue lines indicate the points from about 0.5 m (20 in) and up to 2 m (79 in) from the front end of the bumper.</li> </ul> |
| ⑤ | Projected vehicle path distance guide lines (red/amber)          | Indicates the distance (from front end of bumper) in front of the vehicle. <ul style="list-style-type: none"> <li>The red line indicates the point about 0.5 m (20 in) from the front end of the bumper.</li> <li>The amber lines indicate the points about 1 m (39 in) and 2 m (79 in) from the front end of the bumper.</li> </ul>                                                             |

When Driving

## i-ACTIVSENSE

### CAUTION

*The parking sensor detection range has limitations. For example, obstructions closing in from the side and objects short in height may not be detected. Always confirm the safety around the vehicle visually when driving.*


*For details, refer to the parking sensor obstruction detection indication and warning sound. Refer to Parking Sensor System on page 4-202.*

### NOTE


*The setting can be changed so that the projected vehicle path lines are not displayed. Refer to Personalisation Features on page 9-8.*

### How to use the projected vehicle path line function

(Screen display)



(Actual condition)



Make sure that there are no obstructions within the projected vehicle path lines. Drive the vehicle forward while turning the steering wheel so that no obstructions come within the projected vehicle path lines.


### ▼ Front Wide View

Use the front wide view to assist in checking the safety of the surrounding area when accelerating from a stop or entering a T-shaped intersection and intersection.




**Display range**


(Screen display)



(Actual condition)



**Viewing the screen**



|   | Display/Icon                                                     | Content                                                                                                                                                                                                                                                                                                                                                                                                  |
|---|------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| ① | Extended vehicle width lines and distance guide lines (red/blue) | <p>Indicates the approximate width of the vehicle and the distance (from front end of bumper) in front of the vehicle.</p> <ul style="list-style-type: none"><li>• The red lines indicate the points up to about 0.5 m (20 in) from the front end of the bumper.</li><li>• The blue lines indicate the points from about 0.5 m (20 in) and up to 2 m (79 in) from the front end of the bumper.</li></ul> |

When Driving

## i-ACTIVSENSE


### NOTE

- The parking sensor obstruction detection indication does not display. Switch the screen display to the top view/front view or side view display if the parking sensor warning sound is activated.
- The front wide view screen displays the image in front of the vehicle at a wide angle and corrects the image to help detect approaching obstructions from the side. Therefore, it differs from the actual view.


### ▼ Side View

Use the side view to assist in checking the safety of the surrounding area when accelerating from a stop, parking, or stopping the vehicle.

### Display range



**Viewing the screen**




|   | Display/Icon                         | Content                                                                                                                                                                                                                                |
|---|--------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| ① | Parking sensor view                  | Displays the parking sensor detection condition when the parking sensor is activated.<br>For details, refer to the parking sensor obstruction detection indication and warning sound.<br>Refer to Parking Sensor System on page 4-202. |
| ② | Projected vehicle path lines (amber) | Indicates the approximate projected path of the vehicle.<br>Moves in conjunction with the steering wheel operation.<br>The projected vehicle path lines (amber) indicate the path the inner side of the vehicle is expected to travel. |
| ③ | Vehicle parallel guide lines (blue)  | Indicates the approximate vehicle width including the door mirrors.                                                                                                                                                                    |
| ④ | Vehicle front end guide lines (blue) | Indicates the point about 0.25 m (9.8 in) from the front edge of the vehicle (front edge of the bumper).                                                                                                                               |


**NOTE**  
*The setting can be changed so that the projected vehicle path lines are not displayed.  
Refer to Personalisation Features on page 9-8.*

## How to use the projected vehicle path line function

(Screen display)



(Actual condition)



Make sure that there are no obstructions within the projected vehicle path lines. Turn the steering wheel so that the projected vehicle path lines travel inside of the obstruction (A), and drive the vehicle forward until it passes the obstruction. If the projected vehicle path lines are on an obstruction (B) or outside of the obstruction (C), the vehicle may contact the obstruction when turning the vehicle sharply.

### **CAUTION**

- The parking sensor detection range has limitations. For example, obstructions closing in from the side and objects short in height may not be detected. Always confirm the safety around the vehicle visually when driving.  
For details, refer to the parking sensor obstruction detection indication and warning sound. Refer to Parking Sensor System on page 4-202.
- Do not turn the steering wheel any more until the vehicle has passed the obstruction, even if the obstruction is not visible on the side view image. If the steering wheel is turned even more, the vehicle may contact the obstruction if it is turned sharply.

### **NOTE**


- Because there might be a difference between the image displayed on the screen and the actual conditions, always check the safety of the surrounding area using the mirrors and directly with your eyes when driving.
- Even though the object displayed on the screen, such as a road curb or a division line of a parking space, and the vehicle parallel guide lines appear parallel, they may not actually be parallel.

### ▼ Top View/Rear View


Use the top view/rear view to assist in checking the safety of the surrounding area when accelerating from a stop, parking, or stopping the vehicle.

#### Range of displayed screen image

(Screen display)




(Actual condition)



#### **NOTE**

- In the top view screen, the areas in black at the front and rear of the vehicle image and the seams where each of the camera images merge are blind spots.
- Because images displayed in the top view screen are processed from each camera, the top view screen may display in the following ways.
  - If an image containing an object with a conspicuous colour is picked up by any of the cameras, the whole screen may be affected and it may display in that colour.
  - Obstructions displayed in the rear view may not display on the top view screen.
  - If the position or angle of each camera changes due to tilting of the vehicle, the image may appear distorted.
  - Lines on the road may appear distorted at the seams where each of the camera images merge.
  - The entire screen may appear bright/dark depending on the illumination level around any of the cameras.

**Viewing the screen**

|   | Display/Icon                                                     | Content                                                                                                                                                                                                                                                                                                                                                                                                                                |
|---|------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| ① | Parking sensor view                                              | Displays the parking sensor detection condition when the parking sensor is activated.<br>For details, refer to the parking sensor obstruction detection indication and warning sound.<br>Refer to Parking Sensor System on page 4-202.                                                                                                                                                                                                 |
| ② | Tyre icon                                                        | Indicates the tyre direction. Moves in conjunction with the steering wheel operation.                                                                                                                                                                                                                                                                                                                                                  |
| ③ | Projected vehicle path lines (amber)                             | Indicates the approximate projected path of the vehicle. Moves in conjunction with the steering wheel operation.<br>a) Indicates the path where the rear wheels are expected to travel.<br>b) Indicates the path where the outer side of the vehicle is expected to travel.                                                                                                                                                            |
| ④ | Extended vehicle width lines and distance guide lines (red/blue) | These guide lines indicate the approximate width of the vehicle and distance to a point measured from the rear of the vehicle (from the end of the bumper). <ul style="list-style-type: none"> <li>The red lines indicate the points up to about 0.5 m (20 in) from the rear end of the bumper.</li> <li>The blue lines indicate the points from about 0.5 m (20 in) and up to 2 m (79 in) from the rear end of the bumper.</li> </ul> |
| ⑤ | Projected vehicle path distance guide lines (red/amber)          | These guide lines indicate the approximate distance to a point measured from the rear of the vehicle (from the end of the bumper). <ul style="list-style-type: none"> <li>The red line indicates the point about 0.5 m (20 in) from the rear end of the bumper.</li> <li>The amber lines indicate the points about 1 m (39 in) and 2 m (79 in) from the rear end of the bumper.</li> </ul>                                             |

|   | Display/Icon                               | Content                                                                                                                                                                               |
|---|--------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| ⑥ | Blind Spot Monitoring (BSM) warning lights | Indicates when the Rear Cross Traffic Alert (RCTA) has operated.<br>For details, refer to Rear Cross Traffic Alert (RCTA).<br>Refer to Rear Cross Traffic Alert (RCTA) on page 4-103. |

**NOTE**

*The setting can be changed so that the projected vehicle path lines are not displayed.  
Refer to Personalisation Features on page 9-8.*

**How to use the projected vehicle path line function**

**⚠ CAUTION**


- *The front of the vehicle swings out wide when turning the steering wheel while reversing. Maintain sufficient distance between the vehicle and an obstruction.*
- *The parking sensor detection range has limitations. For example, obstructions closing in from the side and objects short in height may not be detected. Always confirm the safety around the vehicle visually when driving.  
For details, refer to the parking sensor obstruction detection indication and warning sound.  
Refer to Parking Sensor System on page 4-202.*

**NOTE**


- *Because there might be a difference between the image displayed on the screen, such as indicated in the following, and the actual conditions when parking, always check the safety at the rear of the vehicle and the surrounding area directly with your eyes.*
  - *Even though the back end of the parking space (or garage) displayed on the screen and distance guide lines appear parallel, they may not actually be parallel.*
  - *When parking in a space with a division line on only one side of the parking space, even though the division line and the vehicle width guide line appear parallel, they may not actually be parallel.*
- *The following shows an example of vehicle parking with the steering wheel turned to the right while backing up the vehicle. When backing into a parking space from the opposite direction, the steering operation is reversed.*

1. Back the vehicle into the parking space by turning the steering wheel so that the vehicle enters the centre of the parking space.

(Screen display)




(Actual condition)




2. After the vehicle starts entering the parking space, stop and adjust the steering wheel so that the distance between the vehicle width lines and the sides of the parking space on the left and right are roughly equal, and then continue backing up slowly.
3. Once the vehicle width lines and the sides of the parking space on the left and right are parallel, straighten the wheels and back the vehicle slowly into the parking space. Continue checking the vehicle's surroundings and then stop the vehicle in the best possible position. (If the parking space has division lines, check whether the vehicle width guide lines are parallel to them.)

(Screen display)



(Actual condition)




## ▼ Rear Wide View

Use the rear wide view to assist in checking the safety of the surrounding area when accelerating from a stop, parking, or stopping the vehicle.




**Range of displayed screen image**


**(Screen display)**



**(Actual condition)**



**Viewing the screen**



|   | Display/Icon                                                     | Content                                                                                                                                                                                                                                                                                                                                                                                                                                |
|---|------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| ① | Extended vehicle width lines and distance guide lines (red/blue) | <p>These guide lines indicate the approximate width of the vehicle and distance to a point measured from the rear of the vehicle (from the end of the bumper).</p> <ul style="list-style-type: none"><li>• The red lines indicate the points up to about 0.5 m from the rear end of the bumper.</li><li>• The blue lines indicate the points from about 0.5 m (20 in) and up to 2 m (79 in) from the rear end of the bumper.</li></ul> |

|   | Display/Icon                               | Content                                                                                                                                                                               |
|---|--------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| ② | Blind Spot Monitoring (BSM) warning lights | Indicates when the Rear Cross Traffic Alert (RCTA) has operated.<br>For details, refer to Rear Cross Traffic Alert (RCTA).<br>Refer to Rear Cross Traffic Alert (RCTA) on page 4-103. |

**NOTE**


- The parking sensor obstruction detection indication does not display. Switch the screen display to the top view/rear view display if the parking sensor warning sound is activated.
- The rear wide view screen displays the image at the rear of the vehicle at a wide angle and corrects the image to help detect approaching obstructions from the side. Therefore, it differs from the actual view.

**▼ Margin of Error Between Road Surface on Screen and Actual Road Surface**


There might be some margin of error between the road surface appearing on the screen and the actual road surface. A margin of error in the perceived distance could lead to an accident, therefore be aware of the following conditions which can more easily produce errors in the perceived distance.

**The vehicle tilts due to weight of passengers and cargo.**


If the vehicle is tilted, obstructions picked up by a camera can appear farther or closer than the actual distance from the vehicle.

**Front camera**

### Side camera




### Rear camera



### There is a steep up or down grade in the road at the front or rear of the vehicle

If there is a steep up or down grade in the road at the front or rear of the vehicle, obstructions picked up by the camera can appear farther or closer than the actual distance from the vehicle.


### Front camera




When Driving

## i-ACTIVSENSE

### Side camera



### Rear camera




### NOTE

*If the vehicle is on a slope, obstructions taken by the camera can appear farther or closer than the actual distance from the vehicle.*


### Three-dimensional object at vehicle front or rear

Because the vehicle front end guide lines (side camera) or the distance guide lines (rear camera) are displayed based on a flat surface, the distance to the three-dimensional object displayed on the screen is different from the actual distance.

**Side camera**



**Rear camera**




▼ **System Problem Indication**

| Centre display indication                | Cause                              | Action to be taken                                                                             |
|------------------------------------------|------------------------------------|------------------------------------------------------------------------------------------------|
| “No image signal reception” is displayed | The control unit might be damaged. | Have your vehicle inspected by an expert repairer (we recommend an Authorised Mazda Repairer). |
| Screen is pitch-black and blank          | The camera might be damaged.       |                                                                                                |

### Forward Sensing Camera (FSC)\*

Your vehicle is equipped with a Forward Sensing Camera (FSC). The Forward Sensing Camera (FSC) is positioned near the rearview mirror and used by the following systems.

- High Beam Control System (HBC)
- Adaptive LED Headlights (ALH)
- Driver Attention Alert (DAA)
- Lane Departure Warning System (LDWS)
- Lane-keep Assist System (LAS) & Lane Departure Warning System (LDWS)
- Traffic Sign Recognition System (TSR)
- Advanced Smart City Brake Support (Advanced SCBS)
- Smart Brake Support (SBS)



The Forward Sensing Camera (FSC) determines the conditions ahead of the vehicle while travelling at night and detects traffic lanes. The distance in which the Forward Sensing Camera (FSC) can detect objects varies depending on the surrounding conditions.

#### **WARNING**

***Do not modify the suspension:***

*If the vehicle height or inclination is changed, the system will not be able to correctly detect vehicles ahead. This will result in the system not operating normally or mistakenly operating, which could cause a serious accident.*

#### **CAUTION**

➤ *Do not apply accessories, stickers or film to the windscreen near the Forward Sensing Camera (FSC).*

*If the area in front of the Forward Sensing Camera (FSC) lens is obstructed, it will cause the system to not operate correctly. Consequently, each system may not operate normally which could lead to an unexpected accident.*

**4-174** \*Some models.

- *Do not disassemble or modify the Forward Sensing Camera (FSC).  
Disassembly or modification of the Forward Sensing Camera (FSC) will cause a malfunction or mistaken operation. Consequently, each system may not operate normally which could lead to an unexpected accident.*
- *Heed the following cautions to assure the correct operation of the Forward Sensing Camera (FSC).*
  - *Be careful not to scratch the Forward Sensing Camera (FSC) lens or allow it to get dirty.*
  - *Do not remove the Forward Sensing Camera (FSC) cover.*
  - *Do not place objects on the instrument panel which reflect light.*
  - *Always keep the windscreen glass around the camera clean by removing dirt or fogging. Use the windscreen defroster to remove fogging on the windscreen.*
  - *Consult an expert repairer (we recommend an Authorised Mazda Repairer) regarding cleaning the interior side of the windscreen around the Forward Sensing Camera (FSC).*
  - *Consult an expert repairer (we recommend an Authorised Mazda Repairer) before performing repairs around the Forward Sensing Camera (FSC).*
  - *The Forward Sensing Camera (FSC) is installed to the windscreen. Consult an expert repairer (we recommend an Authorised Mazda Repairer) for windscreen repair and replacement.*
  - *When cleaning the windscreen, do not allow glass cleaners or similar cleaning fluids to get on the Forward Sensing Camera (FSC) lens. In addition, do not touch the Forward Sensing Camera (FSC) lens.*
  - *When performing repairs around the rearview mirror, consult an expert repairer (we recommend an Authorised Mazda Repairer).*
  - *Consult an expert repairer (we recommend an Authorised Mazda Repairer) regarding cleaning of the camera lens.*
  - *Do not hit or apply strong force to the Forward Sensing Camera (FSC) or the area around it. If the Forward Sensing Camera (FSC) is severely hit or if there are cracks or damage caused by flying gravel or debris in the area around it, stop using the following systems and consult an expert repairer (we recommend an Authorised Mazda Repairer).*
    - *High Beam Control System (HBC)*
    - *Adaptive LED Headlights (ALH)*
    - *Lane Departure Warning System (LDWS)*
    - *Driver Attention Alert (DAA)*
    - *Lane-keep Assist System (LAS) & Lane Departure Warning System (LDWS)*
    - *Traffic Sign Recognition System (TSR)*
    - *Advanced Smart City Brake Support (Advanced SCBS)*
    - *Smart Brake Support (SBS)*
  - *The direction in which the Forward Sensing Camera (FSC) is pointed has been finely adjusted. Do not change the installation position of the Forward Sensing Camera (FSC) or remove it. Otherwise, it could result in damage or malfunction.*

- Always use tyres for all wheels that are of the specified size, and the same manufacturer, brand, and tread pattern. In addition, do not use tyres with significantly different wear patterns on the same vehicle as the system may not operate normally.
- The Forward Sensing Camera (FSC) includes a function for detecting a soiled windscreen and informing the driver, however, depending on the conditions, it may not detect plastic shopping bags, ice or snow on the windscreen. In such cases, the system cannot accurately determine a vehicle ahead and may not be able to operate normally. Always drive carefully and pay attention to the road ahead.

### NOTE

- In the following cases, the Forward Sensing Camera (FSC) cannot detect target objects correctly, and each system may be unable to operate normally.
  - The height of the vehicle ahead is low.
  - You drive your vehicle at the same speed as the vehicle ahead.
  - Headlights are not turned on during the night or when going through a tunnel.
- In the following cases, the Forward Sensing Camera (FSC) may not be able to detect target objects correctly.
  - Under bad weather condition, such as rain, fog and snow.
  - The window washer is being used or the windscreen wipers are not used when it's raining.
  - Ice, fog, snow, frost, rainfall, dirt, or foreign matter such as a plastic bag is stuck on the windscreen.
  - Trucks with low loading platforms and vehicles with an extremely low or high profile.
  - When driving next to walls with no patterning (including fences and longitudinally striped walls).
  - The tail lights of the vehicle ahead are turned off.
  - A vehicle is outside the illumination range of the headlights.
  - The vehicle is making a sharp turn, or ascending or descending a steep slope.
  - Entering or exiting a tunnel.
  - Heavy luggage is loaded causing the vehicle to tilt.
  - Strong light is shone at the front of the vehicle (back light or high-beam light from on-coming vehicles).
  - There are many light emitters on the vehicle ahead.
  - When the vehicle ahead is not equipped with tail lights or the tail lights are turned off at nighttime.
  - Elongated luggage or cargo is loaded onto installed roof rails and covers the Forward Sensing Camera (FSC).
  - Exhaust gas from the vehicle in front, sand, snow, and water vapour rising from manholes and grating, and water splashed into the air.
  - When towing a malfunctioning vehicle.



- The vehicle is driven with tyres having significantly different wear.
- The vehicle is driven on down slopes or bumpy roads.
- There are water puddles on the road.
- The surroundings are dark such as during the night, early evening, or early morning, or in a tunnel or indoor parking lot.
- The illumination brightness of the headlights is reduced or the headlight illumination is weakened due to dirt or a deviated optical axis.
- The target object enters the blind spot of the Forward Sensing Camera (FSC).
- A person or object bursts onto the road from the shoulder or cuts right in front of you.
- You change lanes and approach a vehicle ahead.
- When driving extremely close to the target object.
- Tyre chains or a temporary spare tyre is installed.
- The vehicle ahead has a special shape. For example, a vehicle towing a trailer house or a boat, or a vehicle carrier carrying a vehicle with its front pointed rearward.
- If the Forward Sensing Camera (FSC) cannot operate normally due to backlight or fog, the system functions related to the Forward Sensing Camera (FSC) are temporarily stopped and the following warning lights turn on. However, this does not indicate a malfunction.
  - High Beam Control System (HBC) warning light (amber)
  - Adaptive LED Headlights (ALH) warning light (amber)
  - Lane Departure Warning System (LDWS) warning light
  - Lane-keep Assist System (LAS) & Lane Departure Warning System (LDWS) warning light
  - Smart Brake Support/Smart City Brake Support (SBS/SCBS) warning light (amber)
- If the Forward Sensing Camera (FSC) cannot operate normally due to high temperatures, the system functions related to the Forward Sensing Camera (FSC) are temporarily stopped and the following warning lights turn on. However, this does not indicate a malfunction. Cool down the area around the Forward Sensing Camera (FSC) such as by turning on the air conditioner.
  - High Beam Control System (HBC) warning light (amber)
  - Adaptive LED Headlights (ALH) warning light (amber)
  - Lane Departure Warning System (LDWS) warning light
  - Lane-keep Assist System (LAS) & Lane Departure Warning System (LDWS) warning light
  - Smart Brake Support/Smart City Brake Support (SBS/SCBS) warning light (amber)

· If the Forward Sensing Camera (FSC) detects that the windscreen is dirty or foggy, the system functions related to the Forward Sensing Camera (FSC) are temporarily stopped and the following warning lights turn on. However, this does not indicate a problem. Remove the dirt from the windscreen or press the defroster switch and defog the windscreen.

- High Beam Control System (HBC) warning light (amber)
- Adaptive LED Headlights (ALH) warning light (amber)
- Lane Departure Warning System (LDWS) warning light
- Lane-keep Assist System (LAS) & Lane Departure Warning System (LDWS) warning light
- Smart Brake Support/Smart City Brake Support (SBS/SCBS) warning light (amber)
- If there are recognizable cracks or damage caused by flying gravel or debris on the windscreen, always have the windscreen replaced. Consult an expert repairer (we recommend an Authorised Mazda Repairer) for replacement.
- **(With Advanced Smart City Brake Support (Advanced SCBS))**

· The Forward Sensing Camera (FSC) recognises pedestrians when all of the following conditions are met:

- The height of a pedestrian is about 1 to 2 meters.
- An outline such as the head, both shoulders, or the legs can be determined.
- In the following cases, the Forward Sensing Camera (FSC) may not be able to detect target objects correctly:
  - Multiple pedestrians are walking, or there are groups of people.
  - A pedestrian is close to a separate object.
  - A pedestrian is crouching, lying, or slouching.
  - A pedestrian suddenly jumps into the road right in front of the vehicle.
  - A pedestrian opens an umbrella, or is carrying large baggage or articles.
  - A pedestrian is in a dark location such as during the night, or blends into the background by wearing clothes matching the background colour.


## Radar Sensor (Front)\*

Your vehicle is equipped with a radar sensor (front).  
The following systems also use the radar sensor (front).

- Mazda Radar Cruise Control (MRCC)
- Distance Recognition Support System (DRSS)
- Smart Brake Support (SBS)

The radar sensor (front) functions by detecting the radio waves reflected off a vehicle ahead or an obstruction sent from the radar sensor.

The radar sensor (front) is mounted behind the front emblem.



If the Smart Brake Support/Smart City Brake Support (SBS/SCBS) Warning Light (amber) is illuminated, the area around the radar sensor may be dirty. Refer to “Warning Guidance” in the centre display (Type B audio).

Refer to If a Warning Light Turns On or Flashes on page 7-23.

### **CAUTION**

*Heed the following precautions to assure correct operation of each system.*

- *Do not adhere stickers (including transparent stickers) to the surface of the radiator grille and front emblem in and around the radar sensor (front), and do not replace the radiator grille and front emblem with any product that is not a genuine product designed for use with the radar sensor (front).*
- *The radar sensor (front) includes a function for detecting soiling of the radar sensor's front surface and informing the driver, however, depending on the conditions, it may require time to detect or it may not detect plastic shopping bags, ice or snow. If this occurs, the system may not operate correctly, therefore always keep the radar sensor (front) clean.*
- *Do not install a grille guard.*
- *If the front part of the vehicle has been damaged in a vehicle accident, the position of the radar sensor (front) may have moved. Stop the system immediately and always have the vehicle inspected at an expert repairer (we recommend an Authorised Mazda Repairer).*

\*Some models. **4-179**

- Do not use the front bumper to push other vehicles or obstructions such as when pulling out of a parking space. Otherwise, the radar sensor (front) could be hit and its position deviated.
- Do not remove, disassemble, or modify the radar sensor (front).
- For repairs, replacement or paint work around the radar sensor (front), consult an expert repairer (we recommend an Authorised Mazda Repairer).
- Do not modify the suspension. If the suspension are modified, the vehicle's posture could change and the radar sensor (front) may not be able to correctly detect a vehicle ahead or an obstruction.

**NOTE**

- Under the following conditions, the radar sensor (front) may not be able to detect vehicles ahead or obstructions correctly and each system may not operate normally.
  - The rear surface of a vehicle ahead does not reflect radio waves effectively, such as an unloaded trailer or an automobile with a loading platform covered by a soft top, vehicles with a hard plastic tailgate, and round-shaped vehicles.
  - Vehicles ahead with low vehicle height and thus less area for reflecting radio waves.
  - Visibility is reduced due to a vehicle ahead casting off water, snow, or sand from its tyres and onto your windscreen.
  - The boot/luggage compartment is loaded with heavy objects or the rear passenger seats are occupied.
  - Ice, snow, or soiling is on the front surface of the front emblem.
  - During inclement weather such as rain, snow, or sand storms.
  - When driving near facilities or objects emitting strong radio waves.
- Under the following conditions, the radar sensor (front) may not be able to detect vehicles ahead or obstructions.
  - The beginning and end of a curve.
  - Roads with continuous curves.
  - Narrow lane roads due to road construction or lane closures.
  - The vehicle ahead enters the radar sensor's blind spot.
  - The vehicle ahead is running abnormally due to accident or vehicle damage.
  - Roads with repeated up and down slopes
  - Driving on poor roads or unpaved roads.
  - The distance between your vehicle and the vehicle ahead is extremely short.
  - A vehicle suddenly comes close such as by cutting into the lane.
- To prevent incorrect operation of the system, use tyres of the same specified size, manufacturer, brand, and tread pattern on all 4 wheels. In addition, do not use tyres with significantly different wear patterns or tyre pressures on the same vehicle (Including the temporary spare tyre).
- If the battery power is weak, the system may not operate correctly.

- *If the vehicle is driven on a road with little traffic and few vehicles ahead or obstructions for the radar sensor (front) to detect, the sensor detects that the radar sensor (front) is dirty and the Smart Brake Support/Smart City Brake Support (SBS/SCBS) Warning Light (amber) may be temporarily turned on. However, it does not indicate a malfunction.*
- *The radar sensors are regulated by the relevant radio wave laws of the country in which the vehicle is driven. If the vehicle is driven abroad, authorization from the country in which the vehicle is driven may be required.*


### Radar Sensors (Rear)\*

Your vehicle is equipped with radar sensors (rear). The following systems also use the radar sensors (rear).

- Blind Spot Monitoring system (BSM)
- Rear Cross Traffic Alert (RCTA)


The radar sensors (rear) function by detecting the radio waves reflected off a vehicle approaching from the rear or an obstruction sent from the radar sensor.

**Saloon**



Radar sensors (rear)

**Hatchback**



Radar sensors (rear)

The radar sensors (rear) are installed inside the rear bumper, one each on the left and right sides.

Always keep the surface of the rear bumper near the radar sensors (rear) clean so that the radar sensors (rear) operate normally. Also, do not apply items such as stickers.

Refer to Exterior Care on page 6-44.

#### **CAUTION**

*If the rear bumper receives a severe impact, the system may no longer operate normally. Stop the system immediately and have the vehicle inspected at an Authorised Mazda Dealer.*

#### **NOTE**

- *The detection ability of the radar sensors (rear) has limitations. In the following cases, the detection ability may lower and the system may not operate normally.*
  - *The rear bumper near the radar sensors (rear) has become deformed.*
  - *Snow, ice or mud adheres to the radar sensors (rear) on the rear bumper.*
  - *Under bad weather conditions such as rain, snow and fog.*

- *Under the following conditions, the radar sensors (rear) cannot detect target objects or it may be difficult to detect them.*
  - *Stationary objects on a road or a road side such as small, two-wheeled vehicles, bicycles, pedestrians, animals, and shopping carts.*
  - *Vehicle shapes which do not reflect radar waves well such as empty trailers with a low vehicle height and sports cars.*
- *Vehicles are shipped with the direction of the radar sensors (rear) adjusted for each vehicle to a loaded vehicle condition so that the radar sensors (rear) detect approaching vehicles correctly. If the direction of the radar sensors (rear) has deviated for some reason, have the vehicle inspected at an Authorised Mazda Dealer.*
- *For repairs or replacement of the radar sensors (rear), or bumper repairs, paintwork, and replacement near the radar sensors, consult an Authorised Mazda Dealer.*
- *Turn off the system while pulling a trailer or while an accessory such as a bicycle carrier is installed to the rear of the vehicle. Otherwise, the radio waves emitted by the radar will be blocked causing the system to not operate normally.*
- *The radar sensors are regulated by the relevant radio wave laws of the country in which the vehicle is driven. If the vehicle is driven abroad, authorization from the country in which the vehicle is driven may be required.*


When Driving

## i-ACTIVSENSE

### Ultrasonic Sensor (Rear)\*


The ultrasonic sensors (rear) function by emitting ultrasonic waves which are reflected off obstructions at the rear and the returning ultrasonic waves are picked up by the ultrasonic sensors (rear).

**Saloon**



Ultrasonic sensor (rear)

**Hatchback**



Ultrasonic sensor (rear)

The ultrasonic sensors (rear) are mounted in the rear bumper.




## Front Camera/Side Cameras/Rear Camera\*

Your vehicle is equipped with a front camera, side cameras, and a rear camera. The 360° View Monitor uses each camera.

The front camera, side cameras, and rear camera shoot images of the area surrounding the vehicle.

Each camera is installed to the following positions.



\*Some models. **4-185**

When Driving

## Cruise Control

### Cruise Control\*

With cruise control, you can set and automatically maintain any speed of more than about 25 km/h (16 mph).


#### **WARNING**

**Do not use the cruise control under the following conditions:**

*Using the cruise control under the following conditions is dangerous and could result in loss of vehicle control.*


- Hilly terrain
- Steep inclines
- Heavy or unsteady traffic
- Slippery or winding roads
- Similar restrictions that require inconsistent speed

#### ▼ Cruise Control Switch



**NOTE**

If your Mazda has the following steering switch, your Mazda is equipped with the Mazda Radar Cruise Control (MRCC) system.  
Refer to Mazda Radar Cruise Control (MRCC) on page 4-107.



**▼ Cruise main indication (white),  
Cruise Set Indication (White)/  
Indicator Light (Green)**

**Cruise main indication (white)**

The cruise main indication (white) is displayed in the instrument cluster when the cruise control system is activated.



**Cruise set indication (white)/indicator  
light (green)**

The cruise set indication (white) is displayed in the instrument cluster and the cruise set indicator light (green) turns on when a cruising speed has been set.



**▼ Activation/Deactivation**

To activate the system, press the MODE switch. The cruise main indication (white) is displayed.

To deactivate the system, press the OFF/CANCEL switch.

The cruise main indication (white) turns off.

**NOTE**

When the MODE switch is pressed while the cruise control system is operating, the cruise control system switches to the Adjustable Speed Limiter (ASL).

## Cruise Control

### ▼ To Set Speed

1. Activate the cruise control system by pressing the MODE switch. The cruise main indication (white) is displayed.
2. Accelerate to the desired speed, which must be more than 25 km/h (16 mph).
3. Set the cruise control by pressing the SET/− switch at the desired speed. The cruise control is set at the moment the SET/− switch is pressed. Release the accelerator pedal simultaneously. The cruise set indication (white) is displayed and the cruise set indicator light (green) turns on.

### NOTE

· The cruise control speed setting cannot be performed under the following conditions:

- **(Automatic transaxle)**  
The selector lever is in the P, N, or R position.
- **(Manual transaxle)**  
The shift lever is in the neutral position.
- The parking brake is applied.
- The MODE switch for the Adjustable Speed Limiter (ASL) is pressed.

- Release the SET/− or RES/+ switch at the desired speed, otherwise the speed will continue increasing while the RES/+ switch is pressed and held, and continue decreasing while the SET/− switch is pressed and held (except when the accelerator pedal is depressed).
- On a steep grade, the vehicle may momentarily slow down while ascending, or speed up while descending.
- The cruise control will cancel if the vehicle speed decreases below 21 km/h (13 mph) when climbing a steep grade.
- The cruise control may cancel at about 15 km/h (9 mph) below the preset speed such as when climbing a long, steep grade.

### ▼ To Increase Cruising Speed

Follow either of these procedures.

#### To increase speed using cruise control switch

Press the RES/+ switch and hold it. Your vehicle will accelerate. Release the switch at the desired speed.

Press the RES/+ switch and release it immediately to adjust the preset speed. Multiple operations will increase the preset speed according to the number of times it is operated.

#### **Increasing speed with a single RES/+ switch operation**

Instrument cluster display for vehicle speed indicated in km/h: 1 km/h (0.6 mph)  
Instrument cluster display for vehicle speed indicated in mph: 1 mph (1.6 km/h)

**To increase speed using accelerator pedal**

Depress the accelerator pedal to accelerate to the desired speed. Press the SET/− switch and release it immediately.

**NOTE**

*Accelerate if you want to speed up temporarily when the cruise control is on. Greater speed will not interfere with or change the set speed. Take your foot off the accelerator to return to the set speed.*

**▼ To Decrease Cruising Speed**

Press the SET/− switch and hold it. The vehicle will gradually slow.  
Release the switch at the desired speed.

Press the SET/− switch and release it immediately to adjust the preset speed. Multiple operations will decrease the preset speed according to the number of times it is operated.

**Decreasing speed with a single SET/− switch operation**

Instrument cluster display for vehicle speed indicated in km/h: 1 km/h (0.6 mph)  
Instrument cluster display for vehicle speed indicated in mph: 1 mph (1.6 km/h)

**▼ To Resume Cruising Speed at More Than 25 km/h (16 mph)**

If the cruise control system temporarily cancelled (such as applying the brake pedal) and the system is still activated, the most recent set speed will automatically resume when the RES/+ switch is pressed.

If vehicle speed is below 25 km/h (16 mph), increase the vehicle speed up to 25 km/h (16 mph) or more and press the RES/+ switch.

**▼ To Temporarily Cancel**

To temporarily cancel the system, use one of these methods:

- Slightly depress the brake pedal.
- **(Manual transaxle)**  
Depress the clutch pedal.
- Press the OFF/CANCEL switch.

If the RES/+ switch is pressed when the vehicle speed is 25 km/h (16 mph) or higher, the system reverts to the previously set speed.

**NOTE**

- *If any of the following conditions occur, the cruise control system is temporarily cancelled.*
  - *The parking brake is applied.*
  - *The MODE switch for the Adjustable Speed Limiter (ASL) is pressed.*
  - **(Automatic transaxle)**  
*The selector lever is in the P, N, or R position.*
  - **(Manual transaxle)**  
*The shift lever is in the neutral position.*
- *When the cruise control system is temporarily cancelled by even one of the applicable cancel conditions, the speed cannot be re-set.*

When Driving

## Cruise Control

---

· ***(Automatic transaxle)***

*The cruise control cannot be cancelled while driving in manual mode (selector lever shifted from D to M position).*

*Therefore, engine braking will not be applied even if the transaxle is shifted down to a lower gear. If deceleration is required, lower the set speed or depress the brake pedal.*

▼ **To Deactivate**

**When a cruising speed has been set (cruise set indication (white) is displayed/cruise set indicator light (green) turns on)**

Long-press the OFF/CANCEL switch or press the OFF/CANCEL switch 2 times.

**When a cruising speed has not been set (cruise main indication (white) is displayed)**

Press the OFF/CANCEL switch.

## Tyre Pressure Monitoring System

### Tyre Pressure Monitoring System


The Tyre Pressure Monitoring System (TPMS) monitors the air pressure of all four tyres. If the air pressure of one or more tyres is too low, the system warns the driver by indicating the tyre pressure monitoring system warning light in the instrument cluster and operating a beep sound. The system monitors the tyre pressures indirectly using the data sent from the ABS wheel speed sensors.

To allow the system to operate correctly, the system needs to be initialized with the specified tyre pressure (value on the tyre pressure label). Follow the procedure and perform the initialization.

Refer to Tyre Pressure Monitoring System Initialization on page 4-193.

The warning light flashes when the system has a malfunction.

Refer to Warning Lights on page 4-29.



ABS wheel speed sensor

#### CAUTION

➤ Each tyre, including the spare (if provided), should be checked monthly when cold and inflated to the inflation pressure recommended by the vehicle manufacturer on the vehicle placard or tyre inflation pressure label. (If your vehicle has tyres of a different size than the size indicated on the vehicle placard or tyre inflation pressure label, you should determine the proper tyre inflation pressure for those tyres.)

As an added safety feature, your vehicle has been equipped with a tyre pressure monitoring system (TPMS) that illuminates a low tyre pressure telltale when one or more of your tyres is significantly under-inflated. Accordingly, when the low tyre pressure telltale illuminates, you should stop and check your tyres as soon as possible, and inflate them to the proper pressure. Driving on a significantly under-inflated tyre causes the tyre to overheat and can lead to tyre failure. Under-inflation also reduces fuel efficiency and tyre tread life, and may affect the vehicle's handling and stopping ability.

## Tyre Pressure Monitoring System

---

*Please note that the TPMS is not a substitute for proper tyre maintenance, and it is the driver's responsibility to maintain correct tyre pressure, even if under-inflation has not reached the level to trigger illumination of the TPMS low tyre pressure telltale.*

*Your vehicle has also been equipped with a TPMS malfunction indicator to indicate when the system is not operating properly.*

*The TPMS malfunction indicator is combined with the low tyre pressure telltale. When the system detects a malfunction, the telltale will flash for approximately one minute and then remain continuously illuminated. This sequence will continue upon subsequent vehicle start-ups as long as the malfunction exists. When the malfunction indicator is illuminated, the system may not be able to detect or signal low tyre pressure as intended. TPMS malfunctions may occur for a variety of reasons, including the installation of replacement or alternate tyres or wheels on the vehicle that prevent the TPMS from functioning properly. Always check the TPMS malfunction telltale after replacing one or more tyres or wheels on your vehicle to ensure that the replacement or alternate tyres and wheels allow the TPMS to continue to function properly.*

➤ *To avoid false readings, the system samples for a little while before indicating a problem. As a result it will not instantaneously register a rapid tyre deflation or blow out.*

### **NOTE**

*Because this system detects slight changes in tyre conditions, the timing of the warning may be faster or slower in the following cases:*

- The size, manufacturer, or the type of tyres is different from the specification.*
- The size, manufacturer, or the type of a tyre is different from the others, or the level of tyre wear is excessively different between them.*
- A run-flat tyre, studless tyre, snow tyre, or tyre chains are used.*
- An emergency tyre is used (The tyre pressure monitoring system warning light may flash and then continue illuminating).*
- A tyre is repaired using the emergency flat tyre repair kit.*
- The tyre pressure is excessively higher than the specified pressure, or the tyre pressure is suddenly lowered for some reason such as a tyre burst during driving.*
- The vehicle speed is lower than about 15 km/h (9.3 mph) (including when the vehicle is stopped), or the drive period is shorter than 5 minutes.*
- The vehicle is driven on an extremely rough road or a slippery, icy road.*
- Hard steering and rapid acceleration/deceleration are repeated such as during aggressive driving on a winding road.*
- Load on the vehicle is applied to a tyre such as by loading heavy luggage to one side of the vehicle.*
- System initialization has not been implemented with the specified tyre pressure.*



## Tyre Pressure Monitoring System


### ▼ Tyre Pressure Monitoring System Initialization

In the following cases, system initialization must be performed so that the system operates normally.

- A tyre pressure is adjusted.
- Tyre rotation is performed.
- A tyre or wheel is replaced.
- The battery is replaced or completely drained.
- The tyre pressure monitoring system warning light is illuminated.

#### Initialization method

1. Park the car in a safe place and firmly apply the parking brake.
2. Let the tyres cool, then adjust the tyre pressure of all four (4) tyres to the specified pressure indicated on the tyre pressure label located on the driver's door frame (door open).  
Refer to Tyres on page 9-6.
3. Switch the ignition ON.
4. Press and hold the tyre pressure monitoring system set switch and verify that the tyre pressure monitoring system warning light in the instrument cluster flashes twice and a beep sound is heard once.



### ⚠ CAUTION

*If the system initialization is performed without adjusting the tyre pressure, the system cannot detect the normal tyre pressure and it may not illuminate the tyre pressure monitoring system warning light even if a tyre pressure is low, or it may illuminate the light even if the pressures are normal.*

*Adjust the tyre pressure on all four tyres and initialize the system when the warning light is turned on. If the warning light turns on for a reason other than a flat tyre, the tyre pressure of all four tyres may have decreased naturally.*

*The system initialization will not be performed if the switch is pressed while the vehicle is being driven.*

## Rear View Monitor

### Rear View Monitor\*

The rear view monitor provides visual images of the rear of the vehicle when reversing.

#### **WARNING**

***Always drive carefully confirming the safety of the rear and the surrounding conditions by looking directly with your eyes:***

*Reversing the vehicle by only looking at the screen is dangerous as it may cause an accident or a collision with an object. The rear view monitor is only a visual assist device when reversing the vehicle. The images on the screen may be different from the actual conditions.*

#### **CAUTION**

- Do not use the rear view monitor under the following conditions: Using the rear view monitor under the following conditions is dangerous and could result in injury or vehicle damage or both.
  - Icy or snow-covered roads.
  - Tyre chains or a temporary spare tyre is installed.
  - The liftgate/boot lid is not fully closed.
  - The vehicle is on a road incline.
- When the display is cold, images may course across the monitor or the screen and may be dimmer than usual, which could cause difficulty in confirming the surrounding conditions of the vehicle. Always drive carefully confirming the safety of the rear and the surrounding conditions by looking directly with your eyes.
- Do not apply excessive force to the camera. The camera position and angle may deviate.
- Do not disassemble, modify, or remove it as it may no longer be waterproof.
- The camera cover is made of plastic. Do not apply degreasing agents, organic solvents, wax, or glass coating agents to the camera cover. If any are spilled on the cover, wipe off with a soft cloth immediately.
- Do not rub the camera cover forcefully with an abrasive or hard brush. The camera cover or lens may be scratched which might affect the images.

#### **NOTE**


- If water, snow, or mud is stuck on the camera lens, wipe it off using a soft cloth. If it cannot be wiped off, use a mild detergent.
- If the camera temperature changes rapidly (Hot to cold, cold to hot), the rear view monitor may not operate correctly.

When Driving

## Rear View Monitor

- When replacing the tyres, consult an expert repairer (we recommend an Authorised Mazda Repairer). Replacing the tyres could result in deviation of the guide lines which appear on the display.
- If the vehicle's front, side, or rear has been involved in a collision, the alignment of the rear view parking camera (location, installation angle) may have deviated. Always consult an expert repairer (we recommend an Authorised Mazda Repairer) to have the vehicle inspected.
- If “No Video Signal Available” is indicated in the display, there could be a problem with the camera. Have your vehicle inspected at an expert repairer (we recommend an Authorised Mazda Repairer).

### ▼ Rear View Parking Camera Location



### ▼ Switching to the Rear View Monitor Display

Shift the shift lever/selector lever to R with the ignition switched ON to switch the display to the rear view monitor display.

#### **NOTE**

When the shift lever/selector lever is shifted from R to another shift lever/selector lever position, the screen returns to the previous display.


## Rear View Monitor

### ▼ Displayable Range on the Screen


The images on the screen may be different from the actual conditions.

#### (Screen display)

Boot lid (saloon)/  
Bumper (hatchback)



#### (Actual view)



### NOTE


- The displayable range varies depending on the vehicle and road conditions.
- The displayable range is limited. Objects under the bumper or around the bumper ends cannot be displayed.
- The distance appearing in the displayed image is different from the actual distance because the rear view parking camera is equipped with a specific lens.
- Some optionally installed vehicle accessories may be picked up by the camera. Do not install any optional parts that can interfere with the camera view, such as illuminating parts or parts made of reflective material.
- It may be difficult to see the display under the following conditions, however, it does not indicate a malfunction.
  - In darkened areas.
  - When the temperature around the lens is high/low.
  - When the camera is wet such as on a rainy day or during periods of high humidity.
  - When foreign material such as mud is stuck around the camera.
  - When the camera lens reflects sunlight or headlight beams.
- Image display may be delayed if the temperature around the camera is low.

## When Driving Rear View Monitor

### ▼ Viewing the Display

Guide lines which indicate the width of the vehicle (yellow) are displayed on the screen as a reference to the approximate width of the vehicle in comparison to the width of the parking space you are about to back into.

Use this display view for parking your vehicle in a parking space or garage.



#### a) Vehicle width guide lines (yellow)

These guide lines serve as a reference to the approximate width of the vehicle.

#### b) Distance guide lines.

These guide lines indicate the approximate distance to a point measured from the vehicle's rear (from the end of the bumper).

- The red and yellow lines indicate the points about 50 cm (19 in) for the red line and 100 cm (39.3 in) for the yellow lines from the rear bumper (at the centre point of each of the lines).

### ⚠ CAUTION

*The guide lines on the screen are fixed lines. They are not synced to the driver's turning of the steering wheel. Always be careful and check the area to the vehicle's rear and the surrounding area directly with your eyes while backing up.*

### ▼ Rear View Monitor Operation

The operation of the rear view monitor when reversing the vehicle varies depending on the traffic, road, and vehicle conditions. The amount of steering and the timing also varies depending on conditions, so confirm the surrounding conditions directly with your eyes and steer the vehicle in accordance with the conditions.

Be well aware of the above cautions prior to using the rear view monitor.

#### NOTE

*Images displayed on the monitor from the rear view parking camera are reversed images (mirror images).*

When Driving


## Rear View Monitor

1. Shift the shift lever/selector lever to R to switch the display to the rear view monitor display.
2. Confirming the surrounding conditions, reverse the vehicle.

(Display condition)




(Vehicle condition)




3. After your vehicle begins entering the parking space, continue backing up slowly so that the distance between the vehicle width lines and the sides of the parking space on the left and right are roughly equal.
4. Continue to adjust the steering wheel until the vehicle width guide lines are parallel to the left and right sides of the parking space.
5. Once they are parallel, straighten the wheels and back your vehicle slowly into the parking space. Continue checking the vehicle's surroundings and then stop the vehicle in the best possible position.

(Display condition)



(Vehicle condition)




6. When the shift lever/selector lever is shifted from R to another shift lever/selector lever position, the screen returns to the previous display.

When Driving

## Rear View Monitor

### NOTE

- If the parking space has division lines, straighten the wheels when the vehicle width guide lines are parallel to them.
- Because there may be a difference between the displayed image, such as indicated below, and the actual conditions when parking, always verify the safety at the rear of the vehicle and the surrounding area directly with your eyes.
- In the image of the parking space (or garage) displayed on the screen, the back end and distance guide lines may appear aligned in the monitor, but they may not actually be aligned on the ground.
- When parking in a space with a division line on only one side of the parking space, the division line and the vehicle width guide line appear aligned in the monitor, but they may not actually be aligned on the ground.




### ▼ Variance Between Actual Road Conditions and Displayed Image

Some variance occurs between the actual road and the displayed road. Such variance in distance perspective could lead to an accident. Note the following conditions that may cause a variance in distance perspective.

#### When the vehicle is tilted due to the weight of passengers and load

When the vehicle rear is lowered, the object displayed on the screen appears farther than the actual distance.




When Driving

## Rear View Monitor

### When there is a steep grade behind the vehicle


When there is a steep upgrade (downgrade) behind the vehicle, the object displayed on the screen appears farther (downgrade: closer) than the actual distance.



### Three-dimensional object on vehicle rear


Because the distance guide lines are displayed based on a flat surface, the distance to the three-dimensional object displayed on the screen is different from the actual distance.

(Screen display)



Sensed distance on screen  $A > B > C$

(Actual condition)



(Actual distance)  $B > C = A$



## Rear View Monitor

---

### ▼ Picture Quality Adjustment

#### **WARNING**

***Always adjust the picture quality of the rear view monitor while the vehicle is stopped:***

*Do not adjust the picture quality of the rear view monitor while driving the vehicle. Adjusting the picture quality of the rear view monitor such as brightness, contrast, colour, and tint while driving the vehicle is dangerous as it could distract your attention from the vehicle operation which could lead to an accident.*

Picture quality adjustment must be done while the shift lever/selector lever is in reverse (R). There are four settings which can be adjusted including, brightness, contrast, tint, and colour. When adjusting, pay sufficient attention to the vehicle surroundings.

1. Select the  icon on the screen to display the tabs.
2. Select the desired tab item.
3. Adjust the brightness, contrast, tint, and colour using the slider.  
If you need to reset, press the reset button.
4. Select the  icon on the screen to close the tab.


When Driving

## Parking Sensor System


### Parking Sensor System\*

The parking sensors use ultrasonic sensors which detect obstructions around the vehicle when the vehicle is driven at low speeds, such as during garage or parallel parking, and a buzzer sound and detection indicator notify the driver of the approximate distance from the vehicle to the surrounding obstruction.


#### Front



#### Rear Saloon



#### Hatchback



\*Some models.

### WARNING

**Do not rely completely on the parking sensor system and be sure to confirm the safety around your vehicle visually when driving:**

*This system can assist the driver in operating the vehicle in the forward and backward directions while parking. The detection ranges of the sensors are limited, therefore, driving the vehicle while relying only on the system may cause an accident. Always confirm the safety around your vehicle visually when driving.*

#### NOTE

- Do not install any accessories within the detection ranges of the sensors. It may affect the system operation.
- Depending on the type of obstruction and the surrounding conditions, the detection range of a sensor may narrow, or the sensors may not be able to detect obstructions.

## Parking Sensor System

---


- *The system may not operate normally under the following conditions:*
  - *Mud, ice, or snow is adhering to the sensor area (Returns to normal operation when removed).*
  - *The sensor area is frozen (Returns to normal operation when the ice is thawed).*
  - *The sensor is covered by a hand.*
  - *The sensor is excessively shocked.*
  - *The vehicle is excessively tilted.*
  - *Under extremely hot or cold weather conditions.*
  - *The vehicle is driven on bumps, inclines, gravel, or grass covered roads.*
  - *Anything which generates ultrasound is near the vehicle, such as another vehicle's horn, the engine sound of a motorcycle, the air brake sound of a large-sized vehicle, or another vehicle's sensors.*
  - *The vehicle is driven in heavy rain or in road conditions causing water-splash.*
  - *A commercially-available wing pole or an aerial for a radio transmitter is installed to the vehicle.*
  - *The vehicle is moving towards a tall or square curbstone.*
  - *An obstruction is too close to the sensor.*
- *Obstructions under the bumper may not be detected. Obstructions that are lower than the bumper or thin which may have been initially detected may no longer be detected as the vehicle approaches more closely to the obstruction.*
- *The following types of obstructions may not be detected:*
  - *Thin objects such as wire or rope*
  - *Things which absorb sonic waves easily such as cotton or snow*
  - *Angular shaped objects*
  - *Very tall objects, and those which are wide at the top*
  - *Small, short objects*
- *Always have the system inspected at an expert repairer (we recommend an Authorised Mazda Repairer) if any shock is applied to the bumpers, even in a minor accident. If the sensors are deviated, they cannot detect obstructions.*
- *The beeper which indicates a system malfunction may not be heard if the ambient temperature is extremely cold, or mud, ice, or snow adheres to the sensor area. Remove any foreign material from the sensor area.*
- *When installing a trailer hitch, consult an expert repairer (we recommend an Authorised Mazda Repairer).*

When Driving

## Parking Sensor System

### ▼ Sensor Detection Range

The sensors detect obstructions within the following range.












Viewing distance display

| Display                                      |                                           |                        | Distance between vehicle and obstruction             |                                                     |
|----------------------------------------------|-------------------------------------------|------------------------|------------------------------------------------------|-----------------------------------------------------|
| Without 360° view monitor                    |                                           | With 360° view monitor | Front Sensor*/Front Corner Sensor*                   | Rear Sensor/Rear Corner Sensor                      |
| Without front sensor and front corner sensor | With front sensor and front corner sensor |                        |                                                      |                                                     |
|                                              |                                           | Green<br>              | Front sensor:<br>Approx. 100—60 cm<br>(39.3—23.6 in) | Rear sensor:<br>Approx. 150—60 cm<br>(59.0—23.6 in) |

When Driving

## Parking Sensor System

| Display                                                                             |                                                                                     |                                                                                             | Distance between vehicle and obstruction                                                                          |                                                                                                                 |
|-------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------|
| Without 360° view monitor                                                           |                                                                                     | With 360° view monitor                                                                      | Front Sensor*/Front Corner Sensor*                                                                                | Rear Sensor/Rear Corner Sensor                                                                                  |
| Without front sensor and front corner sensor                                        | With front sensor and front corner sensor                                           |                                                                                             |                                                                                                                   |                                                                                                                 |
|    |    | Yellow<br> | Front sensor:<br>Approx. 60—45 cm<br>(23.6—17.7 in)<br>Front corner sensor:<br>Approx. 55—38 cm<br>(21.7—15.0 in) | Rear sensor:<br>Approx. 60—45 cm<br>(23.6—17.7 in)<br>Rear corner sensor:<br>Approx. 55—38 cm<br>(21.7—15.0 in) |
|  |   | Amber<br> | Front sensor:<br>Approx. 45—35 cm<br>(17.7—13.7 in)<br>Front corner sensor:<br>Approx. 38—25 cm<br>(15.0—9.8 in)  | Rear sensor:<br>Approx. 45—35 cm<br>(17.7—13.7 in)<br>Rear corner sensor:<br>Approx. 38—25 cm<br>(15.0—9.8 in)  |
|  |  | Red<br>  | Front sensor:<br>Within approx. 35 cm<br>(13.7 in)<br>Front corner sensor:<br>Within approx. 25 cm<br>(9.8 in)    | Rear sensor:<br>Within approx. 35 cm<br>(13.7 in)<br>Rear corner sensor:<br>Within approx. 25 cm<br>(9.8 in)    |

\*Some models. **4-205**

When Driving

## Parking Sensor System

---

### ▼ Park Assist Sensor System Operation

#### Vehicles without front sensor/front corner sensor


The parking sensors can be used when the shift lever/selector lever is shifted to the R position with the ignition switched ON.

#### Vehicles with front sensor/front corner sensor

When the parking sensor switch is pressed with the ignition switched ON, the buzzer sounds and the indicator light turns on.

When the ignition is switched ON with the parking sensor activated, the indicator light turns on.

Press the switch again to stop the operation.



### Operation conditions

The parking sensor system can be used when all of the following conditions are met:

- The ignition is switched ON.
- The parking sensor switch is turned on.

### NOTE

#### · (Automatic transaxle vehicle)

*The detection indicator and buzzer of the front sensors/front corner sensors do not operate when the selector lever is in the P position.*

- *The detection indicator and buzzer sound do not activate when the parking brake is applied.*

### ▼ Obstruction Detection Indication


The position of a sensor which has detected an obstruction is indicated. The gauge illuminates in different areas depending on the distance to an obstruction detected by the sensor.

When Driving


## Parking Sensor System

As the vehicle approaches closer to an obstruction, the zone in the gauge closer to the vehicle illuminates.

### Without 360° view monitor



### With 360° view monitor





\*Some models.

### NOTE






The detection indicator can switch between display and non-display.  
Refer to Personalisation Features on page 9-8.

### System problem notification

If a problem occurs, the driver is notified of the problem by the following indications.

|               | Detection Indicator                                                                 |                                                                                     |                                                                                      | Solution                                                                                                                                             |
|---------------|-------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------|
|               | Without 360° view monitor                                                           |                                                                                     | With 360° view monitor                                                               |                                                                                                                                                      |
|               | Without front sensor and front corner sensor                                        | With front sensor and front corner sensor                                           |                                                                                      |                                                                                                                                                      |
| Disconnection |  |  |  | The system may have a malfunction. Have the vehicle inspected at an expert repairer (we recommend an Authorised Mazda Repairer) as soon as possible. |



## Parking Sensor System

|                    | Detection Indicator                                                                |                                                                                    |                                                                                    | Solution                                                                                                                                                                                                                            |
|--------------------|------------------------------------------------------------------------------------|------------------------------------------------------------------------------------|------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                    | Without 360° view monitor                                                          |                                                                                    | With 360° view monitor                                                             |                                                                                                                                                                                                                                     |
|                    | Without front sensor and front corner sensor                                       | With front sensor and front corner sensor                                          |                                                                                    |                                                                                                                                                                                                                                     |
| System malfunction |   |   |   | The system may have a malfunction. Have the vehicle inspected at an expert repairer (we recommend an Authorised Mazda Repairer) as soon as possible.                                                                                |
| Frost/soiling      |  |  |  | Foreign matter may be on the sensor area corresponding to the obstruction detection indication shown. If the system does not recover, have the vehicle inspected at an expert repairer (we recommend an Authorised Mazda Repairer). |

### ▼ Parking Sensor Warning Beep

The beeper sounds as follows while the system is operating.







#### Front Sensor\*, Rear Sensor

| Distance Detection area | Distance between vehicle and obstruction                                                                                |                                                                                                                          | Beeper sound*1          |
|-------------------------|-------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------|-------------------------|
|                         | Front Sensor*                                                                                                           | Rear Sensor                                                                                                              |                         |
| Farthest distance       | Approx. 100—60 cm (39.3—23.6 in)<br> | Approx. 150—60 cm (59.0—23.6 in)<br> | Slow intermittent sound |





When Driving

## Parking Sensor System

| Distance Detection area | Distance between vehicle and obstruction                                                                             |                                                                                                                       | Beeper sound* <sup>1</sup> |
|-------------------------|----------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------|----------------------------|
|                         | Front Sensor*                                                                                                        | Rear Sensor                                                                                                           |                            |
| Far distance            | Approx. 60—45 cm (23.6—17.7 in)<br> | Approx. 60—45 cm (23.6—17.7 in)<br> | Medium intermittent sound  |
| Middle distance         | Approx. 45—35 cm (17.7—13.7 in)<br> | Approx. 45—35 cm (17.7—13.7 in)<br> | Fast intermittent sound    |
| Close distance          | Within approx. 35 cm (13.7 in)<br> | Within approx. 35 cm (13.7 in)<br> | Continuous sound           |

\*1 The rate at which the intermittent sound beeps increases as the vehicle approaches the obstruction.


### Front Corner Sensor\*, Rear Corner Sensor

| Distance Detection area | Distance between vehicle and obstruction                                                                               | Beeper sound* <sup>1</sup> |
|-------------------------|------------------------------------------------------------------------------------------------------------------------|----------------------------|
|                         | Front*/Rear Corner Sensor                                                                                              |                            |
| Far distance            | Approx. 55—38 cm (21.7—15.0 in)<br> | Medium intermittent sound  |
| Middle distance         | Approx. 38—25 cm (15.0—9.8 in)<br>  | Fast intermittent sound    |

\*Some models. **4-209**

## When Driving

# Parking Sensor System

| Distance Detection area | Distance between vehicle and obstruction                                                                           | Beeper sound*1   |
|-------------------------|--------------------------------------------------------------------------------------------------------------------|------------------|
|                         | Front*/Rear Corner Sensor                                                                                          |                  |
| Close distance          | Within approx. 25 cm (9.8 in)<br> | Continuous sound |

\*1 The rate at which the intermittent sound beeps increases as the vehicle approaches the obstruction.

## NOTE

*If an obstruction is detected in a zone for 6 seconds or more, the beep sound is stopped (except for the close-distance zone). If the same obstruction is detected in another zone, the corresponding beep sound is heard.*

## ▼ When Warning Beep is Activated

The system notifies the driver of an abnormality by activating the beep sound and the indicator light.

| Indicator/Beep                                                                                                       | How to check                                                                                                                                                                    |
|----------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| The indicator light flashes when the parking sensor switch is pressed at a vehicle speed of 10 km/h (6 mph) or less. | The system may have a malfunction. Have the vehicle inspected at an expert repairer (we recommend an Authorised Mazda Repairer) as soon as possible.                            |
| The beep sound is not heard.                                                                                         | The system may have a malfunction. Have the vehicle inspected at an expert repairer (we recommend an Authorised Mazda Repairer) as soon as possible.                            |
| The intermittent sound of the buzzer is heard 5 times.                                                               | Remove any foreign material from the sensor area. If the system does not recover, have the vehicle inspected at an expert repairer (we recommend an Authorised Mazda Repairer). |
| A certain obstruction detection indicator is continuously displayed.                                                 | Refer to Obstruction Detection Indication on page 4-206.                                                                                                                        |

**4-210** \*Some models.

## 5 Interior Features

Use of various features for ride comfort, including air-conditioning and audio system.

### **Air-Conditioning System..... 5-4**

|                           |      |
|---------------------------|------|
| Operating Tips.....       | 5-4  |
| Vent Operation.....       | 5-5  |
| Manual Type.....          | 5-7  |
| Fully Automatic Type..... | 5-11 |

### **Before Using the Audio System..... 5-14**

|                           |      |
|---------------------------|------|
| Audio Control Switch..... | 5-14 |
| AUX/USB mode.....         | 5-15 |
| Aerial.....               | 5-19 |

### **Audio Set [Type A (non-touchscreen)]..... 5-20**

|                                                              |      |
|--------------------------------------------------------------|------|
| Power/Volume/Sound Controls.....                             | 5-20 |
| Clock.....                                                   | 5-22 |
| Operating the Radio.....                                     | 5-23 |
| Operating the Compact Disc (CD) Player*.....                 | 5-25 |
| How to use AUX mode.....                                     | 5-28 |
| How to use USB mode.....                                     | 5-29 |
| How to use iPod mode.....                                    | 5-32 |
| Error Indications.....                                       | 5-34 |
| Bluetooth®.....                                              | 5-35 |
| Bluetooth® Preparation.....                                  | 5-38 |
| Security Setting.....                                        | 5-48 |
| Bluetooth® Audio.....                                        | 5-50 |
| Bluetooth® Hands-Free.....                                   | 5-52 |
| Voice Recognition.....                                       | 5-59 |
| Voice Recognition Learning Function (Speaker Enrolment)..... | 5-61 |
| Troubleshooting.....                                         | 5-63 |

### **Audio Set [Type B (touchscreen)]..... 5-67**

|                                                            |       |
|------------------------------------------------------------|-------|
| Basic Operation Method.....                                | 5-67  |
| Home screen.....                                           | 5-71  |
| Volume/Display/Sound Controls.....                         | 5-72  |
| Operating the Radio.....                                   | 5-74  |
| Operating the Digital Audio Broadcasting (DAB) Radio*..... | 5-77  |
| Operating the Compact Disc (CD) Player*.....               | 5-79  |
| How to use AUX mode.....                                   | 5-82  |
| How to use USB mode.....                                   | 5-83  |
| How to use Apple CarPlay.....                              | 5-89  |
| How to use Android Auto™ mode.....                         | 5-92  |
| Bluetooth®.....                                            | 5-96  |
| Bluetooth® Preparation.....                                | 5-99  |
| Available Language.....                                    | 5-101 |
| Bluetooth® Audio.....                                      | 5-102 |
| How to Use Aha™.....                                       | 5-105 |
| How to Use Stitcher™ Radio... ..                           | 5-108 |
| Bluetooth® Hands-Free.....                                 | 5-110 |
| Voice Recognition.....                                     | 5-119 |
| Settings.....                                              | 5-122 |
| Applications.....                                          | 5-125 |
| Troubleshooting.....                                       | 5-126 |

### **Appendix..... 5-132**

|                              |       |
|------------------------------|-------|
| Things You Need to Know..... | 5-132 |
|------------------------------|-------|



### **Interior Equipment..... 5-141**

|                |       |
|----------------|-------|
| Sunvisors..... | 5-141 |
|----------------|-------|

\*Some models. **5-1**

Interior Lights.....5-141  
Accessory Sockets.....5-143  
Cup Holder.....5-144

Bottle Holder.....5-145  
Storage Compartments.....5-145



# MEMO

## Air-Conditioning System


### Operating Tips

- Operate the air-conditioning system with the engine running.
- To prevent the battery from being discharged, do not leave the fan control dial on for a long period of time with the ignition switched ON when the engine is not running.
- **(With i-stop)**  
The airflow amount may decrease slightly while the i-stop function is operating.
- Clear all obstructions such as leaves, snow and ice from the bonnet and the air inlet in the cowl grille to improve the system efficiency.
- Use the air-conditioning system to defog the windows and dehumidify the air.
- The recirculate mode should be used when driving through tunnels or while in a traffic jam, or when you would like to shut off outside air for quick cooling of the interior.
- Use the outside air position for ventilation or windscreen defrosting.
- If the vehicle has been parked in direct sunlight during hot weather, open the windows to let warm air escape, then run the air-conditioning system.
- Run the air conditioner about 10 minutes at least once a month to keep internal parts lubricated.

- Have the air conditioner checked before the weather gets hot. Lack of refrigerant may make the air conditioner less efficient.

The refrigerant specifications are indicated on a label attached to the inside of the engine compartment. If the wrong type of refrigerant is used, it could result in a serious malfunction of the air conditioner. Consult a professional, government certified repairer for the inspection or repair because a special device is required for the air conditioner maintenance.

For details, consult an expert repairer (we recommend an Authorised Mazda Repairer).



## Air-Conditioning System

### Vent Operation

#### ▼ Adjusting the Vents

##### Directing airflow

To adjust the direction of airflow, move the adjustment knob.

##### **NOTE**


- When using the air conditioner under humid ambient temperature conditions, the system may blow fog from the vents. This is not a sign of trouble but a result of humid air being suddenly cooled.

##### **Centre vents (driver) and Side vents**


##### **Air vent open/close**

##### **NOTE**

The air vents can be fully opened and closed by operating the knob.




##### **Airflow direction adjustment**




##### **Centre vents (front passenger)**

##### **Air vent open/close**




##### **Airflow direction adjustment**




## Air-Conditioning System

### ▼ Selecting the Airflow Mode


#### Instrument panel Vents




#### Defroster and Floor Vents




#### Instrument panel and Floor Vents



#### Defroster Vents



#### Floor Vents




#### **NOTE**

The location airflow exits the air vents and the airflow amount may change depending on the open or close status of the air vents.



## Air-Conditioning System

### Manual Type



#### ▼ Control Switches

##### Temperature control dial

This dial controls temperature. Turn it clockwise for hot and anticlockwise for cold.

##### **NOTE**

When the mode is set to or with the fan control dial in a position other than 0 and the temperature control dial in the maximum cold position, the air intake selector switches to the recirculated air position and the A/C turns on automatically.

If A/C is not desired, press the A/C switch to turn it off.

##### Fan control dial

This dial allows variable fan speeds. The fan has seven speeds.

##### Mode selector dial

Turn the mode selector dial to select airflow mode (page 5-6).

##### **NOTE**

- The mode selector dial can be set at the intermediate positions (●) between each mode. Set the dial to an intermediate position if you want to split the airflow between the two modes.
- For example, when the mode selector dial is at the ● position between the and positions, airflow from the floor vent is less than that of the position.

##### A/C switch

Press the A/C switch to turn the air conditioner on. The indicator light on the switch will illuminate when the fan control dial is in any position except OFF.

Press the switch once again to turn the air conditioner off.

## Air-Conditioning System

### NOTE

*The air conditioner may not function when the outside temperature approaches 0 °C (32 °F).*

### Air intake selector

This switch controls the source of air entering the vehicle.

Press the air intake selector switch to alternate between the outside air and recirculated air positions.

### **Recirculated air position** (↻)

Outside air is shut off. Air within the vehicle is recirculated.

### **Outside air position** (↻)

Outside air is allowed to enter the cabin. Use this mode for ventilation or windscreen defrosting.



### **WARNING**

### ***Do not use the recirculated air position in cold or rainy weather:***

*Using the recirculated air position in cold or rainy weather is dangerous as it will cause the windows to fog up. Your vision will be hampered, which could lead to a serious accident.*

### Rear window defogger switch

Press the rear window defogger switch to defrost the rear window.

Refer to Rear Window Defogger on page 4-57.

### ▼ Heating

1. Set the mode selector dial to the ↻ position.

5-8

2. Set the air intake selector to the outside air position.
3. Set the temperature control dial to the hot position.
4. Set the fan control dial to the desired speed.
5. If dehumidified heating is desired, turn on the air conditioner.

### NOTE

- If the windscreen fogs up easily, set the mode selector dial to the ↻ position.
- If cooler air is desired at face level, set the mode selector dial at the ↻ position and adjust the temperature control dial to maintain maximum comfort.
- The air to the floor is warmer than air to the face (except when the temperature control dial is set at the extreme hot or cold position).

### ▼ Cooling (With air conditioner)

1. Set the mode selector dial to the ↻ position.
2. Set the temperature control dial to the cold position.
3. Set the fan control dial to the desired speed.
4. Turn on the air conditioner by pressing the A/C switch.
5. After cooling begins, adjust the fan control dial and temperature control dial as needed to maintain maximum comfort.



### **CAUTION**

*If the air conditioner is used while driving up long hills or in heavy traffic, monitor the high engine coolant temperature warning light to see if it is illuminated or flashing (page 7-23).*

## Air-Conditioning System

*The air conditioner may cause engine overheating. If the warning light is illuminated or flashing, turn the air conditioner off (page 7-18).*

### NOTE

- When maximum cooling is desired, set the temperature control dial to the extreme cold position and set the air intake selector to the recirculated air position, then turn the fan control dial fully clockwise.
- If warmer air is desired at floor level, set the mode selector dial at the  position and adjust the temperature control dial to maintain maximum comfort.
- The air to the floor is warmer than air to the face (except when the temperature control dial is set at the extreme hot or cold position).

### ▼ Ventilation

1. Set the mode selector dial to the  position.
2. Set the air intake selector to the outside air position.
3. Set the temperature control dial to the desired position.
4. Set the fan control dial to the desired speed.

### ▼ Windscreen Defrosting and Defogging

1. Set the mode selector dial to the  position.
2. Set the temperature control dial to the desired position.
3. Set the fan control dial to the desired speed.

4. If dehumidified heating is desired, turn on the air conditioner.

### WARNING

**Do not defog the windscreen using the  position with the temperature control set to the cold position:**

Using the  position with the temperature control set to the cold position is dangerous as it will cause the outside of the windscreen to fog up. Your vision will be hampered, which could lead to a serious accident. Set the temperature control to the hot or warm position when using the  position.

### NOTE

- For maximum defrosting, turn on the air conditioner, set the temperature control dial to the extreme hot position, and turn the fan control dial fully clockwise.
- If warm air is desired at the floor, set the mode selector dial to the  position.
- In the  position, the outside air position is automatically selected.

### ▼ Dehumidifying (With air conditioner)

Operate the air conditioner in cool or cold weather to help defog the windscreen and side windows.

1. Set the mode selector dial to the desired position.
2. Set the air intake selector to the outside air position.
3. Set the temperature control dial to the desired position.
4. Set the fan control dial to the desired speed.

## Air-Conditioning System

---


5. Turn on the air conditioner by pressing the A/C switch.

**NOTE**

*One of the functions of the air conditioner is dehumidifying the air and, to use this function, the temperature does not have to be set to cold. Therefore, set the temperature control dial to the desired position (hot or cold) and turn on the air conditioner when you want to dehumidify the cabin air.*

## Air-Conditioning System

### Fully Automatic Type



#### ▼ Control Switches

##### Temperature control dial

This dial controls temperature. Turn it clockwise for hot and anticlockwise for cold.

##### Fan control dial

The fan has seven speeds.

##### **AUTO position**

The amount of airflow will be automatically controlled in accordance with the set temperature.

##### **Except AUTO position**

The airflow amount can be adjusted to the desired level by turning the dial.

##### **0 position**

To turn off the system, set the dial to 0 position.

##### Mode selector dial

Turn the mode selector dial to select airflow mode (page 5-6).

##### **AUTO position**

The airflow mode automatically adjusts to the selected temperature.

##### **Except AUTO position**

The desired airflow position can be selected by turning the dial.

##### **NOTE**

- With the airflow mode set to the position and the temperature control dial set at a medium temperature, heated air is directed to the feet and air at a comparably lower temperature will flow through the central, left and right vents.
- When the fan control dial is ON, and the mode selector dial is in the or position, the air conditioner is automatically turned on and the outside air position is automatically selected to defrost the windscreen.

## Air-Conditioning System

### A/C switch

The air conditioner (cooling/dehumidifying functions) can be turned on or off by pressing the switch while the fan control dial is at a position other than 0. The indicator light turns on while the air conditioner is operating.

#### **NOTE**

*The air conditioner may not function when the outside temperature approaches 0 °C (32 °F).*

### Air intake selector

Outside or recirculated air positions can be selected. Press the switch to select outside/recirculated air positions.

#### **Recirculated air position (indicator light illuminated)**

Outside air is shut off. Use this position when going through tunnels, driving in congested traffic (high engine exhaust areas) or when quick cooling is desired.

#### **Outside air position (indicator light turned off)**

Outside air is allowed to enter the cabin. Use this mode for ventilation or windscreen defrosting.



### **WARNING**

**Do not use the  position in cold or rainy weather:**

*Using the  position in cold or rainy weather is dangerous as it will cause the windows to fog up. Your vision will be hampered, which could lead to a serious accident.*

### Rear window defogger switch

Press the rear window defogger switch to defrost the rear window. Refer to Rear Window Defogger on page 4-57.

#### **▼ Operation of Automatic Air Conditioner**

1. Set the mode selector dial to the AUTO position.
2. Set the air intake selector to the outside air position (indicator light turned off).

#### **NOTE**

*If the recirculated air position is used for long periods in cold weather or high humidity, the windscreen may fog up more easily.*

3. Set the fan control dial to the AUTO position.
4. Press the A/C switch to operate the air conditioner (turn indicator light on).
5. Set the temperature control dial to the desired position.
6. To turn off the system, set the fan control dial to the 0 position.

#### **NOTE**

- *Set the control dial to the recommended temperature of 25 °C (77 °F), and then adjust it as desired.*
- *Setting the temperature to maximum hot or cold will not provide the desired temperature at a faster rate.*
- *When selecting heat, the system will restrict airflow until it has warmed to prevent cold air from blowing out of the vents.*

## Air-Conditioning System

### ▼ Windscreen Defrosting and Defogging

Set the mode selector dial to the  position and turn the fan control dial to the desired speed.

In this position, the outside air position is automatically selected, and when the fan control dial is ON, the air conditioner automatically turns on. The air conditioner will directly dehumidify the air to the front windscreen and side windows (page 5-6). Airflow amount will be increased.

### WARNING

**Set the temperature control to the hot or warm position when defogging ( position):**

Using the  position with the temperature control set to the cold position is dangerous as it will cause the outside of the windscreen to fog up. Your vision will be hampered, which could lead to a serious accident.


### NOTE

Use the temperature control dial to increase the air flow temperature and defog the windscreen more quickly.

### ▼ Sunlight/Temperature Sensor


#### Sunlight sensor

Do not place objects on the sunlight sensor. Otherwise, the interior temperature may not adjust correctly.




#### Interior temperature sensor

Do not cover the interior temperature sensor. Otherwise, the interior temperature may not adjust correctly.



## Before Using the Audio System

### Audio Control Switch



#### ▼ Adjusting the Volume

To increase the volume, press up the volume switch (+).

To decrease the volume, press down the volume switch (-).



#### ▼ Seek Switch

##### AM/FM radio

Press the seek switch (left/right arrows). The radio switches to the next/previous stored station in the order that it was stored. Press and hold the seek switch (left/right arrows) to seek all usable stations at a higher or lower frequency whether programmed or not.

Radio stations which have been previously stored in the auto memory tuning (Type A)/favourite radio (Type B) can be called up by pressing the seek switch (left/right arrows) while any radio station stored in the auto memory tuning (Type A)/favourite radio (Type B) is being received. Radio stations can be called up in the order they were stored with each press of the switch (left/right arrows).



##### DAB radio (Type B)\*

Press the Seek switch (left/right arrows) while listening to DAB radio to call up a station previously stored to the favourites list. With each operation of the switch, radio stations can be called up in the order they were stored.

Press and hold the seek switch (right arrow) to go to the next station, (left arrow) to return to the previous station.

##### USB Audio/Bluetooth® Audio/CD\*

Press the seek switch (right arrow) to skip forward to the beginning of the next track.

Press the seek switch (left arrow) within a few seconds after playback begins to track down to the beginning of the previous track.

Press the seek switch (left arrow) after a few seconds have elapsed to start playback from the beginning of the current track.

Press and hold the seek switch (left/right arrows) to continuously switch the tracks up or down.



## Before Using the Audio System

### Aha™/Stitcher™ Radio (Type B)

Press the seek switch (▶▶) to skip forward to the beginning of the next track.

Press and hold the seek switch (▶▶) to evaluate the playback of the current song as “Like”.

Press and hold the seek switch (◀◀) to evaluate the playback of the current song as “Dislike”.

### AUX/USB mode

Audio can be heard from the vehicle's speakers by connecting a commercially-available portable audio unit to the auxiliary jack.

A commercially-available, non-impedance (3.5 $\phi$ ) stereo mini plug lead is required.

Contact an expert repairer (we recommend an Authorised Mazda Repairer) for details.


In addition, audio can be played from the vehicle audio device by connecting a USB device to the USB port.

#### NOTE

##### (Type B)


*The SD card slot is for the navigation system. For vehicles with the navigation system, the SD card (Mazda genuine) with stored map data is inserted into the SD card slot and used.*

### Type A (Without CD player)




## Before Using the Audio System


### Type A (With CD player)



### Type B (Without CD player)



### Type B (With CD player)



- ① How to use AUX mode (Type A)..... page 5-28

- ② How to use USB mode (Type A)..... page 5-29
- ③ How to use iPod mode (Type A)..... page 5-32
- ④ How to use AUX mode (Type B)..... page 5-82
- ⑤ How to use USB mode (Type B)..... page 5-83
- ⑥ How to use Apple CarPlay (Type B)..... page 5-89
- ⑦ How to use Android Auto™ mode (Type B)..... page 5-92

### WARNING

**Do not adjust the portable audio unit or a similar product while driving the vehicle:**

Adjusting the portable audio unit or a similar product while driving the vehicle is dangerous as it could distract your attention from the vehicle operation which could lead to a serious accident. Always adjust the portable audio unit or a similar product while the vehicle is stopped.

### CAUTION

Depending on the portable audio device, noise may occur when the device is connected to the vehicle accessory socket. (If noise occurs, do not use the accessory socket.)

### NOTE


- This mode may not be usable depending on the portable audio device to be connected.
- Before using the auxiliary jack/USB port, refer to the instruction manual for the portable audio device.

## Before Using the Audio System


- Use a commercially-available, non-impedance (3.5 $\phi$ ) stereo mini plug for connecting the portable audio unit to the auxiliary jack. Before using the auxiliary jack, read the manufacturer's instructions for connecting a portable audio unit to the auxiliary jack.
- To prevent discharging of the battery, do not use the auxiliary input for long periods with the engine off or idling.
- When connecting a device to the auxiliary jack or USB port, noise may occur depending on the connected device. If the device is connected to the vehicle's accessory socket, the noise can be reduced by unplugging it from the accessory socket.

### ▼ How to connect USB port/Auxiliary jack


#### Type A (Without CD player)




#### Type A (With CD player)



#### Type B (Without CD player)



#### Type B (With CD player)



## Before Using the Audio System

---

### Connecting a device

1. If there is a cover on the AUX jack or USB port, remove the cover.
2. Connect the connector on the device to the USB port.

### Connecting with a connector lead

1. If there is a cover on the AUX jack or USB port, remove the cover.
2. Connect the device plug/connector lead to the auxiliary jack/USB port.



***Do not allow the connection plug cord to get tangled with the parking brake or the shift lever (manual transaxle)/selector lever (automatic transaxle):***

*Allowing the plug cord to become tangled with the parking brake or the shift lever (manual transaxle)/selector lever (automatic transaxle) is dangerous as it could interfere with driving, resulting in an accident.*



*Do not place objects or apply force to the auxiliary jack/USB port with the plug connected.*

### **NOTE**

- *Insert the plug into the auxiliary jack/USB port securely.*
- *Insert or pull out the plug with the plug perpendicular to the auxiliary jack/USB port hole.*
- *Insert or remove the plug by holding its base.*
- **(Type B)**  
*Use the USB terminal indicated by the*  
*mark when using Apple CarPlay and Android Auto™.*

## Before Using the Audio System

### Aerial

#### ▼ Saloon

The aerial is embedded into the rear window glass.


#### CAUTION

*When washing the inside of the window which has an aerial, use a soft cloth dampened in lukewarm water, gently wiping the aerial lines. Use of glass cleaning products could damage the aerial.*

#### ▼ Hatchback

##### Type A\*

To remove the aerial, turn it anticlockwise. To install the aerial, turn it clockwise. Make sure the aerial is securely installed.




#### CAUTION

- *To prevent damage to the aerial, remove it before entering a car wash facility or passing beneath a low overhead clearance.*
- *Be careful around the aerial when removing snow from the roof. Otherwise the aerial could be damaged.*

#### **NOTE**

*When leaving your vehicle unattended, we recommend that you remove the aerial and store it inside the vehicle.*

##### Type B\*



##### Type C\*

The aerial is embedded into the window glass.


#### CAUTION

*When washing the inside of the window which has an aerial, use a soft cloth dampened in lukewarm water, gently wiping the aerial lines. Use of glass cleaning products could damage the aerial.*

\*Some models.

## Audio Set [Type A (non-touchscreen)]

### Power/Volume/Sound Controls



#### ▼ Power ON/OFF

Switch the ignition to ACC or ON. Press the power/volume dial to turn the audio system on. Press the power/volume dial again to turn the audio system off.

#### ▼ Volume adjustment

To adjust the volume, turn the power/volume dial. Turn the power/volume dial clockwise to increase volume, anticlockwise to decrease it.

#### ▼ Audio sound adjustment

1. Press the menu button (**MENU**) to select the function. The selected function will be indicated.
2. Turn the audio control dial to adjust the selected functions as follows:

| Indication                           | Setting value       |                 |
|--------------------------------------|---------------------|-----------------|
|                                      | Turn Anti-clockwise | Turn Clockwise  |
| ALC<br>(Automatic volume adjustment) | Level decrease      | Level increase  |
| BASS<br>(Low pitch sound)            | Decrease bass       | Increase bass   |
| TREB<br>(Treble sound)               | Decrease treble     | Increase treble |

| Indication                                     | Setting value                |                              |
|------------------------------------------------|------------------------------|------------------------------|
|                                                | Turn Anti-clockwise          | Turn Clockwise               |
| FADE<br>(Front/back volume balance)            | Shift the sound to the front | Shift the sound to the rear  |
| BAL<br>(Left/right volume balance)             | Shift the sound to the left  | Shift the sound to the right |
| BEEP<br>(Audio operation sound)                | Off                          | On                           |
| BT SETUP                                       | Select mode                  |                              |
| 12Hr < > 24Hr<br>(12 Hr/24 Hr time adjustment) | 12Hr<br>(Flashing)           | 24Hr<br>(Flashing)           |

#### NOTE

If not operated for several seconds, the display returns to the previous display. To reset bass, treble, fade, and balance, press the menu button (**MENU**) for 2 seconds. The unit will beep and "CLEAR" will be displayed.

## Audio Set [Type A (non-touchscreen)]

---

### **ALC (Automatic volume adjustment)**

The automatic level control (ALC) changes the audio volume automatically according to the vehicle speed. The faster the vehicle speed, the higher the volume increases. ALC has ALC OFF and ALC LEVEL 1 to 7 modes. At ALC LEVEL 7, the amount that the volume can increase is at the maximum. Select the mode according to the driving conditions.

### **BEEP (Audio operation sound)**

The setting for the operation sound when pressing and holding a button can be changed. The initial setting is ON. Set to OFF to mute the operation sound.

### **BT SETUP mode**


Music and other audio such as voice data recorded on portable audio devices and mobile phones available on the market which are equipped with the Bluetooth® transmission function can be listened to via wireless transmission over the vehicle's speakers. Using the BT SETUP mode, these devices can be programmed to the Bluetooth® unit or changed (page 5-38).

### **12Hr < > 24Hr (12 Hr/24 Hr time adjustment)**

Rotating the audio control dial switches the display between 12 and 24-hour clock time (page 5-22).

## Audio Set [Type A (non-touchscreen)]

### Clock



#### ▼ Setting the time

The clock can be set at any time when the ignition is switched to ACC or ON.

1. To adjust the time, press the clock button (**FM/AM**) for about 2 seconds until a beep is heard.
2. The clock's current time will flash.

#### Time adjustment

- To adjust the time, press the hour/minute set button (**◀▶**) while the clock's current time is flashing.
  - The hours advance while the hour set button (**◀**) is pressed. The minutes advance while the minute set button (**▶**) is pressed.
3. Press the clock button (**FM/AM**) again to start the clock.

#### ▼ Time resetting

1. Press the clock button (**FM/AM**) for about 2 seconds until a beep is heard.
2. Press the :00 button (1).
3. When the button is pressed, the time will be reset as follows:  
(Example)  
12:01—12:29→12:00  
12:30—12:59→1:00


#### NOTE

- When the :00 button (1) is pressed, the seconds will start at "00".
- Switching between 12 and 24-hour clock time:  
Press the menu button (**MENU**) several times until 12 and 24-hour clock time are displayed. Turn the audio control dial in either direction, select the desired clock setting while the preferred clock time is flashing.



## Audio Set [Type A (non-touchscreen)]

### Operating the Radio



#### ▼ Radio ON

Press a band selector button (**FM/AM**) to turn the radio on.

#### ▼ Band selection

Successively pressing the band selector button (**FM/AM**) switches the bands as follows: FM1→FM2→AM.

The selected mode will be indicated.

#### NOTE

*If the FM broadcast signal becomes weak, reception automatically changes from STEREO to MONO for reduced noise.*

#### ▼ Tuning

The radio has the following tuning methods: Manual, Seek, Scan, Preset channel, and Auto memory tuning. The easiest way to tune stations is to set them on preset channels.

#### Manual tuning

Select the station by pressing the tuning button (**◀▶**) lightly.

#### Seek tuning

Automatic search for radio stations starts when the tuning button (**◀▶**) is pressed until a beep sound is heard. The search stops when a station is found.

#### NOTE

*If you continue to press and hold the button, the frequency will continue changing without stopping.*

#### Scan tuning

Press and hold the scan button (**MEDIA**) to automatically sample strong stations. Scanning stops at each station for about 5 seconds. To hold a station, press and hold the scan button (**MEDIA**) again during this interval.

#### Preset channel tuning

The 6 preset channels can be used to store 6 AM and 12 FM stations.

1. To set a channel first select AM, FM1, or FM2. Tune to the desired station.
2. Press a channel preset button for about 2 seconds until a beep is heard. The preset channel number or station frequency will be displayed. The station is now held in the memory.

## Audio Set [Type A (non-touchscreen)]

---

3. Repeat this operation for the other stations and bands you want to store. To tune one in the memory, select AM, FM1, or FM2 and then press its channel preset button. The station frequency or the channel number will be displayed.

### Auto memory tuning

This is especially useful when driving in an area where the local stations are not known.

Press and hold the auto memory button (**AUTO-M**) for about 2 seconds until a beep is heard; the system will automatically scan and temporarily store up to 6 stations with the strongest frequencies in each selected band in that area.


After scanning is completed, the station with the strongest frequency will be tuned and its frequency displayed. Press and release the auto memory button (**AUTO-M**) to recall stations from the auto-stored stations. One stored station will be selected each time and its frequency and channel number will be displayed.

### **NOTE**

*If no stations can be tuned after scanning operations, "A" will be displayed.*

## Audio Set [Type A (non-touchscreen)]

### Operating the Compact Disc (CD) Player\*



| Type                        | Playable data                                                                                      |
|-----------------------------|----------------------------------------------------------------------------------------------------|
| Music/MP3/WMA/AAC CD player | <ul style="list-style-type: none"> <li>• Music data (CD-DA)</li> <li>• MP3/WMA/AAC file</li> </ul> |

#### NOTE

If a disc has both music data (CD-DA) and MP3/WMA/AAC files, playback of the 2 or 3 file types differs depending on how the disc was recorded.

#### Inserting the CD

Insert the CD into the slot, label-side up. The auto-loading mechanism will set the CD and begin play.

#### NOTE

There will be a short lapse before play begins while the player reads the digital signals on the CD.

#### Ejecting the CD

Press the CD eject button (▲) to eject the CD.

#### ▼ Playback

Press the media button (**MEDIA**) to switch to CD mode and start playback.

#### NOTE

The CD mode cannot be selected if a CD has not been inserted.

#### Pause

To stop playback, press the Play/Pause button (4).

Press the button again to resume playback.

#### Fast-forward/Reverse

Press and hold the fast-forward button (▶▶) to advance through a track at high speed.

\*Some models.

## Audio Set [Type A (non-touchscreen)]

Press and hold the reverse button (⏮) to reverse through a track at high speed.

### Track search

Press the track up button (⏮) once to skip forward to the beginning of the next track. Press the track down button (⏭) within a few seconds after playback begins to track down to the beginning of the previous track.

Press the track down button (⏭) after a few seconds have elapsed to start playback from the beginning of the current track.

### Folder search (during MP3/WMA/AAC CD playback)

To change to the previous folder, press the folder down button (▼), or press the folder up button (▲) to advance to the next folder.

### Music scan

#### **During music CD playback**

This function scans the titles on a CD and plays 10 seconds of each song to aid you in finding a song you want to listen to. Press and hold the scan button (MEDIA) during playback to start the scan play operation (the track number will flash). Press and hold the scan button (MEDIA) again to cancel scan playback.

#### **During MP3/WMA/AAC CD playback**

This function scans the titles in a folder currently being played and plays 10 seconds of each song to aid you in finding a song you want to listen to. Press and hold the scan button (MEDIA) during playback to start the scan play operation (the track number will flash).

Press and hold the scan button (MEDIA) again to cancel scan playback.

### **NOTE**

*If the unit is left in scan, normal playback will resume where scan was selected.*

### Repeat playback

#### **During music CD playback**

1. Press the repeat button (1) during playback to play the current track repeatedly. "TRACK RPT" is displayed (⌂ is displayed next to RPT at the bottom of the display area).
2. Press the button again to cancel the repeat playback.

#### **During MP3/WMA/AAC CD playback**

##### **(Track repeat)**

1. Press the repeat button (1) during playback to play the current track repeatedly. "TRACK RPT" is displayed (⌂ is displayed next to RPT at the bottom of the display area).
2. To cancel the repeat playback, press the button again after 3 seconds.

##### **(Folder repeat)**

1. Press the repeat button (1) during playback, and then press the button again within 3 seconds to play the tracks in the current folder repeatedly. "FOLDER RPT" is displayed (⌂ is displayed next to RPT at the bottom of the display area).
2. Press the button again to cancel the repeat playback.

### Random playback

Tracks are randomly selected and played.

## Audio Set [Type A (non-touchscreen)]

### During music CD playback

1. Press the random button (2) during playback to play the tracks on the CD randomly. "DISC RDM" is displayed (🎵 is displayed next to RDM at the bottom of the display area).
2. Press the button again to cancel the random playback.

### During MP3/WMA/AAC CD playback (Folder random)

1. Press the random button (2) during playback to play the tracks in the folder randomly. "FOLDER RDM" is displayed (📁 is displayed next to RDM at the bottom of the display area).
2. To cancel the random playback, press the button again after 3 seconds.


### (CD random)

1. Press the random button (2) during playback, and then press the button again within 3 seconds to play the tracks on the CD randomly. "DISC RDM" is displayed (🎵 is displayed next to RDM at the bottom of the display area).
2. Press the button again to cancel the random playback.


### ▼ Switching the display

The information displayed on the audio display changes as follows each time the text button (3) is pressed during playback.

### Music CD

| Button                                                                             | Information displayed on audio display |
|------------------------------------------------------------------------------------|----------------------------------------|
|  | Track number/Elapsed time              |
|                                                                                    | Track number                           |
|                                                                                    | Track name                             |
|                                                                                    | Album name                             |
|                                                                                    | Artist name                            |

### MP3/WMA/AAC CD

| Button                                                                              | Information displayed on audio display |
|-------------------------------------------------------------------------------------|----------------------------------------|
|  | File number/Elapsed time               |
|                                                                                     | Folder number/File number              |
|                                                                                     | File name                              |
|                                                                                     | Folder name                            |
|                                                                                     | Album name                             |
|                                                                                     | Song name                              |
|                                                                                     | Artist name                            |

### NOTE

- The information viewable in the display is only CD information (such as artist name, song title) which has been recorded to the CD.
- This unit cannot display some characters. Characters which cannot be displayed are indicated by an asterisk (\*).

## Audio Set [Type A (non-touchscreen)]

### Display scroll

Only 13 characters can be displayed at one time. To display the rest of the characters of a long title, press and hold the text button (3). The display scrolls the next 13 characters. Press and hold the text button (3) again after the last 13 characters have been displayed to return to the beginning of the title.

### **NOTE**

*The number of characters which can be displayed is restricted.*

### How to use AUX mode

1. Switch the ignition to ACC or ON.
2. Press the power/volume dial to turn the audio system on.
3. Press the media button (**MEDIA**) of the audio unit to change to the AUX mode.


A rectangular button with rounded corners and a thin black border. The word "MEDIA" is printed in bold, black, sans-serif capital letters in the center of the button.

### **NOTE**

- When the device is not connected to the auxiliary jack, the mode does not switch to the AUX mode.
- Adjust the audio volume using the portable audio device or audio unit.
- Audio adjustments other than audio volume can only be done using the portable audio device.
- If the connection plug is pulled out from the auxiliary jack while in AUX mode, noise may occur.

## Audio Set [Type A (non-touchscreen)]

### How to use USB mode



| Type     | Playable data    |
|----------|------------------|
| USB mode | MP3/WMA/AAC file |

This unit does not support a USB 3.0 device. In addition, other devices may not be supported depending on the model or OS version.

#### ▼ Playback

1. Switch the ignition to ACC or ON.
2. Press the power/volume dial to turn the audio system on.
3. Press the media button (**MEDIA**) to switch to the USB mode and start playback.

#### NOTE

- Some devices such as smart phones may require a setting change to allow operation using a USB connection.
- When the USB device is not connected, the mode does not switch to USB mode.
- When there is no playable data in the USB device, "NO CONTENTS" is flashed.
- Playback of the USB device is in the order of the folder numbers. Folders which have no MP3/WMA/AAC files are skipped.

• Do not remove the USB device while in the USB mode. The data may be damaged.

#### Pause

To stop playback, press the play/pause button (4).  
Press the button again to resume playback.

#### Fast-forward/Reverse

Press and hold the fast-forward button (▶▶) to advance through a track at high speed.  
Press and hold the reverse button (◀◀) to reverse through a track at high speed.

#### Track search

Press the track up button (▶▶) once to skip forward to the beginning of the next track.  
Press the track down button (◀◀) within a few seconds after playback begins to track down to the beginning of the previous track.

Press the track down button (◀◀) after a few seconds have elapsed to start playback from the beginning of the current track.

## Audio Set [Type A (non-touchscreen)]

### Folder search

To change to the previous folder, press the folder down button (▼), or press the folder up button (▲) to advance to the next folder.

### Music scan

This function scans the titles in a folder currently being played and plays 10 seconds of each song to aid you in finding a song you want to listen to.

Press and hold the scan button (MEDIA) during playback to start the scan play operation (the track number will flash). Press and hold the scan button (MEDIA) again to cancel scan playback.

### NOTE

*If the unit is left in scan, normal playback will resume where scan was selected.*

### Repeat playback

#### Track repeat

1. Press the repeat button (1) during playback to play the current track repeatedly. "TRACK RPT" is displayed (♫ is displayed next to RPT at the bottom of the display area).
2. To cancel the repeat playback, press the button again after 3 seconds.

#### Folder repeat

1. Press the repeat button (1) during playback, and then press the button again within 3 seconds to play the tracks in the current folder repeatedly. "FOLDER RPT" is displayed (📁 is displayed next to RPT at the bottom of the display area).
2. Press the button again to cancel the repeat playback.

### Random playback

Tracks are randomly selected and played.

#### Folder random


1. Press the random button (2) during playback to play the tracks in the folder randomly. "FOLDER RDM" is displayed (📁 is displayed next to RDM at the bottom of the display area).
2. To cancel the random playback, press the button again after 3 seconds.

#### All random

1. Press the random button (2) during playback, and then press the button again within 3 seconds to play the tracks in the USB device randomly. "ALL RDM" is displayed (📁 is displayed next to RDM at the bottom of the display area).
2. Press the button again to cancel the random playback.

### ▼ Switching the display

The information displayed on the audio display changes as follows each time the text button (3) is pressed during playback.

| Button                                                                              | Information displayed on audio display |
|-------------------------------------------------------------------------------------|----------------------------------------|
|  | File number/Elapsed time               |
|                                                                                     | Folder number/File number              |
|                                                                                     | File name                              |
|                                                                                     | Folder name                            |
|                                                                                     | Album name                             |
|                                                                                     | Song name                              |
|                                                                                     | Artist name                            |



## Audio Set [Type A (non-touchscreen)]

---

**NOTE**

- The information (artist name, music name) is displayed only when the USB device information in the USB device has information which can be displayed on the screen.
- This unit cannot display some characters. Characters which cannot be displayed are indicated by an asterisk (\*).

**Display scroll**


Only 13 characters can be displayed at one time. To display the rest of the characters of a long title, press and hold the text button (3). The display scrolls the next 13 characters. Press and hold the text button (3) again after the last 13 characters have been displayed to return to the beginning of the title.

**NOTE**

*The number of characters which can be displayed is restricted.*

## Audio Set [Type A (non-touchscreen)]

### How to use iPod mode



An iPod may not be compatible depending on the model or OS version. In this case, an error message is displayed.

#### **NOTE**

*The iPod functions on the iPod cannot be operated while it is connected to the unit because the unit controls the iPod functions.*

#### **▼ Playback**

1. Switch the ignition to ACC or ON.
2. Press the power/volume dial to turn the audio system on.
3. Press the media button (**MEDIA**) to switch to the iPod mode and start playback.

#### **NOTE**

- When an iPod is not connected, the mode does not switch to the iPod mode.
- When there is no playable data in the iPod, "NO CONTENTS" is flashed.
- Do not remove the iPod while in the iPod mode. Otherwise, the data could be damaged.

#### **Pause**

To stop playback, press the play/pause button (4).

Press the button again to resume playback.

#### **Fast-forward/Reverse**

Press and hold the fast-forward button (▶▶) to advance through a track at high speed. Press and hold the reverse button (◀◀) to reverse through a track at high speed.

#### **Track search**

Press the track up button (▶▶) once to skip forward to the beginning of the next track. Press the track down button (◀◀) within a few seconds (depends on iPod software version) after playback begins to track down to the beginning of the previous track.

Press the track down button (◀◀) after a few seconds (depends on iPod software version) have elapsed to start playback from the beginning of the current track.

#### **Category search**

Press the category down button (5) to select the previous category and press the category up button (6) to select the next category.

## Audio Set [Type A (non-touchscreen)]

### NOTE

The types of categories include Playlist, Artist, Album, Song, Podcast, Genre, Composer, and Audio book.

### List search

Press the list down button (▼) to select the previous list and press the list up button (▲) to select the next list.

### NOTE

When the selected category is Song or Audio book, there is no list.

### Music scan

This function scans the titles in a list currently being played and plays 10 seconds of each song to aid you in finding a song you want to listen to.

Press and hold the scan button (MEDIA) during playback to start the scan play operation (the track number will flash). Press and hold the scan button (MEDIA) again to cancel scan playback.

### NOTE

If the unit is left in scan, normal playback will resume where scan was selected.

### Repeat playback

1. Press the repeat button (1) during playback to play the current track repeatedly. "TRACK RPT" is displayed (🎵 is displayed next to RPT at the bottom of the display area).
2. Press the button again to cancel the repeat playback.

### Random playback

Tracks are randomly selected and played.

### Song random

1. Press the random button (2) during playback to play the tracks in the list randomly. "SONG RDM" is displayed (🎵 is displayed next to RDM at the bottom of the display area).
2. To cancel the random playback, press the button again after 3 seconds.

### Album random


1. Press the random button (2) during playback, and then press the button again within 3 seconds to play the tracks in the iPod randomly. "ALBUM RDM" is displayed (🎵 is displayed next to RDM at the bottom of the display area).
2. Press the button again to cancel the random playback.

### NOTE

The track number being played randomly is in the order of the iPod shuffle table.

### ▼ Switching the display

The information displayed on the audio display changes as follows each time the text button (3) is pressed during playback.

| Button                                                                               | Information displayed on audio display |
|--------------------------------------------------------------------------------------|----------------------------------------|
|  | File number/Elapsed time               |
|                                                                                      | File number                            |
|                                                                                      | Category name                          |
|                                                                                      | Artist name                            |
|                                                                                      | Album name                             |
|                                                                                      | Song name                              |

## Audio Set [Type A (non-touchscreen)]

---

### NOTE

- The information (artist name, music name) is displayed only when the iPod has information which can be displayed.
- This unit cannot display some characters. Characters which cannot be displayed are indicated by an asterisk (\*).

### Display scroll

13 characters can be displayed at one time. To display the rest of the characters of a long title, press and hold the text button (3). The display scrolls the next 13 characters. Press and hold the text button (3) again after the last 13 characters have been displayed to return to the beginning of the title.

### NOTE

The number of characters which can be displayed is restricted.

## Error Indications

If you see an error indication on the display, take appropriate action according to the following methods. If you cannot clear the error indication, take the vehicle to an expert repairer (we recommend an Authorised Mazda Repairer).

### CHECK CD

If “CHECK CD” is displayed, it means that there is some CD malfunction. Check the CD for damage, dirt, or smudges, and then properly reinsert it. If the message appears again, insert another known good CD.

### CHECK USB

When the message “CHECK USB” is displayed, it indicates that there is some error in the USB device. Verify that the content recorded in the USB device has MP3/WMA/AAC files and re-connect correctly.

### CHECK iPod

If the message “CHECK iPod” is displayed, it indicates that there is a malfunction in the iPod. Verify that the content recorded in the iPod has playable files and connect correctly.

## Audio Set [Type A (non-touchscreen)]

### Bluetooth®

#### ▼ Introduction

##### Bluetooth® Hands-Free outline

When a Bluetooth® device (mobile phone) is connected to the vehicle's Bluetooth® unit, a call can be made or received by pressing the talk button, pick-up button, or hang-up button on the audio remote control switch. For example, even if a device (mobile phone) is in your coat pocket, a call can be made without taking the device (mobile phone) out and operating it directly.

##### Bluetooth® audio outline

When a portable audio unit equipped with the Bluetooth® communication function is paired to the vehicle, you can listen to music stored on the paired portable audio device from the vehicle's speakers. It is not necessary to connect the portable audio device to the vehicle's external input terminal. After programming, operate the vehicle audio control panel to play/stop the audio.

#### NOTE

- *For your safety, a device can be paired only when the vehicle is parked. If the vehicle starts to move, the pairing procedure will end. Park the vehicle in a safe place before pairing.*
- *The communication range of a Bluetooth® equipped device is about 10 meters (32 ft) or less.*
- *Basic audio operation is available using voice commands even if Bluetooth® is not connected.*



*Some Bluetooth® mobile devices are not compatible with the vehicle. Consult an expert repairer (we recommend an Authorised Mazda Repairer), Mazda's call centre or Web support centre for information regarding Bluetooth® mobile device compatibility:*

#### ➤ Australia

*Phone: 1800-352-703 during business hours (10am—4pm Eastern Standard Time)*

*Web: [www.mazda.com.au](http://www.mazda.com.au)*

#### ➤ New Zealand

*Web: [www.mazdahandsfree.co.nz](http://www.mazdahandsfree.co.nz)*

## Audio Set [Type A (non-touchscreen)]


---

### Applicable Bluetooth® specification (Recommended)


Ver. 2.0

#### ▼ Component Parts


##### Audio unit



##### Talk button, Pick-up button and Hang-up button



##### Microphone



### Microphone (hands-free)

The microphone is used for speaking voice commands or when making a Hands-free call.

#### Talk button

Activates the voice recognition. In addition, it skips the voice guidance.

#### Pick-up button

Responds to incoming calls. In addition, after selecting a contact or dialing a number, it places the call when the button is pressed.

#### Hang-up button

Ends the call or refuses an incoming call. In addition, it ends the voice recognition operation.

## Audio Set [Type A (non-touchscreen)]

---

### **Volume adjustment**

The power/volume dial of the audio unit is used to adjust the volume. Turn the dial to the right to increase volume, to the left to decrease it.

The volume can also be adjusted using the volume button on the steering wheel.

### ***NOTE***

*If the volume is lower compared to other audio modes, increase the volume from the device side.*

## Audio Set [Type A (non-touchscreen)]

### Bluetooth® Preparation

#### ▼ Bluetooth® Hands-Free Preparation

##### Pairing code setting

The 4-digit pairing code setting for registration of your cell phone (pairing) can be set beforehand.

##### **NOTE**

*The initial setting value is "0000".*

1. Press the pick-up button or talk button with a short press.
2. **Say:** [Beep] "Setup"
3. **Prompt:** "Select one of the following: Pairing options, confirmation prompts, password, select phone or select music player."
4. **Say:** [Beep] "Pairing options"
5. **Prompt:** "Select one of the following: Pair, Edit, Delete, List, or Set pairing Code."
6. **Say:** [Beep] "Set pairing code"
7. **Prompt:** "Your current pairing code is XXXX. Do you want to change it to a different pairing pin code?"
8. **Say:** [Beep] "Yes"
9. **Prompt:** "Please say a 4-digit pairing code."
10. **Say:** [Beep] "YYYY"
11. **Prompt:** "YYYY is this correct?"
12. **Say:** [Beep] "Yes" or "No"
13. If "Yes", go to Step 14. If "No", the procedure returns to Step 9.
14. **Prompt:** "Your new pairing pin code is YYYY. Use this pairing code when pairing devices to the Hands free system. Do you want to pair a device now?"
15. **Say:** [Beep] "Yes" or "No"

16. If "Yes", the system switches to the device registration mode. If "No", the system returns to standby status.

#### ▼ Device pairing (Bluetooth® Hands-Free)

To use Bluetooth® Hands-Free, the device equipped with Bluetooth® has to be paired to the Bluetooth® unit using the following procedure.

A maximum of seven devices including hands-free mobile phones and Bluetooth® audio devices can be paired to one vehicle.

##### **NOTE**

- *A device can be paired only when the vehicle is parked. If the vehicle starts to move, the pairing procedure will end. Pairing is dangerous while driving - pair up your device before you start driving. Park the car in a safe place before paired.*
- *If a Bluetooth® device has already been paired to the vehicle as a Bluetooth® audio device, it does not need to be paired again when using the device as a hands-free mobile phone. Conversely, it does not need to be paired again as a Bluetooth® audio device if it has already been paired as a hands-free mobile phone.*
- *Since the communication range of a Bluetooth® equipped device is about 10 m (32 ft), if a device is placed within a 10 m (32 ft) radius of the vehicle, it may be detected/paired unintentionally while another device is being paired.*



## Audio Set [Type A (non-touchscreen)]

1. Activate the Bluetooth® application of the device.

### NOTE

*For the operation of the device, refer to its instruction manual.*

2. Press the pick-up button or talk button with a short press.
3. **Say:** [Beep] "Setup"
4. **Prompt:** "Select one of the following: Pairing options, confirmation prompts, password, select phone or select music player."
5. **Say:** [Beep] "Pairing options"
6. **Prompt:** "Select one of the following: Pair, edit, delete, list, or set pairing code."
7. **Say:** [Beep] "Pair"
8. **Prompt:** "Start the pairing process on your Bluetooth® device. Your pairing code is 0000 (XXXX). Input this on your Bluetooth® device. See device manual for instructions."
9. Using the device, perform a search for the Bluetooth® device (Peripheral device).

### NOTE

*For the operation of the device, refer to its instruction manual.*

10. Select "Mazda" from the device list searched by the device.
11. Input the 4-digit pairing code to the device.
12. **Prompt:** "Please say the name of the device after the beep."

13. **Say:** [Beep] "XXXX - - -" (Speak a "device tag", an arbitrary name for the device.)

Example: "Stan's device."

### NOTE

*Say a paired "device tag" within 10 seconds.*

*If more than 2 devices are to be paired, they cannot be paired with the same or similar "device tag".*

14. **Prompt:** "Adding XXXXXX - - - (Ex. "Stan's device") (Device tag). Is this correct?"

15. **Say:** [Beep] "Yes"

16. **Prompt:** "Pairing complete"

After a device is registered, the system automatically identifies the device. By activating Bluetooth® Hands-Free again, or by activating Bluetooth® Hands-Free first after switching the ignition from OFF to ACC, the system reads out a voice guidance, "XXXXXX - - - (Ex. "Stan's device") (Device tag) is connected".

### NOTE

- When the pairing is completed, the  symbol is displayed.
- Some Bluetooth® audio devices need a certain amount of time before the  symbol is displayed.
- Device registration can also be done by operating the audio unit.
- Depending on the device, the registration status may be lost after a certain period of time. If this occurs, repeat the entire process from Step 1.

## Audio Set [Type A (non-touchscreen)]

---

### Registered device read-out

Bluetooth® Hands-Free can read-out the devices registered to its system.

#### **NOTE**

*Do this function only when parked. It is too distracting to attempt while driving and you may make too many errors to be effective.*

1. Press the pick-up button or talk button with a short press.
2. **Say:** [Beep] “Setup”
3. **Prompt:** “Select one of the following: Pairing options, confirmation prompts, password, select phone or select music player.”
4. **Say:** [Beep] “Pairing options”
5. **Prompt:** “Select one of the following: Pair, edit, delete, list, or set pairing code.”
6. **Say:** [Beep] “List”

7. **Prompt:** “XXXXXX..., XXXXX..., XXXXX... (Ex. Device A, device B, device C)” (The voice guidance reads out the device tags registered to the hands-free system.)

Press the talk button with a short press during the read-out at the desired device, and then say one of the following voice commands to execute it.

- “Select phone”: Selects device (Mobile phone) when the talk button is short-pressed.
  - “Select music player”: Selects device (Music player) when the talk button is short-pressed.
  - “Edit”: Edits device when the talk button is short-pressed.
  - “Continue”: Continues the list read-out.
  - “Delete”: Deletes the registered device when the talk button is short-pressed.
  - “Previous”: Returns to the previous device in read-out when the talk button is short-pressed.
8. **Prompt:** “End of list, would you like to start from the beginning?”
  9. **Say:** [Beep] “No”
  10. **Prompt:** “Returning to main menu.”

## Audio Set [Type A (non-touchscreen)]

### ▼ Device selection (Bluetooth® Hands-Free)

If several devices have been paired, the Bluetooth® unit links the device last paired. If you would like to link a different paired device, it is necessary to change the link. The order of device priority after the link has been changed is maintained even when the ignition is switched off.

#### (Hands-free phone)

1. Press the pick-up button or talk button with a short press.
2. **Say:** [Beep] "Setup"
3. **Prompt:** "Select one of the following: Pairing options, confirmation prompts, password, select phone or select music player."
4. **Say:** [Beep] "Select phone"
5. **Prompt:** "Please say the name of the device you would like to select. Available devices are XXXXX... (Ex. device A), XXXXX... (Ex. device B), XXXXX... (Ex. device C). Which device please?"
6. **Say:** [Beep] "X" (Say the number for the mobile phone to be connected.)
7. **Prompt:** "XXXXX... (Ex. device B...) (Registered device tag) is this correct?"
8. **Say:** [Beep] "Yes"
9. **Prompt:** "XXXXX... (Ex. device B...) (Device tag) selected."

#### (Music player)

1. Press the pick-up button or talk button with a short press.
2. **Say:** [Beep] "Setup"

3. **Prompt:** "Select one of the following: Pairing options, confirmation prompts, password, select phone or select music player."
4. **Say:** [Beep] "Select music player"
5. **Prompt:** "Please say the name of the device you would like to select. Available devices are XXXXX... (Ex. device A), XXXXX... (Ex. device B), XXXXX... (Ex. device C). Which device please?"
6. **Say:** [Beep] "X" (Say the number for the music player to be connected.)
7. **Prompt:** "XXXXX... (Ex. device B...) (Registered device tag) is this correct?"
8. **Say:** [Beep] "Yes"
9. **Prompt:** "XXXXX... (Ex. device B...) (Device tag) selected."

#### NOTE

- When the selected device connection is completed, the  or  symbol is displayed.
- Some Bluetooth® audio devices need a certain amount of time before the  or  symbol is displayed.
- Device (Music player) selection can also be done by operating the panel button.

### ▼ Deleting a device (Bluetooth® Hands-Free)

Registered devices (Mobile phone) can be deleted individually or collectively.

#### NOTE

*Do this function only when parked. It is too distracting to attempt while driving and you may make too many errors to be effective.*

## Audio Set [Type A (non-touchscreen)]

1. Press the pick-up button or talk button with a short press.
2. **Say:** [Beep] "Setup"
3. **Prompt:** "Select one of the following: Pairing options, confirmation prompts, password, select phone or select music player."
4. **Say:** [Beep] "Pairing options"
5. **Prompt:** "Select one of the following: Pair, edit, delete, list, or set pairing code."

### NOTE

*A registered device (Mobile phone) can be deleted using the registration list.*

6. **Say:** [Beep] "Delete"
7. **Prompt:** "Please say the name of the device you would like to delete.  
Available devices are XXXXX... (Ex. device A), XXXXX... (Ex. device B), XXXXX... (Ex. device C), or all.  
Which device please?"
8. **Say:** [Beep] "X" (Say the number of the device to be deleted.)

### NOTE

*Say "All" to delete all devices (Mobile phone).*

9. **Prompt:** "Deleting XXXXX... (Ex. device B...) (Registered device tag). Is this correct?"
10. **Say:** [Beep] "Yes"
11. **Prompt:** "Deleted"

### ▼ Registered device editing (Bluetooth® Hands-Free)

1. Press the pick-up button or talk button with a short press.
2. **Say:** [Beep] "Setup"

3. **Prompt:** "Select one of the following: Pairing options, confirmation prompts, password, select phone or select music player."
4. **Say:** [Beep] "Pairing options"
5. **Prompt:** "Select one of the following: Pair, edit, delete, list, or set pairing code."
6. **Say:** [Beep] "Edit"
7. **Prompt:** "Please say the name of the device you would like to edit.  
Available devices are XXXXX... (Ex. device A), XXXXX... (Ex. device B), XXXXX... (Ex. device C). Which device please?"
8. **Say:** [Beep] "X" (Say the number of the device to be edited.)
9. **Prompt:** "New name please?"
10. **Say:** [Beep] "XXXXXX... (Ex. device C)" (Speak a "device tag", an arbitrary name for the device.)
11. **Prompt:** "XXXXXX... (Ex. device C) (Device tag), is this correct?"
12. **Say:** [Beep] "Yes"
13. **Prompt:** "New name saved."


### ▼ Bluetooth® Audio Preparation

#### Bluetooth® audio device set-up

Bluetooth® audio pairing, changes, deletions, and display of paired device information can be performed.


## Audio Set [Type A (non-touchscreen)]

- The mode changes as follows each time the menu button (**MENU**) is pressed. Select "BT SETUP".



\* Depending on the mode selected, the indication changes.

- Turn the audio control dial and select a desired mode.



| Display      | Mode                  | Function                                 |
|--------------|-----------------------|------------------------------------------|
| PAIR DE-VICE | Pairing mode          | Bluetooth® audio device pairing          |
| LINK CHANGE  | Link change mode      | Changing link to Bluetooth® audio device |
| PAIR DE-LETE | Pairing deletion mode | Deleting link to Bluetooth® audio device |

| Display     | Mode                            | Function                                         |
|-------------|---------------------------------|--------------------------------------------------|
| DEVICE INFO | Device information display mode | Displaying vehicle's Bluetooth® unit information |

- Press the audio control dial to determine the mode.

### ▼ Bluetooth® audio device pairing (Bluetooth® Audio)

Any Bluetooth® audio device must be paired to the vehicle's Bluetooth® unit before it can be listened to over the vehicle's speakers.

A maximum of seven devices including Bluetooth® audio devices and hands-free mobile phones can be paired to one vehicle.

#### NOTE

- If a Bluetooth® device has already been paired to the vehicle as a hands-free mobile phone, it does not need to be paired again when using the device as a Bluetooth® audio device. Conversely, it does not need to be paired again as a hands-free mobile phone if it has already been paired as a Bluetooth® audio device.
- Device registration can also be done using voice recognition.

Concerning the operation of a Bluetooth® audio device itself, refer to its instruction manual.

Some Bluetooth® audio devices have PIN codes (four digits). Refer to the audio device's instruction manual because the pairing procedure differs depending on whether it has a PIN code or not.

## Audio Set [Type A (non-touchscreen)]

### Pairing a Bluetooth® audio device which has a four-digit PIN code

1. Using the audio control dial, select the pairing mode “PAIR DEVICE” in the “BT SETUP” mode. (Refer to “Bluetooth® audio device set-up” for details.)
2. Press the audio control dial to determine the mode.  
After “ENTER PIN” is displayed on the audio display for 3 seconds, “PIN 0000” is displayed and the PIN code can be input.
3. Input the PIN code of your Bluetooth® audio device by pressing channel preset buttons 1 to 4 while “PIN 0000” is displayed.  
Press channel preset button 1 to input the first digit, 2 for the second, 3 for the third, and 4 for the fourth. For example, if the PIN code were “4213”, press channel preset button 1 four times (1, 2, 3, 4), button 2 twice (1, 2), button 3 once (1), and button 4 three times (1, 2, 3). If the “PIN 0000” display disappears before finishing the PIN code input, repeat the procedure from Step 1.

#### NOTE

*Some devices accept only a particular pairing code (Usually, “0000” or “1234”).*

*If pairing cannot be completed, refer to the owner's manual of your mobile device, and try those numbers if necessary.*

4. Press the audio control dial while the input PIN code is displayed.  
“PAIRING” flashes on the display.

5. Operate the Bluetooth® audio device and set it to the pairing mode while “PAIRING” is flashing.
6. When the pairing is completed, “♪” and “PAIR SUCCESS” are displayed after about 10 — 30 seconds, after which “PAIR SUCCESS” continues to be displayed for 3 seconds, and then the unit returns to the normal display.

#### NOTE

- Some Bluetooth® audio devices need a certain amount of time before the “♪” symbol is displayed.
- If the pairing failed, “Err” flashes for 3 seconds.
- Pairing cannot be performed while the vehicle is moving. If you attempt to perform pairing while the vehicle is moving, “PAIR DISABLE” is displayed.
- If seven Bluetooth® audio devices have already been paired to the vehicle, pairing cannot be performed and “MEMORY FULL” is displayed. Delete one paired device to pair another one.

### Pairing a Bluetooth® audio device which does not have a four-digit PIN code

1. Using the audio control dial, select the pairing mode “PAIR DEVICE” in the “BT SETUP” mode. (Refer to “Bluetooth® audio set up” for details.)
2. Press the audio control dial to determine the mode. After “ENTER PIN” is displayed on the audio display for 3 seconds, “PIN 0000” is displayed and the PIN code can be input.

## Audio Set [Type A (non-touchscreen)]

3. Press the audio control dial while “PIN 0000” is displayed.  
“PAIRING” flashes on the audio display.
4. Operate the Bluetooth® audio device and set it to the pairing mode while “PAIRING” is flashing.
5. As the Bluetooth® audio device requires a PIN code, input “0000”.
6. When the pairing is completed, “♪” and “PAIR SUCCESS” are displayed after about 10 — 30 seconds, after which “PAIR SUCCESS” continues to be displayed for 3 seconds, and then the unit returns to the normal display.

### NOTE

- If pairing cannot be completed, try “1234” instead. Refer to the owner's manual of your mobile device for the right PIN code.
- Some Bluetooth® audio devices need a certain amount of time before the “♪” symbol is displayed.
- If the pairing failed, “Err” flashes for 3 seconds.
- Pairing cannot be performed while the vehicle is moving. If you attempt to perform pairing while the vehicle is moving, “PAIR DISABLE” is displayed.
- If seven Bluetooth® audio devices have already been paired to the vehicle, pairing cannot be performed and “MEMORY FULL” is displayed. Delete one paired device to pair another one.


### ▼ Device selection (Bluetooth® Audio)

If several devices have been paired, the Bluetooth® unit links the device last paired. If you would like to link a different paired device, it is necessary to change the link. The order of device priority after the link has been changed is maintained even when the ignition is switched off.

1. Using the audio control dial, select the link change mode “LINK CHANGE” in the “BT SETUP” mode. (Refer to “Bluetooth® audio device set-up” for details.)
2. Press the audio control dial to determine the mode.
3. The name of the currently linked Bluetooth® audio device is displayed. If no Bluetooth® audio device is currently linked, the name of the first device among the paired devices is displayed.

## Audio Set [Type A (non-touchscreen)]

4. Turn the audio control dial to select the name of the device you would like to link.



5. Press the audio control dial to select the device you would like to link. The “♪” symbol disappears, and “PAIRING” flashes in the audio display.

### NOTE

When “GO BACK” is selected and the audio control dial is pressed, the display returns to “LINK CHANGE”.

6. If the link to the desired device is successful, the “♪” symbol is displayed again, together with “LINK CHANGED”. “LINK CHANGED” is displayed for 3 seconds, then it returns to the normal display.

### NOTE

- Some Bluetooth® audio devices need a certain amount of time before the “♪” symbol is displayed.

- If a hands-free type mobile phone has been the most recently paired device, the Bluetooth® unit links this device. If you would like to use a Bluetooth® audio type device which has been previously paired to the Bluetooth® unit, the link must be changed to this device.
- If an error occurs while trying to link a device, “Err” flashes in the display for 3 seconds, and the display returns to “LINK CHANGE”. If this occurs, check the pairing status of the Bluetooth® audio device and the location of the device in the vehicle (not in the luggage compartment/boot or a metal-type box), and then try the link operation again.
- Device selection can also be done using voice recognition.

### How to confirm the device currently linked

Switch to the link-change mode. (Refer to “Changing the link to a Bluetooth® audio device”)

The device name displayed first is the device which is currently linked.


### ▼ Deleting a device (Bluetooth® Audio)

1. Using the audio control dial, select the pairing delete mode “PAIR DELETE” in the “BT SETUP” mode. (Refer to “Bluetooth® audio device set-up” for details.)
2. Press the audio control dial to determine the mode.
3. The name of the first device among the paired devices is displayed.



## Audio Set [Type A (non-touchscreen)]

4. Rotate the audio control dial and select the name of the paired device you would like to delete.



### NOTE

Only the names of paired devices can be displayed. If only one device is paired, only the name for this device is displayed.

5. If a selection other than “GO BACK” is made and the audio control dial is pressed, “SURE ? NO” is displayed.
6. Rotate the audio control dial clockwise and switch the display to “SURE ? YES”.

### NOTE

The display changes as follows depending on whether the audio control dial is rotated clockwise or anticlockwise.  
 -Clockwise: “SURE ? YES” displayed  
 -Anticlockwise: “SURE ? NO” displayed

7. Press the audio control dial to delete the selected device.

### NOTE

Select “GO BACK” and press the audio control dial to return to the “PAIR DELETE” display.


8. “PAIR DELETED” is displayed for 3 seconds after the deletion is completed, and then it returns to the normal display.

### NOTE

If an error occurs while trying to delete the paired device, “Err” flashes in the display for 3 seconds and the display returns to “LINK DELETE”.

### ▼ Bluetooth® audio device information display

1. Using the audio control dial, select the pair device information display mode “DEVICE INFO” in the “BT SETUP” mode. (Refer to “Bluetooth® audio device set-up” for details.)
2. Press the audio control dial to determine the mode.
3. The name of the Bluetooth® unit device is displayed.
4. Rotate the audio control dial to select the information for the Bluetooth® unit which you would like to view.



## Audio Set [Type A (non-touchscreen)]

### **NOTE**

*When “GO BACK” is selected and the audio control dial is pressed, the display returns to “DEVICE INFO”.*

## Security Setting

If a password is set, the system cannot be activated unless the password is input.

### **NOTE**

*Do this function only when parked. It is too distracting to attempt while driving and you may make too many errors to be effective.*

### **Password setting**

1. Press the pick-up button or talk button with a short press.
2. **Say:** [Beep] “Setup”
3. **Prompt:** “Select one of the following: Pairing options, confirmation prompts, password, select phone or select music player.”
4. **Say:** [Beep] “Password”
5. **Prompt:** “Password is disabled. Would you like to enable it?”
6. **Say:** [Beep] “Yes”
7. **Prompt:** “Please say a 4-digit password. Remember this password. It will be required to use this system.”
8. **Say:** [Beep] “XXXX” (Say a desired 4-digit password, “PCode”.)
9. **Prompt:** “Password XXXX (Password, PCode). Is this correct?”
10. **Say:** [Beep] “Yes”
11. **Prompt:** “Password is enabled.”

### **Using Bluetooth® Hands-Free with a password**

1. Press the pick-up button or talk button with a short press.
2. **Prompt:** “Hands-Free system is locked. State the password to continue.”
3. **Say:** [Beep] “XXXX” (Say the set password “PCode”.)

## Audio Set [Type A (non-touchscreen)]

4. If the correct password is input, voice guidance “XXXXXX... (Ex. “Mary's device”) (Device tag) is connected” is announced.

If the password is incorrect, voice guidance “XXXX (4-digit password, Pcode) incorrect password, please try again” is announced.

### Cancelling the password

#### **NOTE**

*Do this function only when parked. It is too distracting to attempt while driving and you may make too many errors to be effective.*

1. Press the pick-up button or talk button with a short press.
2. **Say:** [Beep] “Setup”
3. **Prompt:** “Select one of the following: Pairing options, confirmation prompts, password, select phone or select music player.”
4. **Say:** [Beep] “Password”
5. **Prompt:** “Password is enabled. Would you like to disable it?”
6. **Say:** [Beep] “Yes”
7. **Prompt:** “Password is disabled.”

### Confirmation Prompts

The confirmation prompt confirms the command content to the user before advancing to the operation requested by the user. When this function is turned on, the system reads out the voice input command previously received and confirms whether the command is correct before advancing to the command execution.

When the confirmation prompt function is turned on:

(Ex. “Calling John's device. Is this correct?”)

When the confirmation prompt function is turned off:

(Ex. “Calling John's device.”)

#### **NOTE**

*If the confirmation prompt function is turned off when making an emergency call, the system reads out and confirms the command before executing it.*

1. Press the pick-up button or talk button with a short press.
2. **Say:** [Beep] “Setup”
3. **Prompt:** “Select one of the following: Pairing options, confirmation prompts, password, select phone or select music player.”
4. **Say:** [Beep] “Confirmation prompts”
5. **Prompt:** “Confirmation prompts are on/off. Would you like to turn confirmation prompts off/on?”
6. **Say:** [Beep] “Yes”
7. **Prompt:** “Confirmation prompts are off/on.”

## Audio Set [Type A (non-touchscreen)]

### Bluetooth® Audio

#### Applicable Bluetooth® specification (Recommended)

Ver. 2.0

#### Response profile

- A2DP (Advanced Audio Distribution Profile) Ver. 1.0
- AVRCP (Audio/Video Remote Control Profile) Ver. 1.0/1.3

A2DP is a profile which transmits only audio to the Bluetooth® unit. If your Bluetooth® audio device corresponds only to A2DP, but not AVRCP, you cannot operate it using the control panel of the vehicle's audio system. In this case, only the operations on the mobile device are available the same as when a portable audio device for a non-compliant Bluetooth® device is connected to the AUX terminal.

| Function             | A2DP | AVRCP    |          |
|----------------------|------|----------|----------|
|                      |      | Ver. 1.0 | Ver. 1.3 |
| Playback             | —    | X        | X        |
| Pause                | —    | X        | X        |
| File (Track) up/down | —    | X        | X        |
| Reverse              | —    | —        | X        |
| Fast-forward         | —    | —        | X        |
| Text display         | —    | —        | X        |

X: Available

—: Not available

#### NOTE

- The battery consumption of Bluetooth® audio devices increases while Bluetooth® is connected.

- If a general mobile phone device is USB connected during music playback over the Bluetooth® connection, the Bluetooth® connection is disconnected. For this reason, you cannot have music playback over a Bluetooth® connection and music playback using a USB connection at the same time.
- The system may not operate normally depending on the Bluetooth® audio device.

#### ▼ Switching to Bluetooth® audio mode

To listen to music or voice audio recorded to a Bluetooth® audio device, switch to the Bluetooth® audio mode to operate the audio device using the audio system control panel. Any Bluetooth® audio device must be paired to the vehicle's Bluetooth® unit before it can be used. Refer to Bluetooth® Preparation (Type A) on page 5-38.

1. Turn on the Bluetooth® audio device's power.
2. Switch the ignition to ACC or ON. Make sure that the “🎵” symbol is displayed in the audio display. The symbol is not displayed if an un-paired Bluetooth® audio device is being used or the vehicle's Bluetooth® unit has a malfunction.

#### NOTE

Some Bluetooth® audio devices need a certain amount of time before the “🎵” symbol is displayed.

3. Press the media button (**MEDIA**) to switch to the Bluetooth® audio mode and start playback.

## Audio Set [Type A (non-touchscreen)]

**If the current device version is lower than AVRCP Ver. 1.3:** “BT Audio” is displayed.

**If the current device is AVRCP Ver. 1.3:** The playback time is displayed.

### NOTE

- If the Bluetooth® audio device does not begin playback, press the Play/Pause button (4).
- If a call is received on a hands-free mobile phone during playback from the Bluetooth® audio device, the playback is stopped. Playback from the Bluetooth® audio device resumes after the call ends.

### ▼ Playback

1. To listen to a Bluetooth® audio device over the vehicle's speaker system, switch the mode to Bluetooth® audio mode. (Refer to “Switching to Bluetooth® audio mode”)
2. To stop playback, press the Play/Pause button (4).
3. Press the button again to resume playback.

### Selecting a file (track)

#### Selects the next file (track)

Short-press the track up button (▶▶).

#### Selects the beginning of the current file (track)

Short-press the track down button (◀◀).

### Fast-forward/Reverse (AVRCP Ver. 1.3)

#### Fast-forward


Press and hold the fast-forward button (▶▶▶).

#### Reverse

Press and hold the reverse down button (◀◀◀).

### ▼ Switching the display (only AVRCP Ver. 1.3)

The information displayed on the audio display changes as follows each time the text button (3) is pressed during playback.

| Button                                                                             | Information displayed on audio display |
|------------------------------------------------------------------------------------|----------------------------------------|
|  | Elapsed time                           |
|                                                                                    | Album name                             |
|                                                                                    | Song name                              |
|                                                                                    | Artist name                            |

### NOTE

- If title information is not available, “NO TITLE” is displayed.
- This unit cannot display some characters. Characters which cannot be displayed are indicated by an asterisk (\*).

### Display scroll

Only 13 characters can be displayed at one time. To display the rest of the characters of a long title, press and hold the text button (3). The display scrolls the next 13 characters. Press and hold the text button (3) again after the last 13 characters have been displayed to return to the beginning of the title.

### ▼ Bluetooth® audio device information display

If a Bluetooth® audio device is connected, the following information is displayed in the audio display.

**Audio Set [Type A (non-touchscreen)]**

| Category      | AVRCP Ver.<br>lower than 1.3 | AVRCP<br>Ver. 1.3 |
|---------------|------------------------------|-------------------|
| Device name   | X                            | X                 |
| Title         | —                            | X                 |
| Artist name   | —                            | X                 |
| Album name    | —                            | X                 |
| File number   | —                            | X                 |
| Playback time | —                            | X                 |
| Folder number | —                            | —                 |

X: Available

—: Not available

**NOTE**

Some information may not display depending on the device, and if the information cannot be displayed, "NO TITLE" is indicated.

**Bluetooth® Hands-Free****▼ Making a Call****Phonebook Usage**

Telephone calls can be made by saying the name of a person (voice tag) whose phone number has been registered in Bluetooth® Hands-Free in advance. Refer to Phonebook registration.

1. Press the pick-up button or talk button with a short press.
2. **Say:** [Beep] "Call"
3. **Prompt:** "Name please."
4. **Say:** [Beep] "XXXXX..." (Ex. "John's phone")" (Say a voice tag registered in the phonebook.)
5. **Prompt:** "Calling XXXXX..." (Ex. "John's phone") XXXX (Ex. "at home"). Is this correct?" (Voice tag and phone number location registered in phonebook).
6. **Say:** [Beep] "Yes"
7. **Prompt:** "Dialing"

**NOTE**

The "Call" command and the voice tag can be combined.

Ex. In Step 2, say, "Call John's phone", then, Steps 3 and 4 can be skipped.

**Phonebook registration**

Phone numbers can be registered to the Bluetooth® Hands-Free phonebook.

**NOTE**

Do this function only when parked. It is too distracting to attempt while driving and you may make too many errors to be effective.

## Audio Set [Type A (non-touchscreen)]

1. Press the pick-up button or talk button with a short press.
  2. **Say:** [Beep] "Phonebook"
  3. **Prompt:** "Select one of the following: New entry, edit, list names, delete, erase all or import contact."
  4. **Say:** [Beep] "New entry"
  5. **Prompt:** "Name please."
  6. **Say:** [Beep] "XXXXXX..." (Ex. "Mary's phone") (Say a voice tag for the name registered.)
  7. **Prompt:** "Adding XXXXXX... (Ex. "Mary's phone") (Registered voice tag). Is this correct?"
  8. **Say:** [Beep] "Yes"
  9. **Prompt:** "Home, Work, Mobile, or Other?"
  10. **Say:** [Beep] "Mobile" (Say "Home", "Work", "Mobile", or "Other", for the desired location to be registered.)
  11. **Prompt:** "Mobile (Location to be registered). Is this correct?"
  12. **Say:** [Beep] "Yes"
  13. **Prompt:** "Number, please."
  14. **Say:** [Beep] "XXXXXXXXXXXX" (Say the phone number to be registered.)
  15. **Prompt:** "XXXXXXXXXXXX (Phone number registration). After the beep, continue to add numbers, or say Go-Back to re-enter the last entered numbers, or press the Pick-Up button to save the number."
  16. **(Registration)**  
Press the pick-up button or say "Enter", then go to Step 17.  
**(Adding/inputting telephone number)**  
Say, "XXXX" (desired telephone number), then go to Step 15.  
**(Telephone number correction)**  
Say, "Go Back". The prompt replies, "Go Back. The last entered numbers have been removed.". Then go back to Step 13.
  17. **Prompt:** "Number saved. Would you like to add another number for this entry?"
  18. **Say:** [Beep] "Yes" or "No".
  19. If "Yes", an additional phone number registration can be made for the same entry.  
If "No", the system returns to standby status.
- (Import contact)**
- Phonebook data from your device (Mobile phone) can be sent and registered to your Bluetooth® Hands-Free phonebook using Bluetooth®.
1. Press the pick-up button or talk button with a short press.
  2. **Say:** [Beep] "Phonebook"
  3. **Prompt:** "Select one of the following: New entry, edit, list names, delete, erase all or import contact."
  4. **Say:** [Beep] "Import contact"
  5. **Prompt:** "The hands free system is ready to receive a contact from a phone. Only a home, a work, and a mobile number can be imported. This process requires operation of a mobile phone. Refer to the phone's manual for more information."

## Audio Set [Type A (non-touchscreen)]

6. **Prompt:** “X (Number of locations which include data) numbers have been imported. What name would you like to use for these numbers?”
7. **Say:** [Beep] “XXXXXX... (Ex. “Mary’s phone”)” (Say a voice tag for the name registered.)
8. **Prompt:** “Adding XXXXX... (Ex. “Mary’s phone”) (Voice tag). Is this correct?”
9. **Say:** [Beep] “Yes”
10. **Prompt:** “Number saved. Would you like to import another contact?”
11. **Say:** [Beep] “Yes” or “No”
12. If “Yes”, the procedure proceeds to Step 5.  
If “No”, the system returns to standby status.

### Editing phonebook

The data registered to the Bluetooth® Hands-Free phonebook can be edited.

#### NOTE

*Do this function only when parked. It is too distracting to attempt while driving and you may make too many errors to be effective.*

1. Press the pick-up button or talk button with a short press.
2. **Say:** [Beep] “Phonebook”
3. **Prompt:** “Select one of the following: New entry, edit, list names, delete, erase all or import contact.”
4. **Say:** [Beep] “Edit”
5. **Prompt:** “Please say the name of the entry you would like to edit or say, “List names”.”
6. **Say:** [Beep] “XXXXXX... (Ex. “Mary’s phone”)” (Say the voice tag for the registered name to be edited in the phonebook.)

5-54

7. **Prompt:** “Home, Work, Mobile, or Other?”
8. **Say:** [Beep] “Home” (Say the registered location to be edited: “Home”, “Work”, “Mobile”, or “Other”.)
9. **Prompt:** “XXXXXX... (Ex. “Mary’s phone”) (Registered voice tag) XXXX (Ex. “Home”) (Registered location). Is this correct?”
10. **Say:** [Beep] “Yes”
11. **Prompt:** “The current number is XXXXXXXXXXXX (Ex. “555-1234”) (Currently registered number). New number, please.”

#### NOTE

*If there was no previous phone number registered to a location (Ex. “Work”), the prompt will only read out “Number, please”*

12. **Say:** [Beep] “XXXXXXXXXXXX (Ex. “555-5678”)” (Say the new phone number to be registered.)
13. **Prompt:** “XXXXXXXX (Telephone number) After the beep, continue to add numbers, or say Go-Back to re-enter the last entered numbers, or press the Pick-Up button to save the number.”
14. **(Number Change)**  
Press the pick-up button, then go to Step 15.  
**(Adding/inputting telephone number)**  
Say, “XXXX” (desired telephone number), then go to Step 13.  
**(Telephone number correction)**  
Say, “Go Back”. The prompt replies, “Go Back. The last entered numbers have been removed. Number, please.”. Then go back to Step 12.



## Audio Set [Type A (non-touchscreen)]

15. **Prompt:** "Number changed."

### Phonebook data deletion

#### (Erasing individual phonebook data)

Individual data registered to the Bluetooth® Hands-Free phonebook can be cleared.

#### **NOTE**

*Do this function only when parked. It is too distracting to attempt while driving and you may make too many errors to be effective.*

1. Press the pick-up button or talk button with a short press.
2. **Say:** [Beep] "Phonebook"
3. **Prompt:** "Select one of the following: New entry, edit, list names, delete, erase all or import contact."
4. **Say:** [Beep] "Delete"
5. **Prompt:** "Please say the name of the entry you would like to delete or say, 'List names'."
6. **Say:** [Beep] "XXXXXX... (Ex. 'John's phone') " (Say the registered voice tag to be deleted from the phonebook.)
7. **Prompt:** "Deleting XXXXXX... (Ex. 'John's phone') (Registered voice tag) Home (Registered location). Is this correct?"
8. **Say:** [Beep] "Yes"
9. **Prompt:** "XXXXXX... (Ex. 'John's phone') (Registered voice tag) Home (Registered location) deleted."

#### (Complete deletion of the phonebook data)

All data registered to the Bluetooth® Hands-Free phonebook can be erased.

#### **NOTE**

*Do this function only when parked. It is too distracting to attempt while driving and you may make too many errors to be effective.*

1. Press the pick-up button or talk button with a short press.
2. **Say:** [Beep] "Phonebook"
3. **Prompt:** "Select one of the following: New entry, edit, list names, delete, erase all or import contact."
4. **Say:** [Beep] "Erase all"
5. **Prompt:** "Are you sure you want to delete everything from your Hands Free system phonebook?"
6. **Say:** [Beep] "Yes"
7. **Prompt:** "You are about to delete everything from your Hands Free system phonebook. Do you want to continue?"
8. **Say:** [Beep] "Yes"
9. **Prompt:** "Please wait, deleting the Hands Free system phonebook."
10. **Prompt:** "Hands-Free system phonebook deleted."

#### Read-out of names registered to the Bluetooth® Hands-Free phonebook

Bluetooth® Hands-Free can read out the list of names registered to its phonebook.

1. Press the pick-up button or talk button with a short press.
2. **Say:** [Beep] "Phonebook"
3. **Prompt:** "Select one of the following: New entry, edit, list names, delete, erase all or import contact."
4. **Say:** [Beep] "List names"

## Audio Set [Type A (non-touchscreen)]

5. **Prompt:** “XXXXX..., XXXXX..., XXXXX... (Ex. “John's phone”, Mary's phone, Bill's phone)” (Voice guidance reads out the voice tags registered to the phonebook.)  
Press the talk button with a short press during the read-out at the desired name, and then say one of the following voice commands to execute it.
  - “Continue”: Continues the list readout.
  - “Call”: Calls the registered phonebook data when the talk button is short-pressed.
  - “Edit”: Edits the registered phonebook data when the talk button is short-pressed.
  - “Delete”: Deletes the registered phonebook data when the talk button is short-pressed.
  - “Previous”: Returns to the previous phonebook data in read-out when the talk button is short-pressed.
6. **Prompt:** “End of list, would you like to start from the beginning?”
7. **Say:** [Beep] “No”

### Redial Function

Redialing the number of the person previously dialed using the phone is possible.

1. Press the pick-up button or talk button with a short press.
2. **Say:** [Beep] “Redial”
3. **Prompt:** “Dialing”

### Telephone Number Input

#### **NOTE**

*Practice this while parked until you are confident you can do it while driving in a non-taxing road situation. If you are not completely comfortable, make all calls from a safe parking position, and only start driving when you can devote your full attention to driving.*

1. Press the pick-up button or talk button with a short press.
2. **Say:** [Beep] “Dial”
3. **Prompt:** “Number, please”
4. **Say:** [Beep] “XXXXXXXXXXXXX (Telephone number)”
5. **Prompt:** “XXXXXXXXXXXXX. (Telephone number) After the beep, continue to add numbers, or say Go-Back to re-enter the last entered numbers, or press the Pick-Up button to execute dialing.”
6. **(Dialing)**  
Press the pick-up button or say “Dial”, then go to Step 7.  
**(Adding/inputting telephone number)**  
Say, “XXXX” (desired telephone number), then go to Step 5.  
**(Telephone number correction)**  
Say, “Go Back”. The prompt replies, “Go Back. The last entered numbers have been removed.”. Then go back to Step 3.
7. **Prompt:** “Dialing”

#### **NOTE**

*The “Dial” command and a telephone number can be combined.  
Ex. In Step 2, say, “Dial 123-4567” then, Steps 3 and 4 can be skipped.*

## Audio Set [Type A (non-touchscreen)]

### ▼ Receiving an Incoming Call

1. **Prompt:** “Incoming call, press the pick-up button to answer”
2. To accept the call, press the pick-up button.  
To reject the call, press the hang-up button.

### ▼ Hanging Up a Call

Press the hang-up button during the call. A beep sound will confirm that call is ended.

### ▼ Mute

The microphone can be muted during a call.

1. Press the talk button with a short press.
2. **Say:** [Beep] “Mute”
3. **Prompt:** “Microphone muted”

### Cancelling mute

1. Press the talk button with a short press.
2. **Say:** [Beep] “Mute off”
3. **Prompt:** “Microphone unmuted”

### ▼ Transferring a Call from Hands-Free to a Device (Mobile Phone)

Communication between the hands-free unit and a device (Mobile phone) is cancelled, and the line can be switched to a standard call using a device (Mobile phone).

1. Press the talk button with a short press.
2. **Say:** [Beep] “Transfer call”
3. **Prompt:** “Transferred call to phone”

### ▼ Transferring a Call from a Device (Mobile Phone) to Hands-Free

Communication between devices (Mobile phone) can be switched to Bluetooth® Hands-Free.

1. Press the talk button with a short press.
2. **Say:** [Beep] “Transfer call”
3. **Prompt:** “Transferred call to Hands Free system”

### ▼ Call interrupt

A call can be interrupted to receive an incoming call from a third party. Switch to a new incoming call using the following methods.

#### (Method 1)

1. Press the pick-up button.
2. **Prompt:** “Swapping calls.”

#### (Method 2)

1. Press the talk button with a short press.
2. **Say:** [Beep] “Swap calls”
3. **Prompt:** “Swapping calls.”

## Audio Set [Type A (non-touchscreen)]

### NOTE

- To refuse an incoming call, press the hang-up button.
- After receiving a new incoming call, the previous call is placed on hold.

### Switching calls

Switching back to the previous call can also be done.

#### Method 1

1. Press the pick-up button.
2. **Prompt:** "Swapping calls."

#### Method 2

1. Press the talk button with a short press.
2. **Say:** [Beep] "Swap calls"
3. **Prompt:** "Swapping calls."

### Three-way call function

1. Press the talk button with a short press.
2. **Say:** [Beep] "Join calls"
3. **Prompt:** "Joining calls"

### Making a call using a telephone number

1. Press the talk button with a short press.
2. **Say:** [Beep] "Dial"
3. **Prompt:** "Number, please"
4. **Say:** [Beep] "XXXXXXXXXXXXX (Telephone number)"
5. **Prompt:** "XXXXXXXXXXXXX. (Telephone number) After the beep, continue to add numbers, or say Go-Back to re-enter the last entered numbers, or press the Pick-Up button to execute dialing."

### 6. (Dialing)

Press the pick-up button or say "Dial", then go to Step 7.

#### **(Adding/inputting telephone number)**

Say, "XXXX" (desired telephone number), then go to Step 5.

#### **(Telephone number correction)**

Say, "Go Back". The prompt replies, "Go Back. The last entered numbers have been removed.". Then go back to Step 3.

### 7. **Prompt:** "Dialing"

### Making calls using the phonebook

1. Press the talk button with a short press.
2. **Say:** [Beep] "Call"
3. **Prompt:** "Name please."
4. **Say:** [Beep] "XXXXX... (Ex. "John's phone")" (Say a voice tag registered in the phonebook.)
5. **Prompt:** "Calling XXXXX... (Ex. "John's phone") XXXX (Ex. "at home"). Is this correct?" (Voice tag and phone number location registered in phonebook).
6. **Say:** [Beep] "Yes"
7. **Prompt:** "Dialing"

### Redialing function

1. Press the talk button with a short press.
2. **Say:** [Beep] "Redial"
3. **Prompt:** "Dialing"

### Ending the current call

Press the hang-up button during the call.

## Audio Set [Type A (non-touchscreen)]

### ▼ DTMF (Dual Tone Multi-Frequency Signal) Transmission

This function is used when transmitting DTMF via the user's voice. The receiver of a DTMF transmission is generally a home telephone answering machine or a company's automated guidance call centre (When you send tone signals back according to the voice guidance recording).

1. Press the talk button with a short press.
2. **Say:** [Beep] "XXXX... send" (Say DTMF code)
3. **Prompt:** "Sending XXXX... (DTMF code)"

### Voice Recognition

In this section, the basic operation of the voice recognition is explained.

#### Activating Voice Recognition

To Activate the Main Menu: Press the pick-up button or talk button with a short press.

#### Ending Voice Recognition

Use one of the following methods:

- Press and hold the talk-button.
- Press the hang-up button.

#### Skipping Voice Guidance (for faster operation)

Press and release the talk-button.

#### **NOTE**

- The Bluetooth® Hands-Free system is operable several seconds after the ignition is switched to ACC or ON (requires less than 15 seconds).
- When operating the audio unit or the A/C while using Bluetooth® Hands-Free, the beep sounds or voice guidance (audio unit)/cannot be heard.

#### Tutorial

The tutorial explains how to use Bluetooth® Hands-Free.

To activate the tutorial, do the following:

1. Press the pick-up button or talk button with a short press.
2. **Say:** [Beep] "Tutorial"
3. Follow the prompts to receive the appropriate voice guidance instructions.

## Audio Set [Type A (non-touchscreen)]

---

### **Commands useable anytime during voice recognition**

“Help” or “Go Back” are commands which can be used at anytime during voice recognition.

#### **Help function use**

The help function informs the user of all the available voice commands under the current conditions.

1. **Say:** [Beep] “Help”
2. Follow the prompts to receive the appropriate voice guidance instructions.

#### **Returning to previous operation**

This command is for returning to the previous operation while in the voice recognition mode.

**Say:** [Beep] “Go Back”

### **To prevent a deterioration in the voice recognition rate and voice quality, the following points should be observed:**

- **The voice recognition cannot be performed while voice guidance or the beep sound is operating. Wait until the voice guidance or the beep sound is finished before saying your commands.**
- Dialects or different wording other than hands-free prompts cannot be recognised by voice recognition. Speak in the wording specified by the voice commands.
- It is not necessary to face the microphone or approach it. Speak the voice commands while maintaining a safe driving position.
- Do not speak too slow or too loud.

- Speak clearly, without pausing between words or numbers.
- Close the windows to reduce loud noises from outside the vehicle, or turn down the airflow of the air-conditioning system while Bluetooth® Hands-Free is being used.
- Make sure the vents are not directing air up towards the microphone.

#### **NOTE**

*If the voice recognition performance is not satisfactory.*

*Refer to Voice Recognition Learning Function (Speaker Enrolment) (Type A) on page 5-61.*

*Refer to Troubleshooting on page 5-63.*

## Audio Set [Type A (non-touchscreen)]

### Voice Recognition Learning Function (Speaker Enrolment)

The voice recognition learning function enables voice recognition appropriate to the characteristics of the user's voice. If the recognition of the voice input commands to the system is not adequate, this function can largely improve the system's voice recognition of the user. If your voice can be recognised sufficiently without using this function, you may not realize the added benefit of the function. To register your voice, the voice input command list must be read out. Read out the list when the vehicle is parked. Perform the registration in as quiet a place as possible (page 5-59). The registration must be performed completely. The required time is a few minutes. The user needs to be seated in the driver's seat with the voice input command list for voice recognition learning visible.

#### ▼ When voice recognition learning is done for the first time

1. Press the pick-up button or talk button with a short press.
2. **Say:** [Beep] "Voice training"
3. **Prompt:** "This operation must be performed in a quiet environment while the vehicle is stopped. See the owner's manual for the list of required training phrases. Press and release the talk button when you are ready to begin. Press the hang-up button to cancel at any time."
4. Press the talk button with a short press.
5. The voice guidance reads out the voice input command number (refer to the voice input command list for voice recognition learning). (Ex. "Please read phrase 1")
6. **Say:** [Beep] "0123456789" (Say the voice input command for voice recognition learning (1 to 8) according to the voice guidance.)
7. **Prompt:** "Speaker enrolment is complete."

#### NOTE

*If an error occurred in the voice recognition learning, re-learning can be done by pressing the talk button with a short press.*

#### ▼ Voice recognition re-learning

If voice recognition learning has already been done.

1. Press the pick-up button or talk button with a short press.
2. **Say:** [Beep] "Voice training"
3. **Prompt:** "Enrolment is enabled/disabled. Would you like to disable/enable or retrain?"
4. **Say:** [Beep] "Retrain"
5. **Prompt:** "This operation must be performed in a quiet environment while the vehicle is stopped. See the owner's manual for the list of required training phrases. Press and release the talk button when you are ready to begin. Press the hang-up button to cancel at any time."
6. Press the talk button with a short press.
7. The voice guidance reads out the voice input command number (refer to the voice input command list for voice recognition learning). (Ex. "Please read phrase 1")

## Audio Set [Type A (non-touchscreen)]

8. **Say:** [Beep] “0123456789” (Say the voice input command for voice recognition learning (1 to 8) according to the voice guidance.)
9. **Prompt:** “Speaker enrolment is complete.”

### NOTE

*If an error occurred in the voice recognition learning, re-learning can be done by pressing the talk button with a short press.*

### Voice input command list for voice recognition learning

When reading out, the following points must be observed:

- Read out the numbers one at a time correctly and naturally.  
(For example, “1234” must be read out “one, two, three, four” not “twelve, thirty four”.)
- Do not read out parentheses. “(” and hyphens “-” are used for separating numbers in a phone number.

Ex.

“(888) 555-1212” must be spoken “Eight, eight, eight, five, five, five, one, two, one, two.”

| Phrase | Command        |
|--------|----------------|
| 1      | 0123456789     |
| 2      | (888) 555-1212 |
| 3      | Call           |
| 4      | Dial           |
| 5      | Setup          |
| 6      | Cancel         |
| 7      | Continue       |
| 8      | Help           |

### NOTE

- The applicable phrase appears in the audio display.
- After user voice registration is completed, voice guidance “Speaker enrolment is complete” is announced.

### Voice recognition learning on/off

1. Press the pick-up button or talk button with a short press.
2. **Say:** [Beep] “Voice training”
3. **Prompt:** “Enrolment is enabled/disabled. Would you like to disable/enable or retrain?”
4. **Say:** [Beep] “Disable” or “Enable”
5. When “Disable” is spoken, the voice recognition learning is turned off.  
When “Enable” is spoken, the voice recognition learning is turned on.
6. **Prompt:** “Speaker Enrolment is disabled/enabled.”



## Audio Set [Type A (non-touchscreen)]

### Troubleshooting

#### Mazda Bluetooth® Hands-Free Customer Service

If you have any problems with Bluetooth®, contact our toll-free customer service centre.

- **Australia**

Phone: 1800-352-703 during business hours (10am—4pm Eastern Standard Time)

Web: [www.mazda.com.au](http://www.mazda.com.au)

- **New Zealand**

Web: [www.mazdahandsfree.co.nz](http://www.mazdahandsfree.co.nz)

#### Bluetooth® Device pairing, connection problems

| Symptom                                                 | Cause                                                                                                                                                            | Solution method                                                                                                                                                                                                                                                                                                                                         |
|---------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Unable to perform pairing                               | —                                                                                                                                                                | First make sure the device is compatible with the Bluetooth® unit, and then check whether the Bluetooth® function and the Find Mode/Visible setting*1 on the device are turned on. If pairing is still not possible after this, contact an expert repairer (we recommend an Authorised Mazda Repairer) or Mazda Bluetooth® Hands-Free Customer Service. |
| Pairing cannot be performed again                       | The pairing information paired to the Bluetooth® unit or device is not recognised correctly.                                                                     | Perform pairing using the following procedure. <ul style="list-style-type: none"> <li>• Clear “Mazda” stored in the device.</li> <li>• Perform pairing again.</li> </ul>                                                                                                                                                                                |
| Unable to perform pairing                               | The Bluetooth® function and the Find Mode/Visible setting*1 on the device may turn off automatically after a period of time has elapsed depending on the device. | Check whether the Bluetooth® function and the Find Mode/Visible setting*1 on the device are turned on and pairing or reconnect.                                                                                                                                                                                                                         |
| Does not connect automatically when starting the engine |                                                                                                                                                                  |                                                                                                                                                                                                                                                                                                                                                         |
| Automatically connects, but then disconnects suddenly   |                                                                                                                                                                  |                                                                                                                                                                                                                                                                                                                                                         |
| Disconnects intermittently                              | The device is in a location in which radio wave interference can occur easily, such as inside a bag in a rear seat, in a rear pocket of a pair of pants.         | Move the device to a location in which radio wave interference is less likely to occur.                                                                                                                                                                                                                                                                 |
| Does not connect automatically when starting the engine | The pairing information is updated when the device OS is updated.                                                                                                | Perform pairing again.                                                                                                                                                                                                                                                                                                                                  |

\*1 Setting which detects the existence of a device external to the Bluetooth® unit.

## Audio Set [Type A (non-touchscreen)]

### NOTE

- When the OS of the device is updated, the pairing information may be deleted. If this happens, reprogramme the pairing information to the Bluetooth® unit.
- If you pair your phone which has already been paired to your vehicle more than once in the past, you need to delete “Mazda” on your mobile device. Then, execute the Bluetooth® search on your mobile device once again, and pair to a newly detected “Mazda”.
- Before you pair your device, make sure that Bluetooth® is “ON”, both on your phone and on the vehicle.
- If Bluetooth®-enabled devices are used in the following locations or conditions, connection via Bluetooth® may not be possible.
  - The device is in a location hidden from the unit such as behind or under a seat, or inside the glove compartment.
  - The device contacts or is covered by a metal object or body.
  - The device is set to power-saving mode.
- Different Bluetooth®-enabled devices can be used for Bluetooth® Hands-Free and Bluetooth® audio. For example, device A can be connected as a Bluetooth® Hands-Free device and device B can be connected as a Bluetooth® audio device. However, the following may occur when they are used at the same time.
  - The Bluetooth® connection of the device is disconnected.
  - Noise occurs in the Hands-Free audio.
  - Hands-Free operates slowly.

### Voice recognition related problems

| Symptom                      | Cause                                                                                                                                                                                                                                                                                                                                                                               | Solution method                                                                                                                                                                                           |
|------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Poor voice recognition       | <ul style="list-style-type: none"> <li>• Excessive, slow speech.</li> <li>• Excessive, forceful speech (shouting).</li> <li>• Speaking before the beep sound has ended.</li> <li>• Loud noise (speaking or noise from outside/inside vehicle).</li> <li>• Airflow from A/C is blowing against the microphone.</li> <li>• Speaking in off-standard expressions (dialect).</li> </ul> | Regarding the causes indicated on the left, be careful with how you speak. In addition, when numbers are spoken in a sequence, recognition ability will improve if no stop is placed between the numbers. |
| False recognition of numbers |                                                                                                                                                                                                                                                                                                                                                                                     |                                                                                                                                                                                                           |
| Poor voice recognition       | There is a malfunction in the microphone.                                                                                                                                                                                                                                                                                                                                           | A poor connection or malfunction with the microphone may have occurred. Consult an expert repairer (we recommend an Authorised Mazda Repairer).                                                           |

## Audio Set [Type A (non-touchscreen)]

| Symptom                                                 | Cause                                                                              | Solution method                                                                                                                                                                                                                                                                                                                                                     |
|---------------------------------------------------------|------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Phone-related voice recognition is disabled             | There is a problem with the connection between the Bluetooth® unit and the device. | If there is any malfunction after checking the pairing situation, check for device pairing or connection problems.                                                                                                                                                                                                                                                  |
| Names in the phonebook are not easily recognised        | The Bluetooth® system is under a condition in which recognition is difficult.      | By carrying out the following measures, the rate of recognition will improve. <ul style="list-style-type: none"> <li>• Clear memory from the phonebook which is not used very often.</li> <li>• Avoid shortened names, use full names. (Recognition improves the longer the name is. By not using names such as “Mum”, “Dad”, recognition will improve.)</li> </ul> |
| When operating the audio, a song name is not recognised | Song names cannot be recognised by voice.                                          | —                                                                                                                                                                                                                                                                                                                                                                   |
| You want to skip guidance                               | —                                                                                  | Guidance can be skipped by quickly pressing and releasing the Talk button.                                                                                                                                                                                                                                                                                          |

### Regarding problems with calls

| Symptom                                                               | Cause                                                                                                                                       | Solution method                                   |
|-----------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------|
| When starting a call, vehicle noise from the other party can be heard | For about 3 seconds after starting a call, the Bluetooth® unit's Noise Suppression function requires time to adapt to the call environment. | This does not indicate a problem with the device. |
| The other party cannot be heard or the speaker's voice is quiet       | The volume is set at zero or low.                                                                                                           | Increase the volume.                              |

**Audio Set [Type A (non-touchscreen)]**

---

**Other problems**

| Symptom                                                                                                                                 | Cause                                                                  | Solution method                                                                                                                                               |
|-----------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------|
| The indication for the remaining battery is different between the vehicle and the device                                                | The indication method is different between the vehicle and the device. | —                                                                                                                                                             |
| When a call is made from the vehicle, the telephone number is updated in the incoming/outgoing call record but the name does not appear | The number has not been registered into the phonebook.                 | If the number has been registered into the phonebook, the incoming/outgoing call record is updated by the name in the phonebook when the engine is restarted. |
| The cell phone does not synchronize with the vehicle regarding the incoming/outgoing call record                                        | Some types of cell phones do not synchronize automatically.            | Operate the cell phone for synchronization.                                                                                                                   |
| It takes a long time to complete the function for changing the language                                                                 | A maximum of 60 seconds is required.                                   | —                                                                                                                                                             |

## Audio Set [Type B (touchscreen)]

### Basic Operation Method

#### NOTE

- The explanation of functions described in this manual may differ from the actual operation, and the shapes of screens and buttons and the letters and characters displayed may also differ from the actual appearance.
- Additionally, depending on future software updates, the content may successively change without notice.
- For additional information regarding Mazda Connect, please refer to the following Website.  
<http://infotainment.mazdahandsfree.com/>

Audio Set (Type B) has 3 different human interfaces.


- Commander switch
  - Touch panel
  - Voice recognition with steering switch and microphone
- Refer to Voice Recognition on page 5-119.

#### ▼ Commander switch operation

#### NOTE

For safety reasons, some operations are disabled while the vehicle is being driven.

#### Volume dial operation




Press the volume dial to mute and pause. However, while an audio source which cannot be paused such as FM radio is playing, only mute is available. Press the volume dial again to resume the audio.

Turn the volume dial to adjust the volume. The volume increases by turning the dial clockwise, and decreases by turning it anticlockwise.

## Audio Set [Type B (touchscreen)]

### Switches around commander knob



The following operations can be done by pressing the switches around the commander knob.

: Displays the home screen.


: Displays the Entertainment screen.

**NAV** : Displays the Navigation screen (Only navigation-equipped vehicles). For operation of the Navigation screen, refer to the navigation system manual. If the SD card for the navigation system is not inserted, the compass indicating the direction in which the vehicle is moving is displayed.

: Displays the Favourites screen. Long-press to store particular items in Favourites. (Radio, phonebook and destination of the navigation system can be programmed.)

: Returns to previous screen.

### Commander knob operation



#### (Selection of icons on screen)

1. Tilt or turn the commander knob and move the cursor to the desired icon.
2. Press the commander knob and select the icon.

## Audio Set [Type B (touchscreen)]

### NOTE

Long-press operation of the commander knob is also possible for some functions.


### ▼ Touch panel operation



Do not press the screen strongly or press it with a sharp-pointed object. Otherwise, the screen could be damaged.


### NOTE

For safety reasons, operation of the centre display is disabled while the vehicle is being driven. However, items not displayed in grey can be operated using the commander switch while the vehicle is being driven.



### Touch & Tap

1. Touch or tap on the item indicated on the screen.
2. The operation is launched and the next item is displayed.




### Slide (USB audio only)

1. Touch the setting item displaying a slider bar.


## Audio Set [Type B (touchscreen)]

2. Touch the slider with your finger and move to the desired level.



### Swipe

1. Touch the screen with your finger and move up or down.
2. Items which were not displayed can be displayed.



### Return to previous screen

1. Touch the .


### Displaying the home screen

1. Touch the .



## Audio Set [Type B (touchscreen)]

### Home screen




| Icon                                                                                | Function                                                                                                                                                                                                                                                                                                                                                                                                 |
|-------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|    | <b>Applications</b><br>Information such as average fuel economy, maintenance, and warnings can be verified. Depending on the grade and specification, the screen display may differ.                                                                                                                                                                                                                     |
|    | <b>Entertainment</b><br>Operates audio such as the radio and CDs. The audio source most recently used is displayed. An audio source which cannot be used at that time is skipped and the previous audio source is displayed.<br><br>To change the audio source, select the  icon displayed at the bottom of the screen. |
|  | <b>Communication</b><br>Bluetooth® related functions are available.                                                                                                                                                                                                                                                                                                                                      |
|  | <b>Navigation</b><br>Navigation screen is displayed (vehicles with navigation system).<br>If the SD card for the navigation system is not inserted, the compass indicating the direction in which the vehicle is moving is displayed.<br>The compass may not indicate the correct bearing when the vehicle is stopped or traveling at a slow speed.                                                      |
|  | <b>Settings</b><br>Overall setting menu (Such as display, sound, Bluetooth® and Language). Depending on the grade and specification, the screen display may differ.                                                                                                                                                                                                                                      |


## Audio Set [Type B (touchscreen)]

### Volume/Display/Sound Controls

Commander switch



Audio control switch



#### ▼ Volume adjustment

Turn the commander switch volume dial. The volume switch on the steering switch can also be pressed.

#### NOTE

Press the volume dial to mute and pause. However, while an audio source which cannot be paused such as FM radio is playing, only mute is available. Press the volume dial again to resume the audio.

#### ▼ Display setting

Select the  icon on the home screen to display the Settings screen.

Select the **Display** tab to select the item you would like to change.

#### Display OFF/Clock

The centre display can be turned off. Select **Turn Display Off** to turn the display off. When **Turn Display Off and Show Clock** is selected the centre display turns off and the clock is displayed. The centre display can be turned back on as follows:

- Touch the centre display.

- Operate the commander switch.

#### Daytime/nighttime (Mode) screen setting

The daytime or nighttime screen can be selected.

**Auto** :

#### (With auto-light control)

Switches screen automatically according to position lights illumination condition. However, when the light sensor detects that the surrounding area is bright such as when the position lights are turned on in the daytime, the screen is switched to the daytime screen\*1

#### (Without auto-light control)

Switches screen automatically according to position lights illumination condition.\*1

**Day** : Daytime screen setting

**Night** : Nighttime screen setting

\*1 The display is constantly on daytime screen when the illumination dimmer is cancelled.

#### Brightness adjustment

Adjust the centre display brightness using the slider.

## Audio Set [Type B (touchscreen)]

### Contrast adjustment

Adjust the centre display contrast using the slider.

### Display setting reset

All of the screen setting values can be reset to their initial settings.

1. Select **Reset**.
2. Select **Yes**.

### ▼ Audio sound adjustment

Select the  icon on the home screen to display the Settings screen.

Select the **Sound** tab to select the item you would like to change.

| Indication                                                                        | Setting value                                                                    |
|-----------------------------------------------------------------------------------|----------------------------------------------------------------------------------|
| Bass<br>(Low pitch sound)                                                         | <b>+</b> Side: Low pitch enhancement<br><b>-</b> Side: Low pitch reduction       |
| Treble<br>(Treble sound)                                                          | <b>+</b> Side: Treble enhancement<br><b>-</b> Side: Treble reduction             |
| Fade<br>(Front/Rear volume balance)                                               | Front: Front speaker volume enhancement<br>Rear: Rear speaker volume enhancement |
| Balance<br>(Left/right volume balance)                                            | Right: Right speaker volume enhancement<br>Left: Left speaker volume enhancement |
| Guidance Volume<br>(Volume adjustment during route guidance on navigation screen) | Left: Low volume<br>Right: High volume                                           |
| ALC<br>(Automatic volume adjustment)                                              | Off—Adjustment at seven levels                                                   |
| Beep<br>(Audio operation sound)                                                   | On/Off                                                                           |

### ALC (Automatic volume adjustment)

The automatic level control (ALC) is a feature that automatically adjusts audio volume according to the vehicle speed. The volume increases in accordance with the increase in vehicle speed, and decreases as vehicle speed decreases.

## Audio Set [Type B (touchscreen)]

### Operating the Radio

#### ▼ Radio ON

Select the  icon on the home screen to display the Entertainment screen. When selecting the desired radio, the following icons are indicated in the lower part of the centre display.

#### AM/FM Radio

| Icon                                                                                | Function                                                                                                                                                                                                                                                                                                                                      |
|-------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|    | Displays the Entertainment menu. Use to switch to a different audio source.                                                                                                                                                                                                                                                                   |
|    | Displays the list of receivable RDS radio stations (FM only).                                                                                                                                                                                                                                                                                 |
|    | Displays the station list (AM only).<br>Select <b>Update Station List</b> to display the frequencies of up to 10 radio stations on the auto memory preset list.<br>Select the desired frequency.                                                                                                                                              |
|   | Displays the Favourites list. Long-press to store radio station currently being aired.                                                                                                                                                                                                                                                        |
|  | You can search for receivable radio stations.<br>Scanning stops at each station for about 5 seconds.<br>Select again to continue receiving the radio station.                                                                                                                                                                                 |
|  | You can change the radio frequency manually.<br>Rotate the commander knob, slide the screen, or touch the radio frequency.<br>Press ◀ or ▶ to change the radio frequency one step at a time.<br>When ◀ or ▶ is long-pressed, the radio frequency changes continually. It stops when you remove your hand from the icon or the commander knob. |
|  | Switches the TA mode on and off.                                                                                                                                                                                                                                                                                                              |
|  | Automatic radio station selection.                                                                                                                                                                                                                                                                                                            |
|  | When long-pressed, the radio frequency changes continually. It stops when you remove your hand from the icon or the commander knob.                                                                                                                                                                                                           |
|  | Displays the FM settings screen (FM only).<br>On/Off of Alternative frequency and Region lock can be set.                                                                                                                                                                                                                                     |
|  | Displays sound settings to adjust audio quality level.<br>Refer to Volume/Display/Sound Controls on page 5-72.                                                                                                                                                                                                                                |

## Audio Set [Type B (touchscreen)]

### NOTE

When the or icon is selected while FM is selected, each programme is selected.

### ▼ Favourites Radio

Selected stations can be registered for convenient operation. Up to 50 stations can be registered. The Favourites list is common to AM, FM and DAB radio\*.

#### Registering to Favourites

Long-press the icon to register the current radio station. The registration can also be performed using the following procedure.

1. Select the icon to display the Favourites list.
2. Select **Add/Edit Radio Favourites**.
3. Select **Add <active station>**.
4. The station is added to the bottom of the Favourites list.

### NOTE

If the battery is disconnected, your Favourites list will be not deleted.

#### Selecting radio station from Favourites

1. Select the icon to display the Favourites list.
2. Select the radio frequency to tune in the radio station.

#### Deleting from Favourites

1. Select the icon to display the Favourites list.
2. Select **Add/Edit Radio Favourites**.
3. Select **Delete**.
4. Select the radio frequency you want to delete.
5. Select **Delete**.

### Changing Favourites list order

1. Select the icon to display the Favourites list.
2. Select **Add/Edit Radio Favourites**.
3. Select **Move**.
4. Select a radio frequency. The selected radio station can be moved.
5. Slide the radio station or move it using the commander switch, then select **OK**.

### ▼ Radio Data System (RDS)

#### Alternative frequency (AF)

AF functions on FM stations. Turn on the AF mode. If the radio reception of the current station weakens, the system switches to an alternative station automatically.

If you wish to continue a regional programme, turn on the Region lock (REG) mode.

#### AF/REG on or off switching

Select the icon while in FM mode to switch to the FM settings screen. AF/REG on or off switching can be performed as follows:

##### (AF mode on/off)

Select On/Off on the FM settings screen.

##### (REG mode on/off)

While the AF mode is on, select On/Off.

#### Traffic announcement (TA)

Select **TA** during FM/AM reception to switch to the TA mode.

If a TA broadcast is received while in the TA mode, the TA broadcast intercedes even while using other functions (FM, CD, USB device, AUX, BT audio, Aha™ radio, or Stitcher™ radio), and “Traffic Announcement” is displayed.

\*Some models.

## Audio Set [Type B (touchscreen)]

---

If a TA is received on the Entertainment screen, **Cancel** is displayed on the screen. Select **Cancel** to cancel the received TA and return to TA reception stand-by. If a TA is received on a screen other than the Entertainment screen, the selection screens for **TA Off**, **Cancel**, and **Close** are displayed on the screen. If **Close** is selected, the selection screen turns off when a TA is received while continuing to receive TAs.

### Selection from Station List

List of receivable RDS radio stations is displayed. You can easily select the station you want to listen to from the list. If a radio station name is not available, the frequency is displayed. In addition, radio stations which have been programmed to a Genre code (Programme types like Rock, News, and so on) can also be displayed separately by category.

#### **NOTE**

*It may take longer to display the station list depending on the reception conditions.*

1. Select the **≡** icon to display the radio station list.
2. Select the radio frequency to tune in the radio station.

### (Selecting Genre)

1. Select the **Genre** on the station list screen to display the genre list screen.
2. Select the genre to display the radio station list in the genre.

#### **NOTE**

*Only one Genre can be selected.*

## Audio Set [Type B (touchscreen)]

### Operating the Digital Audio Broadcasting (DAB) Radio\*

#### ▼ What is DAB radio?

DAB radio is a digital broadcasting system for radio.

DAB radio provides a high-quality radio sound source using an auto frequency switching function in boundary areas.


By displaying the radio text, information such as the song name and artist name can be displayed.

#### NOTE

*This unit is also compatible with DAB+ radio.*

#### ▼ Radio ON

1. Select  on the home screen to display the Entertainment screen.
2. Select , the following icons are displayed at the bottom of the screen.

| Icon                                                                                | Function                                                                                                                                                                                                                                                                                                                   |
|-------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|   | Displays the Entertainment menu. Use to switch to a different audio source.                                                                                                                                                                                                                                                |
|  | Displays the station list (ensemble and station).<br>Select  to update the station list.<br>Select  to select the ensemble you want to display.      |
|  | Displays the favourites list. Press and hold to store the currently tuned station to the favourites list.<br>Refer to Operating the Radio (Type B) on page 5-74.                                                                                                                                                           |
|  | Searches your desired station from the station list.<br>Tunes to each station in the station list for 10 seconds.<br>Select again when your desired station is tuned.<br><br><b>NOTE</b><br><i>If the station list is not available, it switches to the station list update screen. Perform the station list updating.</i> |
|  | Switches the TA mode on and off.<br>Refer to Operating the Radio (Type B) on page 5-74.                                                                                                                                                                                                                                    |
|  | Returns to the previous station.<br>Touch and hold to return to the top station in the previous ensemble.                                                                                                                                                                                                                  |
|  | Goes to the next station.<br>Touch and hold to go to the top station in the next ensemble.                                                                                                                                                                                                                                 |
|  | Displays the DAB radio setting screen.                                                                                                                                                                                                                                                                                     |


\*Some models.

## Audio Set [Type B (touchscreen)]

| Icon                                                                              | Function                                                                                                       |
|-----------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------|
|  | Displays sound settings to adjust audio quality level.<br>Refer to Volume/Display/Sound Controls on page 5-72. |

### Example of use (Update station list and listen to DAB radio)

1. Select the  icon and display the following screen.
2. Select **Update List** to update the station list.
3. Select **Select Ensemble** to select the ensemble you want to display.
4. Select a desired station to start radio reception.



### ▼ DAB radio setting

1. Select the  icon while using DAB radio.
2. Select the desired item and perform the setting.  
The items which can be set are as follows:

| Item          | Setting                 | Function                                                                                                                |
|---------------|-------------------------|-------------------------------------------------------------------------------------------------------------------------|
| BAND Settings | Band III/L<br>Band/Both | Frequency band can be changed.                                                                                          |
| DAB-FM Link   | On/Off                  | On: If the reception condition is bad, an FM station which is providing the same broadcast is searched and switched to. |

| Item         | Setting | Function                                                                                                                |
|--------------|---------|-------------------------------------------------------------------------------------------------------------------------|
| DAB-DAB Link | On/Off  | On: If the reception condition is bad, a DAB station which is providing the same broadcast is searched and switched to. |
| Radio Text   | On/Off  | On: Radio text is displayed.                                                                                            |


### NOTE

- The radio text may not be displayed depending on the radio station.
- The radio text cannot be displayed in DAB-FM mode.
- If there is no DAB radio signal, "Signal Lost" is displayed on the screen.  
Change the ensemble or radio station, or perform station list updating.



## Audio Set [Type B (touchscreen)]

### Operating the Compact Disc (CD) Player\*



| Type                            | Playable data                                                                                      |
|---------------------------------|----------------------------------------------------------------------------------------------------|
| Music/MP3/WMA/AA<br>C CD player | <ul style="list-style-type: none"> <li>• Music data (CD-DA)</li> <li>• MP3/WMA/AAC file</li> </ul> |

#### **NOTE**

*If a disc has both music data (CD-DA) and MP3/WMA/AAC files, playback of the 2 or 3 file types differs depending on how the disc was recorded.*

#### **Inserting the CD**

Insert the CD into the slot, label-side up. The auto-loading mechanism will set the CD and begin play.

#### **NOTE**

*There will be a short lapse before play begins while the player reads the digital signals on the CD.*

#### **Ejecting the CD**

Press the CD eject button (▲) to eject the CD.

\*Some models.

## Audio Set [Type B (touchscreen)]

### ▼ Playback

Select the  icon on the home screen with a CD inserted and display the Entertainment screen. When  is selected, the following icons are indicated in the lower part of the centre display.


| Icon                                                                                | Function                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |
|-------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|    | Displays the Entertainment menu. Use to switch to a different audio source.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
|    | <p><b>(Music CD)</b><br/>Displays the track list of the CD.<br/>Select the track you want to play.</p> <p><b>(MP3/WMA/AAC CD)</b><br/>Displays the top level folder/file list.<br/>Select the folder you want to select.<br/>The files in the selected folder are displayed.<br/>Select the file you want to play.</p>                                                                                                                                                                                                                                                                                |
|    | <p><b>(MP3/WMA/AAC CDs only)</b><br/>Displays the file list of the folder currently being played.<br/>Select the song you want to listen to.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
|  | <p><b>(Music CD)</b><br/>Replays the song currently being played repeatedly.<br/>Select it again to cancel.</p> <p><b>(MP3/WMA/AAC CD)</b><br/>Replays the song currently being played repeatedly.<br/>When selected again, the songs in the folder are played repeatedly.<br/>Select it again to cancel.</p>                                                                                                                                                                                                                                                                                         |
|  | <p><b>(Music CD)</b><br/>Plays songs on the CD in random order.<br/>Select it again to cancel.</p> <p><b>(MP3/WMA/AAC CD)</b><br/>Plays songs in the folder in random order.<br/>When selected again, the songs on the CD are played in random order.<br/>Select it again to cancel.</p>                                                                                                                                                                                                                                                                                                              |
|  | <p><b>(Music CD)</b><br/>The beginning of each track on a CD is played to aid in searching for a desired track.<br/>When selected again, the operation is cancelled and the song currently being played continues.</p> <p><b>(MP3/WMA/AAC CD)</b><br/>The beginning of each track in a folder is played to aid in searching for a desired track.<br/>When selected again, the operation is cancelled and the song currently being played continues.</p> <p>If the audio is operated during scan-play, the track being scan-played is played normally.<br/>Then, the audio operation is performed.</p> |

## Audio Set [Type B (touchscreen)]

| Icon                                                                              | Function                                                                                                                                                                                                                                                                                                                                               |
|-----------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|  | If selected within a few seconds of a song which has started to play, the previous song is selected.<br>If more than a few seconds have elapsed after a song has begun to play, the song currently being played is replayed from the beginning.<br>Long-press to fast reverse. It stops when you remove your hand from the icon or the commander knob. |
|  | Plays a CD. When selected again, playback is temporarily stopped.                                                                                                                                                                                                                                                                                      |
|  | Advances to the beginning of the next song.<br>Long-press to fast forward. It stops when you remove your hand from the icon or the commander knob.                                                                                                                                                                                                     |
|  | Displays sound settings to adjust audio quality level.<br>Refer to Volume/Display/Sound Controls on page 5-72.                                                                                                                                                                                                                                         |

### Example of use (When searching for a song from the top level of an MP3/WMA/AAC CD)

1. Select the  icon to display the folder/file list at the top level.
2. When the folder is selected, folders/file lists in the folder are displayed.
3. Select the desired song.



### NOTE

- Select  to move to a folder one level higher.
- The appearance of the repeat and shuffle icons changes depending on the type of operation in which the function is used.

## Audio Set [Type B (touchscreen)]

### How to use AUX mode

#### ▼ Playback

1. Select the  icon on the home screen to display the Entertainment screen.
2. Select **AUX** to switch to the AUX mode. The following icons are displayed in the lower part of the centre display.

| Icon                                                                              | Function                                                                                                       |
|-----------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------|
|  | Displays the Entertainment menu. Use to switch to a different audio source.                                    |
|  | Displays sound settings to adjust audio quality level.<br>Refer to Volume/Display/Sound Controls on page 5-72. |

#### NOTE

- If a device is not connected to the auxiliary jack, the mode does not switch to the AUX mode.
- Adjust the audio volume using the portable audio device, commander switch, or audio control switch.
- Audio adjustments can also be made using the portable audio device's volume setting.
- If the connection plug is pulled out from the auxiliary jack while in AUX mode, noise may occur.

## Audio Set [Type B (touchscreen)]

### How to use USB mode

| Type     | Playable data        |
|----------|----------------------|
| USB mode | MP3/WMA/AAC/OGG file |

This unit does not support a USB 3.0 device. In addition, other devices may not be supported depending on the model or OS version.

The recommended capacity of the USB memory is 32 GB or less.

USB devices formatted to FAT32 are supported (USB devices formatted to other formats such as NTFS are not supported).

#### ▼ Playback

1. Select the  icon on the home screen to display the Entertainment screen.
2. Select **USB 1** or **USB 2** to switch the USB mode. The following icons are displayed in the lower part of the centre display.

| Icon                                                                                | Function                                                                                                                                                                                                                                                                                                                                   |
|-------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|   | Displays the Entertainment menu. Use to switch to a different audio source.                                                                                                                                                                                                                                                                |
|  | Category list is displayed.                                                                                                                                                                                                                                                                                                                |
|  | Current track list is displayed.<br>Select a desired track to play it.                                                                                                                                                                                                                                                                     |
|  | Plays the current track repeatedly.<br>Select it again to play the tracks in the current track list repeatedly.<br>When selected again, the function is cancelled.                                                                                                                                                                         |
|  | Tracks in the current track list are played randomly.<br>Select it again to cancel.                                                                                                                                                                                                                                                        |
|  | Starts playing a track similar to the current track using Gracenote®'s More Like This™.<br>Select the desired song from the category list to cancel More Like This™.                                                                                                                                                                       |
|  | If selected within a few seconds from the beginning of a song which has started to play, the previous song is selected.<br>If more than a few seconds have elapsed, the song currently being played is replayed from the beginning.<br>Long-press to fast reverse. It stops when you remove your hand from the icon or the commander knob. |
|  | Track is played. When selected again, playback is temporarily stopped.                                                                                                                                                                                                                                                                     |
|  | Advances to the beginning of the next song.<br>Long-press to fast forward.                                                                                                                                                                                                                                                                 |

## Audio Set [Type B (touchscreen)]

| Icon                                                                              | Function                                                                                                       |
|-----------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------|
|  | Displays sound settings to adjust audio quality level.<br>Refer to Volume/Display/Sound Controls on page 5-72. |

### NOTE

- If a file name in the USB memory is too long, it could cause operation problems such as not being able to playback the song.  
(Recommended: Within 80 characters)
- The album art may not display depending on the album art size.
- To move to the desired location on the track, move the slider indicating the playback time.
- The appearance of the repeat and shuffle icons changes depending on the type of operation in which the function is used.

### Category list

Select the  icon to display the following category list.

Select a desired category and item.

| Category            | Function                                                                                                        |
|---------------------|-----------------------------------------------------------------------------------------------------------------|
| Playlist*1          | Displays playlists on the device.                                                                               |
| Artist              | Displays the artist name list.<br>All the tracks or tracks for each album of the selected artist can be played. |
| Album               | Displays the album name list.                                                                                   |
| Song                | All the tracks in the device are displayed.                                                                     |
| Genre               | Displays the genre list.<br>All the tracks or tracks per album or artist in the selected genre can be played.   |
| Audiobook*2         | Displays the audiobook list.<br>Chapters can be selected and played.                                            |
| Podcast*2           | Displays the podcast list.<br>Episode can be selected and played.                                               |
| Apple Music Radio*2 | Displays Apple Music Radio stations.<br>A station can be selected and played.                                   |
| Folder*3            | Displays the folder/file list.                                                                                  |

\*1 Playlist folders of Apple devices are not supported.

\*2 Apple device only

\*3 USB-Sticks and USB-Android™ device only

### Example of use (to play all tracks in USB device)

#### (Method 1)

1. Select  to display the category list.

2. Select **[Song]**.  
All the tracks in the USB device are displayed.
3. Select a desired track.

## Audio Set [Type B (touchscreen)]

---

The selected track is played. All the tracks in the USB device can be played by continuing playback.

**NOTE**

*Only the tracks in the desired category selected in Step 2 are played.*

**(Method 2)\*1**

1. Select  to display the category list.
2. Select .  
All the folders in the USB device are displayed.

3. Select .

All the tracks in the USB device are displayed.

4. Select a desired track.

The selected track is played. All the tracks in the USB device can be played by continuing playback.

- \*1 Can be operated using an Android™ device or USB flash memory.

**NOTE**

*Only the tracks in the desired folder selected in Step 3 are played.*

## Interior Features

### Audio Set [Type B (touchscreen)]

---

#### ▼ Gracenote® Database

When a USB device or Bluetooth® device is connected to this unit and the audio is played, the album name, artist name, genre and title information are automatically displayed if there is a match in the vehicle's database compilation to the music being played. The information stored in this device uses database information in the Gracenote® music recognition service.



*For information related to the most recent Gracenote® database which can be used and how to install it, go to the Mazda Hands Free Website:*

- (Australia)  
[www.mazda.com.au](http://www.mazda.com.au)
- (New Zealand)  
<http://www.mazdahandsfree.com>

#### Introduction

Gracenote, the Gracenote logo and logotype are either a registered trademark or a trademark of Gracenote, Inc. in the United States and/or other countries.



#### Gracenote® End User License Agreement

This application or device contains software from Gracenote, Inc. of Emeryville, California ("Gracenote"). The software from Gracenote (the "Gracenote Software") enables this application to perform disc and/or file identification and obtain music-related information, including name, artist, track, and title information ("Gracenote Data") from online servers or embedded databases (collectively, "Gracenote Servers") and to perform other functions. You may use Gracenote Data only by means of the intended End-User functions of this application or device.



## Audio Set [Type B (touchscreen)]

You agree that you will use Gracenote Data, the Gracenote Software, and Gracenote Servers for your own personal non-commercial use only. You agree not to assign, copy, transfer or transmit the Gracenote Software or any Gracenote Data to any third party. YOU AGREE NOT TO USE OR EXPLOIT GRACENOTE DATA, THE GRACENOTE SOFTWARE, OR GRACENOTE SERVERS, EXCEPT AS EXPRESSLY PERMITTED HEREIN. You agree that your non-exclusive license to use the Gracenote Data, the Gracenote Software, and Gracenote Servers will terminate if you violate these restrictions. If your license terminates, you agree to cease any and all use of the Gracenote Data, the Gracenote Software, and Gracenote Servers. Gracenote reserves all rights in Gracenote Data, the Gracenote Software, and the Gracenote Servers, including all ownership rights. Under no circumstances will Gracenote become liable for any payment to you for any information that you provide. You agree that Gracenote, Inc. may enforce its rights under this Agreement against you directly in its own name.

The Gracenote service uses a unique identifier to track queries for statistical purposes. The purpose of a randomly assigned numeric identifier is to allow the Gracenote service to count queries without knowing anything about who you are. For more information, see the web page for the Gracenote Privacy Policy for the Gracenote service.

The Gracenote Software and each item of Gracenote Data are licensed to you "AS IS." Gracenote makes no representations or warranties, express or implied, regarding the accuracy of any Gracenote Data from in the Gracenote Servers. Gracenote reserves the right to delete data from the Gracenote Servers or to change data categories for any cause that Gracenote deems sufficient. No warranty is made that the Gracenote Software or Gracenote Servers are error-free or that functioning of Gracenote Software or Gracenote Servers will be uninterrupted. Gracenote is not obligated to provide you with new enhanced or additional data types or categories that Gracenote may provide in the future and is free to discontinue its services at any time.

GRACENOTE DISCLAIMS ALL WARRANTIES EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, IMPLIED WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, TITLE, AND NON-INFRINGEMENT. GRACENOTE DOES NOT WARRANT THE RESULTS THAT WILL BE OBTAINED BY YOUR USE OF THE GRACENOTE SOFTWARE OR ANY GRACENOTE SERVER. IN NO CASE WILL GRACENOTE BE LIABLE FOR ANY CONSEQUENTIAL OR INCIDENTAL DAMAGES OR FOR ANY LOST PROFITS OR LOST REVENUES.

© Gracenote, Inc. 2009

### Updating the database

The Gracenote® media database can be updated using USB device.

1. Connect a USB device containing the software for updating Gracenote®.
2. Select the  icon on the home screen to display the Settings screen.
3. Select the **System** tab and select **Music Database Update**.

## Interior Features

### Audio Set [Type B (touchscreen)]

---

4. Select **Search**. The list of the update package stored in the USB device and the version are displayed.
5. Select the package to use the update.
6. Select **Install**.

#### **NOTE**

*Gracenote® can be downloaded from the Mazda Hands-free Website.*

## Audio Set [Type B (touchscreen)]

### How to use Apple CarPlay

#### ▼ What is Apple CarPlay?

Apple CarPlay allows you to make calls, send or receive messages, and listen to music using your iPhone with the vehicle's audio system, or search for destinations using the maps. In addition, voice recognition operation is possible using Siri.

#### CAUTION

➤ YOU EXPRESSLY ACKNOWLEDGE AND AGREE THAT USE OF APPLE CARPLAY ("THE APPLICATION") IS AT YOUR SOLE RISK AND THAT THE ENTIRE RISK AS TO SATISFACTORY QUALITY, PERFORMANCE, ACCURACY AND EFFORT IS WITH YOU TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, AND THAT THE APPLICATION AND INFORMATION ON THE APPLICATION IS PROVIDED "AS IS" AND "AS AVAILABLE", WITH ALL FAULTS AND WITHOUT WARRANTY OF ANY KIND, AND MAZDA HEREBY DISCLAIMS ALL WARRANTIES AND CONDITIONS WITH RESPECT TO THE APPLICATION AND INFORMATION ON THE APPLICATION, EITHER EXPRESS, IMPLIED OR STATUTORY, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES AND/OR CONDITIONS OF MERCHANTABILITY, SATISFACTORY QUALITY, FITNESS FOR A PARTICULAR PURPOSE, ACCURACY, QUIET ENJOYMENT, AND NONINFRINGEMENT OF THIRD PARTY RIGHTS. AS EXAMPLES, AND WITHOUT LIMITATION, MAZDA DISCLAIMS ANY WARRANTY REGARDING THE ACCURACY OF DATA PROVIDED BY THE APPLICATION, SUCH AS THE ACCURACY OF DIRECTIONS, ESTIMATED TRAVEL TIME, SPEED LIMITS, ROAD CONDITIONS, NEWS, WEATHER, TRAFFIC, OR OTHER CONTENT PROVIDED BY APPLE, ITS AFFILIATES, OR THIRD PARTY PROVIDERS; MAZDA DOES NOT GUARANTEE AGAINST LOSS OF APPLICATION DATA, WHICH MAY BE LOST AT ANY TIME; MAZDA DOES NOT GUARANTEE THAT THE APPLICATION OR ANY SERVICES PROVIDED THROUGH THEM WILL BE PROVIDED AT ALL TIMES OR THAT ANY OR ALL SERVICES WILL BE AVAILABLE AT ANY PARTICULAR TIME OR LOCATION. FOR EXAMPLE, SERVICES MAY BE SUSPENDED OR INTERRUPTED WITHOUT NOTICE FOR REPAIR, MAINTENANCE, SECURITY FIXES, UPDATES, ETC., SERVICES MAY BE UNAVAILABLE IN YOUR AREA OR LOCATION, ETC. IN ADDITION, YOU UNDERSTAND THAT CHANGES IN THIRD PARTY TECHNOLOGY OR GOVERNMENT REGULATION MAY RENDER THE SERVICES AND/OR APPLICATIONS OBSOLETE AND/OR UNUSABLE.

TO THE EXTENT NOT PROHIBITED BY LAW, IN NO EVENT SHALL MAZDA OR ITS AFFILIATES BE LIABLE FOR PERSONAL INJURY, OR ANY INCIDENTAL, SPECIAL, INDIRECT OR CONSEQUENTIAL DAMAGES WHATSOEVER, INCLUDING, WITHOUT LIMITATION, DAMAGES FOR LOSS OF PROFITS, CORRUPTION OR LOSS OF DATA, FAILURE TO TRANSMIT OR RECEIVE ANY DATA, BUSINESS INTERRUPTION OR ANY OTHER COMMERCIAL DAMAGES OR LOSSES, ARISING OUT OF OR RELATED TO THE APPLICATION OR YOUR USE OF OR INABILITY TO USE THE APPLICATION OR INFORMATION ON THE APPLICATION.

## Audio Set [Type B (touchscreen)]

➤ When using Apple CarPlay, please avoid distraction and use Apple CarPlay responsibly.  
Stay fully aware of driving conditions and always obey applicable laws.

### NOTE

- Apple CarPlay is provided by Apple and its use is subject to your agreement to the Apple CarPlay terms of use, which are included as part of the Apple iOS terms of use.
- When using Apple CarPlay, location, speed, and other vehicle data is transferred to your iPhone. For further details, refer to Apple's Privacy Policy.

### ▼ Switching to Apple CarPlay

Connect the iPhone by inserting the Apple-genuine connector cord to the USB terminal indicated by the  mark.

Refer to How to connect USB port/Auxiliary jack on page 5-17.

### NOTE


- When you switch your iPhone connection from Bluetooth® to the vehicle's USB terminal, the system switches to Apple CarPlay. The applications which was being used via Bluetooth® connection can be used continuously. However, the available functions of the applications using Bluetooth® connection and those on Apple CarPlay may differ.
- If the iPhone is connected to the USB terminal not indicated by the  mark, the system operates in USB mode.

### Display of Apple CarPlay Screen

Use any of the following methods to display the Apple CarPlay screen in the centre display.

- Select  on the home screen.
- Long press  on the commander switch.
- Select  on the home screen, and select **Apple CarPlay** from the Applications screen.

Apple CarPlay home screen



## Audio Set [Type B (touchscreen)]

### NOTE

The icons and icon positions displayed on the Apple CarPlay home screen may differ depending on the connected iPhone and iOS version.

| No. | Icon                                                                              | Explanation                                                                                                                                        |
|-----|-----------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------|
| ①   | Icon for connected iPhone                                                         | Launches the Apple CarPlay application.<br>Refer to the help information available with each application for the method of using each application. |
| ②   |  | Switches to the Mazda Connect home screen.                                                                                                         |
| ③   |  | Displays the Apple CarPlay home screen.                                                                                                            |

### Convenient Ways to Use Apple CarPlay

| Item                                               | Operation method                                                                                                                                                                                                                                                                                                |
|----------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Activating the voice recognition function (Siri)*1 | Activate Siri using any of the following two methods to operate Apple CarPlay by voice.<br><ul style="list-style-type: none"> <li>• Press the talk button on the audio control switch.</li> <li>• Press and hold .</li> </ul> |
| To display the NowPlaying screen                   | When music is playing in Apple CarPlay and a screen other than the NowPlaying screen is being displayed, press  on the commander switch to display the NowPlaying screen.                                                  |
| To display the MAP screen                          | When using map route guidance in Apple CarPlay and a screen other than the MAP screen is being displayed, press <b>NAV</b> on the commander switch to display the MAP screen.                                                                                                                                   |
| To return to Mazda Connect screen                  | Press and hold  on the commander switch.                                                                                                                                                                                     |

\*1 The voice recognition function of Mazda Connect cannot be used while Apple CarPlay is connected.

### To End Apple CarPlay

To end Apple CarPlay, disconnect the Apple-genuine connector cord from the USB terminal and disconnect the iPhone from the connector cord.

### NOTE

If the connector cord is disconnected from the USB terminal during music playback using Apple CarPlay, the audio source selection will no longer be available and the vehicle's audio device will be muted.

## Audio Set [Type B (touchscreen)]

### How to use Android Auto™ mode

#### ▼ What is Android Auto™?

Android Auto™ is an application which allows the operation of an Android™ Smartphone using the vehicle's audio. Android Auto™ functions such as the phone, messages, music, and map can be used with the vehicle's audio system.

#### CAUTION

➤ YOU EXPRESSLY ACKNOWLEDGE AND AGREE THAT USE OF ANDROID AUTO™ ("THE APPLICATION") IS AT YOUR SOLE RISK AND THAT THE ENTIRE RISK AS TO SATISFACTORY QUALITY, PERFORMANCE, ACCURACY AND EFFORT IS WITH YOU TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, AND THAT THE APPLICATION AND INFORMATION ON THE APPLICATION IS PROVIDED "AS IS" AND "AS AVAILABLE," WITH ALL FAULTS AND WITHOUT WARRANTY OF ANY KIND, AND MAZDA HEREBY DISCLAIMS ALL WARRANTIES AND CONDITIONS WITH RESPECT TO THE APPLICATION AND INFORMATION ON THE APPLICATION, EITHER EXPRESS, IMPLIED OR STATUTORY, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES AND/OR CONDITIONS OF MERCHANTABILITY, SATISFACTORY QUALITY, FITNESS FOR A PARTICULAR PURPOSE, ACCURACY, QUIET ENJOYMENT, AND NONINFRINGEMENT OF THIRD PARTY RIGHTS. AS EXAMPLES, AND WITHOUT LIMITATION, MAZDA DISCLAIMS ANY WARRANTY REGARDING THE ACCURACY OF DATA PROVIDED BY THE APPLICATION, SUCH AS THE ACCURACY OF DIRECTIONS, ESTIMATED TRAVEL TIME, SPEED LIMITS, ROAD CONDITIONS, NEWS, WEATHER, TRAFFIC, OR OTHER CONTENT PROVIDED BY GOOGLE, ITS AFFILIATES, OR THIRD PARTY PROVIDERS; MAZDA DOES NOT GUARANTEE AGAINST LOSS OF APPLICATION DATA, WHICH MAY BE LOST AT ANY TIME; MAZDA DOES NOT GUARANTEE THAT THE APPLICATION OR ANY SERVICES PROVIDED THROUGH THEM WILL BE PROVIDED AT ALL TIMES OR THAT ANY OR ALL SERVICES WILL BE AVAILABLE AT ANY PARTICULAR TIME OR LOCATION. FOR EXAMPLE, SERVICES MAY BE SUSPENDED OR INTERRUPTED WITHOUT NOTICE FOR REPAIR, MAINTENANCE, SECURITY FIXES, UPDATES, ETC., SERVICES MAY BE UNAVAILABLE IN YOUR AREA OR LOCATION, ETC. IN ADDITION, YOU UNDERSTAND THAT CHANGES IN THIRD PARTY TECHNOLOGY OR GOVERNMENT REGULATION MAY RENDER THE SERVICES AND/OR APPLICATIONS OBSOLETE AND/OR UNUSABLE.

TO THE EXTENT NOT PROHIBITED BY LAW, IN NO EVENT SHALL MAZDA OR ITS AFFILIATES BE LIABLE FOR PERSONAL INJURY, OR ANY INCIDENTAL, SPECIAL, INDIRECT OR CONSEQUENTIAL DAMAGES WHATSOEVER, INCLUDING, WITHOUT LIMITATION, DAMAGES FOR LOSS OF PROFITS, CORRUPTION OR LOSS OF DATA, FAILURE TO TRANSMIT OR RECEIVE ANY DATA, BUSINESS INTERRUPTION OR ANY OTHER COMMERCIAL DAMAGES OR LOSSES, ARISING OUT OF OR RELATED TO THE APPLICATION OR YOUR USE OF OR INABILITY TO USE THE APPLICATION OR INFORMATION ON THE APPLICATION.

## Audio Set [Type B (touchscreen)]

- *When using Android Auto™, please avoid distraction and use Android Auto™ responsibly. Stay fully aware of driving conditions and always obey applicable laws.*

### NOTE

- *Android Auto™ is provided by Google and its use is subject to your agreement to the Android Auto™ terms of use.*
- *When using Android Auto™, location, speed, and other vehicle data is transferred to your smart phone. For further details, refer to Google's Privacy Policy.*

### ▼ How to use the Android Auto™ mode

Insert an Android™ Smartphone-genuine connector cord into the USB terminal indicated by the  icon to connect the Smartphone.

Refer to How to connect USB port/Auxiliary jack on page 5-17.

### NOTE


- *When an Android™ Smartphone connected to Bluetooth® is connected to the vehicle's USB terminal, Bluetooth® is used by Android Auto™ and the system switches to Android Auto™ mode.*
- *If the Android™ Smartphone is connected to a USB terminal with no  icon indicated, the system operates in USB mode.*

### Display of Android Auto™ Mode Screen

Use any of the following methods to display the Android Auto™ mode screen in the centre display.

- Select  on the home screen, and select **Android Auto** from the Applications screen.
- Select  on the home screen.
- Press and hold  on the commander switch.

Android Auto™ mode home screen



## Audio Set [Type B (touchscreen)]

### NOTE

The media displayed on the Android Auto™ home screen may differ depending on the use conditions and version of the connected Android™ Smartphone.

| No. | Icon                                                                              | Explanation                                                                                                                                    |
|-----|-----------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------|
| ①   | —                                                                                 | Displays the use history of each application. The displayed contents differ depending on the application that has been started and its status. |
| ②   |  | Switches to the map application.                                                                                                               |
| ③   |  | Switches to the call mode.                                                                                                                     |
| ④   |  | Displays the Android Auto™ home screen.                                                                                                        |
| ⑤   |  | Switches to the Music application.                                                                                                             |
| ⑥   |  | Switches to the Mazda Connect home screen.                                                                                                     |

### Convenient ways to use Android Auto™ mode

| Item                                  | Operation method                                                                                                                                                                                                                                                                                                                                                                                                             |
|---------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Operation using voice recognition*1   | Any of the following methods can be used to start the voice recognition mode and operate Android Auto™ by voice. <ul style="list-style-type: none"> <li>• Speak the words, “OK Google”.</li> <li>• Select the  icon on the Android Auto™ screen.</li> <li>• Press and hold the talk button on the audio remote control switch.</li> </ul> |
| To display the NowPlaying screen      | When music is playing in Android Auto™ and a screen other than the NowPlaying screen is being displayed, press  on the commander switch to display the NowPlaying screen.                                                                                                                                                               |
| To display the MAP screen             | When using map route guidance in Android Auto™ and a screen other than the MAP screen is being displayed, press <b>NAV</b> on the commander switch to display the Android Auto™ MAP screen.                                                                                                                                                                                                                                  |
| To return to the Mazda Connect screen | Press and hold  on the commander switch.                                                                                                                                                                                                                                                                                                  |

\*1 The voice recognition function of Mazda Connect cannot be used while Android Auto™ is connected.

### To end Android Auto™


To end the Android Auto™ mode, disconnect the Android™-genuine connector cord from the USB terminal or disconnect the Android™ Smartphone from the connector cord.



## Audio Set [Type B (touchscreen)]

### If Android Auto™ cannot be connected

When the message, “Mobile Device Error”, is displayed and Android Auto™ cannot be connected



Make sure that the Android™ Smartphone in question is compatible with Android Auto™. Before trying to reconnect your Android™ Smartphone to the connector cord, do the Bluetooth® device pairing again.

### **If the Android Auto™ do not operate, please do these steps**

Depending on your Android™ Smartphone, the connection setting may have been in charging mode only when the connector cord is connected.

In this case, switch off the Android Auto™ connection setting once, and then switch it back on while connected to USB mode.

The connection setting can be changed to the Android Auto™ connection in the **Devices** tab on the Settings screen (page 5-122).

## Audio Set [Type B (touchscreen)]

### Bluetooth®

#### ▼ Introduction

##### **Bluetooth® Hands-Free outline**

When a Bluetooth® device (mobile phone) is connected to the vehicle's Bluetooth® unit via radio wave transmission, a call can be made or received by pressing the talk button, pick-up button, or hang-up button on the audio remote control switch, or by operating the centre display.

##### **Bluetooth® audio outline**

When a portable audio unit equipped with the Bluetooth® communication function is paired to the vehicle, you can listen to music stored on the paired portable audio device from the vehicle's speakers. It is not necessary to connect the portable audio device to the vehicle's external input terminal. After programming, operate the vehicle audio control panel to play/stop the audio.

#### **NOTE**

- *For your safety, a device can be paired only when the vehicle is parked. If the vehicle starts to move, the pairing procedure will end. Park the vehicle in a safe place before pairing.*
- *The communication range of a Bluetooth® equipped device is about 10 meters (32 ft) or less.*
- *Basic audio operation is available using voice commands even if Bluetooth® is not connected.*
- *For safety reasons, operation of the centre display is disabled while the vehicle is being driven. However, items not displayed in grey can be operated using the commander switch while the vehicle is being driven.*



Some Bluetooth® mobile devices are not compatible with the vehicle. Consult an expert repairer (we recommend an Authorised Mazda Repairer), Mazda's call centre or Web support centre for information regarding Bluetooth® mobile device compatibility:

#### ➤ Australia

Phone: 1800-352-703 during business hours (10am—4pm Eastern Standard Time)

Web: [www.mazda.com.au](http://www.mazda.com.au)

## Audio Set [Type B (touchscreen)]

➤ New Zealand


Web: [www.mazdahandsfree.co.nz](http://www.mazdahandsfree.co.nz)

### Applicable Bluetooth® specification (Recommended)


Ver. 1.1/1.2/2.0 + EDR/2.1 + EDR/3.0 (conformity)

### ▼ Component Parts


#### Audio unit



#### Talk button, Pick-up button and Hang-up button



#### Microphone



### Microphone (hands-free)

The microphone is used for speaking voice commands or when making a Hands-free call.

### Talk button

Activates the voice recognition. In addition, it skips the voice guidance.

### Pick-up button

Responds to incoming calls. In addition, after selecting a contact or dialing a number, it places the call when the button is pressed.

## Audio Set [Type B (touchscreen)]

---

### Hang-up button

Ends the call or refuses an incoming call. In addition, it ends the voice recognition operation.

### Commander switch

The commander switch is used for volume adjustment and display operation. Tilt or turn the commander knob to move the cursor. Press the commander knob to select the icon.

### Volume adjustment

The volume dial of the commander switch is used to adjust the volume. Turn the dial to the right to increase volume, to the left to decrease it.

The volume can also be adjusted using the volume button on the steering wheel.

### **NOTE**

- Press the volume dial to switch the audio MUTE on and off.
- If the volume is lower compared to other audio modes, increase the volume from the device side.

Conversation volume and the volume of the voice guidance and ringtone can each be set in advance.

1. Select the  icon on the home screen to display the Communication screen.
2. Select **Settings**.
3. Adjust the **Phone Volume** and the **VR and Ringtone** using the slider.

## Audio Set [Type B (touchscreen)]

### Bluetooth® Preparation

#### ▼ Device pairing

To use Bluetooth® audio and Hands-Free, the device equipped with Bluetooth® has to be paired to the unit using the following procedure. A maximum of 7 devices including Bluetooth® audio devices and hands-free mobile phones can be paired.

#### NOTE

- The Bluetooth® system may not operate for 1 or 2 minutes after the ignition is switched to ACC or ON. However, this does not indicate a problem. If the Bluetooth® system does not connect automatically after 1 or 2 minutes have elapsed, make sure that the Bluetooth® setting on the device is normal and attempt to reconnect the Bluetooth® device from the vehicle side.
- If Bluetooth®-enabled devices are used in the following locations or conditions, connection via Bluetooth® may not be possible.
  - The device is in a location hidden from the centre display such as behind or under a seat, or inside the glove compartment.
  - The device contacts or is covered by a metal object or body.
  - The device is set to power-saving mode.

#### Pairing Procedure

1. Select the  icon on the home screen to display the Settings screen.
2. Select the **Devices** tab.
3. Select **Bluetooth**.

4. Turn the Bluetooth® setting on.
5. Select **Add New Device** to display the message and switch to the device operation.
6. Using your device, perform a search for the Bluetooth® device (Peripheral device).
7. Select “Mazda” from the device list searched by the device.
8. **(Device with Bluetooth® version 2.0)**  
Input the displayed 4-digit pairing code into the device.

#### **(Device with Bluetooth® version 2.1 or higher)**

Make sure the displayed 6-digit code on the audio is also displayed on the device, and touch the **Yes**.

Connection permission and phonebook access permission for your mobile device may be required depending on the mobile device.

9. If pairing is successful, the functions of the device connected to Bluetooth® are displayed.
10. **(Devices compatible with Mazda E-mail / SMS function)**  
SMS (Short Message Service) messages, and E-mail for the device are downloaded automatically. A download permission operation for your device may be required depending on the device.

#### NOTE

- When Call history and messages are downloaded automatically, each automatic download setting must be on. Refer to Communication Settings on page 5-118.

## Audio Set [Type B (touchscreen)]

After a device is registered, the system automatically identifies the device. By activating Bluetooth® Hands-Free again, or by activating Bluetooth® Hands-Free first after switching the ignition from OFF to ACC, the device connection condition is indicated in the centre display.

### IMPORTANT note about pairing and automatic reconnection:

- If pairing is redone on the same mobile phone device, first clear “Mazda” displayed on the Bluetooth® setting screen of the mobile device.
- When the OS of the device is updated, the pairing information may be deleted. If this happens, reprogramme the pairing information to the Bluetooth® unit.
- Before you pair your device, make sure that Bluetooth® is “ON”, both on your phone and on the vehicle.

### ▼ Device selection

If several devices have been paired, the Bluetooth® unit links the device last paired. If you would like to link a different paired device, it is necessary to change the link. The order of device priority after the link has been changed is maintained even when the ignition is switched off.

### Connecting other devices

1. Select the  icon on the home screen to display the Settings screen.
2. Select the **Devices** tab.
3. Select **Bluetooth**.
4. Turn the Bluetooth® setting on.
5. Select the name of the device you would like to connect.

### 6. **Telephone And Audio** selection

Connects both devices as hands-free and Bluetooth® audio.

#### **Telephone Only** selection

Connects as a hands-free device.

#### **Audio Only** selection

Connects as Bluetooth® audio.

### NOTE

- The following functions can be used for the Hands-free or audio.
- Hands-free: Phone calls and E-mail/SMS
- Audio: Bluetooth® audio, Aha™, Stitcher™ radio

### Disconnecting a device

1. Select the  icon on the home screen to display the Settings screen.
2. Select the **Devices** tab.
3. Select **Bluetooth**.
4. Turn the Bluetooth® setting on.
5. Select the device name which is currently connected.
6. Select **Disconnect**.

### ▼ Deleting a device

### Selecting and deleting devices

1. Select the  icon on the home screen to display the Settings screen.
2. Select the **Devices** tab.
3. Select **Bluetooth**.
4. Turn the Bluetooth® setting on.
5. Select the device name which you would like to delete.
6. Select **Remove Paired Device**.
7. Select **Yes**.

## Audio Set [Type B (touchscreen)]

### Deleting all devices

1. Select the  icon on the home screen to display the Settings screen.
2. Select the **Devices** tab.
3. Select **Bluetooth**.
4. Select **Bluetooth Settings**.
5. Select **Remove All Paired Devices**.
6. Select **Yes**.

### ▼ Changing PIN code

PIN code (4 digits) can be changed.

1. Select the  icon on the home screen to display the Settings screen.
2. Select the **Devices** tab.
3. Select **Bluetooth**.
4. Select **Bluetooth Settings**.
5. Select **Change Paircode**.
6. Input the new PIN code to be set.
7. Select .

### Available Language

The language can be changed.  
Refer to Settings on page 5-122.

#### **NOTE**

*Depending on the language, it may only be available for the screen display, but not for the voice recognition.*

## Audio Set [Type B (touchscreen)]

### Bluetooth® Audio

#### Applicable Bluetooth® specification (Recommended)

Ver. 1.1/1.2/2.0 + EDR/2.1 + EDR/3.0  
(conformity)

#### Response profile

- A2DP (Advanced Audio Distribution Profile) Ver. 1.0/1.2
- AVRCP (Audio/Video Remote Control Profile) Ver. 1.0/1.3/1.4

A2DP is a profile which transmits only audio to the Bluetooth® unit. If your Bluetooth® audio device corresponds only to A2DP, but not AVRCP, you cannot operate it using the control panel of the vehicle's audio system. In this case, only the operations on the mobile device are available the same as when a portable audio device for a non-compliant Bluetooth® device is connected to the AUX terminal.

| Function             | A2DP | AVRCP    |                                |                                |
|----------------------|------|----------|--------------------------------|--------------------------------|
|                      |      | Ver. 1.0 | Ver. 1.3                       | Ver. 1.4                       |
| Playback             | X    | X        | X                              | X                              |
| Pause                | X    | X        | X                              | X                              |
| File (Track) up/down | —    | X        | X                              | X                              |
| Reverse              | —    | —        | X                              | X                              |
| Fast-forward         | —    | —        | X                              | X                              |
| Text display         | —    | —        | X                              | X                              |
| Repeat               | —    | —        | De-<br>pends<br>on de-<br>vice | De-<br>pends<br>on de-<br>vice |

| Function           | A2DP | AVRCP    |                                |                                |
|--------------------|------|----------|--------------------------------|--------------------------------|
|                    |      | Ver. 1.0 | Ver. 1.3                       | Ver. 1.4                       |
| Shuffle            | —    | —        | De-<br>pends<br>on de-<br>vice | De-<br>pends<br>on de-<br>vice |
| Scan               | —    | —        | De-<br>pends<br>on de-<br>vice | De-<br>pends<br>on de-<br>vice |
| Folder up/<br>down | —    | —        | —                              | De-<br>pends<br>on de-<br>vice |

X: Available

—: Not available

#### NOTE

- The battery consumption of Bluetooth® audio devices increases while Bluetooth® is connected.
- If a general mobile phone device is USB connected during music playback over the Bluetooth® connection, the Bluetooth® connection is disconnected. For this reason, you cannot have music playback over a Bluetooth® connection and music playback using a USB connection at the same time.
- If a device which supports AVRCP Ver. 1.6 or higher is connected, song information may not display correctly.
- The system may not operate normally depending on the Bluetooth® audio device.



## Audio Set [Type B (touchscreen)]

### ▼ Switching to Bluetooth® audio mode

To listen to music or voice audio recorded to a Bluetooth® audio device, switch to the Bluetooth® audio mode to operate the audio device using the audio system control panel. Any Bluetooth® audio device must be paired to the vehicle's Bluetooth® unit before it can be used.

Refer to Bluetooth® Preparation (Type B) on page 5-99.

1. Turn on the Bluetooth® audio device's power.
2. Switch the ignition to ACC or ON.
3. Select the  icon on the home screen to display the Entertainment screen.
4. When **Bluetooth** is selected, switches to the Bluetooth® audio mode to begin playback.

#### NOTE

- If the Applications screen is not displayed on the device, Bluetooth® audio may not play on the centre display.
- If Bluetooth® audio is used after using Aha™ or Stitcher™ radio, the application on the mobile device has to be closed first.
- If the Bluetooth® audio device does not begin playback, select the  icon.
- If the mode is switched from Bluetooth® audio mode to another mode (radio mode), audio playback from the Bluetooth® audio device stops.

### ▼ Playback

To listen to a Bluetooth® audio device over the vehicle's speaker system, switch the mode to Bluetooth® audio mode. (Refer to “Switching to Bluetooth® audio mode”)

After switching to the Bluetooth® audio mode, the following icons are displayed in the lower part of the display. Icons which can be used differ depending on the version of the Bluetooth® audio device which you are currently using.

| Icon                                                                                | Function                                                                                                                                                                                                                                                    |
|-------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|  | Displays the Entertainment menu. Use to switch to a different audio source.                                                                                                                                                                                 |
|  | (AVRCP Ver. 1.4 only)<br>Displays the top level folder/file list.<br>Select the folder which you want to select.<br>The files in the selected folder are displayed.<br>Select the file you want to play.                                                    |
|  | (AVRCP Ver. 1.3 or higher)<br>Replays the song currently being played repeatedly.<br>When selected again, the songs in the folder are played repeatedly.<br>Select it again to cancel.<br>Icons change when the song is repeated or the folder is repeated. |

## Audio Set [Type B (touchscreen)]

| Icon                                                                               | Function                                                                                                                                                                                                                                                                          |
|------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|   | (AVRCP Ver. 1.3 or higher)<br>Plays songs in the folder in random order.<br>When selected again, the songs on the device are played in random order.<br>Select it again to cancel.<br>Icons change during folder shuffle or device shuffle.                                       |
|   | Scans the titles in a folder and plays the beginning of each song to aid in finding a desired song.<br>When selected again, the beginning of each song on the device is played.<br>When selected again, the operation is cancelled and the song currently being played continues. |
|   | Returns to the beginning of the previous song.<br>Long-press to fast reverse. It stops when you remove your hand from the icon or the commander knob.                                                                                                                             |
|   | Plays the Bluetooth® audio. When selected again, playback is temporarily stopped.                                                                                                                                                                                                 |
|   | Advances to the beginning of the next song.<br>Long-press to fast forward. It stops when you remove your hand from the icon or the commander knob.                                                                                                                                |
|  | Displays sound settings to adjust audio quality level.<br>Refer to Volume/Display/Sound Controls on page 5-72.                                                                                                                                                                    |

### ▼ Bluetooth® Audio Device Information Display

When connecting a Bluetooth® audio device, the unit searches the following information from the database stored in the vehicle and it is displayed on the screen. The database information stored in this device uses database information in the Gracenote® music recognitions service.

|                                    | AVRCP Ver. lower than 1.3 | AVRCP Ver. 1.3 | AVRCP Ver. 1.4 or higher |
|------------------------------------|---------------------------|----------------|--------------------------|
| Device name                        | X                         | X              | X                        |
| Remaining battery charge of device | X                         | X              | X                        |
| Song name                          | —                         | X              | X                        |
| Artist name                        | —                         | X              | X                        |
| Album name                         | —                         | X              | X                        |

|                 | AVRCP Ver. lower than 1.3 | AVRCP Ver. 1.3 | AVRCP Ver. 1.4 or higher |
|-----------------|---------------------------|----------------|--------------------------|
| Playback time   | —                         | X              | X                        |
| Genre name      | —                         | X              | X                        |
| Album art image | —                         | X              | X                        |

X: Available

—: Not available

#### NOTE

*Some information may not display depending on the device, and if the information cannot be displayed, "Unknown - - -" is indicated.*

Refer to Gracenote® Database on page 5-86 for the method of updating the database.

## Audio Set [Type B (touchscreen)]

### How to Use Aha™

#### ▼ What is Aha™?

Aha™\*1 is an application which can be used to enjoy various Internet content such as Internet radio and podcasts.

Stay connected to your friends activities by getting updates from Facebook and Twitter. Using the location-based service, nearby services and destinations can be searched or real-time local information can be obtained.

For details on Aha™, refer to “<http://www.aharadio.com/>”.

\*1 Aha™, the Aha™ logo, and the Aha™ trade dress are trademarks or registered trademarks of Harman International Industries, Inc., used with permission.

#### NOTE

- The service content provided by Aha™ varies depending on the country in which the user resides. In addition, the service is not available in some countries.
- To operate Aha™ from your Bluetooth® device, perform the following in advance:
  - Install the Aha™ application to your device.
  - Create an Aha™ account for your device.
  - Log onto Aha™ using your device.
  - Select the preset station on your device.
- If the Applications screen is not displayed on the device, Aha™ may not play on the centre display.

#### ▼ Playback

Select the  icon on the home screen to display the Entertainment screen. When **aha** is selected, the following icons are displayed at the bottom of the centre display. The displayed icon differs depending on the selected station.

In addition, icons other than the following icons may be displayed.

| Icon                                                                                | Function                                                                             |
|-------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------|
|  | Displays the Entertainment menu. Use to switch to a different audio source.          |
|  | Displays the main menu.<br>Use to switch to other stations.                          |
|  | Displays the content list.<br>Use to switch to other desired content on the station. |
|  | <b>Like</b> *1<br>Evaluates the current content as “Like”.                           |

## Interior Features


### Audio Set [Type B (touchscreen)]

| Icon | Function                                                                                                                                                              |
|------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | <b>Dislike*1</b><br>Evaluates the current content as “Dislike”.                                                                                                       |
|      | Reverses for 15 seconds.                                                                                                                                              |
|      | <b>Map (vehicles with navigation system)</b><br>Displays the destination searched by the location based services on the navigation system.                            |
|      | <b>Call</b><br>A call can be made to the telephone number of a shop searched using the Location Based Services. Available when a device is connected as a Hands-Free. |
|      | Returns to the previous content.                                                                                                                                      |
|      | Pauses playback of the content. When selected again, playback resumes.                                                                                                |
|      | Goes to the next content.                                                                                                                                             |
|      | Fast-forwards for 30 seconds.                                                                                                                                         |
|      | Displays sound settings to adjust audio quality level.<br>Refer to Volume/Display/Sound Controls on page 5-72.                                                        |

\*1 Some stations may use alternate variations of Like and Dislike, based on station type or provider.

### Main menu

Select the icon.



Switch the tab and select the station category.

| Tab     | Function                                                                                                           |
|---------|--------------------------------------------------------------------------------------------------------------------|
| Presets | Displays the preset station list set on the device.<br>Select the preset station name to play the station content. |

## Audio Set [Type B (touchscreen)]

| Tab    | Function                                                                                                                                                                                                                    |
|--------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Nearby | <p>Select the desired station.</p> <p>Guidance is provided to the searched destination near the vehicle's position.</p> <p>You can designate desired categories previously set using the filter setting on your device.</p> |

### NOTE

The available Location Based Services may differ because the services depend on the content provided by Aha™.


### Example of use (Location Based Services)

1. Select the desired station from the “Nearby” tab on the main menu.  
The destination name or address playback starts in the order of the destination name list.



2. When the  icon is selected, the currently displayed destination is displayed on the navigation system (vehicles with navigation system).
3. When the  icon is selected, a phone call is placed to the currently displayed destination.

4. Select the  icon to display the content list.  
Selection of other destinations from the list can be made.



## Audio Set [Type B (touchscreen)]

### How to Use Stitcher™ Radio

#### ▼ What is Stitcher™ Radio?

Stitcher™\*1 radio is an application which can be used to listen to Internet radio or stream podcasts.

Recommended content is automatically selected by registering content which you put into your favourites, or by pressing the Like or Dislike button.

For details on Stitcher™ Radio, refer to “<http://stitcher.com/>”.

\*1 Stitcher™, the Stitcher™ logo, and the Stitcher™ trade dress are trademarks or registered trademarks of Stitcher, Inc., used with permission.

#### NOTE

- To operate Stitcher™ Radio from your Bluetooth® device, perform the following in advance:
  - Install the Stitcher™ Radio application to your device.
  - Create a Stitcher™ Radio account for your device.
  - Log onto Stitcher™ Radio using your device.
- If the Applications screen is not displayed on the device, Stitcher™ may not play on the centre display.

#### ▼ Playback

Select the  icon on the home screen to display the Entertainment screen. When **Stitcher** is selected, the following icons are indicated in the bottom part of the centre display.


| Icon                                                                                | Function                                                                                         |
|-------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------|
|  | Displays the Entertainment menu. Use to switch to a different audio source.                      |
|  | Displays the station list.<br>Use to switch to other stations.                                   |
|  | <b>Dislike</b><br>Evaluates the current programme as “Dislike”.                                  |
|  | <b>Like</b><br>Evaluates the current programme as “Like”.                                        |
|  | Adds the current station to your favourites or deletes the current station from your favourites. |
|  | Reverses for 30 seconds.                                                                         |

## Audio Set [Type B (touchscreen)]

| Icon                                                                              | Function                                                                                                       |
|-----------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------|
|  | Plays the station. Select it again to pause playback.                                                          |
|  | Goes to the next station.                                                                                      |
|  | Displays sound settings to adjust audio quality level.<br>Refer to Volume/Display/Sound Controls on page 5-72. |

### Station list

- Select the  icon to display the station list.
  - Favourites station name: Select to display the programme registered to your favourites.
  - Category name: A recommended category selected from your favourites by Stitcher™ is displayed.  
Select it to display the category programme.



- Select the programme name to play it.

### Add to your favourites

If the current programme has not been registered to your favourites, it can be registered to your favourites.

- Select the ★ icon to display the favourites station which the registration can be added.
- Select the station name which you want to register.
- Select **[OK]** to add the programme to the selected favourites station.

### NOTE

- Multiple favourites stations can be selected and registered.
- Favourites stations registered by oneself as well those set by default are displayed.

### Delete from your favourites

If the current programme has already been registered to your favourites, the programme can be deleted from your favourites.

- Select the ★ icon.

## Audio Set [Type B (touchscreen)]

---

2. The programme is automatically deleted from the favourites station.

### Bluetooth® Hands-Free

#### ▼ Making a Call

For Mazda Connect, making calls is possible using any of the following 6 methods:

- Phonebook downloaded from Bluetooth® device (mobile phone) (voice recognition function can be used)
- Favourites
- Call record
- Dialing a telephone number (voice recognition function can be used)
- “Redial” - Voice recognition command for making a call to the latest outgoing call record.
- “Call back” - Voice recognition command for making a call to the latest incoming call record.

#### Phonebook Usage

Telephone calls can be made by saying the contact name in the downloaded phonebook or the name of a person whose phone number has been registered in the Bluetooth® Hands-Free. Refer to Import contact (Download Phonebook).

1. Press the talk button.
2. Wait for the beep sound.
3. **Say:** “Call XXXXX... (Ex. “John”) Mobile”. (You can also say, “Home”, “Work”, or “Other” instead of “Mobile”, depending on how you set up your contact information.)
4. Follow the voice guidance to make the call, or simple press the pick-up button on the steering switch during or after the guidance to make the call.



## Audio Set [Type B (touchscreen)]

### Screen operation

1. Select the  icon on the home screen to display the Communication screen.
2. Select **Contacts** to display the contact list.
3. Select the contact you would like to call to display the details for the contact.
4. Select the desired phone number to make the call.

### Import contact (Download Phonebook)

Phonebook data from your device (Mobile phone) can be sent and registered to your Bluetooth® Hands-Free phonebook using Bluetooth®.

#### (Automatic downloading)

The “Auto Download Contacts” setting must be on. When hands-free is connected to the device, the phonebook is downloaded automatically.

Refer to Communication Settings on page 5-118.

#### (Manually downloading)

If the “Auto Download Contacts” setting is off, download the phonebook using the following procedure.

1. Select the  icon on the home screen to display the Communication screen.
2. Select **Contacts** to display the contact list.
3. Select **Edit Contacts**.
4. Select **Import All Contacts** or **Import Selected Contact** to switch to the device operation.
5. If **Import All Contacts** is selected, select **Download**.

6. Download will be started from the mobile phone.

### NOTE

- If “Import All Contacts” is performed after saving the phonebook to the Bluetooth® unit, the phonebook will be overwritten.
- A maximum of 1,000 contacts can be registered to the phonebook.
- Phonebook, incoming/outgoing call record, and favourite memories are exclusive to each mobile phone to protect privacy.
- Contacts with no telephone number are not registered.

### Favourites Contacts

A maximum of 50 contacts can be registered. It will take less time to make a call after registering the telephone number. In addition, you do not have to look for the person you want to call in the phonebook.

### Registering to your favourites

1. Select the  icon on the home screen to display the Communication screen.
2. Select **Favourites** to display the favourites list.
3. Select **Add/Edit Communication Favourites**.
4. Select **Add New Contact** or **Add New Contact Details**.
5. Select from the displayed list.

### NOTE

When “Add New Contact” is selected, information such as the selected person’s name is also registered. In addition, when “Add New Contact Details” is selected, only the telephone number of the selected person is registered.

## Audio Set [Type B (touchscreen)]

### Calling a favourite

1. Select the  icon on the home screen to display the Communication screen.
2. Select **Favourites** to display the favourites list.
3. **(If only one phone number is registered to contact)**  
Select the contact information you would like to call. Go to Step 5.  
**(If multiple phone numbers are registered to contact)**  
Select the contact you would like to call to display the screen indicating the details for the contact. Go to Step 4.
4. Select the phone number you would like to call.
5. Select **Yes**.

### Deleting a favourite

1. Select the  icon on the home screen to display the Communication screen.
2. Select **Favourites** to display the favourites list.
3. Select **Add/Edit Communication Favourites**.
4. Select **Delete**.
5. Select the contact information which you would like to delete.
6. Select **Delete**.

### Changing the display order of your favourites list

1. Select the  icon on the home screen to display the Communication screen.
2. Select **Favourites** to display the favourites list.
3. Select **Add/Edit Communication Favourites**.
4. Select **Move**.
5. The contact can be moved after it is selected.

6. Slide the contact or move it using the commander switch, then select **OK**.

### Changing contact name of your favourites

1. Select the  icon on the home screen to display the Communication screen.
2. Select **Favourites** to display the favourites list.
3. Select **Add/Edit Communication Favourites**.
4. Select **Rename**.
5. Select the contact to display the keyboard screen.
6. If a new name is input and **OK** is selected, the contact name is stored.

#### NOTE

*If the contact is long-pressed when the favourites list is displayed, the contact information can be edited (deleted, moved).*

### Telephone Number Input

#### NOTE

*Practice this while parked until you are confident you can do it while driving in a non-taxing road situation. If you are not completely comfortable, make all calls from a safe parking position, and only start driving when you can devote your full attention to driving.*

1. Select the  icon on the home screen to display the Communication screen.
2. When **Dial Phone** is pressed, the dial pad is displayed.
3. Input the telephone number using the dial pad.
4. Select  to make the call.

## Audio Set [Type B (touchscreen)]

---

### Numeral or symbol entry

Use the dial pad.

Long-press the to input +.

Select to delete the currently input value.

Long-press to delete all input values.

### Redial Function

Makes a call to the last person called (latest person on outgoing call record) from the mobile phone/vehicle.

1. Press the talk button.
2. Wait for the beep sound.
3. **Say:** “Redial”

### Call back Function

Makes a call to the last person who called your (latest person on incoming call record) mobile phone/vehicle.

1. Press the talk button.
2. Wait for the beep sound.
3. **Say:** “Call back”

## Audio Set [Type B (touchscreen)]

### ▼ Receiving an Incoming Call

When an incoming call is received, the incoming call notification screen is displayed. The “Incoming Call Notifications” setting must be on.

Refer to Communication Settings on page 5-118.

To accept the call, press the pick-up button on the audio control switch or select **Answer** on the screen.

To reject the call, press the hang-up button on the audio control switch or select **Ignore** on the screen.

The following icons are displayed on the screen during a call. Icons which can be used differ depending on use conditions.

| Icon                                                                                | Function                                                                                                                                                                                                                                                                                                   |
|-------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|    | Displays the Communication menu.                                                                                                                                                                                                                                                                           |
|    | Ends the call.                                                                                                                                                                                                                                                                                             |
|    | <b>Transferring a call from hands-free to a mobile phone</b><br>Communication between the Bluetooth® unit and a device (mobile phone) is cancelled, and an incoming call will be received by the device (mobile phone) like a standard call.                                                               |
|  | <b>Transferring a call from a device (mobile phone) to hands-free</b><br>Communication between devices (mobile phone) can be switched to Bluetooth® Hands-Free.                                                                                                                                            |
|  | <b>Mute</b><br>The microphone can be muted during a call.<br>When selected again, the mute is cancelled.                                                                                                                                                                                                   |
|  | To make a 3-way call, select the contacts from the following:<br><b>Call History</b> : Call History is displayed.<br><b>Contacts</b> : The phonebook is displayed.<br><b>Dial</b> : The dial pad is displayed. Input the phone number.<br>The device may be unusable depending on the contractual content. |
|  | The call on hold is made to make a 3-way call.<br>The device may be unusable depending on the contractual content.                                                                                                                                                                                         |
|  | Switches the call on hold.                                                                                                                                                                                                                                                                                 |
|  | <b>DTMF (Dual Tone Multi-Frequency Signal) Transmission</b><br>This function is used when transmitting DTMF via the dial pad. The receiver of a DTMF transmission is generally a home telephone answering machine or a company's automated guidance call centre.<br>Input the number using a dial pad.     |

## Audio Set [Type B (touchscreen)]

### NOTE

- If the ignition is switched off during a hands-free call, the line is transferred to the device (Mobile phone) automatically.
- If the DTMF code has two or more digits or symbols, each one must be transmitted individually.

### ▼ Call Interrupt

A call can be interrupted to receive an incoming call from a third party.

When **Hold + Answer** is selected or the pick-up button on the steering wheel is pressed, the current call is held and the system switches to the new incoming call.

When **End + Answer** is selected, the current call is ended and the system switches to the new incoming call (GSM network only).

When **Ignore** is selected or the hang-up button on the steering wheel is pressed, an incoming call is refused.

### NOTE

- The function may not be available depending on the contractual content of the mobile device.
- The function may not be operable depending on the type of the telephone network and the mobile device.

### ▼ Receiving and Replying to Messages (available only with E-mail/SMS compatible phones)

SMS (Short Message Service) messages, and E-mail received by connected devices can be downloaded, displayed, and played (read by the system).

Additionally, replies can also be made to calls and messages in the received messages.

### Downloading messages

Up to 20 new messages can be downloaded and displayed from a connected device.

### NOTE

For E-mail, 20 messages for each account can be downloaded.

### (Automatic downloading)

The “Auto Download Email” (E-mail) or “Auto Download SMS” (SMS) setting must be on. A message is downloaded automatically when the Bluetooth® unit is connected to the device.

Refer to Communication Settings on page 5-118.

### (Manually downloading)

When the “Auto Download Email” (E-mail) or “Auto Download SMS” (SMS) setting is off, the message is downloaded using the following procedure.

1. Select the  icon on the home screen to display the Communication screen.
2. Select **Email** or **SMS** to display the Inbox.
3. Select **Update Inbox**.
4. Download will be started from the mobile phone.

### NOTE

- Attached data is not downloaded.
- Messages up to 1 kilobyte (E-mail)/ 140-bytes (SMS) can be downloaded.
- A message list is created for each device.

## Audio Set [Type B (touchscreen)]

- If the connected device does not correspond to MAP 1.0, the AT command is used to download. The downloaded message indicates that it is already read.
- Downloading using the AT command may not function depending on the connected device.
- If an iPhone is connected, the following functions cannot be used.

- Downloading past messages
- Replying to messages

\*iPhone is a trademark of Apple Inc., registered in the U.S. and other countries.

### Receiving messages

#### (Method 1)

When a device receives a message, a message received notification is displayed.

The “Email Notifications” (E-mail) or “SMS Notifications” (SMS) setting must be on.

Refer to Communication Settings on page 5-118.

Select **[Read]** and display the message.

#### (Method 2)

1. Select the  icon on the home screen to display the Communication screen.
2. Select **[Notifications]** and display the new message list for E-mail and SMS.
3. Select the message you would like to display.

The following icons are displayed in the lower part of the details on the message. Icons which can be used differ depending on use conditions.

| Icon                                                                                | Function                                                                                                                                                                                                   |
|-------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|  | Displays the Communication menu.                                                                                                                                                                           |
|  | Displays the inbox.                                                                                                                                                                                        |
|  | Plays back a message.<br>When selected again, playback is temporarily stopped.                                                                                                                             |
|  | Displays the previous message.                                                                                                                                                                             |
|  | Displays the next message.                                                                                                                                                                                 |
|  | Only replies to the sender of the currently displayed message.<br>Select the sentence on the displayed reply screen and select the sentence for sending from the preset message.<br>Select <b>[Send]</b> . |

## Audio Set [Type B (touchscreen)]


| Icon                                                                              | Function                                                                                                                                                                                               |
|-----------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|  | <b>(Only E-mail)</b><br>Replies to all members including CC.<br>Select the sentence on the displayed reply screen and select the sentence for sending from the preset message.<br>Select <b>Send</b> . |
|  | Makes a call to a person who sent a message.<br>For E-mail, this function may not work depending on the device.                                                                                        |
|  | Deletes a message.<br>The messages stored in a device is also deleted.                                                                                                                                 |

### NOTE

Up to 3 preset messages can be selected.

### Example of use (verify unread E-mail)

1. Select the  icon on the home screen to display the Communication screen.
2. Select **Email** to display the inbox.



3. Select the unread message displayed in bold.
4. The details of the message are displayed and replying to the message, making a call, or playback can be performed.

### Changing account for displaying (E-mail only)

1. Select  **Inbox**.

2. Select the account which you would like to display. Only the messages for the selected account are displayed in the inbox.

### Editing preset messages

1. Select the  icon on the home screen to display the Communication screen.
2. Select **Settings**.
3. Select **Preset Messages**.
4. Select the preset message which you would like to edit. The keyboard screen is displayed.
5. When the message is input and  is selected, the message is stored as a preset message.

### NOTE

- Select the  icon to change the language.
- Select the  icon to switch between capitalized and lower-case characters.
- Select the  icon to return to the previous screen without storing the edit.

## Audio Set [Type B (touchscreen)]

### ▼ Communication Settings

Select the  icon on the home screen to display the Communication screen.

Select **Settings** to change the setting.

| Item                        | Setting                   | Function                                                                                                                                                                                       |
|-----------------------------|---------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Bluetooth®                  | —                         | Go to Bluetooth® setting menu.<br>Refer to Bluetooth® Preparation on page 5-99.                                                                                                                |
| Incoming Call Notifications | On/Off                    | Notifies when an incoming call is received.                                                                                                                                                    |
| Auto Download SMS           | On/Off                    | Downloads SMS automatically when the Bluetooth® unit is connected to the device.                                                                                                               |
| SMS Notifications           | On/Off                    | Notifies when a new SMS is received.                                                                                                                                                           |
| Auto Download Email*1       | On/Off                    | Downloads E-mail automatically when the Bluetooth® unit is connected to the device.                                                                                                            |
| Email Notifications         | On/Off                    | Notifies when a new E-mail is received.                                                                                                                                                        |
| Auto Download Call History  | On/Off                    | Downloads Call History automatically when the Bluetooth® unit is connected to the device.                                                                                                      |
| Auto Download Contacts*1    | On/Off                    | Downloads the phonebook automatically when the Bluetooth® unit is connected to the device.                                                                                                     |
| Ringtone                    | Fixed/<br>In-band/Off     | The type of ring tone can be changed. Three selections are available including the standard ring tone set on the vehicle, the ring tone registered to your Bluetooth® device, or no ring tone. |
| Phone Volume                | Adjusts using the slider. | Adjusts the conversation volume.                                                                                                                                                               |
| VR and Ringtone             | Adjusts using the slider. | Adjusts the voice guidance and ringtone volume.                                                                                                                                                |
| Contacts Sort Order         | First Name, Last Name     | Displays the contact information in alphabetical order of the first name.                                                                                                                      |
|                             | Last Name, First Name     | Displays the contact information in alphabetical order of the last name.                                                                                                                       |
| Preset Messages             | —                         | Edits the preset message.<br>Refer to Receiving and Replying to Messages (available only with E-mail/SMS compatible phones) on page 5-115.                                                     |
| Reset                       | —                         | Initializes all Communication Settings.                                                                                                                                                        |

\*1 Depending on the device, it may be necessary to acquire download permission on the device side.



## Audio Set [Type B (touchscreen)]

### Voice Recognition

#### ▼ Basic Operation Method

##### Activating Voice Recognition

Press the talk button.

##### Ending Voice Recognition

Use one of the following methods:

- Press the hang-up button.
- Say, “Cancel”.
- Operate the commander switch or the centre display (only when vehicle is stopped).

##### Skipping Voice Guidance (for faster operation)

Press and release the talk button.

##### Troubleshooting for Voice Recognition

If you do not understand an operation method while in the voice recognition mode, say “Tutorial” or “Help”.

##### Commands useable anytime during voice recognition

“Go Back” and “Cancel” are commands which can be used at anytime during voice recognition.

##### **Returning to previous operation**

To return to the previous operation, say, “Go Back” while in voice recognition mode.

##### **Cancel**

To put the Bluetooth® Hands-Free system in standby mode, say, “Cancel” while in voice recognition mode.

To prevent a deterioration in the voice recognition rate and voice quality, the following points should be observed:

- The voice recognition cannot be performed while voice guidance or the beep sound is operating. Wait until the voice guidance or the beep sound is finished before saying your commands.
- Phone related commands are available only when your phone is connected via Bluetooth®. Make sure your phone is connected via Bluetooth® before you operate phone related voice commands.
- Music play commands, such as Play Artist and Play Album can be used only in USB audio mode.
- Do not speak too slowly or loudly (no loud voice).
- Speak clearly, without pausing between words or numbers.
- Dialects or different wording other than hands-free prompts cannot be recognised by voice recognition. Speak in the wording specified by the voice commands.
- It is not necessary to face the microphone or approach it. Speak the voice commands while maintaining a safe driving position.
- Close the windows to reduce loud noises from outside the vehicle, or turn down the airflow of the air-conditioning system while Bluetooth® Hands-Free is being used.
- Make sure the vents are not directing air up towards the microphone.

Interior Features

## Audio Set [Type B (touchscreen)]

---

**NOTE**

*If the voice recognition performance is not satisfactory.*

*Refer to Troubleshooting on page 5-126.*

## Audio Set [Type B (touchscreen)]

### ▼ Voice Command List

#### Voice command

When the talk button is pressed and the following command is spoken, the audio or navigation can be operated. The commands in the () can be omitted. The specified name and number are put into the {}.

#### Standard command

| Voice command                 | Function                                                 |
|-------------------------------|----------------------------------------------------------|
| Help                          | Usable commands can be verified.                         |
| Tutorial                      | Basic voice commands and methods of use can be verified. |
| (Navigate/Take me/Drive) Home | Set the destination to Home.                             |

#### Communication (phone) related command

| Voice command                                                                    | Function                                                                                  |
|----------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------|
| Call {name in phonebook} (mobile/home/work/other)<br>Example: "Call John Mobile" | Call to the contact in the downloaded phonebook.<br>Refer to Making a Call on page 5-110. |
| Redial                                                                           | Call to the last contact you called.<br>Refer to Making a Call on page 5-110.             |
| Callback                                                                         | Call to the last contact who called you.<br>Refer to Making a Call on page 5-110.         |

#### Entertainment (audio) related command

| Voice command                  | Function                                                                                                                           | Corresponding audio source |
|--------------------------------|------------------------------------------------------------------------------------------------------------------------------------|----------------------------|
| (Go to/Play) Bluetooth (Audio) | Switches the audio source to BT audio.<br>Can also switch to each audio source by similarly using commands such as FM, AM, or USB. | All                        |
| Play Artist {Artist name}      | Plays the selected artist.                                                                                                         | USB                        |

#### Navigation related command\*

For the navigation screen voice commands, refer to the separate navigation system manual.

#### **NOTE**

- Some commands cannot be used depending on the grade and specification.
- Some commands cannot be used depending on the device connection conditions and the use conditions.
- The commands are examples of the available commands.

## Audio Set [Type B (touchscreen)]

### Settings

#### NOTE

Depending on the grade and specification, the screen display may differ.

Select the  icon on the home screen and display the Settings screen.

Switch the tab and select the setting item you want to change.

You can customize settings in the setup display as follows:

| Tab     | Item                                                              | Function                                                                                                                                                                                                    |
|---------|-------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| AD-Disp | Height<br>Brightness Control<br>Other                             | Refer to Active Driving Display on page 4-26.                                                                                                                                                               |
| Display | Refer to Volume/Display/Sound Controls on page 5-72.              |                                                                                                                                                                                                             |
| Safety  | 360° View Monitor<br>Distance Recognition Support System<br>Other | Refer to Personalisation Features on page 9-8.                                                                                                                                                              |
| Sound   | Refer to Volume/Display/Sound Controls on page 5-72.              |                                                                                                                                                                                                             |
| Clock   | Adjust Time                                                       | Displays the currently set time is displayed.<br>Press <b>+</b> to advance the hour/minute, and select <b>-</b> to move the hour/minute back.<br>AM/PM can only be selected with the 12-hour clock display. |
|         | GPS Sync                                                          | Synchronizes with GPS when turned on.<br>When turned off, the time can be changed from "Adjust Time".                                                                                                       |
|         | Time Format                                                       | Changes the display between 12 and 24-hour clock time.                                                                                                                                                      |
|         | Time Zone Select                                                  | When it's not synchronized with GPS, select the region you want to specify.                                                                                                                                 |
|         | Daylight Savings Time                                             | Turns the daylight saving time setting on/off.<br>When ON, the time advances 1 hour. When OFF, it returns to normal time.                                                                                   |

## Audio Set [Type B (touchscreen)]

| Tab     | Item               | Function                                                                                                                                                                                                                                          |
|---------|--------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Vehicle | Rain Sensing Wiper | Refer to Personalisation Features on page 9-8.                                                                                                                                                                                                    |
|         | Other              |                                                                                                                                                                                                                                                   |
| Devices | Bluetooth          | Refer to Bluetooth® Preparation on page 5-99.                                                                                                                                                                                                     |
|         | Android Auto       | An Android Auto™ mode connection can be set on or off when connecting an Android™ Smartphone.<br>The setting takes effect directly after switching on/off.<br>Displays in grey and cannot be selected if an Android™ Smartphone is not connected. |
|         | Apple CarPlay      | An Apple CarPlay connection can be set on or off when connecting an iPhone.<br>For the setting to take effect, it is necessary to connect the iPhone again.<br>Displays in grey and cannot be selected if an iPhone is not connected.             |
|         | Network Management | Wi-Fi™ is used to obtain Navi POI/Real Time Traffic function (Such as gas prices, weather, nearest restaurant)                                                                                                                                    |

# Interior Features

## Audio Set [Type B (touchscreen)]

| Tab    | Item                  |                            | Function                                                                                                                                                                                                                                                                                                                                                  |
|--------|-----------------------|----------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| System | Tool Tips             |                            | Turns button explanations ON/OFF.                                                                                                                                                                                                                                                                                                                         |
|        | Language              |                            | Changes the language.                                                                                                                                                                                                                                                                                                                                     |
|        | Temperature           |                            | Changes the setting between Fahrenheit and Celsius.                                                                                                                                                                                                                                                                                                       |
|        | Distance              |                            | Changes the setting between miles and kilometres.                                                                                                                                                                                                                                                                                                         |
|        | Music Database Update |                            | Used to update Gracenote®. Gracenote® is used with USB Audio and Bluetooth® Audio, and provides:<br>1. Supplementary music information (Such as song name, artist name)<br>2. Voice recognition assistance for Play Artist and Play Album<br>Gracenote® can be downloaded from the Mazda Handsfree Website.<br>Refer to Gracenote® Database on page 5-86. |
|        | Factory Reset         |                            | Memory and settings are initialized to the factory settings.<br>The initialization launches by selecting the <b>Yes</b> button.                                                                                                                                                                                                                           |
|        | About                 | Agreements and Disclaimers | Verify the disclaimer and agree.                                                                                                                                                                                                                                                                                                                          |
|        |                       | Version Information        | Can verify the current audio unit OS version and Gracenote® Database version.                                                                                                                                                                                                                                                                             |

## Audio Set [Type B (touchscreen)]

### Applications

**NOTE**

Depending on the grade and specification, the screen display may differ.

Select the  icon on the home screen to display the Applications screen. The following information can be verified.

| Top screen             |                  | Item                                                                                                 | Function                                                      |
|------------------------|------------------|------------------------------------------------------------------------------------------------------|---------------------------------------------------------------|
| Fuel Economy Monitor   |                  | Fuel Consumption Display<br>Control Status Display<br>Effectiveness Display<br>Ending Screen Display | Refer to Fuel Economy Monitor on page 4-69.                   |
| Vehicle Status Monitor | Warning Guidance | Warnings currently active can be verified.                                                           | Refer to If a Warning Light Turns On or Flashes on page 7-23. |
|                        | Maintenance      | Scheduled Maintenance<br>Tyre Rotation<br>Oil Change                                                 | Refer to Maintenance Monitor on page 6-8.                     |
| Apple CarPlay          |                  | —                                                                                                    | Refer to How to use Apple CarPlay on page 5-89.               |
| Android Auto           |                  | —                                                                                                    | Refer to How to use Android Auto™ mode on page 5-92.          |

**Audio Set [Type B (touchscreen)]****Troubleshooting****Apple CarPlay use-related issues**

| Symptom                                                                                                                                 | Cause                                                                                                                                                                                | Solution method                                                                                                                                                                                                                                                                                                                                                                            |
|-----------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Apple CarPlay cannot launch even though an Apple-genuine connector cord is inserted into the USB port and it is connected to my iPhone. | You used the wrong USB port.                                                                                                                                                         | Use the USB port displaying the  mark to start Apple CarPlay.                                                                                                                                                                                                                                           |
| The error message, "Mobile device error" is displayed after connecting my iPhone to the USB port.                                       | There is mis-communication between the vehicle's audio system and your iPhone.                                                                                                       | Disconnect the connector cord from the USB port once and then reconnect it.                                                                                                                                                                                                                                                                                                                |
| The icon of the application I want to use is not displayed on the home screen of Apple CarPlay.                                         | Only applications compatible with Apple CarPlay are displayed on the screen.                                                                                                         | Contact the application's supplier.                                                                                                                                                                                                                                                                                                                                                        |
| Voice recognition using Siri is poor or incorrect for commands or contact names.                                                        | There are many possible reasons for this such as:<br>1. Poor network connectivity<br>2. Road noise/sound of air blowing from air conditioner<br>3. Incorrect iPhone language setting | 1. Use the commander switch to complete the task or wait until there is sufficient network connectivity before using Siri again.<br>2. For better voice recognition, speak loud and clear.<br>3. Make sure that the iPhone language is set correctly (Example: US English vs UK English).<br>If you are still having difficulty using Siri, visit the Apple support site or contact Apple. |
| There is a difference in the audio volume between Bluetooth® audio and Apple CarPlay.                                                   | —                                                                                                                                                                                    | Check the volume of the audio on the device connected via Bluetooth®. The volume on some devices connected via Bluetooth® can be adjusted.                                                                                                                                                                                                                                                 |

**Android Auto™ use-related issues**

| Symptom                                                                                                                                                             | Cause                                                                              | Solution method                                                                                                                                                              |
|---------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| The Android Auto™ mode does not launch even though the Android™-genuine connector cord is inserted into the USB port and it is connected to my Android™ Smartphone. | The Android Auto™ application has not been downloaded to your Android™ Smartphone. | To use Android Auto™ with your vehicle, the Android Auto™ application is required on your Android™ Smartphone. Download the Android Auto™ application from the Google Play™. |
|                                                                                                                                                                     | You used the wrong USB port.                                                       | Use the USB port displaying the  mark to start the Android Auto™ mode.                  |



## Audio Set [Type B (touchscreen)]

| Symptom                                                                                                                                                       | Cause                                                                                         | Solution method                                                                                                                                                  |
|---------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| The error message, "Mobile device error" is displayed after connecting my Android™ Smartphone to the USB port.                                                | There is mis-communication between the vehicle's audio system and your Android™ Smartphone.   | Disconnect the connector cord from the USB port once and then reconnect it.                                                                                      |
|                                                                                                                                                               | Your Android™ Smartphone cannot be paired because another device is connected via Bluetooth®. | Disconnect the other device's Bluetooth® connection, disconnect the connector cord of the Android™ Smartphone from the USB terminal once, and then reconnect it. |
| The icon of the application I want to use is not displayed on the home screen while in Android Auto™ mode.                                                    | Only applications compatible with Android Auto™ are displayed on the screen.                  | Contact the application's supplier.                                                                                                                              |
| <ul style="list-style-type: none"> <li>• Voice recognition is poor or incorrect.</li> <li>• Voice recognition responds slowly or it does not work.</li> </ul> | —                                                                                             | If you are having difficulty using the voice recognition, visit the Android Auto™ support site or contact Google™.                                               |
| There is a difference in the audio volume between Bluetooth® audio and Android Auto™.                                                                         | —                                                                                             | Check the volume of the audio on the device connected via Bluetooth®. The volume on some devices connected via Bluetooth® can be adjusted.                       |

### Mazda Bluetooth® Hands-Free Customer Service

If you have any problems with Bluetooth®, contact our toll-free customer service centre.

• Australia

Phone: 1800-352-703 during business hours (10am—4pm Eastern Standard Time)

Web: [www.mazda.com.au](http://www.mazda.com.au)

• New Zealand

Web: [www.mazdahandsfree.co.nz](http://www.mazdahandsfree.co.nz)

## Audio Set [Type B (touchscreen)]

### Bluetooth® Device pairing, connection problems

| Symptom                                                                                                                                          | Cause                                                                                                                                                            | Solution method                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
|--------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Unable to perform pairing.                                                                                                                       | —                                                                                                                                                                | Make sure that the Bluetooth® device is compatible with the Bluetooth® unit, and that Bluetooth® and Find Mode*1 are on and the airplane mode is off in the Bluetooth® device setting. Turn off the power of the Bluetooth® device once, then turn it back on. If pairing is still not possible after this, contact an expert repairer (we recommend an Authorised Mazda Repairer) or Mazda Bluetooth® Hands-Free Customer Service.                                                                                                     |
| Pairing cannot be performed again.                                                                                                               | The pairing information paired to the Bluetooth® unit or device is not recognised correctly.                                                                     | Perform pairing using the following procedure:<br>1. Delete the applicable Bluetooth® device on the Mazda Connect.<br>2. Delete “Mazda” from the Bluetooth® search screen of the Bluetooth® device.<br>3. Perform pairing again.<br>If pairing is not possible after trying the procedure, turn off the power of the Bluetooth® device once, then turn it back on. If pairing is still not possible after this, contact an expert repairer (we recommend an Authorised Mazda Repairer) or Mazda Bluetooth® Hands-Free Customer Service. |
| It takes time for automatic connection.                                                                                                          | There are a lot of paired Bluetooth® devices.                                                                                                                    | Delete the pairing information for unused Bluetooth® devices.<br>If it takes time for an automatic connection even though the above operation has been done, do a manual connection.                                                                                                                                                                                                                                                                                                                                                    |
| Unable to perform pairing.<br>Does not connect automatically when starting the engine.<br>Automatically connects, but then disconnects suddenly. | The Bluetooth® function and the Find Mode/Visible setting*1 on the device may turn off automatically after a period of time has elapsed depending on the device. | Check whether the Bluetooth® function and the Find Mode/Visible setting*1 on the device are turned on and pairing or reconnect.                                                                                                                                                                                                                                                                                                                                                                                                         |

## Audio Set [Type B (touchscreen)]

| Symptom                                                  | Cause                                                                                                                                                    | Solution method                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |
|----------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Disconnects intermittently.                              | The device is in a location in which radio wave interference can occur easily, such as inside a bag in a rear seat, in a rear pocket of a pair of pants. | Move the device to a location in which radio wave interference is less likely to occur.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
| Does not connect automatically when starting the engine. | The pairing information is updated when the device OS is updated.                                                                                        | <p>Perform pairing using the following procedure:</p> <ol style="list-style-type: none"> <li>1. Delete the applicable Bluetooth® device on the Mazda Connect.</li> <li>2. Delete “Mazda” from the Bluetooth® search screen of the Bluetooth® device.</li> <li>3. Perform pairing again.</li> </ol> <p>If pairing is not possible after trying the procedure, turn off the power of the Bluetooth® device once, then turn it back on. If pairing is still not possible after this, contact an expert repairer (we recommend an Authorised Mazda Repairer) or Mazda Bluetooth® Hands-Free Customer Service.</p> |

\*1 Setting which detects the existence of a device external to the Bluetooth® unit.

### NOTE

- When the OS of the device is updated, the pairing information may be deleted. If this happens, reprogramme the pairing information to the Bluetooth® unit.
- If you pair your phone which has already been paired to your vehicle more than once in the past, you need to delete “Mazda” on your mobile device. Then, execute the Bluetooth® search on your mobile device once again, and pair to a newly detected “Mazda”.
- Before you pair your device, make sure that Bluetooth® is “ON”, both on your phone and on the vehicle.
- If Bluetooth®-enabled devices are used in the following locations or conditions, connection via Bluetooth® may not be possible.
  - The device is in a location hidden from the centre display such as behind or under a seat, or inside the glove compartment.
  - The device contacts or is covered by a metal object or body.
  - The device is set to power-saving mode.

## Audio Set [Type B (touchscreen)]

· Different Bluetooth®-enabled devices can be used for Bluetooth® Hands-Free and Bluetooth® audio. For example, device A can be connected as a Bluetooth® Hands-Free device and device B can be connected as a Bluetooth® audio device. However, the following may occur when they are used at the same time.

- The Bluetooth® connection of the device is disconnected.
- Noise occurs in the Hands-Free audio.
- Hands-Free operates slowly.

### Voice recognition related problems

| Symptom                                                  | Cause                                                                                                                                                                                                                                                                                                                                                                               | Solution method                                                                                                                                                                                                                                                                                                                                                            |
|----------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Poor voice recognition.                                  | <ul style="list-style-type: none"> <li>· Excessive, slow speech.</li> <li>· Excessive, forceful speech (shouting).</li> <li>· Speaking before the beep sound has ended.</li> <li>· Loud noise (speaking or noise from outside/inside vehicle).</li> <li>· Airflow from A/C is blowing against the microphone.</li> <li>· Speaking in off-standard expressions (dialect).</li> </ul> | Regarding the causes indicated on the left, be careful with how you speak. In addition, when numbers are spoken in a sequence, recognition ability will improve if no stop is placed between the numbers.                                                                                                                                                                  |
| False recognition of numbers.                            |                                                                                                                                                                                                                                                                                                                                                                                     |                                                                                                                                                                                                                                                                                                                                                                            |
| Poor voice recognition.                                  | There is a malfunction in the microphone.                                                                                                                                                                                                                                                                                                                                           | A poor connection or malfunction with the microphone may have occurred. Consult an expert repairer (we recommend an Authorised Mazda Repairer).                                                                                                                                                                                                                            |
| Phone-related voice recognition is disabled.             | There is a problem with the connection between the Bluetooth® unit and the device.                                                                                                                                                                                                                                                                                                  | If there is any malfunction after checking the pairing situation, check for device pairing or connection problems.                                                                                                                                                                                                                                                         |
| Names in the phonebook are not easily recognised.        | The Bluetooth® system is under a condition in which recognition is difficult.                                                                                                                                                                                                                                                                                                       | <p>By carrying out the following measures, the rate of recognition will improve.</p> <ul style="list-style-type: none"> <li>· Clear memory from the phonebook which is not used very often.</li> <li>· Avoid shortened names, use full names. (Recognition improves the longer the name is. By not using names such as “Mum”, “Dad”, recognition will improve.)</li> </ul> |
| When operating the audio, a song name is not recognised. | Song names cannot be recognised by voice.                                                                                                                                                                                                                                                                                                                                           | —                                                                                                                                                                                                                                                                                                                                                                          |

## Audio Set [Type B (touchscreen)]

| Symptom                    | Cause | Solution method                                                            |
|----------------------------|-------|----------------------------------------------------------------------------|
| You want to skip guidance. | —     | Guidance can be skipped by quickly pressing and releasing the talk button. |

### Regarding problems with calls

| Symptom                                                                | Cause                                                                                                                                       | Solution method                                    |
|------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------|
| When starting a call, vehicle noise from the other party can be heard. | For about 3 seconds after starting a call, the Bluetooth® unit's Noise Suppression function requires time to adapt to the call environment. | This does not indicate a problem with the device.  |
| The other party cannot be heard or the speaker's voice is quiet.       | The volume is set at zero or low.                                                                                                           | Increase the volume.                               |
| The phone does not receive calls.                                      | The “Incoming Call Notifications” setting in the Communication Settings is off.                                                             | Turn the “Incoming Call Notifications” setting on. |

### Other problems

| Symptom                                                                                                                                  | Cause                                                                  | Solution method                                                                                                                                               |
|------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------|
| The indication for the remaining battery is different between the vehicle and the device.                                                | The indication method is different between the vehicle and the device. | —                                                                                                                                                             |
| When a call is made from the vehicle, the telephone number is updated in the incoming/outgoing call record but the name does not appear. | The number has not been registered into the phonebook.                 | If the number has been registered into the phonebook, the incoming/outgoing call record is updated by the name in the phonebook when the engine is restarted. |
| The cell phone does not synchronize with the vehicle regarding the incoming/outgoing call record.                                        | Some types of cell phones do not synchronize automatically.            | Operate the cell phone for synchronization.                                                                                                                   |
| It takes a long time to complete the function for changing the language.                                                                 | A maximum of 60 seconds is required.                                   | —                                                                                                                                                             |

## Appendix

### Things You Need to Know

#### WARNING

***Always adjust the audio while the vehicle is stopped:***

*Do not adjust the audio control switches while driving the vehicle. Adjusting the audio while driving the vehicle is dangerous as it could distract your attention from the vehicle operation which could lead to a serious accident. Even if the audio control switches are equipped on the steering wheel, learn to use the switches without looking down at them so that you can keep your maximum attention on the road while driving the vehicle.*


#### CAUTION

*For the purposes of safe driving, adjust the audio volume to a level that allows you to hear sounds outside of the vehicle including car horns and particularly emergency vehicle sirens.*


#### NOTE

- To prevent the battery from being discharged, do not leave the audio system on for a long period of time when the engine is not running.*
- If a cellular phone or CB radio is used in or near the vehicle, it could cause noise to occur from the audio system, however, this does not indicate that the system has been damaged.*

Do not spill any liquid on the audio system.



Do not insert any objects, other than CDs, into the slot.




#### ▼ Radio Reception

##### AM characteristics

AM signals bend around such things as buildings or mountains and bounce off the ionosphere.


Therefore, they can reach longer distances than FM signals.

Because of this, 2 stations may sometimes be picked up on the same frequency at the same time.




### FM characteristics

An FM broadcast range is usually about 40—50 km (25—30 miles) from the source. Because of extra coding needed to break the sound into 2 channels, stereo FM has even less range than monaural (non-stereo) FM.




Signals from an FM transmitter are similar to beams of light because they do not bend around corners, but they do reflect. Unlike AM signals, FM signals cannot travel beyond the horizon. Therefore, FM stations cannot be received at the great distances possible with AM reception.



Atmospheric conditions can also affect FM reception. High humidity will cause poor reception. However, cloudy days may provide better reception than clear days.


### Multipath noise

Since FM signals can be reflected by obstructions, it is possible to receive both the direct signal and the reflected signal at the same time. This causes a slight delay in reception and may be heard as a broken sound or a distortion. This problem may also be encountered when in close proximity to the transmitter.



### Flutter/Skip noise

Signals from an FM transmitter move in straight lines and become weak in valleys between tall buildings, mountains, and other obstacles. When a vehicle passes through such an area, the reception conditions may change suddenly, resulting in annoying noise.



## Appendix


### Weak signal noise

In suburban areas, broadcast signals become weak because of distance from the transmitter. Reception in such fringe areas is characterised by sound breakup.




### Strong signal noise

This occurs very close to a transmitter tower. The broadcast signals are extremely strong, so the result is noise and sound breakup at the radio receiver.



### Station drift noise

When a vehicle reaches the area of 2 strong stations broadcasting at similar frequencies, the original station may be temporarily lost and the second station picked up. At this time there will be some noise from this disturbance.



### ▼ Operating Tips for CD Player


#### Condensation phenomenon

Immediately after turning on the heater when the vehicle is cold, the CD or optical components (prism and lens) in the CD player may become clouded with condensation. At this time, the CD will eject immediately when placed in the unit. A clouded CD can be corrected simply by wiping it with a soft cloth. Clouded optical components will clear naturally in about an hour. Wait for normal operation to return before attempting to use the unit.


#### Handling the CD player

The following precautions should be observed.

- Do not use deformed or cracked CDs. The disc may not eject resulting in a malfunction.




- Do not use non-conventional discs such as heart-shaped, octagonal discs, etc. The disc may not eject resulting in a malfunction.







- If the memory portion of the CD is transparent or translucent, do not use the disc.



- A new CD may have rough edges on its inner and outer perimeters. If a disc with rough edges is used, proper setting will not be possible and the CD player will not play the CD. In addition, the disc may not eject resulting in a malfunction. Remove the rough edges in advance by using a ball-point pen or pencil as shown in the following figure. To remove the rough edges, rub the side of the pen or pencil against the inner and outer perimeter of the CD.




- When driving over uneven surfaces, the sound may jump.



- CDs bearing the logo shown in the illustration can be played. No other discs can be played.



- Use discs that have been legitimately produced. If illegally-copied discs such as pirated discs are used, the system may not operate properly.
- Be sure never to touch the signal surface when handling the CDs. Pick up a CD by grasping the outer edge or the edge of the hole and the outer edge.



- Do not stick paper or tape on the CD. Avoid scratching the reverse side (the side without a label). The disc may not eject resulting in a malfunction.
- Dust, finger smudges, and dirt can decrease the amount of light reflected from the signal surface, thus affecting sound quality. If the CD should become soiled, gently wipe it with a soft cloth from the centre of the CD to the edge.

## Appendix

- Do not use record sprays, antistatic agents, or household spray cleaners. Volatile chemicals such as benzine and thinner can also damage the surface of the CD and must not be used. Anything that can damage, warp, or fog plastic should never be used to clean CDs.
- The CD player ejects the CD if the CD is inserted upside down. Also dirty and/or defective CDs may be ejected.
- Do not insert cleaning discs in the CD player.
- Do not insert any disc with a peel-off seal affixed to it.
- This unit may not be able to play certain CD-R/CD-RWs made using a computer or music CD recorder due to disc characteristics, scratches, smudges, dirt, etc., or due to dust or condensation on the lens inside the unit.
- Storing CDs in the vehicle exposed to direct sunlight or high temperature may damage the CD-R/CD-RWs, and make them unplayable.
- CD-R/CD-RW exceeding 700 MB cannot be played.
- This unit may not be able to play certain discs made using a computer due to the application (writing software) setting used. (For details, consult the store where the application was purchased.)
- It is possible that certain text data, such as titles, recorded on a CD-R/CD-RW may not be displayed when musical data (CD-DA) is playing.
- The period from when a CD-RW is inserted to when it begins playing is longer than a normal CD or CD-R.
- Completely read the instruction manual and cautions for CD-R/CD-RWs.

- Do not use discs with cellophane tape adhering, partially peeled off labels, or adhesive material exuding from the edges of the CD label. Also, do not use discs with a commercially-available CD-R label affixed. The disc may not eject resulting in a malfunction.

### ▼ Operating Tips for MP3

MP3 stands for MPEG Audio Layer 3, which is standardised voice compression established by the ISO<sup>\*1</sup> working group (MPEG).

Use of MP3 allows for audio data to be compressed to approximately a tenth of the source data size.

This unit plays files with the extension (.mp3) as MP3 files.

<sup>\*1</sup> International Organisation for Standardisation

### CAUTION

*Do not use an audio file extension on files other than audio files. In addition, do not change the audio file extension. Otherwise, the unit will not recognise the file correctly resulting in noise or a malfunction.*

**NOTE**

*Supply of this product only conveys a license for private, non-commercial use and does not convey a license nor imply any right to use this product in any commercial (i.e. revenue-generating) real time broadcasting (terrestrial, satellite, lead and/or any other media), broadcasting/streaming via the Internet, intranets and/or other networks or in other electronic content distribution systems, such as pay-audio or audio-on-demand applications. An independent license for such use is required. For details, please visit <http://www.mp3licensing.com>.*

- This audio system handles MP3 files that have been recorded on CD-R/CD-RW/CD-ROMs.
- When naming an MP3 file, be sure to add an MP3 file extension (.mp3) after the file name.
- The number of characters which can be displayed is restricted.

**▼ Operating Tips for WMA**

WMA is short for Windows Media\*<sup>1</sup> Audio and is the audio compression format used by Microsoft\*<sup>1</sup>.

Audio data can be created and stored at a higher compression ratio than MP3.

This unit plays files with the extension (.wma) as WMA files.

\*<sup>1</sup> Windows Media and Microsoft are registered trademarks of Microsoft Corporation U.S. in the United States and other countries.

**⚠ CAUTION**

*Do not use an audio file extension on files other than audio files. In addition, do not change the audio file extension. Otherwise, the unit will not recognise the file correctly resulting in noise or a malfunction.*

- WMA files written under specifications other than the indicated specification may not play normally or files or folder names may not display correctly.
- The file extension may not be provided depending on the computer operating system, version, software, or settings. In this case, add the file extension “.wma” to the end of the file name, and then write it to the disc/memory.

**▼ Operating Tips for AAC**

AAC stands for Advanced Audio Coding, which is standardised voice compression established by the ISO\*<sup>1</sup> working group (MPEG). Audio data can be created and stored at a higher compression ratio than MP3.

This unit plays files with the extensions (.aac\*<sup>2</sup>/.m4a/.wav\*<sup>2</sup>) as the AAC files.

**⚠ CAUTION**

*Do not use an audio file extension on files other than audio files. In addition, do not change the audio file extension. Otherwise, the unit will not recognise the file correctly resulting in noise or a malfunction.*

- AAC files written under specifications other than the indicated specification may not play normally or files or folder names may not display correctly.

## Appendix

- The file extension may not be provided depending on the computer operating system, version, software, or settings. In this case, add the file extension “.aac\*2”, “.m4a”, or “.wav\*2” to the end of the file name, and then write it to the disc/memory.

\*1 International Organisation for Standardisation

\*2 Type B

### ▼ Operating Tips for OGG

OGG is the audio compression format for Xiph. Org Foundation.

Audio data can be created and stored at a higher compression ratio than MP3.

This unit plays files with the extension (.ogg) as OGG files.

### CAUTION

*Do not use an audio file extension on files other than audio files. In addition, do not change the audio file extension. Otherwise, the unit will not recognise the file correctly resulting in noise or a malfunction.*

- OGG files written under specifications other than the indicated specification may not play normally or files or folder names may not display correctly.
- The file extension may not be provided depending on the computer operating system, version, software, or settings. In this case, add the file extension “.ogg” to the end of the file name, and then write it to the memory.

### ▼ Operating Tips for USB device

This unit plays audio files as follows:

| Extension | Playback with this unit |
|-----------|-------------------------|
| .mp3      | MP3                     |
| .wma      | WMA                     |
| .aac*1    | AAC                     |
| .m4a      |                         |
| .wav*1    | WAV                     |
| .ogg*1    | OGG                     |

### CAUTION

*Do not use an audio file extension on files other than audio files. In addition, do not change the audio file extension. Otherwise, the unit will not recognise the file correctly resulting in noise or a malfunction.*

### NOTE

- Playback may not be possible depending on the type and condition of the USB flash memory even if the audio file complies with the standard.
- A copyright protected WMA/AAC file cannot be played in this unit.
- **(Type B)**  
*If a file name in the USB memory is too long, it could cause operation problems such as not being able to playback the song.*  
*(Recommended: Within 80 characters)*
- *The order of the music data stored in the device may differ from the playback order.*
- *To prevent loss or damage of stored data, we recommend that you always back up your data.*

· **(Type A)**

*If a device exceeds the maximum electric current value of 1,000 mA, it may not operate or recharge when connected.*

· **(Type B)**

*If the current consumption of the connected device exceeds the following current value, it may not operate or recharge.*

- Apple device is connected : 2,100 mA
- Device compatible with BCI.2 is connected : 1,500 mA
- Device other than the above is connected : 500 mA
- Do not pull out the USB device while in the USB mode (only pull it out while in FM/AM radio or CD mode).
- The device will not operate if the data is password protected.

MP3/WMA/AAC/OGG files written under specifications other than the indicated specification may not play normally or files/folder names may not display correctly.

\*1 Type B

▼ **Operating Tips for iPod**

This unit supports playback of music files recorded to an iPod.

\* iPod is a trademark of Apple Inc., registered in the U.S. and other countries.

The iPod may not be compatible depending on the model or OS version. In this case, an error message is displayed.

**⚠ CAUTION**

- Remove the iPod when it is not in use. Because the iPod is not designed to withstand excessive changes in temperature inside the cabin, it could be damaged or the battery may deteriorate due to the excessive temperature or humidity inside the cabin if it is left in the vehicle.
- If data in the iPod is lost while it is connected to the unit, Mazda cannot guarantee recovery of any lost data.
- If the iPod battery is deteriorated, the iPod may not recharge and playback may not be possible when it is connected to the unit.
- For details on using the iPod, refer to the iPod instruction manual.
- When connecting the iPod to a USB port, all commands are made from the audio unit. iPod control is not possible.

**NOTE**

*The audio unit cannot display images or videos stored in an iPod.*

▼ **Agreements and disclaimers related to Apple CarPlay**

This unit is compatible with Apple CarPlay which can operate an iPhone using the vehicle's audio device.

\* iPhone, Siri and Apple Music are trademarks of Apple Inc., registered in the U.S. and other countries.

\* Apple CarPlay is trademarks of Apple Inc.

## Appendix

---

\* iOS is a trademark or registered trademark of Cisco in the U.S. and other countries and is used under license.

May not be compatible depending on the model or OS version.

### CAUTION

- *For the purposes of safety, do not operate your iPhone while driving.*
- *Disconnect the iPhone when it is not in use. If the device is left in the cabin, it could be damaged or the battery may deteriorate due to the excessive temperature or humidity inside the cabin.*
- *If the iPhone battery has deteriorated, it may not recharge or play audio even if it is connected to this unit.*
- *Before use, carefully read the user instructions for the iPhone.*

### NOTE

*To prevent loss or damage of stored data, we recommend that you always back up your data.*

### ▼ Operating Tips for Android™

Requires the Android Auto app on Google Play and an Android compatible smartphone running Android™ 5.0 Lollipop or higher.

### CAUTION

- *For the purposes of safety, do not operate your Android™ Smartphone while driving.*
- *Disconnect the Android™ Smartphone when it is not in use. If the device is left in the cabin, it could be damaged or the battery may weaken due to the excessive temperature or humidity inside the cabin.*
- *If the Android™ Smartphone battery has deteriorated, it may not recharge or play audio even if it is connected to this unit.*
- *Before use, carefully read the user instructions for the Android™ Smartphone.*

### NOTE


*To prevent loss or damage of stored data, we recommend that you always back up your data.*

\* Google, Android, Android Auto and other related marks are trademarks of Google LLC.

Interior Equipment

Sunvisors

When you need a sunvisor, lower it for use in front or swing it to the side.



▼ Vanity Mirrors


To use the vanity mirror, lower the sunvisor.

Interior Lights

**NOTE**  
*Do not leave the lights on for long periods while the engine is turned off. Otherwise, the battery power could be depleted.*


Overhead Lights

| Switch Position | Overhead Lights                                                                                                                                          |
|-----------------|----------------------------------------------------------------------------------------------------------------------------------------------------------|
| OFF             | Light off                                                                                                                                                |
| DOOR            | <ul style="list-style-type: none"><li>• Light is on when any door is open</li><li>• Light is on or off when the illuminated entry system is on</li></ul> |
| ON              | Light on                                                                                                                                                 |



Map Lights

When the overhead light switch is in the door or off position, press the lens to illuminate the map lights, and then press the lens again to turn them off.




## Interior Equipment

### **NOTE**

The map lights will not turn off even if the lens is pressed in the following cases:

- The overhead light switch is in the **ON** position.
- The overhead light switch is in the door position with the door open.
- The illuminated entry system is on.


### **Luggage Compartment Lights (Hatchback)**



| Switch Position | Luggage Compartment Light          |
|-----------------|------------------------------------|
| OFF             | Light off                          |
| ON              | Light on when the liftgate is open |

### **Boot Light (Saloon)**

The boot light is on when the lid is open and off when it's closed.



### **NOTE**

To prevent the battery from being discharged, do not leave the boot open for a long period when the engine is not running.



## Interior Equipment

### ▼ Illuminated Entry System

The overhead lights turn on when any of the following operations is done with the overhead light switch in the DOOR position.

- The driver's door is unlocked with the ignition is switched OFF.
- The ignition is switched OFF with all doors closed.

#### NOTE


- The illumination time differs depending on the operation.
- **Battery saver**  
If an interior light is left on with the ignition switched OFF, the light is turned off automatically after about 30 minutes to prevent battery depletion.
- The operation of the illuminated entry system can be changed.  
Refer to Personalisation Features on page 9-8.

### Accessory Sockets


Only use genuine Mazda accessories or the equivalent requiring no greater than 120 W (DC 12 V, 10 A).

The ignition must be switched to ACC or ON.

#### Type A



#### Type B



## Interior Equipment

### CAUTION

- To prevent accessory socket damage or electrical failure, pay attention to the following:
  - Do not use accessories that require more than 120 W (DC 12 V, 10 A).
  - Do not use accessories that are not genuine Mazda accessories or the equivalent.
  - Close the cover when the accessory socket is not in use to prevent foreign objects and liquids from getting into the accessory socket.
  - Correctly insert the plug into the accessory socket.
  - Do not insert the cigarette lighter into the accessory socket.
- Noise may occur on the audio playback depending on the device connected to the accessory socket.
- Depending on the device connected to the accessory socket, the vehicle's electrical system may be affected, which could cause the warning light to illuminate. Disconnect the connected device and make sure that the problem is resolved. If the problem is resolved, disconnect the device from the socket and switch the ignition off. If the problem is not resolved, consult an expert repairer (we recommend an Authorised Mazda Repairer).

### NOTE

To prevent discharging of the battery, do not use the socket for long periods with the engine off or idling.

### Cup Holder


### WARNING

**Never use a cup holder to hold hot liquids while the vehicle is moving:**

Using a cup holder to hold hot liquids while the vehicle is moving is dangerous. If the contents spill, you could be scalded.

**Do not put anything other than cups or drink cans in cup holders:**


Putting objects other than cups or drink cans in a cup holder is dangerous. During sudden braking or manoeuvring, occupants could be hit and injured, or objects could be thrown around the vehicle, causing interference with the driver and the possibility of an accident. Only use a cup holder for cups or drink cans.



## Interior Equipment

### Bottle Holder

Bottle holders are on the inside of the front doors.



#### CAUTION

*Do not use the bottle holders for containers without caps. The contents may spill when opening/closing the door or while driving the vehicle.*

### Storage Compartments

#### WARNING

##### **Keep storage boxes closed when driving:**

*Driving with the storage boxes open is dangerous. To reduce the possibility of injury in an accident or a sudden stop, keep the storage boxes closed when driving.*

##### **Do not put articles in storage spaces with no lid:**


*Putting articles in storage spaces with no lid is dangerous as they could be thrown around the cabin if the vehicle is suddenly accelerated and cause injury depending on how the article is stored.*

#### CAUTION

*Do not leave lighters or eyeglasses in the storage boxes while parked under the sun. A lighter could explode or the plastic material in eyeglasses could deform and crack from high temperature.*

##### **▼ Glove Compartment**

To open the glove compartment, pull the latch toward you.



## Interior Equipment

---

To close the glove compartment, firmly press in the centre of the glove compartment lid.

### ▼ Centre Console Tray




***Never use a cup holder to hold hot liquids while the vehicle is moving:***

*Using a cup holder to hold hot liquids while the vehicle is moving is dangerous. If the contents spill, you could be scalded.*

A cup or small items can be placed on the centre console tray using the centre console divider.


The centre console tray is large enough to place a small item when the centre console divider is not in use.



▼ **Luggage Compartment**

**Cargo Sub-Compartment (Hatchback)**

Lift the boot mat.



**NOTE**

***Loading golf bags (only Saloon)***


*(Some golf bags may not fit using the following methods depending on their sizes.)*

*Up to two golf bags can be carried in the boot.*


*First golf bag: Place the golf bag in the luggage compartment with its bottom pointed to the left and fit it into the front of the compartment.*

*Second golf bag: Place the golf bag in the luggage compartment with its bottom pointed to the left and fit it into the back of the compartment.*

**First golf bag**



**Second golf bag**



The arrows indicate the bottoms of the golf bags.

## Interior Equipment

---


### ▼ Rear Coat Hooks

#### **WARNING**

***Never hang heavy or sharp objects on the assist grips and coat hooks:***

*Hanging heavy or sharp-ended objects such as a coat hanger from the assist grips or coat hooks is dangerous as they can fly off and hit an occupant in the cabin if a curtain air bag was to deploy, which could result in serious injury or death.*

Always hang clothes on the coat hooks and the assist grips without hangers.



# 6

## Maintenance and Care

How to keep your Mazda in top condition.

|                                   |            |                              |             |
|-----------------------------------|------------|------------------------------|-------------|
| <b>Essential Information.....</b> | <b>6-2</b> | Brake/Clutch Fluid.....      | 6-17        |
| Introduction.....                 | 6-2        | Window Washer Fluid.....     | 6-18        |
| <b>Scheduled Maintenance.....</b> | <b>6-3</b> | Body Lubrication.....        | 6-18        |
| Scheduled Maintenance.....        | 6-3        | Wiper Blades.....            | 6-19        |
| Maintenance Monitor.....          | 6-8        | Battery.....                 | 6-22        |
| <b>Owner Maintenance.....</b>     | <b>6-9</b> | Key Battery Replacement..... | 6-25        |
| Owner Maintenance                 |            | Tyres.....                   | 6-27        |
| Precautions.....                  | 6-9        | Light Bulbs.....             | 6-30        |
| Bonnet.....                       | 6-11       | Fuses.....                   | 6-37        |
| Engine Compartment                |            | Emission Control Maintenance |             |
| Overview.....                     | 6-13       | (Australia).....             | 6-42        |
| Engine Oil.....                   | 6-14       | <b>Appearance Care.....</b>  | <b>6-44</b> |
| Engine Coolant.....               | 6-16       | Exterior Care.....           | 6-44        |
|                                   |            | Interior Care.....           | 6-50        |

## Essential Information

### Introduction

Be careful not to hurt yourself when inspecting your vehicle, replacing a tyre, or doing some kind of maintenance such as car washing.

In particular, wear thick work gloves such as cotton gloves when touching areas that are difficult to see while inspecting or working on your vehicle. Doing inspections or procedures with your bare hands could cause injury.

If you are unsure about any procedure this manual describes, we strongly urge you to have a reliable and qualified technician perform the work, we recommend an Authorised Mazda Repairer.

Authorised Mazda technicians and genuine Mazda parts are dedicated to your vehicle. Without this expertise and the parts that have been designed and made especially for your Mazda, inadequate, incomplete, and insufficient servicing may result in problems. This could lead to vehicle damage or an accident and injuries.


For expert advice and quality service, consult an Authorised Mazda Repairer.

The owner should retain evidence that proper maintenance has been performed as prescribed.

A claim against a warranty will not qualify if it results from lack of maintenance and not from defective material or authorised workmanship.

The malfunction diagnosis connector is designed exclusively for connecting the specially designed device to perform on-board diagnosis.

Do not connect any devices other than the specially designed malfunction diagnosis devices for servicing. If any device other than the malfunction diagnosis device is connected, it may affect the vehicle's electrical devices or lead to damage such as battery depletion.





## Scheduled Maintenance

### Scheduled Maintenance

#### NOTE

After the prescribed period, continue to follow the described maintenance at the recommended intervals.

#### Emission control and related systems

The ignition and fuel systems are highly important to the emission control system and to efficient engine operation. Do not tamper with them.

All inspections and adjustments must be made by an expert repairer, we recommend an Authorised Mazda Repairer.

#### ▼ Australia and New Zealand

##### Australia

| Maintenance Interval                                                | Base Scheduled Maintenance required every 10,000 km, or not longer than 12 months, whichever occurs first |    |    |    |    |    |    |    |    |    |     |     |     |     |     |     |     |
|---------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------|----|----|----|----|----|----|----|----|----|-----|-----|-----|-----|-----|-----|-----|
|                                                                     | Service                                                                                                   | 1  | 2  | 3  | 4  | 5  | 6  | 7  | 8  | 9  | 10  | 11  | 12  | 13  | 14  | 15  | 16  |
|                                                                     | ×1000 km                                                                                                  | 10 | 20 | 30 | 40 | 50 | 60 | 70 | 80 | 90 | 100 | 110 | 120 | 130 | 140 | 150 | 160 |
| Air filter*1                                                        |                                                                                                           |    | C  |    | C  |    | C  |    | C  |    | C   |     | C   |     | C   |     | C   |
| Evaporative system (if installed)                                   | I                                                                                                         |    |    |    |    | I  |    |    |    | I  |     |     |     | I   |     |     |     |
| Drive belts*2                                                       | I                                                                                                         |    |    | I  |    | I  |    | I  |    | I  |     | I   |     | I   |     | I   |     |
| Engine oil & filter*3                                               | R                                                                                                         | R  | R  | R  | R  | R  | R  | R  | R  | R  | R   | R   | R   | R   | R   | R   | R   |
| Cooling system                                                      |                                                                                                           |    | I  |    | I  |    | I  |    | I  |    | I   |     | I   |     | I   |     | I   |
| Fuel lines and hoses                                                | I                                                                                                         |    |    | I  |    | I  |    | I  |    | I  |     | I   |     | I   |     | I   |     |
| Battery*4                                                           | I                                                                                                         | I  | I  | I  | I  | I  | I  | I  | I  | I  | I   | I   | I   | I   | I   | I   | I   |
| Brake lines, hoses and connections                                  | I                                                                                                         | I  | I  | I  | I  | I  | I  | I  | I  | I  | I   | I   | I   | I   | I   | I   | I   |
| Brake fluid*5                                                       | I                                                                                                         | I  | I  | I  | I  | I  | I  | I  | I  | I  | I   | I   | I   | I   | I   | I   | I   |
| Parking brake                                                       | I                                                                                                         | I  | I  | I  | I  | I  | I  | I  | I  | I  | I   | I   | I   | I   | I   | I   | I   |
| Power brake unit (Brake booster) and hoses                          | I                                                                                                         | I  | I  | I  | I  | I  | I  | I  | I  | I  | I   | I   | I   | I   | I   | I   | I   |
| Disc brakes                                                         | I                                                                                                         | I  | I  | I  | I  | I  | I  | I  | I  | I  | I   | I   | I   | I   | I   | I   | I   |
| Drum brakes                                                         | I                                                                                                         | I  | I  | I  | I  | I  | I  | I  | I  | I  | I   | I   | I   | I   | I   | I   | I   |
| Steering operation and linkages                                     |                                                                                                           |    | I  |    | I  |    | I  |    | I  |    | I   |     | I   |     | I   |     | I   |
| Front and rear suspension, ball joints and wheel bearing axial play |                                                                                                           |    | I  |    | I  |    | I  |    | I  |    | I   |     | I   |     | I   |     | I   |
| Driveshaft dust boots                                               | I                                                                                                         |    |    | I  |    | I  |    | I  |    | I  |     | I   |     | I   |     | I   |     |
| Exhaust system and heat shields                                     | I                                                                                                         |    |    | I  |    | I  |    | I  |    | I  |     | I   |     | I   |     | I   |     |
| Bolts and nuts on chassis and body                                  |                                                                                                           |    | T  |    | T  |    | T  |    | T  |    | T   |     | T   |     | T   |     | T   |
| All electrical system*6                                             | I                                                                                                         | I  | I  | I  | I  | I  | I  | I  | I  | I  | I   | I   | I   | I   | I   | I   | I   |

## Scheduled Maintenance

| Maintenance Interval                                              | Base Scheduled Maintenance required every 10,000 km, or not longer than 12 months, whichever occurs first |    |    |    |    |    |    |    |    |    |     |     |     |     |     |     |     |
|-------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------|----|----|----|----|----|----|----|----|----|-----|-----|-----|-----|-----|-----|-----|
|                                                                   | Service                                                                                                   | 1  | 2  | 3  | 4  | 5  | 6  | 7  | 8  | 9  | 10  | 11  | 12  | 13  | 14  | 15  | 16  |
|                                                                   | ×1000 km                                                                                                  | 10 | 20 | 30 | 40 | 50 | 60 | 70 | 80 | 90 | 100 | 110 | 120 | 130 | 140 | 150 | 160 |
| Tyres (including spare tyre) (with inflation pressure adjustment) |                                                                                                           | I  | I  | I  | I  | I  | I  | I  | I  | I  | I   | I   | I   | I   | I   | I   | I   |
| Tyre rotation*7                                                   |                                                                                                           | I  | I  | I  | I  | I  | I  | I  | I  | I  | I   | I   | I   | I   | I   | I   | I   |
| Road test                                                         |                                                                                                           | I  | I  | I  | I  | I  | I  | I  | I  | I  | I   | I   | I   | I   | I   | I   | I   |
| M-MDS check of Vehicle Management and Safety Systems              |                                                                                                           |    | I  |    | I  |    | I  |    | I  |    | I   |     | I   |     | I   |     | I   |
| Emergency flat tyre repair kit (if installed)*8                   |                                                                                                           | I  | I  | I  | I  | I  | I  | I  | I  | I  | I   | I   | I   | I   | I   | I   | I   |

| Additional Scheduled Maintenance items |                                                                                  |
|----------------------------------------|----------------------------------------------------------------------------------|
| Fuel filter                            | Replace every 150,000 km                                                         |
| Spark plugs                            | Replace every 120,000 km                                                         |
| Air filter*1                           | Replace every 60,000 km or 3 years                                               |
| Engine coolant*9                       | Replace at first 200,000 km or 10 years; after that, every 100,000 km or 5 years |
| Brake fluid*5                          | Replace every 40,000 km or 2 years                                               |
| Manual transaxle oil                   | Replace every 100,000 km or 5 years                                              |
| Cabin air filter (if installed)        | Replace every 40,000 km or 2 years                                               |

### Chart symbols:

**I:** Inspect and clean, repair, adjust, fill up, or replace if necessary.

**R:** Replace

**L:** Lubricate

**C:** Clean

**T:** Tighten

**D:** Drain

### Remarks:

\*1 If the vehicle is operated in very dusty or sandy areas, clean and if necessary, replace the air filter more often than the recommended intervals.

\*2 Also inspect the air conditioner drive belts, if installed.

If the vehicle is operated primarily under any of the following conditions, inspect the drive belts at every 10,000 km or 1 year.

- Driving in dusty conditions
- Extended periods of idling or low speed operation
- Driving for long period in cold temperatures or driving regularly at short distance only
- Driving in extremely hot conditions
- Driving in mountainous conditions continually
- Driving for long period in extremely wet or heavy rain condition

\*3 If the vehicle is operated primarily under any of the following conditions, replace the engine oil and oil filter more often than the recommended intervals.

- Driving in dusty conditions

## Scheduled Maintenance

- b) Extended periods of idling or low speed operation
- c) Driving for long period in cold temperatures or driving regularly at short distance only
- d) Driving in extremely hot conditions
- e) Driving in mountainous conditions continually
- \*4 Inspect the battery electrolyte level, specific gravity and outer appearance. The sealed battery only requires an outer appearance inspection.
- \*5 If the brakes are used extensively (for example, continuous hard driving or mountain driving) or if the vehicle is operated in extremely humid climates, replace the brake fluid annually.
- \*6 This is a full function check of electrical systems such as lights, wiper and washer systems (including wiper blades), and power windows.
- \*7 If the vehicle is operated primarily under any of the following conditions, rotate the tyres more often than the recommended intervals.
  - a) Driving on bumpy roads, gravel roads, snowy roads or dirt roads
  - b) Driving uphill and downhill frequently
  - c) Repeated short-distance driving
  - d) On roads having many roundabouts
- \*8 Check the tyre repair fluid expiration date every year when performing the periodic maintenance. Replace the tyre repair fluid bottle with new one before the expiration date.
- \*9 Use of FL-22 is recommended when replacing engine coolant. Using engine coolant other than FL-22 may cause serious damage to the engine and cooling system.

### NOTE

Please ask Mazda Repairer to check Mazda computer network to ensure there are no outstanding campaign or recall actions on the vehicle.

### New Zealand

| Maintenance Interval               | Number of months or kilometres, whichever comes first                            |    |    |    |    |    |    |    |    |     |     |     |     |     |     |     |     |  |
|------------------------------------|----------------------------------------------------------------------------------|----|----|----|----|----|----|----|----|-----|-----|-----|-----|-----|-----|-----|-----|--|
|                                    | Months                                                                           | 12 | 24 | 36 | 48 | 60 | 72 | 84 | 96 | 108 | 120 | 132 | 144 | 156 | 168 | 180 | 192 |  |
|                                    | ×1000 km                                                                         | 10 | 20 | 30 | 40 | 50 | 60 | 70 | 80 | 90  | 100 | 110 | 120 | 130 | 140 | 150 | 160 |  |
| Fuel filter                        | Replace every 150,000 km                                                         |    |    |    |    |    |    |    |    |     |     |     |     |     |     |     |     |  |
| Spark plugs                        | Replace every 120,000 km                                                         |    |    |    |    |    |    |    |    |     |     |     |     |     |     |     |     |  |
| Air filter*1                       |                                                                                  | C  |    | C  |    | C  |    | C  |    | C   |     | C   |     | C   |     | C   |     |  |
|                                    | Replace every 60,000 km or 3 years                                               |    |    |    |    |    |    |    |    |     |     |     |     |     |     |     |     |  |
| Evaporative system (if installed)  |                                                                                  |    |    | I  |    |    |    | I  |    |     |     | I   |     |     |     |     | I   |  |
| Drive belts*2                      | I                                                                                |    | I  |    | I  |    | I  |    | I  |     | I   |     | I   |     | I   |     | I   |  |
| Engine oil & filter*3              | R                                                                                | R  | R  | R  | R  | R  | R  | R  | R  | R   | R   | R   | R   | R   | R   | R   | R   |  |
| Cooling system                     |                                                                                  | I  |    | I  |    | I  |    | I  |    | I   |     | I   |     | I   |     | I   |     |  |
| Engine coolant*4                   | Replace at first 200,000 km or 10 years; after that, every 100,000 km or 5 years |    |    |    |    |    |    |    |    |     |     |     |     |     |     |     |     |  |
| Fuel lines and hoses               | I                                                                                |    | I  |    | I  |    | I  |    | I  |     | I   |     | I   |     | I   |     | I   |  |
| Battery*5                          | I                                                                                | I  | I  | I  | I  | I  | I  | I  | I  | I   | I   | I   | I   | I   | I   | I   | I   |  |
| Brake lines, hoses and connections | I                                                                                | I  | I  | I  | I  | I  | I  | I  | I  | I   | I   | I   | I   | I   | I   | I   | I   |  |
| Brake fluid*6                      | I                                                                                | I  | I  | I  | I  | I  | I  | I  | I  | I   | I   | I   | I   | I   | I   | I   | I   |  |

## Scheduled Maintenance

| Maintenance Interval                                                | Number of months or kilometres, whichever comes first |    |    |    |    |    |    |    |    |     |     |     |     |     |     |     |     |  |
|---------------------------------------------------------------------|-------------------------------------------------------|----|----|----|----|----|----|----|----|-----|-----|-----|-----|-----|-----|-----|-----|--|
|                                                                     | Months                                                | 12 | 24 | 36 | 48 | 60 | 72 | 84 | 96 | 108 | 120 | 132 | 144 | 156 | 168 | 180 | 192 |  |
|                                                                     | ×1000 km                                              | 10 | 20 | 30 | 40 | 50 | 60 | 70 | 80 | 90  | 100 | 110 | 120 | 130 | 140 | 150 | 160 |  |
|                                                                     | Replace every 40,000 km or 2 years                    |    |    |    |    |    |    |    |    |     |     |     |     |     |     |     |     |  |
| Parking brake                                                       | I                                                     | I  | I  | I  | I  | I  | I  | I  | I  | I   | I   | I   | I   | I   | I   | I   | I   |  |
| Power brake unit (Brake booster) and hoses                          | I                                                     | I  | I  | I  | I  | I  | I  | I  | I  | I   | I   | I   | I   | I   | I   | I   | I   |  |
| Disc brakes                                                         | I                                                     | I  | I  | I  | I  | I  | I  | I  | I  | I   | I   | I   | I   | I   | I   | I   | I   |  |
| Drum brakes                                                         | I                                                     | I  | I  | I  | I  | I  | I  | I  | I  | I   | I   | I   | I   | I   | I   | I   | I   |  |
| Steering operation and linkages                                     |                                                       | I  |    | I  |    | I  |    | I  |    | I   |     | I   |     | I   |     | I   |     |  |
| Manual transaxle oil                                                | Replace every 100,000 km or 5 years                   |    |    |    |    |    |    |    |    |     |     |     |     |     |     |     |     |  |
| Front and rear suspension, ball joints and wheel bearing axial play |                                                       | I  |    | I  |    | I  |    | I  |    | I   |     | I   |     | I   |     | I   |     |  |
| Driveshaft dust boots                                               |                                                       | I  |    | I  |    | I  |    | I  |    | I   |     | I   |     | I   |     | I   |     |  |
| Exhaust system and heat shields                                     |                                                       |    |    |    |    |    |    | I  |    |     |     |     |     |     |     |     | I   |  |
| Bolts and nuts on chassis and body                                  |                                                       | T  |    | T  |    | T  |    | T  |    | T   |     | T   |     | T   |     | T   |     |  |
| All electrical system*7                                             |                                                       | I  |    | I  |    | I  |    | I  |    | I   |     | I   |     | I   |     | I   |     |  |
| Cabin air filter (if installed)                                     | Replace every 40,000 km or 2 years                    |    |    |    |    |    |    |    |    |     |     |     |     |     |     |     |     |  |
| Tyres (including spare tyre) (with inflation pressure adjustment)   | I                                                     | I  | I  | I  | I  | I  | I  | I  | I  | I   | I   | I   | I   | I   | I   | I   | I   |  |
| Tyre rotation*8                                                     | I                                                     | I  | I  | I  | I  | I  | I  | I  | I  | I   | I   | I   | I   | I   | I   | I   | I   |  |
| Road test                                                           | I                                                     | I  | I  | I  | I  | I  | I  | I  | I  | I   | I   | I   | I   | I   | I   | I   | I   |  |
| M-MDS check of Vehicle Management and Safety Systems                | I                                                     | I  | I  | I  | I  | I  | I  | I  | I  | I   | I   | I   | I   | I   | I   | I   | I   |  |
| Emergency flat tyre repair kit (if installed)*9                     | Inspect annually.                                     |    |    |    |    |    |    |    |    |     |     |     |     |     |     |     |     |  |

### Chart symbols:

**I:** Inspect: Inspect and clean, repair, adjust, fill up, or replace if necessary.

**R:** Replace

**L:** Lubricate

**C:** Clean

**T:** Tighten

**D:** Drain

### Remarks:

\*1 If the vehicle is operated in very dusty or sandy areas, clean and if necessary, replace the air filter more often than the recommended intervals.

\*2 Also inspect the air conditioner drive belts, if installed.

If the vehicle is operated primarily under any of the following conditions, inspect the drive belts at every 10,000 km or 1 year.

- Driving in dusty conditions
- Extended periods of idling or low speed operation
- Driving for long period in cold temperatures or driving regularly at short distance only

## Scheduled Maintenance

---

- d) Driving in extremely hot conditions
- e) Driving in mountainous conditions continually
- f) Driving for long period in extremely wet or heavy rain condition
- \*3 If the vehicle is operated primarily under any of the following conditions, replace the engine oil and oil filter more often than the recommended intervals.
  - a) Driving in dusty conditions
  - b) Extended periods of idling or low speed operation
  - c) Driving for long period in cold temperatures or driving regularly at short distance only
  - d) Driving in extremely hot conditions
  - e) Driving in mountainous conditions continually
- \*4 Use of FL-22 is recommended when replacing engine coolant. Using engine coolant other than FL-22 may cause serious damage to the engine and cooling system.
- \*5 Inspect the battery electrolyte level, specific gravity and outer appearance. The sealed battery only requires an outer appearance inspection.
- \*6 If the brakes are used extensively (for example, continuous hard driving or mountain driving) or if the vehicle is operated in extremely humid climates, replace the brake fluid annually.
- \*7 This is a full function check of electrical systems such as lights, wiper and washer systems (including wiper blades), and power windows.
- \*8 If the vehicle is operated primarily under any of the following conditions, rotate the tyres more often than the recommended intervals.
  - a) Driving on bumpy roads, gravel roads, snowy roads or dirt roads
  - b) Driving uphill and downhill frequently
  - c) Repeated short-distance driving
  - d) On roads having many roundabouts
- \*9 Check the tyre repair fluid expiration date every year when performing the periodic maintenance. Replace the tyre repair fluid bottle with new one before the expiration date.

**NOTE**

*Please ask Mazda Repairer to check Mazda computer network to ensure there are no outstanding campaign or recall actions on the vehicle.*

## Scheduled Maintenance

### Maintenance Monitor

1. Select the  icon on the home screen to display the Applications screen.
2. Select “Vehicle Status Monitor”.
3. Select “Maintenance” to display the maintenance list screen.
4. Switch the tab and select the setting item you want to change.

You can customize settings in the setup display as follows:

| Tab           | Item                  | Explanation                                                                                                                                                                                                                                                                    |
|---------------|-----------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Scheduled     | Setting               | Notification can be switched on/off.                                                                                                                                                                                                                                           |
|               | Time (months)         | Displays the time or distance until maintenance is due.                                                                                                                                                                                                                        |
|               | Distance (km or mile) | Select this item to set the maintenance period.<br>The wrench indication/indicator light in the instrument cluster will be illuminated when the remaining distance is less than 1,000 km or 600 mile, or the remaining number of days is less than 15 (whichever comes first). |
|               | Reset                 | Resets the time and distance to the initial values.<br>Once the system turns on, it needs to be reset whenever carrying out maintenance.                                                                                                                                       |
| Tyre Rotation | Setting               | Notification can be switched on/off.                                                                                                                                                                                                                                           |
|               | Distance (km or mile) | Displays the distance until tyre rotation is due.<br>Select this item to set the tyre rotation distance.<br>The wrench indication/indicator light in the instrument cluster will be illuminated when the remaining distance is less than 1,000 km or 600 mile.                 |
|               | Reset                 | Resets the remaining distance to the initial value.<br>Once the system turns on, it needs to be reset whenever rotating the tyres.                                                                                                                                             |
| Oil Change    | Setting               | Notification can be switched on/off.                                                                                                                                                                                                                                           |
|               | Distance (km or mile) | Displays the distance until the oil replacement is due.<br>Select this item to set the oil replacement distance.<br>The wrench indication/indicator light in the instrument cluster will be illuminated when the remaining distance is less than 1,000 km or 600 mile.         |
|               | Reset                 | Resets the remaining distance to the initial value.<br>Once the system turns on, it needs to be reset whenever replacing the engine oil.                                                                                                                                       |

## Owner Maintenance Precautions

### Routine Service

We highly recommend that these items be inspected daily, or at least every week.

- Engine Oil Level (page 6-15)
- Engine Coolant Level (page 6-16)
- Brake and clutch Fluid Level (page 6-17)
- Washer Fluid Level (page 6-18)
- Battery Maintenance (page 6-23)
- Tyre Inflation Pressure (page 6-27)

Improper or incomplete service may result in problems. This section gives instructions only for items that are easy to perform.

As explained in the Introduction (page 6-2), several procedures can be done only by a qualified service technician with special tools.

Improper do-it yourself maintenance during the warranty period may affect warranty coverage. For details, read the separate Mazda Warranty statement provided with the vehicle. If you are unsure about any servicing or maintenance procedure, have it done by an expert repairer, we recommend an Authorised Mazda Repairer.

There are strict environmental laws regarding the disposal of waste oil and fluids. Please dispose of your waste properly and with due regard to the environment.

We recommend that you entrust the oil and fluid changes of your vehicle to an Authorised Mazda Repairer.

### **WARNING**

***Do not perform maintenance work if you lack sufficient knowledge and experience or the proper tools and equipment to do the work. Have maintenance work done by a qualified technician:***

*Performing maintenance work on a vehicle is dangerous if not done properly. You can be seriously injured while performing some maintenance procedures.*

## Owner Maintenance

---

***If you must run the engine while working under the bonnet, make certain that you remove all jewellery (especially rings, bracelets, watches, and necklaces) and all neckties, scarves, and similar loose clothing before getting near the engine or cooling fan which may turn on unexpectedly:***

*Working under the bonnet with the engine running is dangerous. It becomes even more dangerous when you wear jewellery, loose clothing or have long hair or a long beard. Either can become entangled in moving parts and result in injury.*



***Pull over to a safe location, then switch the ignition off and make sure the fan is not running before attempting to work near the cooling fan:***

*Working near the cooling fan when it is running is dangerous. The fan could continue running indefinitely even if the engine has stopped and the engine compartment temperature is high. You could be hit by the fan and seriously injured.*

***Do not leave items in the engine compartment:***

*After you have finished checking or doing servicing in the engine compartment, do not forget and leave items such as tools or rags in the engine compartment.*

*Tools or other items left in the engine compartment could cause engine damage or a fire leading to an unexpected accident.*



## Bonnet


### **WARNING**

***Always check that the bonnet is closed and securely locked:***


*A bonnet that is not closed and securely locked is dangerous as it could fly open while the vehicle is moving and block the driver's vision which could result in a serious accident.*

#### ▼ Opening the Bonnet


1. With the vehicle parked, pull the release handle to unlock the bonnet.



2. Insert your hand into the bonnet opening, slide the latch lever to the right, and lift up the bonnet.



3. Grasp the support rod in the padded area and secure it in the support rod hole indicated by the arrow to hold the bonnet open.




#### ▼ Closing the Bonnet

1. Check under the bonnet area to make certain all filler caps are in place and all loose items (e.g. tools, oil containers, etc.) have been removed.

## Owner Maintenance

---

2. Lift the bonnet, grasp the padded area on the support rod, and secure the support rod in the clip. Verify that the support rod is secured in the clip before closing the bonnet.




3. Lower the bonnet slowly to a height of about 20 cm (7.9 in) above its closed position and then let it drop.

### CAUTION

*When closing the bonnet, do not push it excessively such as by applying your weight. Otherwise, the bonnet could be deformed.*

## Engine Compartment Overview

Windscreen washer fluid reservoir



## Owner Maintenance

### Engine Oil

#### NOTE

*Changing the engine oil should be done by an expert repairer (we recommend an Authorised Mazda Repairer).*

#### ▼ Recommended Oil

In order to follow the maintenance interval (page 6-3) and to protect the engine from damage caused by poor lubrication, it is vitally important to make use of engine oil with the correct specification. Do not use oils which do not meet the specification and requirements listed. Use of unsuitable oil may lead to engine damage which is not covered by the Mazda Warranty.

Engine oil viscosity, or thickness, has an effect on fuel economy and cold-weather operation (starting and oil flow).

Low-viscosity engine oils can provide improved fuel economy and cold-weather performance.

#### Engine oil specifications

| Temperature Range SAE Viscosity Numbers |                                  |
|-----------------------------------------|----------------------------------|
| Grade                                   | °C -40 -30 -20 -10 0 10 20 30 40 |
|                                         | °F -40 -20 0 20 40 60 80 100     |
| API SL/SM/SN or ILSAC GF-III/GF-IV/GF-V |                                  |

Use ILSAC GF-III/GF-IV/GF-V, or API service SL or higher.

When choosing an oil, consider the temperature range your vehicle will operate in before the next oil change.

Then select the recommended viscosity from the chart.



➤ *Using oils of viscosity besides those recommended for specific temperature ranges could result in engine damage.*

### New Zealand

Mazda recommends using Mazda Motor Oil which has been specifically designed and tested to meet the stringent Mazda Engineering Standards (MES) for your Mazda. To ensure engine longevity is not compromised particularly under the harsh climatic conditions existing in New Zealand, we only recommend using genuine Mazda engine oil which is available throughout the Mazda Repairer network.


If Mazda Motor Oil is not selected for use, always use an engine oil meeting the specifications.

### NOTE

· It is normal for all engines to consume engine oil under normal driving conditions. Engine oil consumption may be as high as 0.8 L/1,000 km (1 L/800 miles). This may be as a result of evaporation, internal ventilation or burning of the lubricating oil in the working engine. Oil consumption may be higher when the engine is new due to the running-in process. Oil consumption is also dependant on engine speed and engine load. Under extreme driving conditions, oil consumption may be higher.

### ▼ Inspecting Engine Oil Level

1. Be sure the vehicle is on a level surface.
2. Warm up the engine to normal operating temperature.
3. Turn it off and wait at least 5 minutes for the oil to return to the sump.
4. Pull out the dipstick, wipe it clean, and reinsert it fully.



5. Pull it out again and examine the level. The level is normal if it is between the MIN and MAX marks. If it is near or below MIN, add enough oil to bring the level to MAX.

### ⚠ CAUTION

*Do not overfill the engine oil. This may cause engine damage.*

6. Make sure the O-ring on the dipstick is positioned properly before reinserting the dipstick.
7. Reinsert the dipstick fully.

## Owner Maintenance

### Engine Coolant

#### ▼ Inspecting Coolant Level

#### WARNING

**Do not use a match or live flame in the engine compartment. DO NOT ADD COOLANT WHEN THE ENGINE IS HOT:**  
A hot engine is dangerous. If the engine has been running, parts of the engine compartment can become very hot. You could be burned. Carefully inspect the engine coolant in the coolant reservoir, but do not open it.



**Pull over to a safe location, then switch the ignition off and make sure the fan is not running before attempting to work near the cooling fan:**

Working near the cooling fan when it is running is dangerous. The fan could continue running indefinitely even if the engine has stopped and the engine compartment temperature is high. You could be hit by the fan and seriously injured.



**Do not remove either cooling system cap when the engine and radiator are hot:**

When the engine and radiator are hot, scalding coolant and steam may shoot out under pressure and cause serious injury.


#### NOTE

*Changing the coolant should be done by an expert repairer (we recommend an Authorised Mazda Repairer).*

Inspect the antifreeze protection and coolant level in the coolant reservoir at least once a year—at the beginning of the winter season—and before travelling where temperatures may drop below freezing.

Inspect the condition and connections of all cooling system and heater hoses. Replace any that are swollen or deteriorated.

The coolant should be at full in the radiator and between the F and L marks on the coolant reservoir when the engine is cool.




If it is at or near L, add enough coolant to the coolant reservoir to provide freezing and corrosion protection and to bring the level to F.

Securely tighten the coolant reservoir tank cap after adding coolant.

**CAUTION**

- Radiator coolant will damage paint. Rinse it off quickly if spilled.
- If the "FL22" mark is shown on or near the cooling system cap, use of FL-22 is recommended when replacing engine coolant. Using engine coolant other than FL-22 may cause serious damage to the engine and cooling system.



If the coolant reservoir is empty or new coolant is required frequently, consult an expert repairer (we recommend an Authorised Mazda Repairer).

**Brake/Clutch Fluid**

▼ **Inspecting Brake/Clutch Fluid Level**

**WARNING**


**If the brake/clutch fluid level is low, have the brakes inspected:**

A low brake/clutch fluid level is dangerous. A low level could indicate brake lining wear or a brake system leak which could cause the brakes to fail and lead to an accident.

The brakes and clutch draw fluid from the same reservoir.

Inspect the fluid level in the reservoir regularly. It should be kept between the MAX and MIN lines.

The level normally drops with accumulated distance, a condition associated with wear of brake and clutch linings. If it is excessively low, have the brake/clutch system inspected by an expert repairer (we recommend an Authorised Mazda Repairer).



## Owner Maintenance

### Window Washer Fluid


#### ▼ Inspecting Washer Fluid Level



***Use only windscreen washer fluid or plain water in the reservoir:***

*Using radiator antifreeze as washer fluid is dangerous. If sprayed on the windscreen, it will dirty the windscreen, affect your visibility, and could result in an accident.*

Inspect fluid level in the washer fluid reservoir; add fluid if necessary.



Use plain water if washer fluid is unavailable.  
But use only washer fluid in cold weather to prevent it from freezing.

#### **NOTE**

*Front and rear washer fluid is supplied from the same reservoir.*

### Body Lubrication

All moving points of the body, such as door and bonnet hinges and locks, should be lubricated each time the engine oil is changed. Use a nonfreezing lubricant on locks during cold weather.

Make sure the bonnet's secondary latch keeps the bonnet from opening when the primary latch is released.



## Wiper Blades

### CAUTION

- *Hot waxes applied by automatic car washers have been known to affect the wiper's ability to clean windows.*
- *To prevent damage to the wiper blades, do not use petrol, paraffin, paint thinner, or other solvents on or near them.*
- *When the wiper lever is in the AUTO position and the ignition is switched ON, the wipers may move automatically in the following cases:*
  - *If the windscreen above the rain sensor is touched.*
  - *If the windscreen above the rain sensor is wiped with a cloth.*
  - *If the windscreen is struck with a hand or other object.*
  - *If the rain sensor is struck with a hand or other object from inside the vehicle.*

*Be careful not to pinch hands or fingers as it may cause injury, or damage the wipers. When washing or servicing the vehicle, make sure the wiper lever is in the OFF position.*

Contamination of either the windscreen or the blades with foreign matter can reduce wiper effectiveness. Common sources are insects, tree sap, and hot wax treatments used by some commercial car washes.

If the blades are not wiping properly, clean the window and blades with a good cleaner or mild detergent; then rinse thoroughly with clean water. Repeat if necessary.

### ▼ Replacing Windscreen Wiper Blades

When the wipers no longer clean well, the blades are probably worn or cracked. Replace them.

### CAUTION


*To prevent damage to the wiper arms and other components, do not try to sweep the wiper arm by hand.*

### NOTE

*When raising both windscreen wiper arms, raise the driver's side wiper arm first. When lowering the wiper arms, slowly lower the wiper arm from the passenger's side first while supporting it with your hand. Forcefully lowering the wiper arms could damage the wiper arm and blade, and may scratch or crack the windscreen.*

Replace the wiper blades using the following procedure.

1. Raise the wiper arm and turn the blade assembly to expose the plastic locking clip. Compress the clip and slide the assembly downward; then lift it off the arm.




## Owner Maintenance


### CAUTION

To prevent damage to the windscreen let the wiper arm down easily, do not let it slap down on the windscreen.

2. Hold the end of the rubber and pull until the tabs are free of the metal support.



3. Remove the metal stiffeners from each blade rubber and install them in the new blade.




### CAUTION

- Do not bend or discard the stiffeners. You need to use them again.
- If the metal stiffeners are switched, the blade's wiping efficiency could be reduced.  
So do not use the driver's side metal stiffeners on the passenger's side, or vice versa.

- Be sure to reinstall the metal stiffeners in the new blade rubber so that the curve is the same as it was in the old blade rubber.

4. Carefully insert the new blade rubber. Then install the blade assembly in the reverse order of removal.



### NOTE

Install the blade so that the tabs are toward the bottom of the wiper arm.

### ▼ Replacing Rear Window Wiper Blade (Hatchback)


When the wiper no longer cleans well, the blade is probably worn or cracked. Replace it.

### CAUTION

To prevent damage to the wiper arm and other components, do not move the wiper by hand.

Maintenance and Care  
**Owner Maintenance**


1. Raise the wiper arm and rotate the wiper blade to the right until it unlocks, then remove the blade.




**CAUTION**

*To prevent damage to the rear window, do not let the wiper arm fall on it.*

2. Pull down the blade rubber and slide it out of the blade holder.




3. Remove the metal stiffeners from the blade rubber and install them in the new blade.



**CAUTION**

*Do not bend or discard the stiffeners. You need to use them again.*

4. Carefully insert the new blade rubber. Then install the blade assembly in the reverse order of removal.



## Owner Maintenance

### Battery

#### **WARNING**



***Read the following precautions carefully before using the battery or inspecting to ensure safe and correct handling:***



***Always wear eye protection when working near the battery:***

*Working without eye protection is dangerous. Battery fluid contains SULPHURIC ACID which could cause blindness if splashed into your eyes. Also, hydrogen gas produced during normal battery operation, could ignite and cause the battery to explode.*



***Wear eye protection and protective gloves to prevent contact with battery fluid:***

*Spilled battery fluid is dangerous.*

*Battery fluid contains SULPHURIC ACID which could cause serious injuries if it gets in eyes, or on the skin or clothing. If this happens, immediately flush your eyes with water for 15 minutes or wash your skin thoroughly and get medical attention.*



***Always keep batteries out of the reach of children:***

*Allowing children to play near batteries is dangerous. Battery fluid could cause serious injuries if it gets in the eyes or on the skin.*



***Keep flames and sparks away from open battery cells and do not allow metal tools to contact the positive (+) or negative (–) terminal of the battery when working near a battery. Do not allow the positive (+) terminal to contact the vehicle body:***

*Flames and sparks near open battery cells are dangerous. Hydrogen gas, produced during normal battery operation, could ignite and cause the battery to explode. An exploding battery can cause serious burns and injuries. Keep all flames including cigarettes and sparks away from open battery cells.*

## Owner Maintenance




**Keep all flames and sparks away from open battery cells because hydrogen gas is produced from open battery cells while charging the battery or adding battery fluid:**


Flames and sparks near open battery cells are dangerous. Hydrogen gas, produced during normal battery operation, could ignite and cause the battery to explode. An exploding battery can cause serious burns and injuries. Keep all flames including cigarettes and sparks away from open battery cells.

### NOTE

Before performing battery maintenance, remove the battery cover.



### ▼ Battery Maintenance



To get the best service from a battery:


- Keep it securely mounted.
- Keep the top clean and dry.
- Keep terminals and connections clean, tight, and coated with petroleum jelly or terminal grease.

- Rinse off spilled electrolyte immediately with a solution of water and baking soda.
- If the vehicle will not be used for an extended time, disconnect the battery leads and charge the battery every 6 weeks.

## Owner Maintenance

### ▼ Inspecting Electrolyte Level

A low level of electrolyte fluid will cause the battery to discharge quickly.



Inspect the electrolyte level at least once a week. If it is low, remove the caps and add enough distilled water to bring the level between the upper and lower level (illustration).

#### **Do not overfill.**

Examine the specific gravity of the electrolyte with a hydrometer, especially during cold weather. If it is low, recharge the battery.

### ▼ Battery Recharging

#### **NOTE**

- Before performing maintenance or recharging the battery, turn off all accessories and stop the engine.
- To disconnect the battery, remove the negative lead first. Install it last when connecting the battery.
- Be sure to remove the caps before recharging the battery.
- **(With i-stop system)**  
Do not quick-charge the battery.

- If the battery quickly discharges because, for example, the lights were left on too long with the engine off, slow-charge it as required by battery size and charger capacity.
- If the battery gradually discharges because of high electric load while the vehicle is being used, recharge it as required by battery size and charger capacity.

### ▼ Battery Replacement

Contact an Mazda Repairer for battery replacement.

## Key Battery Replacement

If the buttons on the transmitter are inoperable and the operation indicator light does not flash, the battery may be dead.

Replace with a new battery before the transmitter becomes unusable.

### CAUTION

- *Make sure the battery is installed correctly. Battery leakage could occur if it is not installed correctly.*
- *When replacing the battery, be careful not to touch any of the internal circuitry and electrical terminals, bend the electrical terminals, or get dirt in the transmitter as the transmitter could be damaged.*
- *There is the danger of explosion if the battery is not correctly replaced.*
- *Dispose of used batteries according to the following instructions.*
  - *Insulate the plus and minus terminals of the battery using cellophane or equivalent tape.*
  - *Never disassemble.*
  - *Never throw the battery into fire or water.*
  - *Never deform or crush.*
- *Replace only with the same type battery (CR2025 or equivalent).*

The following conditions indicate that the battery power is low:


- The KEY indicator light (green) flashes in the instrument cluster for about 30 seconds after the engine is switched OFF.

- The system does not operate and the operation indicator light on the transmitter does not flash when the buttons are pressed.
- The system's operational range is reduced.


Replacing the battery at an expert repairer (we recommend an Authorised Mazda Repairer), is recommended to prevent damage to the key. If replacing the battery by yourself, follow the instruction.

### Replacing the key battery

1. Press the knob and pull out the auxiliary key.




2. Twist a tape-wrapped flathead screwdriver in the direction of the arrow and open the cover slightly.




## Owner Maintenance


3. Insert the tape-wrapped flathead screwdriver into the gap and slide it in the direction of the arrow.



4. Twist the flathead screwdriver in the direction of the arrow and remove the cover.




5. Remove the battery cap, then remove the battery.




### CAUTION

➤ Be careful not to allow the rubber ring shown in the figure to be scratched or damaged.


➤ If the rubber ring detaches, reattach it before inserting a new battery.



6. Insert a new battery with the positive pole facing up, and then cover the battery with the battery cap.



7. Close the cover.



8. Reinsert the auxiliary key.



## Tyres

For reasons of proper performance, safety, and better fuel economy, always maintain recommended tyre inflation pressures and stay within the recommended load limits and weight distribution.

### **WARNING**

#### **Using Different Tyre Types:**

*Driving your vehicle with different types of tyres is dangerous. It could cause poor handling and poor braking; leading to loss of control.*

*Except for the limited use of the temporary spare tyre, use only the same type tyres (radial, bias-belted, bias-type) on all four wheels.*

#### **Using Wrong-Sized Tyres:**

*Using any other tyre size than what is specified for the vehicle (page 9-6) is dangerous. It could seriously affect ride, handling, ground clearance, tyre clearance, and speedometer calibration. This could cause you to have an accident. Use only tyres that are the correct size specified for the vehicle.*

#### **▼ Tyre Inflation Pressure**

### **WARNING**

#### **Always inflate the tyres to the correct pressure:**

*Overinflation or underinflation of tyres is dangerous. Adverse handling or unexpected tyre failure could result in a serious accident.*

*Refer to Tyres on page 9-6.*

#### **Use only a Mazda-genuine tyre valve cap:**

*Use of a non-genuine part is dangerous as the correct tyre air pressure cannot be maintained if the tyre valve becomes damaged. If the vehicle is driven under this condition, the tyre air pressure will decrease which could result in a serious accident. Do not use any part for the tyre valve cap that is not a Mazda-genuine part.*

Inspect all tyre pressures monthly (including the spare) when the tyres are cold. Maintain recommended pressures for the best ride, handling, and minimum tyre wear.

Refer to the specification charts (page 9-6).

#### **NOTE**

- *Always check tyre pressure when tyres are cold.*
- *Warm tyres normally exceed recommended pressures. Do not release air from warm tyres to adjust the pressure.*
- *Underinflation can cause reduced fuel economy, uneven and accelerated tyre wear, and poor sealing of the tyre bead, which will deform the wheel and cause separation of tyre from rim.*
- *Overinflation can produce a harsh ride, uneven and accelerated tyre wear, and a greater possibility of damage from road hazards.*

*Keep your tyre pressure at the correct levels. If one frequently needs inflating, have it inspected.*

## Owner Maintenance


### ▼ Tyre Rotation

#### **WARNING**

##### **Rotate tyres periodically:**

*Irregular tyre wear is dangerous. To equalize tread wear for maintaining good performance in handling and braking, rotate the tyres every 10,000 km (6,250 miles), or sooner if irregular wear develops.*

During rotation, inspect them for correct balance.



Do not include (TEMPORARY USE ONLY) spare tyre in rotation.

Also, inspect them for uneven wear and damage. Abnormal wear is usually caused by one or a combination of the following:

- Incorrect tyre pressure
- Improper wheel alignment
- Out-of-balance wheel
- Severe braking

After rotation, inflate all tyre pressures to specification (page 9-6) and inspect the wheel nuts for tightness.

#### **CAUTION**

*Rotate unidirectional tyres and radial tyres that have an asymmetrical tread pattern or studs only from front to rear, not from side to side. Tyre performance will be reduced if rotated from side to side.*

### ▼ Replacing a Tyre

#### **WARNING**

##### **Always use tyres that are in good condition:**


*Driving with worn tyres is dangerous. Reduced braking, steering, and traction could result in an accident.*

##### **Replace all four tyres at the same time:**

*Replacing just one tyre is dangerous. It could cause poor handling and poor braking resulting in loss of vehicle control. Mazda strongly recommends that you replace all four tyres at the same time.*

If a tyre wears evenly, a wear indicator will appear as a solid band across the tread.

Replace the tyre when this happens.



You should replace the tyre before the band crosses the entire tread.

### ▼ Temporary Spare Tyre

Inspect the temporary spare tyre at least monthly to make sure it is properly inflated and stored.

#### **NOTE**

*The temporary spare tyre condition gradually deteriorates even if it has not been used.*

The temporary spare tyre is easier to handle because of its construction which is lighter and smaller than a conventional tyre. This tyre should be used only for an emergency and only for a short distance.

Use the temporary spare tyre only until the conventional tyre is repaired, which should be as soon as possible.

Refer to Tyre on page 9-6.

### **CAUTION**

- Do not use your temporary spare tyre rim with a snow tyre or a conventional tyre. Neither will properly fit and could damage both tyre and rim.
- The temporary spare tyre has a tread life of less than 5,000 km (3,000 miles). The tread life may be shorter depending on driving conditions.
- The temporary spare tyre is for limited use, however, if the tread wear solid-band indicator appears, replace the tyre with the same type of temporary spare (page 6-28).

### ▼ Replacing a Wheel

### **WARNING**

**Always use wheels of the correct size on your vehicle:**

*Using a wrong-sized wheel is dangerous. Braking and handling could be affected, leading to loss of control and an accident.*

### **CAUTION**

*A wrong-sized wheel may adversely affect:*

- Tyre fit
- Wheel and bearing life
- Ground clearance
- Snow-chain clearance
- Speedometer calibration
- Headlight aim
- Bumper height


#### **NOTE**

- When replacing a wheel, make sure the new one is the same as the original factory wheel in diameter, rim width, and offset (inset/outset).
- For details, contact an expert repairer (we recommend an Authorised Mazda Repairer).


Proper tyre balancing provides the best riding comfort and helps reduce tread wear. Out-of-balance tyres can cause vibration and uneven wear, such as cupping and flat spots.

### Light Bulbs


Type A




Type B



Saloon



Hatchback



- ① Headlights (Low/High beam)
- ② Headlights (Wide-range low beam)\*
- ③ Headlights (High beam)\*
- ④ Running lights
- ⑤ Running lights/Position lights
- ⑥ Position lights
- ⑦ Front direction indicator lights
- ⑧ Side direction indicator lights
- ⑨ Brake lights/Tail lights
- ⑩ Rear direction indicator lights
- ⑪ Reverse lights
- ⑫ High-mount brake light

**6-30**

\*Some models.

- ⑬ Number plate lights
- ⑭ Overhead lights (Front)/Map lights
- ⑮ Boot light (Saloon)
- ⑯ Luggage compartment light (Hatchback)

**CAUTION**

*When removing the lens or lamp unit using a flathead screwdriver, make sure that the flathead screwdriver does not contact the interior terminal. If the flathead screwdriver contacts the terminal, a short circuit may occur.*

**NOTE**

- To replace the bulb, contact an expert repairer (we recommend an Authorised Mazda Repairer).
- Use the protective cover and carton for the replacement bulb to dispose of the old bulb promptly and out of the reach of children.


**▼ Replacing Exterior Light Bulbs**

**Headlights, Running lights/Position lights (Type A), Side direction indicator lights, High-mount brake light**

The LED bulb cannot be replaced as a single unit because it is an integrated unit. The LED bulb has to be replaced with the unit. We recommend an Authorised Mazda Repairer when the replacement is necessary.


**Front direction indicator lights, Position lights (Type B)**

1. If you are changing the right bulb, start the engine, turn the steering wheel all the way to the left, and turn off engine. If you are changing the left bulb, turn the steering wheel to the right, and turn off engine.
2. Make sure the headlight switch is off.
3. Pull the centre of each plastic retainer and remove the retainers.




## Owner Maintenance

4. Turn the screw anticlockwise and remove it, and then partially peel back the mudguard.




5. Turn the socket and bulb assembly anticlockwise and remove it.
6. Disconnect the bulb from the socket.

### Front direction indicator lights



### Position lights (Type B)




7. Install the new bulb in the reverse order of the removal procedure.

6-32

### Rear direction indicator lights, Brake lights/Tail lights


#### Saloon

1. Make sure the ignition is switched off, and the headlight switch is off.
2. Remove the cover.




3. Turn the socket and bulb assembly anticlockwise and remove it.
4. Disconnect the bulb from the socket.

### Rear direction indicator lights



### Brake lights/Tail lights




5. Install the new bulb in the reverse order of the removal procedure.
6. Insert the cover tabs and install the cover.

#### **NOTE**


*Verify that the cover is securely installed.*

### Hatchback

1. Make sure the ignition is switched off, and the headlight switch is off.
2. Turn the bolts anticlockwise and remove them.




3. Pull the unit rearward to remove it.




4. Turn the socket and bulb assembly anticlockwise and remove it.
5. Disconnect the bulb from the socket.

### Rear direction indicator lights



### Brake lights/Tail lights




6. Install the new bulb in the reverse order of the removal procedure.

## Owner Maintenance


### Reverse lights

#### Saloon

1. Make sure the ignition is switched off, and the headlight switch is off.
2. Pull the centre of each plastic retainer and remove the retainers.
3. Peel back the boot lid trim.




4. Disconnect the electrical connector from the bulb by pressing the tab on the connector with your finger and pulling the connector.



5. Turn the socket and bulb assembly anticlockwise and remove it.

6. Disconnect the bulb from the socket.



7. Install the new bulb in the reverse order of the removal procedure.

#### Hatchback

The LED bulb cannot be replaced as a single unit because it is an integrated unit. The LED bulb has to be replaced with the unit. We recommend an Authorised Mazda Repairer when the replacement is necessary.


### Number plate lights

#### Saloon


1. Make sure the ignition is switched off, and the headlight switch is off.
2. Pull the centre of each plastic retainer and remove the retainers.



3. Peel back the boot lid trim.



4. Turn the socket and bulb assembly anticlockwise and remove it.
5. Disconnect the bulb from the socket.




6. Install the new bulb in the reverse order of the removal procedure.


#### Hatchback

1. Make sure the ignition is switched off, and the headlight switch is off.
2. Wrap a flathead screwdriver with a soft cloth to prevent damage to the light unit.


3. Insert a flathead screwdriver into the position shown in the figure and pull the light unit outward.



4. Disconnect the electrical connector from the bulb by pressing the tab on the connector with your finger and pulling the connector.



5. Turn the socket and bulb assembly anticlockwise and remove it.
6. Disconnect the bulb from the socket.





7. Install the new bulb in the reverse order of the removal procedure.

## Owner Maintenance

### ▼ Replacing Interior Light Bulbs

#### Overhead lights/Map lights

1. Wrap a small flathead screwdriver with a soft cloth to prevent damage to the lens, and then remove the lens by carefully prying on the edge of the lens with the flathead screwdriver.
2. Disconnect the bulb by pulling it out.




3. Install the new bulb in the reverse order of the removal procedure.

#### Boot light (Saloon)

1. Press both sides of the lens cap to remove it.




2. Disconnect the bulb by pulling it out.



3. Install the new bulb in the reverse order of the removal procedure.

#### Luggage compartment light (Hatchback)

1. Wrap a small flathead screwdriver with a soft cloth to prevent damage to the lens and remove the lens by carefully prying on the edge of the lens with the flathead screwdriver.
2. Disconnect the bulb by pulling it out.



3. Install the new bulb in the reverse order of the removal procedure.

## Fuses

Your vehicle's electrical system is protected by fuses.

If any lights, accessories, or controls do not work, inspect the appropriate circuit protector. If a fuse has blown, the inside element will be melted.


If the same fuse blows again, avoid using that system and consult an expert repairer (we recommend an Authorised Mazda Repairer) as soon as possible.

### ▼ Fuse Replacement


#### Replacing the fuses on the vehicle's left side

If the electrical system does not work, first inspect the fuses on the vehicle's left side.


1. Make sure the ignition is switched off, and other switches are off.
2. Open the fuse panel cover.




3. Pull the fuse straight out with the fuse puller provided on the fuse block located in the engine compartment.



4. Inspect the fuse and replace it if it is blown.



Normal



Blown

5. Insert a new fuse of the same amperage rating, and make sure it fits tightly. If it does not fit tightly, have an expert install it. We recommend an Authorised Mazda Repairer. If you have no spare fuses, borrow one of the same rating from a circuit not essential to vehicle operation, such as the AUDIO or OUTLET circuit.

### **CAUTION**

*Always replace a fuse with a genuine Mazda fuse or equivalent of the same rating. Otherwise you may damage the electric system.*

6. Reinstall the cover and make sure that it is securely installed.


## Owner Maintenance

### Replacing the fuses under the bonnet


If the headlights or other electrical components do not work and the fuses in the cabin are normal, inspect the fuse block under the bonnet.

If a fuse is blown, it must be replaced. Follow these steps:


1. Make sure the ignition is switched off, and other switches are off.
2. Remove the fuse block cover.



3. If any fuse but the MAIN fuse is blown, replace it with a new one **of the same amperage rating**.



Normal



Blown

### **WARNING**


***Do not replace the main fuse by yourself. Have an expert repairer (we recommend an Authorised Mazda Repairer) perform the replacement:***

*Replacing the fuse by yourself is dangerous because the MAIN fuse is a high current fuse. Incorrect replacement could cause an electrical shock or a short circuit resulting in a fire.*

4. Reinstall the cover and make sure that it is securely installed.

▼ Fuse Panel Description

Fuse block (Engine compartment)




| DESCRIPTION |                | FUSE RATING | PROTECTED COMPONENT                |
|-------------|----------------|-------------|------------------------------------|
| 1           | C/U IG1        | 15 A        | For protection of various circuits |
| 2           | ENGINE IG1     | 7.5 A       | Engine control system              |
| 3           | SUNROOF        | 10 A        | —                                  |
| 4           | INTERIOR       | 15 A        | For protection of various circuits |
| 5           | ENG+B          | 7.5 A       | Engine control system              |
| 6           | AUDIO2/ENGINE4 | 15 A        | Engine control system              |
| 7           | METER1         | 10 A        | Instrument cluster                 |
| 8           | SRS1           | 7.5 A       | Air bag                            |
| 9           | METER2         | 7.5 A       | Instrument cluster                 |
| 10          | RADIO          | 7.5 A       | Audio system                       |
| 11          | ENGINE3        | 15 A        | Engine control system              |
| 12          | ENGINE1        | 15 A        | —                                  |
| 13          | ENGINE2        | 15 A        | Engine control system              |
| 14          | AUDIO1         | 25 A        | Audio system                       |
| 15          | A/C MAG        | 7.5 A       | Air conditioner                    |
| 16          | AT PUMP        | 15 A        | Transaxle control system*          |

\*Some models.

## Owner Maintenance

| DESCRIPTION |                  | FUSE RATING | PROTECTED COMPONENT                                 |
|-------------|------------------|-------------|-----------------------------------------------------|
| 17          | AT               | 15 A        | Transaxle control system                            |
| 18          | D.LOCK           | 25 A        | Power door locks                                    |
| 19          | H/L RH           | 20 A        | Headlights (Low/High beam)                          |
| 20          | ENG+B2           | 7.5 A       | Engine control system                               |
| 21          | TAIL             | 20 A        | Tail lights, Number plate lights, Position lights   |
| 22          | ST.HEATER        | 15 A/20 A   | Headlights*                                         |
| 23          | ROOM             | 25 A        | For protection of various circuits                  |
| 24          | FOG              | 15 A        | —                                                   |
| 25          | H/CLEAN          | 20 A        | —                                                   |
| 26          | STOP             | 10 A        | Brake lights                                        |
| 27          | HORN             | 15 A        | Horn                                                |
| 28          | H/L LH           | 20 A        | Headlights (Low/High beam)                          |
| 29          | ABS/DSC S        | 30 A        | ABS, Dynamic stability control system               |
| 30          | HAZARD           | 15 A        | Hazard warning flashers, Direction indicator lights |
| 31          | FUEL PUMP/SCR    | 15 A        | Fuel system                                         |
| 32          | FUEL WARM        | 25 A        | —                                                   |
| 33          | WIPER            | 20 A        | Front window wiper                                  |
| 34          | CABIN+B          | 50 A        | For protection of various circuits                  |
| 35          | FAN2/EPB L       | 30 A        | Cooling fan                                         |
| 36          | FUEL PUMP        | 30 A        | —                                                   |
| 37          | ABS/DSC M        | 50 A        | ABS, Dynamic stability control system               |
| 38          | EVVT             | 20 A        | Engine control system*                              |
| 39          | —                | —           | —                                                   |
| 40          | FAN1/EPB R       | 30 A        | Cooling fan                                         |
| 41          | FAN3             | 40 A        | —                                                   |
| 42          | ENG.MAIN         | 40 A        | Engine control system                               |
| 43          | EPS              | 60 A        | —                                                   |
| 44          | DEFOG            | 40 A        | Rear window defogger                                |
| 45          | IG2              | 30 A        | For protection of various circuits                  |
| 46          | INJECTOR/ENG.SUB | 30 A        | Engine control system                               |
| 47          | HEATER           | 40 A        | Air conditioner                                     |
| 48          | P.WINDOW1        | 30 A        | Power windows                                       |
| 49          | DCDC DE          | 40 A        | —                                                   |

**Fuse block (Left side)**



| DESCRIPTION |           | FUSE RATING | PROTECTED COMPONENT          |
|-------------|-----------|-------------|------------------------------|
| 1           | —         | —           | —                            |
| 2           | —         | —           | —                            |
| 3           | AUDIO2    | 15 A        | Audio system                 |
| 4           | ST.HEATER | 15 A        | —                            |
| 5           | F.OUTLET  | 15 A        | Accessory sockets            |
| 6           | —         | —           | —                            |
| 7           | AT IND    | 7.5 A       | AT shift indicator*          |
| 8           | MIRROR    | 7.5 A       | Power mirror                 |
| 9           | —         | —           | —                            |
| 10          | P.WINDOW2 | 25 A        | Power windows                |
| 11          | R.WIPER   | 15 A        | Rear window wiper and washer |
| 12          | P.SEAT D  | 30 A        | —                            |
| 13          | —         | —           | —                            |
| 14          | SRS2/ESCL | 15 A        | Electronic steering lock     |
| 15          | SEAT WARM | 20 A        | —                            |
| 16          | M.DEF     | 7.5 A       | —                            |

\*Some models. **6-41**

## Owner Maintenance

---

### Emission Control Maintenance (Australia)

Emission control maintenance is periodically required to ensure proper emission control and engine performance. Refer to scheduled maintenance (page 6-3) for information on when and how to perform the following inspections and servicing items.

For owners with a Mazda Workshop Manual, refer to the sections on Predelivery Inspection and Scheduled Maintenance.

#### ▼ Engine

##### Drive belts

Inspect the belts for cracks and other damage. Replace if necessary.

##### Engine oil

When changing the engine oil, use API SL/SM/SN or ILSAC GF-III/GF-IV/GF-V oil of the proper viscosity for your climate.

Change it more frequently during heavy use under any of these conditions:

1. Dusty environment
2. Extended idling or low-speed operations
3. Driving for a prolonged period in cold temperatures or in an extremely humid climate
4. Repeated short-distance driving

##### Oil filter

Do not fail to change the oil filter as prescribed. As with the engine oil, under severe driving conditions, the filter should be changed more frequently.

##### Cooling system

When inspecting hoses (including the heater hose), connections, and clamps, look for leaks, swellings, cracks, and other damage. Replace any defective hose or part.

##### Engine coolant

Change the coolant and flush the cooling system as prescribed.

#### ▼ Fuel System and Air-Intake Control System

##### Fuel lines and hoses

When inspecting the fuel pipes, hoses, connections and clamps, look for leaks, deterioration, and other damage.

Replace any defective hose or part.



## Owner Maintenance

---

### Air filter

Besides replacing the filter regularly, always replace it if it is torn or otherwise damaged. Inspect and replace it more often than prescribed if the vehicle is used in very dusty or sandy areas.

### ▼ Ignition System

#### Spark plugs

To maintain proper engine operation and emission control, spark plugs must always be in good condition.

### ▼ Evaporative Emission Control System

When inspecting evaporative line hoses and connections (including the fuel tank and filler cap), apply pressure to determine pressure-holding capacity. Replace any damaged or deteriorated parts.

## Appearance Care

---

### Exterior Care

The paintwork on your Mazda represents the latest technical developments in composition and methods of application.

Environmental hazards, however, can harm the paint's protective properties, if proper care is not taken.

Here are some examples of possible damage, with tips on how to prevent them.

#### Etching Caused by Acid Rain or Industrial Fallout

##### Occurrence

Industrial pollutants and vehicle emissions drift into the air and mix with rain or dew to form acids. These acids can settle on a vehicle's finish. As the water evaporates, the acid becomes concentrated and can damage the finish.

And the longer the acid remains on the surface, the greater the chance is for damage.

##### Prevention

It is necessary to wash and wax your vehicle to preserve its finish according to the instructions in this section. These steps should be taken immediately after you suspect that acid rain has settled on your vehicle's finish.

#### Damage Caused by Bird Dropping, Insects, or Tree Sap

##### Occurrence

Bird droppings contain acids. If these are not removed they can eat away the clear and colour base coat of the vehicle's paintwork.

When insects stick to the paint surface and decompose, corrosive compounds form. These can erode the clear and colour base coat of the vehicle's paintwork if they are not removed.

Tree sap will harden and adhere permanently to the paint finish. If you scratch the sap off while it is hard, some vehicle paint could come off with it.

##### Prevention

It is necessary to have your Mazda washed and waxed to preserve its finish according to the instructions in this section. This should be done as soon as possible.

Bird droppings can be removed with a soft sponge and water. If you are travelling and these are not available, a moistened tissue may also take care of the problem. The cleaned area should be waxed according to the instructions in this section.

Insects and tree sap are best removed with a soft sponge and water or a commercially available chemical cleaner.

Another method is to cover the affected area with dampened newspaper for 1 to 2 hours. After removing the newspaper, rinse off the loosened debris with water.

## Appearance Care

### Water Marks

#### Occurrence

Rain, fog, dew, and even tap water can contain harmful minerals such as salt and lime. If moisture containing these minerals settles on the vehicle and evaporates, the minerals will concentrate and harden to form white rings. The rings can damage your vehicle's finish.

#### Prevention

It is necessary to wash and wax your vehicle to preserve its finish according to the instructions in this section. These steps should be taken immediately after you find water marks on your vehicle's finish.

### Paint Chipping

#### Occurrence

Paint chipping occurs when gravel thrown in the air by another vehicle's tyres hits your vehicle.

#### How to avoid paint chipping

Keeping a safe distance between you and the vehicle ahead reduces the chances of having your paint chipped by flying gravel.

#### NOTE

- The paint chipping zone varies with the speed of the vehicle. For example, when travelling at 90 km/h (56 mph), the paint chipping zone is 50 m (164 ft).
- In low temperatures a vehicle's finish hardens. This increases the chance of paint chipping.

- Chipped paint can lead to rust forming on your Mazda. Before this happens, repair the damage by using Mazda touch-up paint according to the instructions in this section. Failure to repair the affected area could lead to serious rusting and expensive repairs.

Follow **all** label and container directions when using a chemical cleaner or polish. Read all warnings and cautions.

### ▼ Maintaining the Finish

#### Washing

#### CAUTION

- When the wiper lever is in the AUTO position and the ignition is switched ON, the wipers may move automatically in the following cases:
  - If the windscreen above the rain sensor is touched or wiped with a cloth.
  - If the windscreen is struck with a hand or other object from either outside or inside the vehicle.

Keep hands and scrapers clear of the windscreen when the wiper lever is in the AUTO position and the ignition is switched ON as fingers could be pinched or the wipers and wiper blades damaged when the wipers activate automatically. If you are going to clean the windscreen, be sure the wipers are turned off completely (when it is most likely that the engine is left running) this is particularly important when clearing ice and snow.

## Appearance Care

---

- *Do not spray water in the engine compartment. Otherwise, it could result in engine-starting problems or damage to electrical parts.*
- *When washing and waxing the vehicle, be careful not to apply excessive force to any single area of the vehicle roof or the aerial. Otherwise, you could dent the vehicle or damage the aerial.*

To help protect the finish from rust and deterioration, wash your Mazda thoroughly and frequently, at least once a month, with lukewarm or cold water.

If the vehicle is washed improperly, the paint surface could be scratched. Here are some examples of how scratching could occur.

Scratches occur on the paint surface when:

- The vehicle is washed without first rinsing off dirt and other foreign matter.
- The vehicle is washed with a rough, dry, or dirty cloth.
- The vehicle is washed at a car wash that uses brushes that are dirty or too stiff.
- Cleansers or wax containing abrasives are used.

### NOTE

- *Mazda is not responsible for scratches caused by automatic car washes or improper washing.*
- *Scratches are more noticeable on vehicles with darker paint finishes.*

To minimize scratches on the vehicle's paint finish:

- Rinse off any dirt or other foreign matter using lukewarm or cold water before washing.
- Use plenty of lukewarm or cold water and a soft cloth when washing the vehicle. Do not use a nylon cloth.
- Rub gently when washing or drying the vehicle.
- Take your vehicle only to a car wash that keeps its brushes well maintained.
- Do not use abrasive cleansers or wax that contain abrasives.

### CAUTION

- *Do not use steel wool, abrasive cleaners, or strong detergents containing highly alkaline or caustic agents on chrome-plated or anodised aluminium parts. This may damage the protective coating; also, cleaners and detergents may discolour or deteriorate the paint.*

### ➤ **(With detachable aerial)**

*To prevent damaging the aerial, remove it before entering a car wash facility or passing beneath a low overhead clearance.*

Pay special attention to removing salt, dirt, mud, and other foreign material from the underside of the wings, and make sure the drain holes in the lower edges of the doors and rocker panels are clean.

## Appearance Care

Insects, tar, tree sap, bird droppings, industrial fallout, and similar deposits can damage the finish if not removed immediately. When prompt washing with plain water is ineffective, use a mild soap made for use on vehicles.

Thoroughly rinse off all soap with lukewarm or cold water. Do not allow soap to dry on the finish.

After washing the vehicle, dry it with a clean chamois to prevent water spots from forming.

### **WARNING**

***Dry off brakes that have become wet by driving slowly, releasing the accelerator pedal and lightly applying the brakes several times until the brake performance returns to normal:***

*Driving with wet brakes is dangerous. Increased stopping distance or the vehicle pulling to one side when braking could result in a serious accident. Light braking will indicate whether the brakes have been affected.*

### **When using an automatic car wash**

- Retract the door mirrors.
- The automatic car wash brushes could reduce the paint lustre or hasten paint deterioration.

### **When using a high water pressure car wash**

High water temperature and high water pressure car washers are available depending on the type of car wash machine. If the car washer nozzle is put too close to the vehicle, the force of the spray could damage or deform the molding, affect the sealability of parts, and allow water to penetrate the interior. Keep a sufficient space (30 cm (12 in) or more) between the nozzle and the vehicle. In addition, do not spend too much time spraying the same area of the vehicle, and be very careful when spraying between gaps in doors and around windows.

### **Waxing**

Your vehicle needs to be waxed when water no longer beads on the finish. Always wash and dry the vehicle before waxing it. In addition to the vehicle body, wax the metal trim to maintain its lustre.

1. Use wax which contains no abrasives. Wax containing abrasives will remove paints and could damage bright metal parts.
2. Use a good grade of natural wax for metallic, mica, and solid colours.
3. When waxing, coat evenly with the sponge supplied or a soft cloth.
4. Wipe off the wax with a soft cloth.

### ***NOTE***

*A spot remover to remove oil, tar, and similar materials will usually also take off the wax. Rewax these areas even if the rest of the vehicle does not need it.*

## Appearance Care

### ▼ Paint Damage Touch-up

Repair damage to the finish caused by stone chipping, damage during parking etc., by using Mazda touch-up paint before rust begins to form. First, remove the dirt and grease with a clean soft cloth.

If rust has already begun to form:

1. Remove rust completely with sandpaper.
2. Wipe with a clean soft cloth.
3. Apply rust preventive primer to the area.
4. After drying it completely, apply a suitable top coat material to the area.

Of course there will be no problem if you assign the work to an expert repairer (we recommend an Authorised Mazda Repairer).

### ▼ Cavity Protection

Cavities are treated for protection at the factory, but additional protective treatment after the vehicle has been put into use will extend the life of the body.

Consult an expert repairer (we recommend an Authorised Mazda Repairer) concerning this additional precaution.

### ▼ Bright-Metal Maintenance

- Use tar remover to remove road tar and insects. Never do this with a knife or similar tool.
- To prevent corrosion on bright-metal surfaces, apply wax or chrome preservative and rub it to a high lustre.

- During cold weather or in coastal areas, cover bright-metal parts with a coating of wax or preservative heavier than usual. It would also help to coat them with noncorrosive petroleum jelly or some other protective compound.

### CAUTION

*Do not use steel wool, abrasive cleaners, or strong detergents containing highly alkaline or caustic agents on chrome-plated or anodised aluminium parts. This may result in damage to the protective coating and cause discolouration or paint deterioration.*

### ▼ Undercoating

This special coating is applied to the critical parts of the underside to protect vehicles from damage caused by chemicals or stones. This coating is liable to be damaged with time. Check this coating periodically.

Should repairs be necessary, consult an expert repairer (we recommend an Authorised Mazda Repairer). They are well informed on how repairs should be made.

### ▼ Aluminium Wheel Maintenance\*

A protective coating is provided over the aluminium wheels. Special care is needed to protect this coating.

## Appearance Care

### CAUTION

*Do not use any detergent other than mild detergent. Before using any detergent, verify the ingredients. Otherwise, the product could discolour or stain the aluminium wheels.*

### NOTE

- *Do not use a wire brush or any abrasive cleaner, polishing compound, or solvent on aluminium wheels. They may damage the coating.*
- *Always use a sponge or soft cloth to clean the wheels.*  
*Rinse the wheels thoroughly with lukewarm or cold water. Also, be sure to clean the wheels after driving on dusty or salted roads to help prevent corrosion.*
- *Avoid washing your vehicle in an automatic car wash that uses high-speed or hard brushes.*

### ▼ Plastic Part Maintenance

- When cleaning the plastic lenses of the lights, do not use petrol, paraffin, rectified spirit, paint, thinner, highly acidic detergents, or strongly alkaline detergents. Otherwise, these chemical agents can discolour or damage the surfaces resulting in a significant loss in functionality. If plastic parts become inadvertently exposed to any of these chemical agents, flush with water immediately.

- If plastic parts such as the bumpers become inadvertently exposed to chemical agents or fluids such as petrol, oil, engine coolant, or battery fluid, it could cause discolouration, staining, or paint peeling. Wipe off any such chemical agents or fluids using a soft cloth immediately.
- High water temperature and high water pressure car washers are available depending on the type of high pressure car washer device. If the car washer nozzle is put too close to the vehicle or aimed at one area for an extended period of time, it could deform plastic parts or damage the paint.
- Do not use wax containing compounds (polish). Otherwise, it could result in paint damage.
- In addition, do not use an electrical or air tool to apply wax. Otherwise, the frictional heat generated could result in deformation of plastic parts or paint damage.

## Appearance Care

### Interior Care

#### **WARNING**

**Do not spray water into the vehicle cabin:**

*Spraying water into the vehicle cabin is dangerous as electrical devices such as the audio and switches could get wet resulting in a malfunction or vehicle fire.*

**NOTE**

- Do not wipe the interior using alcohol, chlorine bleach, or organic solvents such as thinner, benzene, and petrol. Otherwise, it may cause discolouration or stains.
- Rubbing hard with a stiff brush or cloth may cause damage.

If the vehicle interior becomes soiled by any of the following, wipe it off immediately using a soft cloth. Leaving it uncleaned could cause discolouration, stains, cracks, or peeling of the coating, and it will make it hard to wipe off later.

- Beverage or fragrance
- Grease or oil
- Soiling

#### ▼ **Seat Belt Maintenance**

1. Clean the soiled area by lightly dabbing it with a soft cloth soaked in a mild detergent (approx. 5%) diluted with water.
2. Wipe off the remaining detergent using a cloth soaked in clean water and wrung out well.

3. Before retracting seat belts which have been pulled out for cleaning, dry them off thoroughly and make sure there is no remaining moisture on them.

#### **WARNING**

**If a seat belt appears frayed or has abrasions, have it replaced by an expert repairer (we recommend an Authorised Mazda Repairer):**

*If a seat belt is used under such a condition, it cannot function at its full capacity which could result in serious injury or death.*

#### **Use a mild detergent to remove soiling from a seat belt:**

*If organic solvents are used for cleaning the seat belts or they become stained or bleached, there is the possibility of them becoming weakened and as a result, they may not function at their full capacity which could cause serious injury or death.*

**NOTE**

*Clean seat belts diligently if they get dirty. Leaving them uncleaned will make it difficult to clean them later, and it may affect the smooth retracting of the seat belt.*

#### ▼ **Vinyl Upholstery Maintenance**

Remove dust and dirt from the vinyl upholstery using a brush or vacuum. Remove soiling from vinyl upholstery using a leather and vinyl upholstery cleaner.



## Appearance Care

### ▼ Upholstery Maintenance

1. Clean the soiled area by lightly dabbing it with a soft cloth soaked in a mild detergent (approx. 5%) diluted with water.
2. Wipe off the remaining detergent using a cloth soaked in clean water and wrung out well.

### ▼ Leather Upholstery Maintenance\*

1. Remove dust and sand using a vacuum cleaner.
2. Wipe off the soiled area with a soft cloth and a suitable, special cleaner or a soft cloth soaked in a mild detergent (about 5%) diluted with water.
3. Wipe off the remaining detergent using a cloth soaked in clean water and wrung out well.
4. Remove moisture with a dry, soft cloth and allow the leather to further dry in a well-ventilated, shaded area. If the leather gets wet such as from rain, remove the moisture and dry it as soon as possible.

#### NOTE

- Because genuine leather is a natural material, its surface is not uniform and it may have natural scars, scratches, and wrinkles.
- To maintain the quality for as long as possible, periodical maintenance, about twice a year, is recommended.
- If the leather upholstery comes into contact with any of the following, clean it immediately.  
Leaving it uncleaned could cause premature wear, mold, or stains.
  - Sand or dirt
  - Grease or oil, such as hand cream

- Alcohol, such as in cosmetic or hair dressing items
- If the leather upholstery gets wet, promptly remove moisture with a dry cloth. Remaining moisture on the surface may cause deterioration such as hardening and shrinkage.
- Exposure to direct sunlight for long periods may cause deterioration and shrinkage. When parking the car under direct sunlight for long periods, shade the interior using sunshades.
- Do not leave vinyl products on the leather upholstery for long periods. They may affect the leather quality and colouring. If the cabin temperature becomes hot, the vinyl may deteriorate and adhere to the genuine leather.

### ▼ Plastic Part Maintenance

#### CAUTION

Do not use polishing agents.  
Depending on the product ingredients, they could cause discolouration, stains, cracks or peeling of the coating.

### ▼ Instrument Panel Top Maintenance

1. Wipe the soiled area with a soft cloth soaked in a mild detergent (approx. 5%) diluted with water.
2. Wipe off the remaining detergent using a cloth soaked in clean water and wrung out well.

\*Some models.

## Appearance Care

---

### ▼ Active Driving Display Maintenance\*

The combiner and mirror surface have a special coating. When cleaning it, do not use a hard cloth, a cloth with a rough surface, or cleaning detergent. Use a fine-textured, soft cloth.

If a chemical solvent gets on the combiner or mirror surface, wipe it off immediately. Otherwise, they could be damaged and the surface coating could be scratched.

### ▼ Panel Maintenance

If a panel becomes soiled, wipe it off with a soft cloth soaked in clean water and thoroughly wrung out.

If some areas require further cleaning, use the following procedure:

1. Wipe the soiled area with a soft cloth soaked in a mild detergent (approx. 5 %) diluted with water.
2. Wipe off the remaining detergent using a cloth soaked in clean water and wrung out well.

#### **NOTE**

*Be particularly careful when cleaning shiny surface panels and metallic parts such as plating as they can be scratched easily.*

### ▼ Cleaning the Window Interiors

If the windows become covered with an oily, greasy, or waxy film, clean them with glass cleaner. Follow the directions on the container.

### CAUTION

- *Do not scrape or scratch the inside of the window glass. It could damage the thermal filaments.*
- *When washing the inside of the window glass, use a soft cloth dampened in lukewarm water, gently wiping the thermal filaments.*  
*Use of glass cleaning products could damage the thermal filaments.*

# 7

## If Trouble Arises

Helpful information on what to do if a problem arises with the vehicle.

|                                     |             |                                         |             |
|-------------------------------------|-------------|-----------------------------------------|-------------|
| <b>Parking in an Emergency.....</b> | <b>7-2</b>  | <b>Towing/Tiedown Hooks.....</b>        | <b>7-21</b> |
| Parking in an Emergency.....        | 7-2         |                                         |             |
| <b>Flat Tyre.....</b>               | <b>7-3</b>  | <b>Warning/Indicator Lights and</b>     |             |
| Spare Tyre and Tool Storage.....    | 7-3         | <b>Warning Sounds.....</b>              | <b>7-23</b> |
| Changing a Flat Tyre.....           | 7-7         | If a Warning Light Turns On or          |             |
|                                     |             | Flashes.....                            | 7-23        |
| <b>Battery Runs Out.....</b>        | <b>7-14</b> | Message Indicated on                    |             |
| Jump-Starting.....                  | 7-14        | Display.....                            | 7-35        |
|                                     |             | Warning Sound is Activated.....         | 7-37        |
| <b>Emergency Starting.....</b>      | <b>7-17</b> | <b>When Liftgate/Boot Lid Cannot be</b> |             |
| Starting a Flooded Engine.....      | 7-17        | <b>Opened.....</b>                      | <b>7-42</b> |
| Push-Starting.....                  | 7-17        | When Liftgate/Boot Lid Cannot be        |             |
|                                     |             | Opened.....                             | 7-42        |
| <b>Overheating.....</b>             | <b>7-18</b> | <b>Active Driving Display Does Not</b>  |             |
| Overheating.....                    | 7-18        | <b>Operate.....</b>                     | <b>7-44</b> |
| <b>Emergency Towing.....</b>        | <b>7-20</b> | If the Active Driving Display Does      |             |
| Towing Description.....             | 7-20        | Not Operate.....                        | 7-44        |


If Trouble Arises

## Parking in an Emergency

---

### Parking in an Emergency

The hazard warning lights should always be used when you stop on or near a roadway in an emergency.



The hazard warning lights warn other drivers that your vehicle is a traffic hazard and that they must take extreme caution when near it.



Depress the hazard warning flasher and all the direction indicators will flash. The hazard warning indicator lights in the instrument cluster flash simultaneously.


#### **NOTE**

- The direction indicators do not work when the hazard warning lights are on.
- Check local regulations about the use of hazard warning lights while the vehicle is being towed to verify that it is not in violation of the law.

## Spare Tyre and Tool Storage


Spare tyre and tools are stored in the locations illustrated in the diagram.

### Saloon



\*1 The jack point attachment can be used by vehicle repair shops and road assistance services. Consult an Authorised Mazda Repairer for details.

### Hatchback



If Trouble Arises


## Flat Tyre

### ▼ Jack


#### To remove the jack

##### Saloon

1. Lift the boot mat.
2. Remove the boot board.




3. Turn the wing bolt and jack screw anticlockwise.




##### Hatchback

1. Remove the cover.



2. Turn the wing bolt and jack screw anticlockwise.




#### To secure the jack

1. Insert the wing bolt into the jack with the jack screw pointing to the right (Saloon) or down (Hatchback) and turn the wing bolt clockwise to temporarily tighten it.


## Flat Tyre

- Turn the jack screw in the direction shown in the figure.

### Saloon



### Hatchback



- Turn the wing bolt completely to secure the jack.

### NOTE

*If the jack is not completely secured, it could rattle while driving. Make sure the jack screw is sufficiently tightened.*

- Return the boot board to its original position (Saloon), or insert the cover tabs and install the cover (Hatchback).

### NOTE

*Verify that the cover is securely installed.*

### Maintenance

- Always keep the jack clean.
- Make sure the moving parts are kept free from dirt or rust.
- Make sure the screw thread is adequately lubricated.

### ▼ Spare Tyre

Your Mazda has a temporary spare tyre. The temporary spare tyre is lighter and smaller than a conventional tyre, and is designed only for emergency use and should be used only for VERY short periods. Temporary spare tyres should NEVER be used for long drives or extended periods.

### ⚠ WARNING

#### **Do not install the temporary spare tyre on the front wheels (driving wheels):**

*Driving with the temporary spare tyre on one of the front driving wheels is dangerous. Handling will be affected. You could lose control of the vehicle, especially on ice or snow bound roads, and have an accident. Move a regular tyre to the front wheel and install the temporary spare tyre to the rear.*

### ⚠ CAUTION

- *When using the temporary spare tyre, driving stability may decrease compared to when using only the conventional tyre. Drive carefully.*

If Trouble Arises


## Flat Tyre

➤ To avoid damage to the temporary spare tyre or to the vehicle, observe the following precautions:

- Do not exceed 80 km/h (50 mph).
- Avoid driving over obstacles. Also, do not drive through an automatic car wash. This tyre's diameter is smaller than a conventional tyre, so the ground clearance is reduced.
- Do not use a tyre chain on this tyre because it will not fit properly.
- Do not use your temporary spare tyre on any other vehicle, it has been designed only for your Mazda.
- Use only one temporary spare tyre on your vehicle at the same time.


### To remove the spare tyre

1. Lift the boot/luggage compartment mat.



2. Turn the spare tyre hold-down bolt anticlockwise.

Spare tyre hold-down bolt



### To secure the spare tyre

Store the spare tyre in the reverse order of removal. After storing, verify that the spare tyre is stored securely.



## Changing a Flat Tyre

**NOTE**

*If the following occurs while driving, it could indicate a flat tyre.*

- *Steering becomes difficult.*
- *The vehicle begins to vibrate excessively.*
- *The vehicle pulls in one direction.*

If you have a flat tyre, drive slowly to a level spot that is well off the road and out of the way of traffic to change the tyre. Stopping in traffic or on the shoulder of a busy road is dangerous.

**⚠ WARNING*****Be sure to follow the directions for changing a tyre:***

*Changing a tyre is dangerous if not done properly. The vehicle can slip off the jack and seriously injure someone.*

*No person should place any portion of their body under a vehicle that is supported by a jack.*

***Never allow anyone inside a vehicle supported by a jack:***


*Allowing someone to remain in a vehicle supported by a jack is dangerous. The occupant could cause the vehicle to fall resulting in serious injury.*

**NOTE**

*Make sure the jack is well lubricated before using it.*

1. Park on a hard, level surface off the right-of-way and firmly set the parking brake.

2. Put a vehicle with an automatic transaxle in Park (P), a manual transaxle in Reverse (R) or 1, and turn off the engine.
3. Turn on the hazard warning flasher.
4. Have passengers get out of the vehicle and away from the vehicle and traffic.
5. Remove any luggage, the jack, tools, and spare tyre (page 7-3).
6. Block the wheel diagonally opposite the flat tyre. When blocking a wheel, place a tyre block both in front and behind the tyre.

**NOTE**

*When blocking a tyre, use rocks or wood blocks of sufficient size if possible to hold the tyre in place.*

## Flat Tyre


### ▼ Removing a Flat Tyre

#### **WARNING**

**When jacking-up a vehicle, always shift the shift lever to 1st or R position (manual transaxle vehicle) or shift the selector lever to P position (automatic transaxle vehicle), apply the parking brake, and place wheel blocks in the position diagonally opposed to the jack:**

Changing a flat tyre without using wheel blocks is dangerous because the vehicle may move and fall off the jack even with the shift lever in 1st or R position, or the selector lever is in P position, which could result in an accident.

1. If your vehicle is equipped with a wheel cover, pry off the wheel cover with the bevelled end of the jack lever.




#### **NOTE**

*Force the end of the jack lever firmly between wheel and cover, or removal will be difficult.*


#### **CAUTION**

*Align the notch on the wheel cover with the valve stem when installing it.*



*Damage could occur during installation if the wheel cover is not properly aligned.*


2. Loosen the wheel nuts by turning them anticlockwise one turn each, but do not remove any wheel nuts until the tyre has been raised off the ground.




3. Place the jack on the ground.

## Flat Tyre


4. Turn the jack screw in the direction shown in the figure and adjust the jack head so that it is close to the jack-up position.



5. Place the jack under the jack-up position closest to the tyre being changed with the jack head squarely under the jack-up point.



6. Continue raising the jack head gradually by rotating the screw with your hand until the jack head is inserted into the jack-up position.



### **WARNING**

***Use only the front and rear jacking positions recommended in this manual:***  
*Attempting to jack the vehicle in positions other than those recommended in this manual is dangerous. The vehicle could slip off the jack and seriously injure or even kill someone. Use only the front and rear jacking positions recommended in this manual.*

If Trouble Arises

## Flat Tyre

***Do not jack up the vehicle in a position other than the designated jack-up position or place any objects on or under the jack:***

*Jacking up the vehicle in a position other than the designated jack-up position or placing objects on or under the jack is dangerous as it could deform the vehicle body or the vehicle could fall off the jack resulting in an accident.*

***Use only the jack provided with your Mazda:***

*Using a jack that is not designed for your Mazda is dangerous. The vehicle could slip off the jack and seriously injure someone.*


***Never place objects under the jack:***

*Jacking the vehicle with an object under the jack is dangerous. The jack could slip and someone could be seriously injured by the jack or the falling vehicle.*

### **NOTE**


*When raising the jack head into the jacking position and aligning the groove in the jack head with the rail under the vehicle body, the top of the jack head contacts the vehicle's underbody without the rail contacting the bottom of the groove.*

7. Insert the jack lever and attach the wheel brace to tyre jack.



## Flat Tyre

8. Turn the jack handle clockwise and raise the vehicle high enough so that the spare tyre can be installed. Before removing the wheel nuts, make sure your Mazda is firmly in position and that it cannot slip or move.



### WARNING

**Do not jack up the vehicle higher than is necessary:**

*Jacking up the vehicle higher than is necessary is dangerous as it could destabilize the vehicle resulting in an accident.*

**Do not start the engine or shake the vehicle while it is jacked up:**

*Starting the engine or shaking the vehicle while it is jacked up is dangerous as it could cause the vehicle to fall off the jack resulting in an accident.*


**Never go under the vehicle while it is jacked up:**

*Going under the vehicle while it is jacked up is dangerous as it could result in death or serious injury if the vehicle were to fall off the jack.*

9. Remove the wheel nuts by turning them anticlockwise; then remove the wheel and centre cap.

### ▼ Mounting the Spare Tyre

1. Remove dirt and grime from the mounting surfaces of the wheel and hub, including the hub bolts, with a cloth.



### WARNING

**Make sure the mounting surfaces of the wheel, hub and wheel nuts are clean before changing or replacing tyres:**


*When changing or replacing a tyre, not removing dirt and grime from the mounting surfaces of the wheel, hub and hub bolts is dangerous. The wheel nuts could loosen while driving and cause the tyre to come off, resulting in an accident.*

2. Mount the spare tyre.

If Trouble Arises

## Flat Tyre

3. Install the wheel nuts with the bevelled edge inward; tighten them by hand.




### **WARNING**

***Do not apply oil or grease to wheel nuts and bolts and do not tighten the wheel nuts beyond the recommended tightening torque:***

*Applying oil or grease to wheel nuts and bolts is dangerous. The wheel nuts could loosen while driving and cause the tyre to come off, resulting in an accident. In addition, wheel nuts and bolts could be damaged if tightened more than necessary.*

4. Turn the wheel brace anticlockwise and lower the vehicle.

5. Use the wheel brace to tighten the nuts in the order shown.



If you are unsure of how tight the nuts should be, have them inspected at an expert repairer (we recommend an Authorised Mazda Repairer).

| Nut tightening torque |                         |
|-----------------------|-------------------------|
| N·m (kgf·m, ft·lbf)   | 108—147 (12—14, 80—108) |

### **WARNING**

***Always securely and correctly tighten the wheel nuts:***

*Improperly or loosely tightened wheel nuts are dangerous. The wheel could wobble or come off. This could result in loss of vehicle control and cause a serious accident.*

***Be sure to reinstall the same nuts you removed or replace them with metric nuts of the same configuration:***

*Because the wheel studs and wheel nuts on your Mazda have metric threads, using a non-metric nut is dangerous. On a metric stud, it would not secure the wheel and would damage the stud, which could cause the wheel to slip off and cause an accident.*

6. Remove the tyre blocks and store the tools and jack.
7. Store the damaged tyre in the luggage compartment.
8. Check the inflation pressure. Refer to Tyres on page 9-6.
9. Have the flat tyre repaired or replaced as soon as possible.

 **WARNING**

***Do not drive with any tyres that have incorrect air pressure:***

*Driving on tyres with incorrect air pressure is dangerous. Tyres with incorrect pressure could affect handling and result in an accident. When you check the regular tyres' air pressure, check the spare tyre, too.*

**NOTE**

*To prevent the jack and tool from rattling, store them properly.*

If Trouble Arises

## Battery Runs Out

### Jump-Starting

Jump-starting is dangerous if done incorrectly. So follow the procedure carefully. If you feel unsure about jump-starting, we strongly recommend that you have a competent service technician do the work.

#### **WARNING**



#### **Follow These Precautions Carefully:**

To ensure safe and correct handling of the battery, read the following precautions carefully before using the battery or inspecting it.



**Keep flames and sparks away from open battery cells and do not allow metal tools to contact the positive (+) or negative (–) terminal of the battery when working near a battery. Do not allow the positive (+) terminal to contact the vehicle body:**

Flames and sparks near open battery cells are dangerous. Hydrogen gas, produced during normal battery operation, could ignite and cause the battery to explode. An exploding battery can cause serious burns and injuries. Keep all flames including cigarettes and sparks away from open battery cells.



**Keep all flames and sparks away from open battery cells because hydrogen gas is produced from open battery cells while charging the battery or adding battery fluid:**

Flames and sparks near open battery cells are dangerous. Hydrogen gas, produced during normal battery operation, could ignite and cause the battery to explode. An exploding battery can cause serious burns and injuries. Keep all flames including cigarettes and sparks away from open battery cells.

**Do not jump-start a frozen battery or one with a low fluid level:**

Jump-starting a frozen battery or one with a low fluid level is dangerous. It may rupture or explode, causing serious injury.

**Connect the negative lead to a good ground point away from the battery:**

Connecting the end of the second jumper lead to the negative (–) terminal of the discharged battery is dangerous.

A spark could cause the gas around the battery to explode and injure someone.



## Battery Runs Out


**Route the jumper leads away from parts that will be moving:**

Connecting a jumper lead near or to moving parts (cooling fans, belts) is dangerous. The lead could get caught when the engine starts and cause serious injury.

**CAUTION**

Use only a 12 V booster system. You can damage a 12 V starter, ignition system, and other electrical parts beyond repair with a 24 V power supply (two 12 V batteries in series or a 24 V motor generator set).

1. Move the booster vehicle so that its battery is as close as possible to your vehicle's battery.
2. Make sure that the power such as for the headlights and air conditioner is turned off.
3. Remove the battery cover.



4. Turn off the booster vehicle's engine and connect the jumper leads in the following order.

Make sure that the jumper leads are securely connected so that they do not disconnect due to engine vibrations.

**1st lead**

- ① Positive (+) terminal on the discharged battery
- ② Positive (+) terminal on booster vehicle's battery


**2nd lead**

- ③ Negative (-) terminal on booster vehicle's battery

If Trouble Arises

## Battery Runs Out

④ Location shown in the figure (do not connect to the negative (-) terminal of the battery)



5. Start the booster vehicle's engine and rev the engine.
6. Start the engine of your vehicle. Run the engines for about 3 minutes to temporarily charge the battery of your vehicle.
7. Disconnect the jumper leads in the reverse order of their connection.
8. Install the battery cover.
9. Have your vehicle inspected by an expert repairer (we recommend an Authorised Mazda Repairer) as soon as possible.

## Emergency Starting

### Starting a Flooded Engine

If the engine fails to start, it may be flooded (excessive fuel in the engine).

Follow this procedure:

1. If the engine does not start within 5 seconds on the first try, wait 10 seconds and try again.
2. Make sure the parking brake is on.
3. Depress the accelerator all the way and hold it there.
4. Depress the clutch pedal (Manual transaxle) or the brake pedal (Automatic transaxle), then press the push button start. If the engine starts, release the accelerator immediately because the engine will suddenly rev up.
5. If the engine fails to start, crank it without depressing the accelerator.

If the engine still does not start using the previous procedure, have your vehicle inspected by an expert repairer (we recommend an Authorised Mazda Repairer).

### Push-Starting

Do not push-start your Mazda.

#### **WARNING**

***Never tow a vehicle to start it:***

*Towing a vehicle to start it is dangerous. The vehicle being towed could surge forward when its engine starts, causing the 2 vehicles to collide. The occupants could be injured.*

#### **CAUTION**

*Do not push-start a vehicle that has a manual transaxle. It can damage the emission control system.*

***NOTE***

*You cannot start a vehicle with an automatic transaxle by pushing it.*

If Trouble Arises

## Overheating

### Overheating

If the high engine coolant temperature warning light turns on, the vehicle loses power, or you hear a loud knocking or pinging noise, the engine is probably too hot.

#### **WARNING**



***Pull over to a safe location, then switch the ignition off and make sure the fan is not running before attempting to work near the cooling fan:***

*Working near the cooling fan when it is running is dangerous. The fan could continue running indefinitely even if the engine has stopped and the engine compartment temperature is high. You could be hit by the fan and seriously injured.*



***Do not remove either cooling system cap when the engine and radiator are hot:***

*When the engine and radiator are hot, scalding coolant and steam may shoot out under pressure and cause serious injury.*

***Open the bonnet ONLY after steam is no longer escaping from the engine:***

*Steam from an overheated engine is dangerous. The escaping steam could seriously burn you.*

If the high engine coolant temperature warning light turns on:

1. Drive safely to the side of the road and park off the right-of-way.
2. Put a vehicle with an automatic transaxle in park (P), a manual transaxle in neutral.
3. Apply the parking brake.
4. Turn off the air conditioner.
5. Check whether coolant or steam is escaping from the engine compartment.

#### **If steam is coming from the engine compartment:**

Do not go near the front of the vehicle. Stop the engine.

Wait until the steam dissipates, then open the bonnet and start the engine.

#### **If neither coolant nor steam is escaping:**

Open the bonnet and idle the engine until it cools.

#### **CAUTION**

*If the cooling fan does not operate while the engine is running, the engine temperature will increase. Stop the engine and call an expert repairer (we recommend an Authorised Mazda Repairer).*

6. Make sure the cooling fan is operating, then turn off the engine after the temperature has decreased.


If Trouble Arises

## Overheating

- When cool, check the coolant level.  
If it is low, look for coolant leaks from the radiator and hoses.

**If you find a leak or other damage, or if coolant is still leaking:**

Stop the engine and call an expert repairer (we recommend an Authorised Mazda Repairer).



**If you find no problems, the engine is cool, and no leaks are obvious:**

Carefully add coolant as required (page 6-16).

**⚠ CAUTION**

*If the engine continues to overheat or frequently overheats, have the cooling system inspected. The engine could be seriously damaged unless repairs are made. Consult an expert repairer (we recommend an Authorised Mazda Repairer).*

If Trouble Arises


## Emergency Towing

### Towing Description

We recommend that towing be done only by an expert repairer (we recommend an Authorised Mazda Repairer) or a commercial tow-truck service.

Proper lifting and towing are necessary to prevent damage to the vehicle. Government and local laws must be followed.


A towed vehicle usually should have its drive wheels (front wheels) off the ground. If excessive damage or other conditions prevent this, use wheel dollies.




When towing with the rear wheels on the ground, release the parking brake.

### CAUTION

➤ Do not tow the vehicle pointed backward with driving wheels on the ground. This may cause internal damage to the transaxle.



➤ Do not tow with sling-type equipment. This could damage your vehicle. Use wheel-lift or flatbed equipment.



If towing service is not available in an emergency, the vehicle may be towed with all four wheels on the ground using the towing hook at the front of the vehicle. Only tow the vehicle on paved surfaces for short distances at low speeds.

## Emergency Towing

### CAUTION

Follow these instructions when towing the vehicle with all wheels on the ground.

- Shift to neutral (Manual transaxle), or the N position (Automatic transaxle).
- Switch the ignition to ACC.
- Release the parking brake.

Remember that power assist for the brakes and steering will not be available when the engine is not running.

### Towing/Tiedown Hooks

### CAUTION


- The towing eyelet should be used in an emergency (to get the vehicle out of a ditch or a snow bank, for example).
- When using the towing eyelets, always pull the lead or chain in a straight direction with respect to the eyelet. Never apply a sideways force.

### NOTE

When towing with chain or lead, wrap the chain or lead with a soft cloth near the bumper to prevent damage to the bumper.

### ▼ Towing Hook-Front

1. Remove the towing eyelet and the wheel brace from the luggage compartment (page 7-3).
2. Wrap a jack lever or similar tool with a soft cloth to prevent damage to a painted bumper, and open the cap located on the front bumper.



If Trouble Arises

## Emergency Towing


### CAUTION

*Do not use excessive force as it may damage the cap or scratch the painted bumper surface.*

#### NOTE

*Remove the cap completely and store it so as not to lose it.*

3. Securely install the towing eyelet using the wheel brace.



4. Hook the towing rope to the towing eyelet.


### CAUTION

*If the towing eyelet is not securely tightened, it may loosen or disengage from the bumper when towing the vehicle. Make sure that the towing eyelet is securely tightened to the bumper.*

#### ▼ Tiedown Hook-Rear

The hook positioned under the rear bumper on the right side is for tying down the vehicle during transport, and it cannot be used for towing other vehicles.

It can be used as a towing hook only when the vehicle must be towed by another vehicle in an emergency case such as when the vehicle is stuck in snow, however, it may damage the bumper.



Tiedown hook

### CAUTION

*When using the hook in such emergency cases, observe the following so as not to damage the tiedown hook or the vehicle body.*

- *The vehicle must be pulled straight to the rear so that no load is applied to the vehicle in the lateral direction.*
- *The bumper may be damaged if the tiedown hook is used as a towing hook.*
- *When using a metal chain or wire lead, wrap a cloth around the attachment area. If the metal chain or wire lead contacts the bumper directly, the bumper could be scratched or damaged.*



## Warning/Indicator Lights and Warning Sounds

### If a Warning Light Turns On or Flashes

If any warning light turns on/flashes, take appropriate action for each light. There is no problem if the light turns off, however if the light does not turn off or turns on/flashes again, consult an Authorised Mazda Repairer.

#### (Vehicles with type B audio)

The details for some warnings can be viewed on the centre display.

1. If the warning light is turned on, select the  icon on the home screen to display the application screen.
2. Select “Vehicle Status Monitor”.
3. Select “Warning Guidance” to display the current warnings.
4. Select the applicable warning to view the warning details.

#### ▼ Stop Vehicle in Safe Place Immediately

If any of the following warning lights turns on, the system may have a malfunction. Stop the vehicle in a safe place immediately and contact an Authorised Mazda Repairer.

| Signal                                                                                                            | Warning                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
|-------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <br>Brake System Warning Light | <p>This warning has the following functions:</p> <p><b>Parking brake warning/Warning light inspection</b><br/>           The light illuminates when the parking brake is applied with the ignition switched to START or ON. It turns off when the parking brake is fully released.</p> <p><b>Low brake fluid level warning</b><br/>           If the brake warning light remains illuminated even though the parking brake is released, the brake fluid may be low or there could be a problem with the brake system. Park the vehicle in a safe place immediately and contact an expert repairer (we recommend an Authorised Mazda Repairer).</p> <p><b>WARNING</b></p> <p><b>Do not drive with the brake system warning light illuminated. Contact an expert repairer (we recommend an Authorised Mazda Repairer) to have the brakes inspected as soon as possible:</b><br/> <i>Driving with the brake system warning light illuminated is dangerous. It indicates that your brakes may not work at all or that they could completely fail at any time. If this light remains illuminated, after checking that the parking brake is fully released, have the brakes inspected immediately.</i></p> <p><b>CAUTION</b></p> <p><i>In addition, the effectiveness of the braking may diminish so you may need to depress the brake pedal more strongly than normal to stop the vehicle.</i></p> |

## Warning/Indicator Lights and Warning Sounds

| Signal                                                                                                                                      | Warning                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
|---------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|  <p>Electronic Brake Force Distribution System Warning</p> | <p>If the electronic brake force distribution control unit determines that some components are operating incorrectly, the control unit may illuminate the brake system warning light and the ABS warning light simultaneously. The problem is likely to be the electronic brake force distribution system.</p> <p><b>WARNING</b></p> <p><b><i>Do not drive with both the ABS warning light and brake warning light illuminated. Have the vehicle towed to an expert repairer (we recommend an Authorised Mazda Repairer) to have the brakes inspected as soon as possible.</i></b></p> <p><i>Driving when the brake system warning light and ABS warning light are illuminated simultaneously is dangerous.</i></p> <p><i>When both lights are illuminated, the rear wheels could lock more quickly in an emergency stop than under normal circumstances.</i></p>                                                                                                                                                                                                                                                                                       |
|  <p>Charging System Warning Light</p>                      | <p>If the warning light turns on while driving, it indicates a problem with the generator or the charging system.</p> <p>Drive to the side of the road and park off the right-of-way. Consult an expert repairer (we recommend an Authorised Mazda Repairer).</p> <p><b>CAUTION</b></p> <p><i>Do not continue driving when the charging system warning light is illuminated because the engine could stop unexpectedly.</i></p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
|  <p>Engine Oil Warning Light</p>                         | <p>This warning light indicates low engine oil pressure.</p> <p><b>CAUTION</b></p> <p><i>Do not run the engine if the oil pressure is low. Otherwise, it could result in extensive engine damage.</i></p> <p>If the light illuminates or the warning indication is displayed while driving:</p> <ol style="list-style-type: none"> <li>1. Drive to the side of the road and park off the right-of-way on level ground.</li> <li>2. Turn off the engine and wait 5 minutes for the oil to drain back into the sump.</li> <li>3. Inspect the engine oil level. (page 6-15) If it's low, add the appropriate amount of engine oil while being careful not to overfill.</li> </ol> <p><b>CAUTION</b></p> <p><i>Do not run the engine if the oil level is low. Otherwise, it could result in extensive engine damage.</i></p> <ol style="list-style-type: none"> <li>4. Start the engine and check the warning light.</li> </ol> <p>If the light remains illuminated even though the oil level is normal or after adding oil, stop the engine immediately and have your vehicle towed to an expert repairer (we recommend an Authorised Mazda Repairer).</p> |


## Warning/Indicator Lights and Warning Sounds

| Signal                                                                                                                                                   | Warning                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
|----------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|  <p>(Red)<br/>High Engine Coolant<br/>Temperature Warning<br/>Light</p> | <p>The light flashes when the engine coolant temperature is extremely high, and illuminates when the engine coolant temperature increases further.</p> <p><b>Handling Procedure</b></p> <p><b>Flashing light</b><br/>Drive slowly to reduce engine load until you can find a safe place to stop the vehicle and wait for the engine to cool down.</p> <p><b>Illuminated light</b><br/>This indicates the possibility of overheating. Park the vehicle in a safe place immediately and stop the engine.<br/>Refer to Overheating on page 7-18.</p> <div style="border: 1px solid black; padding: 5px; text-align: center;">  <b>CAUTION</b> </div> <p><i>Do not drive the vehicle with the high engine coolant temperature warning light illuminated. Otherwise, it could result in damage to the engine.</i></p>                                                                                                                                                                                                                  |
|  <p>Power Steering Mal-<br/>function Indicator Light</p>              | <p>The light illuminates/flashes if the electric power steering has a malfunction. If the light illuminates/flashes, stop the vehicle in a safe place and do not operate the steering wheel. There is no problem if the light turns off after a while. Contact an expert repairer (we recommend an Authorised Mazda Repairer) if the light illuminates/flashes continuously.</p> <p><b>NOTE</b></p> <ul style="list-style-type: none"> <li>• <i>If the indicator light illuminates/flashes, the power steering will not operate normally. If this happens, the steering wheel can still be operated, however, the operation may feel heavy compared to normal, or the steering wheel could vibrate when turning.</i></li> <li>• <i>Repeatedly jerking the steering wheel left and right while the vehicle is stopped or moving extremely slowly will cause the power steering system to go into protective mode which will make the steering feel heavy, but this does not indicate a problem. If this occurs, park the vehicle safely and wait several minutes for the system to return to normal.</i></li> </ul> |

### ▼ Contact Authorised Mazda Repairer and Have Vehicle Inspected

If any of the following warning lights turns on/flashes, the system may have a malfunction. Contact an expert repairer (we recommend an Authorised Mazda Repairer) to have your vehicle inspected.

## Warning/Indicator Lights and Warning Sounds

| Signal                                                                                                    | Warning                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
|-----------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <br>ABS Warning Light    | <p>If the ABS warning light stays on while you're driving, the ABS control unit has detected a system malfunction. If this occurs, your brakes will function normally as if the vehicle had no ABS.</p> <p>Should this happen, consult an expert repairer (we recommend an Authorised Mazda Repairer) as soon as possible.</p> <p><b>NOTE</b></p> <ul style="list-style-type: none"> <li>• When the engine is jump-started to charge the battery, uneven rpm occurs and the ABS warning light may illuminate. If this occurs, it is the result of the weak battery and does not indicate an ABS malfunction.</li> <li>• <b>(With DSC vehicles)</b><br/>The brake assist system does not operate while the ABS warning light is illuminated.</li> </ul>                                                           |
| <br>Master Warning Light | <p><b>Vehicles with type B audio</b></p> <ul style="list-style-type: none"> <li>• The light turns on when the system has a malfunction.</li> <li>• Operate the centre display and verify the content.</li> <li>• Refer to If a Warning Light Turns On or Flashes on page 7-23.</li> </ul> <p><b>Vehicles with type A audio</b></p> <p>The light illuminates continuously if any one of the following occurs. Consult an expert repairer (we recommend an Authorised Mazda Repairer).</p> <ul style="list-style-type: none"> <li>• There is a malfunction in the battery management system.</li> <li>• There is a malfunction in the brake switch.</li> </ul>                                                                                                                                                     |
| <br>Check Engine Light | <p>If this light illuminates while driving, the vehicle may have a problem. It is important to note the driving conditions when the light illuminated and consult an expert repairer (we recommend an Authorised Mazda Repairer).</p> <p>The check engine light may illuminate in the following cases:</p> <ul style="list-style-type: none"> <li>• The engine's electrical system has a problem.</li> <li>• The emission control system has a problem.</li> <li>• The fuel tank level being very low or approaching empty.</li> <li>• The fuel-filler cap is missing or not tightened securely.</li> </ul> <p>If the check engine light remains on, or it flashes continuously, do not drive at high speeds and consult an expert repairer (we recommend an Authorised Mazda Repairer) as soon as possible.</p> |
|                        | <p><b>When the light is turned on</b></p> <p>A problem in the system may be indicated under the following conditions. Have your vehicle inspected at an expert repairer (we recommend an Authorised Mazda Repairer).</p> <ul style="list-style-type: none"> <li>• The light does not turn on when the ignition is switched ON.</li> <li>• The light continues to remain on even though the i-stop OFF switch has been pressed while the engine is running.</li> </ul> <p><b>When the light is flashing</b></p> <p>The light continues to flash if the system has a malfunction. Have your vehicle inspected at an expert repairer (we recommend an Authorised Mazda Repairer).</p>                                                                                                                               |

## Warning/Indicator Lights and Warning Sounds

| Signal                                                                                                                                         | Warning                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
|------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>AT</b><br>Automatic Trans-<br>axle Warning Light*                                                                                           | <p>The light illuminates when the transaxle has a problem.</p> <div>  <b>CAUTION</b> </div> <p><i>If the automatic transaxle warning light illuminates, the transaxle has an electrical problem. Continuing to drive your Mazda in this condition could cause damage to your transaxle. Consult an expert repairer (we recommend an Authorised Mazda Repairer) as soon as possible.</i></p>                                                                                                                                                                                                                                                                                                                                       |
| <br>(Turns on)<br>TCS/DSC Indicator<br>Light*                 | <p>If the light stays on, the TCS, DSC or the brake assist system may have a malfunction and they may not operate correctly. Take your vehicle to an expert repairer (we recommend an Authorised Mazda Repairer).</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |
| <br>Air Bag/Seat Belt<br>Pretensioner System<br>Warning Light | <p>A system malfunction is indicated if the warning light constantly flashes, constantly illuminates or does not illuminate at all when the ignition is switched ON. If any of these occur, consult an expert repairer (we recommend an Authorised Mazda Repairer) as soon as possible. The system may not operate in an accident.</p> <div>  <b>WARNING</b> </div> <p><b><i>Never tamper with the air bag/pretensioner systems and always have an expert repairer (we recommend an Authorised Mazda Repairer) perform all servicing and repairs: Self-servicing or tampering with the systems is dangerous. An air bag/pretensioner could accidentally activate or become disabled causing serious injury or death.</i></b></p> |

\*Some models.

If Trouble Arises

## Warning/Indicator Lights and Warning Sounds

| Signal                                                                                                                                                | Warning                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
|-------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|  <p>(Flashing)<br/>Tyre Pressure Monitoring System Warning Light</p> | <p>If the tyre pressure monitoring system has a malfunction, the tyre pressure warning light flashes for about 1 minute when the ignition is switched ON and then continues illuminating. Have your vehicle checked by an expert repairer (we recommend an Authorised Mazda Repairer) as soon as possible.</p> <p><b>WARNING</b></p> <p><b><i>If the tyre pressure monitoring system warning light illuminates or flashes, or the tyre pressure warning beep sound is heard, decrease vehicle speed immediately and avoid sudden manoeuvring and braking:</i></b></p> <p><i>If the tyre pressure monitoring system warning light illuminates or flashes, or the tyre pressure warning beep sound is heard, it is dangerous to drive the vehicle at high speeds, or perform sudden manoeuvring or braking. Vehicle drivability could worsen and result in an accident.</i></p> <p><i>To determine if you have a slow leak or a flat, pull over to a safe position where you can check the visual condition of the tyre and determine if you have enough air to proceed to a place where air may be added and the system monitored again by an expert repairer (we recommend an Authorised Mazda Repairer) or a tyre repair station.</i></p> <p><b>Do not ignore the TPMS Warning Light:</b></p> <p><i>Ignoring the TPMS warning light is dangerous, even if you know why it is illuminated. Have the problem taken care of as soon as possible before it develops into a more serious situation that could lead to tyre failure and a dangerous accident.</i></p> |
|  <p>(Red)<br/>(Turns on)<br/>KEY Warning Light</p>                 | <p>If any malfunction occurs in the keyless entry system, it illuminates continuously.</p> <p><b>CAUTION</b></p> <p><i>If the key warning indicator light illuminates or the push button start indicator light (amber) flashes, the engine may not start. If the engine cannot be started, try starting it using the emergency operation for starting the engine, and have the vehicle inspected at an expert repairer (we recommend an Authorised Mazda Repairer) as soon as possible.</i></p> <p>Refer to Emergency Operation for Starting the Engine on page 4-10.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |
|  <p>Security Indicator Light</p>                                   | <p>If the engine does not start with the correct key, and the security indicator light remains illuminated or flashing, try the following:</p> <p>Make sure the key is within the operational range for signal transmission. Switch the ignition off, and then restart the engine. If the engine does not start after 3 or more tries, contact an expert repairer (we recommend an Authorised Mazda Repairer).</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |
|  <p>(Amber)<br/>High Beam Control System (HBC) Warning Light*</p>  | <p>The light remains turned on if there is a problem with the system. Have your vehicle inspected at an expert repairer (we recommend an Authorised Mazda Repairer).</p> <p><b>NOTE</b></p> <p><i>If the windscreen area in front of the Forward Sensing Camera (FSC) is fogged or obstructed, the light turns on temporarily. If the light remains turned on, there may be a problem with the system.</i></p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |

## Warning/Indicator Lights and Warning Sounds

| Signal                                                                                                                                                                  | Warning                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |
|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|  <p>(Amber)<br/>Adaptive LED<br/>Headlights (ALH)<br/>Warning Light*</p>               | <p>The light remains turned on if there is a problem with the system. Have your vehicle inspected at an expert repairer (we recommend an Authorised Mazda Repairer).</p> <p><b>NOTE</b><br/><i>If the windscreen area in front of the Forward Sensing Camera (FSC) is fogged or obstructed, the light turns on temporarily. If the light remains turned on, there may be a problem with the system.</i></p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
|  <p>(Turns on)<br/>Lane Departure<br/>Warning System<br/>(LDWS) Warning<br/>Light*</p> | <ul style="list-style-type: none"> <li>• The warning light remains turned on if there is a problem with the system. Have your vehicle inspected at an expert repairer (we recommend an Authorised Mazda Repairer).</li> <li>• The LDWS does not operate when the warning light illuminates.</li> </ul> <p><b>CAUTION</b></p> <ul style="list-style-type: none"> <li>➤ A problem in the system may be indicated under the following conditions. Have your vehicle inspected at an expert repairer (we recommend an Authorised Mazda Repairer).</li> <li>➤ When the light remains turned on while driving the vehicle.<br/>When the system is cancelled automatically, the light turns on. Normally, the system restores automatically and the light turns off, however, if the light remains turned on, there may be a problem with the system.</li> <li>➤ The light does not illuminate when the ignition is switched ON.</li> <li>➤ Always use tyres for all wheels that are of the specified size, and the same manufacture, brand, and tread pattern. In addition, do not use tyres with significantly different wear patterns on the same vehicle. If such improper tyres are used, the LDWS may not operate normally.</li> <li>➤ When an emergency spare tyre is used, the system may not operate normally.</li> </ul> <p><b>NOTE</b><br/><i>If the windscreen area in front of the Forward Sensing Camera (FSC) is fogged or obstructed, the light turns on temporarily. If the light remains turned on, there may be a problem with the system.</i></p> |

\*Some models.

If Trouble Arises

## Warning/Indicator Lights and Warning Sounds

| Signal                                                                                                                                                                                 | Warning                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <br>(Turns on)<br>Lane-keep Assist System (LAS) & Lane Departure Warning System (LDWS) Warning Light* | <ul style="list-style-type: none"><li>• The warning light remains turned on if there is a problem with the system. Have your vehicle inspected at an expert repairer (we recommend an Authorised Mazda Repairer).</li><li>• The system does not operate when the warning light illuminates.</li></ul> <div> <b>CAUTION</b></div> <ul style="list-style-type: none"><li>➤ A problem in the system may be indicated under the following conditions. Have your vehicle inspected at an expert repairer (we recommend an Authorised Mazda Repairer).</li><li>➤ When the light remains turned on while driving the vehicle.<br/>When the system is cancelled automatically, the light turns on. Normally, the system restores automatically and the light turns off, however, if the light remains turned on, there may be a problem with the system.</li><li>➤ The light does not illuminate when the ignition is switched ON.</li><li>➤ Always use tyres for all wheels that are of the specified size, and the same manufacture, brand, and tread pattern. In addition, do not use tyres with significantly different wear patterns on the same vehicle. If such improper tyres are used, the system may not operate normally.</li><li>➤ When an emergency spare tyre is used, the system may not operate normally.</li></ul> <p><b>NOTE</b><br/>If the windscreen area in front of the Forward Sensing Camera (FSC) is fogged or obstructed, the light turns on temporarily. If the light remains turned on, there may be a problem with the system.</p> |
| <br>Blind Spot Monitoring (BSM) OFF Indicator Light*                                                | <p>A problem in the system may be indicated under the following conditions.<br/>Have your vehicle inspected at an expert repairer (we recommend an Authorised Mazda Repairer).</p> <ul style="list-style-type: none"><li>• The light does not turn on when the ignition is switched ON.</li><li>• The light remains on even when the Blind Spot Monitoring (BSM) system can be operated.</li><li>• The light turns on while driving the vehicle.</li></ul> <p><b>NOTE</b><br/>If the vehicle is driven on a road with less traffic and few vehicles that the radar sensors can detect, the system may pause (The Blind Spot Monitoring (BSM) OFF indicator light in the instrument cluster illuminates). However, it does not indicate a malfunction.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |
| <br>(Amber)<br>Mazda Radar Cruise Control (MRCC) Warning Light*                                     | <p>The warning light turns on if there is a malfunction in the system while the Mazda Radar Cruise Control (MRCC) system is on. Have your vehicle inspected at an expert repairer (we recommend an Authorised Mazda Repairer).</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
| <br>LED Headlight Warning Light                                                                     | <p>This light illuminates if there is a malfunction in the LED headlight. Have your vehicle inspected by an expert repairer (we recommend an Authorised Mazda Repairer).</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |

7-30


\*Some models.



## Warning/Indicator Lights and Warning Sounds

### ▼ Taking Action

Take the appropriate action and verify that the warning light turns off.

| Signal                                                                                                                      | Warning                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   | Action to be taken     |
|-----------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------|
| <br>Low Fuel Warning Light                 | <p>The light turns on when the remaining fuel is about 9.0 L (2.3 US gal, 1.9 Imp gal).</p> <p><b>NOTE</b><br/> <i>The light illumination timing may vary because fuel inside the fuel tank moves around according to the driving conditions and the vehicle posture.</i></p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             | Add fuel.              |
| <br>Seat Belt Warning Light (Front seat) | <p>The seat belt warning light turns on if the driver or front passenger's seat is occupied and the seat belt is not fastened with the ignition switched ON.</p> <p>If the driver or front passenger's seat belt is unfastened (only when the front passenger seat is occupied) and the vehicle is driven at a speed faster than about 20 km/h (12 mph), the warning light flashes. After a short time, the warning light stops flashing, but remains illuminated. If a seat belt remains unfastened, the warning light flashes again for a given period of time.</p> <p><b>NOTE</b></p> <ul style="list-style-type: none"> <li>• If the driver or front passenger's seat belt is unfastened after the warning light turns on, and the vehicle speed exceeds 20 km/h (12 mph), the warning light flashes again.</li> <li>• Placing heavy items on the front passenger's seat may cause the front passenger's seat belt warning function to operate depending on the weight of the item.</li> <li>• To allow the front passenger's seat weight sensor to function properly, do not place and sit on an additional seat cushion on the front passenger's seat. The sensor may not function properly because the additional seat cushion could cause sensor interference.</li> <li>• If a small child is seated on the front passenger's seat, the warning light may not operate.</li> </ul> | Fasten the seat belts. |

If Trouble Arises

## Warning/Indicator Lights and Warning Sounds

| Signal                                                                                                                                                                               | Warning                                                                                                                                                                                                                                                                                                                                                                                           | Action to be taken                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>REAR</b> <br>(Red)<br>Seat Belt Warning<br>Light (Rear seat)                                     | <p>If the rear seat belts are not fastened while the ignition is switched ON, the driver and the passenger are alerted by the warning light.</p> <p>The warning light operates even if there is no passenger on the rear seat.</p> <p><b>NOTE</b><br/> <i>If a rear seat belt is not fastened by a certain period of time after the engine has been started, the warning light turns off.</i></p> | Fasten the seat belts.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
| <br>Door-Ajar Warning<br>Light                                                                      | <p>The light turns on if any door/liftgate/boot lid is not closed securely.</p>                                                                                                                                                                                                                                                                                                                   | Close the door/liftgate/boot lid securely.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
| <br>(Amber)<br>Smart Brake Support/<br>Smart City Brake Sup-<br>port (SBS/SCBS)<br>Warning Light* | <p>The light turns on if the windscreen or the radar sensor are dirty, or there is a malfunction in the system.</p>                                                                                                                                                                                                                                                                               | <p><b>Vehicles with type B audio</b><br/>           Verify the reason why the warning light is illuminated on the centre display (page 7-23).<br/>           If the reason why the warning light is illuminated is due to a dirty windscreen, clean the windscreen.<br/>           If the warning light is illuminated because of a dirty radar sensor, clean the front emblem.<br/>           For any other reasons, have the vehicle inspected at an expert repairer (we recommend an Authorised Mazda Repairer).</p> <p><b>Vehicles with type A audio</b><br/>           If the reason why the warning light is illuminated is due to a dirty windscreen, clean the windscreen. For any other reasons, have the vehicle inspected at an expert repairer (we recommend an Authorised Mazda Repairer).</p> |

### Tyre Pressure Monitoring System Warning Light (Turns on)



Take the appropriate action and verify that the warning light turns off.

**7-32** \*Some models.

## Warning/Indicator Lights and Warning Sounds

### Warning

When the warning light illuminates, and the warning beep sound is heard (about 3 seconds), tyre pressure is too low in one or more tyres.



**If the tyre pressure monitoring system warning light illuminates or flashes, or the tyre pressure warning beep sound is heard, decrease vehicle speed immediately and avoid sudden manoeuvring and braking:**

If the tyre pressure monitoring system warning light illuminates or flashes, or the tyre pressure warning beep sound is heard, it is dangerous to drive the vehicle at high speeds, or perform sudden manoeuvring or braking. Vehicle drivability could worsen and result in an accident.

To determine if you have a slow leak or a flat, pull over to a safe position where you can check the visual condition of the tyre and determine if you have enough air to proceed to a place where air may be added and the system monitored again by an expert repairer (we recommend an Authorised Mazda Repairer) or a tyre repair station.

#### **Do not ignore the TPMS Warning Light:**

Ignoring the TPMS warning light is dangerous, even if you know why it is illuminated. Have the problem taken care of as soon as possible before it develops into a more serious situation that could lead to tyre failure and a dangerous accident.

### Action to be taken

Inspect the tyres and adjust to the specified inflation pressure (page 6-27).

#### **NOTE**

- Perform tyre pressure adjustment when the tyres are cold. Tyre pressure will vary according to the tyre temperature, therefore let the vehicle stand for 1 hour or only drive it 1.6 km (1 mile) or less before adjusting the tyre pressures. When pressure is adjusted on hot tyres to the cold inflation pressure, the TPMS warning light/beep may turn on after the tyres cool and pressure drops below specification.  
Also, an illuminated TPMS warning light, resulting from the tyre air pressure dropping due to cold ambient temperature will remain illuminated even if the ambient temperature rises. In this case, it will also be necessary to adjust the tyre air pressures. If the TPMS warning light illuminates due to a drop in tyre air pressure, make sure to check and adjust the tyre air pressures.
- Tyres lose air naturally over time and the TPMS cannot tell if the tyres are getting too soft over time or you have a flat. However, when you find one low tyre in a set of four—that is an indication of trouble; you should have someone drive the vehicle slowly forward so you can inspect any low tyre for cuts and any metal objects sticking through tread or sidewall. Put a few drops of water in the valve stem to see if it bubbles indicating a bad valve. Leaks need to be addressed by more than simply reinflating the tyre as leaks are dangerous — take it to an expert repairer (we recommend an Authorised Mazda Repairer).

If Trouble Arises

## Warning/Indicator Lights and Warning Sounds

### KEY Warning Light

Take the appropriate action and verify that the warning light turns off.


| Signal                                                                                                   | Cause                                                                                                             | Action to be taken                                                                             |
|----------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------|
| <br>(Red)<br>(Flashing) | The advanced key battery is dead.                                                                                 | Replace the key battery (page 6-25).                                                           |
|                                                                                                          | The advanced key is not within the operation range.                                                               | Bring the advanced key into the operation range (page 3-5).                                    |
|                                                                                                          | The advanced key is placed in areas inside the cabin where it is difficult for the key to be detected.            |                                                                                                |
|                                                                                                          | A key from another manufacturer similar to the advanced key is in the operation range.                            | Take the key from another manufacturer similar to the advanced key out of the operation range. |
|                                                                                                          | Without the ignition switched off, the advanced key is taken out of the cabin, and then all the doors are closed. | Bring the advanced key back into the cabin.                                                    |

# Warning/Indicator Lights and Warning Sounds

## Message Indicated on Display

If a message is displayed in the centre display (Type B audio), take appropriate action (in a calm manner) according to the displayed message.

(Display example)



### ▼ Stop Vehicle in Safe Place Immediately

If the following messages are displayed in the centre display (Type B audio), a vehicle system may be malfunctioning. Stop the vehicle in a safe place and contact an expert repairer (we recommend an Authorised Mazda Repairer).


| Display | Indicated Condition                                                   |
|---------|-----------------------------------------------------------------------|
|         | Displays if the engine coolant temperature has increased excessively. |
|         | Displays if the charging system has a malfunction.                    |

If Trouble Arises

## Warning/Indicator Lights and Warning Sounds

### ▼ Verify Display Content

Displays in the following cases:

| Display                                                                           | Indicated Condition/Action to be taken                                                                                                                                                                                                  |
|-----------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|  | <p>The following message is displayed when the temperature around the centre display is high.</p> <p>Lowering the temperature in the cabin or the temperature around the centre display by avoiding direct sunlight is recommended.</p> |

## Warning/Indicator Lights and Warning Sounds

### Warning Sound is Activated

#### ▼ Lights-On Reminder

If lights are on and the ignition is switched to ACC or off, a continuous beep sound will be heard when the driver's door is opened.

#### NOTE

- When the ignition is switched to ACC, the "Ignition Not Switched Off (STOP) Warning Beep" (page 7-38) overrides the lights-on reminder.
- A personalised function is available to change the sound volume for the lights-on reminder.  
Refer to Personalisation Features on page 9-8.

#### ▼ Air Bag/Seat Belt Pretensioner System Warning Beep

If there is a problem with the air bag/seat belt pretensioner systems and the warning light illumination, a warning beep sound will be heard for about 5 seconds every minute.

The air bag and seat belt pretensioner system warning beep sound will continue to be heard for approximately 35 minutes. Have your vehicle inspected at an expert repairer (we recommend an Authorised Mazda Repairer) as soon as possible.

### WARNING

**Do not drive the vehicle with the air bag/seat belt pretensioner system warning beep sounding:**

Driving the vehicle with the air bag/seat belt pretensioner system warning beep sounding is dangerous. In a collision, the air bags and the seat belt pretensioner system will not deploy and this could result in death or serious injury. Contact an expert repairer (we recommend an Authorised Mazda Repairer) to have the vehicle inspected as soon as possible.

#### ▼ Seat Belt Warning Beep

##### Front seat

If the vehicle speed exceeds about 20 km/h (12 mph) with the driver or front passenger's seat belt unfastened, a warning beep sounds continuously. If the seat belt remains unfastened, the beep sound stops once and then continues for about 90 seconds. The beep stops after the driver or front passenger's seat belt is fastened.

#### NOTE

- Placing heavy items on the front passenger seat may cause the front passenger seat belt warning function to operate depending on the weight of the item.
- To allow the front passenger seat weight sensor to function properly, do not place and sit on an additional seat cushion on the front passenger seat. The sensor may not function properly because the additional seat cushion could cause sensor interference.

If Trouble Arises

## Warning/Indicator Lights and Warning Sounds

---

· When a small child sits on the front passenger seat, it is possible that the warning beep will not operate.

### **Rear seat**

The warning beep only sounds if a seat belt is unfastened after being fastened.

### **▼ Ignition Not Switched Off (STOP) Warning Beep**

If the driver's door is opened with the ignition switched to ACC, a beep will be heard continuously in the cabin to notify the driver that the ignition has not been switched OFF (STOP). Under this condition, the keyless entry system will not operate, the vehicle cannot be locked, and the battery voltage will be depleted.

### **▼ Key Removed from Vehicle Warning Beep**

#### **Vehicles with advanced keyless function**

If the key is taken out of the vehicle while the ignition is not switched OFF and all the doors are closed, the beep which sounds outside of the vehicle will be heard 6 times, the beep which sounds inside the vehicle will be heard 6 times.

### **Vehicles without advanced keyless function**

If the key is taken out of the vehicle while the ignition is not switched OFF and all the doors are closed, a beep will be heard in the cabin 6 times.

#### **NOTE**

*Because the key utilizes low-intensity radio waves, the Key Removed From Vehicle Warning may activate if the key is carried together with a metal object or it is placed in a poor signal reception area.*

### **▼ Request Switch Inoperable Warning Beep (With the advanced keyless function)**

If the request switch is pressed with the door open or ajar, or the ignition is not switched OFF with a key being carried, a beep will be heard outside for about 2 seconds to notify the driver that the door or liftgate/boot lid cannot be locked.



## Warning/Indicator Lights and Warning Sounds

### ▼ Key Left-in-luggage Compartment/ Boot Warning Beep (With the advanced keyless function)

If the key is left in the luggage compartment/boot with all the doors locked and the liftgate/boot lid closed, a beep will be heard outside for about 10 seconds to notify the driver that the key is in the luggage compartment/boot. In this case, take out the key by pressing the electric liftgate/boot lid opener and opening the liftgate/boot lid. The key taken out of the luggage compartment/boot may not operate because its functions have been temporarily stopped. To restore the key's functions, perform the applicable procedure (page 3-6).

### ▼ Key Left-in-vehicle Warning Beep (With the advanced keyless function)

If all the doors and luggage compartment/boot are locked using another key while the key is left in the cabin, the beep which sounds outside of the vehicle will be heard for about 10 seconds to notify the driver that the key is in the cabin. In this case, take out the key by opening the door. A key taken out of the vehicle using this method may not operate because its functions have been temporarily stopped. To restore the key's functions, perform the applicable procedure (page 3-6).

### ▼ i-stop Warning Beep\*

- If the driver's door is opened while engine idling is stopped, the warning sound operates to notify the driver that engine idling is stopped. It stops when the driver's door is closed.

### ▼ Electronic Steering Lock Warning Beep

The warning beep operates if the steering wheel is not unlocked after the push button start is pressed. (page 4-4)

### ▼ Vehicle Speed Alarm\*

The vehicle speed alarm function is designed to alarm the driver via a single beep sound and a warning indication in the instrument cluster that the previously set vehicle speed has been exceeded. You can change the vehicle speed setting at which the warning is triggered.

### ▼ Tyre Inflation Pressure Warning Beep

The warning beep sound will be heard for about 3 seconds when there is any abnormality in tyre inflation pressures (page 4-191).

### ▼ Power Steering Warning Buzzer

If the power steering system has a malfunction, the power steering malfunction indicator light turns on or flashes and the buzzer operates at the same time.

Refer to Stop Vehicle in Safe Place Immediately on page 7-23.

### ▼ Blind Spot Monitoring (BSM) System Warning Beep\*

#### Driving forward

The warning beep operates when the direction indicator lever is operated to the side where the Blind Spot Monitoring (BSM) warning light is illuminated.

\*Some models.

## Warning/Indicator Lights and Warning Sounds

### NOTE

A personalised function is available to change the Blind Spot Monitoring (BSM) warning beep sound volume.

Refer to Personalisation Features on page 9-8.

### Reversing

The Blind Spot Monitoring (BSM) warning sound is activated if there is a possibility of collision with a vehicle approaching from behind and from the rear on the left and right sides of the vehicle.

### ▼ Lane Departure Warning Sound\*

While the system is operating, if the system determines that the vehicle may depart from the lane, it sounds a warning sound.

### NOTE

#### · (With Lane-keep Assist System (LAS) & Lane Departure Warning System (LDWS))

The volume of the Lane-keep Assist System (LAS) & Lane Departure Warning System (LDWS) warning sound can be changed.

Refer to Personalisation Features on page 9-8.

#### · The type of the Lane-keep Assist System (LAS) & Lane Departure Warning System (LDWS) warning sound can be changed.

Refer to Personalisation Features on page 9-8.

#### · (With Lane Departure Warning System (LDWS))

The volume of the LDWS warning sound can be changed.

Refer to Personalisation Features on page 9-8.

#### · The type of the LDWS warning sound can be changed.

Refer to Personalisation Features on page 9-8.

### ▼ Mazda Radar Cruise Control (MRCC) System Warnings\*

The Mazda Radar Cruise Control (MRCC) system warnings notify the driver of system malfunctions and cautions on use when required.

Check based on the beep sound.

| Warning beep                                                                                                                                                                 | What to check                                                                                                                                |
|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------|
| The beep sounds 1 time while the Mazda Radar Cruise Control (MRCC) is operating                                                                                              | The vehicle speed is slower than 25 km/h (16 mph) and the Mazda Radar Cruise Control (MRCC) system has been cancelled.                       |
| The beep sounds continuously while driving                                                                                                                                   | The distance between your vehicle and the vehicle ahead is too close. Verify the safety of the surrounding area and reduce vehicle speed.    |
| When the Mazda Radar Cruise Control (MRCC) is operating, the beep sounds and the Mazda Radar Cruise Control (MRCC) warning light (amber) in the instrument cluster turns on. | A malfunction in the system may be indicated. Have your vehicle inspected at an expert repairer (we recommend an Authorised Mazda Repairer). |

## Warning/Indicator Lights and Warning Sounds

---

### ▼ Collision warning\*

If there is a possibility of a collision with a vehicle ahead or an obstruction at the rear of the vehicle, the warning light in the instrument cluster flashes at the same time as the warning indication is displayed in the active driving display, and a warning sound is activated intermittently.

\*Some models.

**7-41**

If Trouble Arises

## When Liftgate/Boot Lid Cannot be Opened

### When Liftgate/Boot Lid Cannot be Opened

If the vehicle battery is dead, the liftgate/boot lid cannot be unlocked and opened. In this case, the liftgate/boot lid can be unlocked by taking care of the dead battery situation.

Refer to Jump-Starting on page 7-14.

If the liftgate/boot lid cannot be unlocked even if the dead battery situation has been resolved, the electrical system may have a malfunction.


In this case, the liftgate/boot lid can be opened using the following procedure as an emergency measure.

**(Hatchback)**


#### CAUTION

➤ Perform the procedure using a cloth to cover sharp edges which could injure your hands.

➤ Perform the procedure carefully when using a flathead screwdriver as it could cause damage to the surrounding area or vehicle parts.




1. Fold down the rear seatbacks.  
Refer to Split Folding the Seatbacks on page 2-11.
2. Pull the centre section of the plastic fastener and remove the fasteners, then remove cover on the interior surface of the liftgate.




## When Liftgate/Boot Lid Cannot be Opened

- Using a flathead screwdriver, open the inner cover.




- Using a flathead screwdriver, turn the lever to the right to unlock the liftgate.




### (Saloon)

- Open the cover.
- Move the lever to the left to fold the seatback.



- Move the lever to the left to open the boot lid.



After performing this emergency measure, have the vehicle inspected at an expert repairer (we recommend an Authorised Mazda Repairer) as soon as possible.

If Trouble Arises

## Active Driving Display Does Not Operate

---

### If the Active Driving Display Does Not Operate

If the active driving display does not operate, switch the ignition off and then restart the engine. If the active driving display does not operate even with the engine restarted, have the vehicle inspected at an expert repairer (we recommend an Authorised Mazda Repairer).

# 8

## Customer Information

Important consumer information including warranties and add-on equipment.

|                               |            |
|-------------------------------|------------|
| <b>Warranty.....</b>          | <b>8-2</b> |
| Registering Your Vehicle in A |            |
| Foreign Country.....          | 8-2        |
| Add-On Non-Genuine Parts and  |            |
| Accessories.....              | 8-3        |

|                                       |            |
|---------------------------------------|------------|
| <b>Cell Phones.....</b>               | <b>8-4</b> |
| Cell Phones Warning.....              | 8-4        |
| <b>Recording of Vehicle Data.....</b> | <b>8-5</b> |
| Recording of Vehicle Data.....        | 8-5        |

## Warranty

---

### Registering Your Vehicle in A Foreign Country

Registering your vehicle in a foreign country may be problematic depending on whether it meets the specific emission and safety standards of the country in which the vehicle will be driven. Consequently, your vehicle may require modifications at personal expense in order to meet the regulations.

In addition, you should be aware of the following issues:

Satisfactory vehicle servicing may be difficult or impossible in another country.

The fuel specified for your vehicle may be unavailable.

Parts, servicing techniques, and tools necessary to maintain and repair your vehicle may be unavailable.

There might not be an Authorised Mazda Repairer in the country you plan to take your vehicle.

The Mazda warranty is valid only in certain countries.



### Add-On Non-Genuine Parts and Accessories

Please note that technical alterations to the original state of your Mazda vehicle can affect the safety of the vehicle. Such technical alterations include not only the use of unsuitable spare parts, but also accessories, fittings or attachments, including rims and tyres.

Genuine Mazda Parts and Genuine Mazda Accessories have been specifically designed for Mazda vehicles.

Other parts and accessories than those mentioned above have not been examined and approved by Mazda unless explicitly stated by Mazda. We cannot certify the suitability of such products. Mazda is not liable for any damage caused by the use of such products.

#### **WARNING**

***Be very careful in choosing and installing add-on electrical equipment, such as mobile telephones, two-way radios, stereo systems, and car alarm systems:***

*Incorrectly choosing or installing improper add-on equipment or choosing an improper installer is dangerous. Essential systems could be damaged, causing engine stalling, air-bag (SRS) activation, ABS/TCS/DSC inactivation, or a fire in the vehicle.*

Mazda assumes no responsibility for death, injury, or expenses that may result from the installation of add-on non-genuine parts or accessories.

## Cell Phones

---

### Cell Phones Warning

#### **WARNING**

***Please comply with the legal regulations concerning the use of communication equipment in vehicles in your country:***

*Use of any electrical devices such as cell phones, computers, portable radios, vehicle navigation or other devices by the driver while the vehicle is moving is dangerous. Dialing a number on a cell phone while driving also ties-up the driver's hands. Use of these devices will cause the driver to be distracted and could lead to a serious accident. If a passenger is unable to use the device, pull off the right-of-way to a safe area before use. If use of a cell phone is necessary despite this warning, use a hands-free system to at least leave the hands free to drive the vehicle. Never use a cell phone or other electrical devices while the vehicle is moving and, instead, concentrate on the full-time job of driving.*

## Recording of Vehicle Data

### Recording of Vehicle Data

This vehicle is equipped with a computer which records the following main vehicle data related to vehicle controls, operation, and other driving conditions.

#### **Recorded data**

- Vehicle conditions such as engine speed and vehicle speed
- Driving operation conditions such as accelerator and brake pedals, and information related to the environmental circumstances while the vehicle is driven
- Malfunction diagnosis information from each on-vehicle computer
- Information related to controls of other on-vehicle computers

#### ***NOTE***




*The recorded data may vary depending on the vehicle grade and optional equipment. Voice and images are not recorded.*

#### **Data handling**



Mazda and its subcontracting parties may obtain and use the recorded data for vehicle malfunction diagnosis, research and development, and quality improvement.

Mazda will not disclose or provide any of the obtained data to a third party unless:

- An agreement from the vehicle owner (agreements from lessor and lessee for leased vehicle) is obtained
- Officially requested by the police or other law enforcement authorities



# MEMO



# 9

## Specifications

Technical information about your Mazda.

**Identification Numbers..... 9-2**

Vehicle Information Labels..... 9-2

**Specifications..... 9-3**

Specifications..... 9-3


**Personalisation Features..... 9-8**

Personalisation Features..... 9-8

## Identification Numbers


### Vehicle Information Labels

#### ▼ Model Plate




#### ▼ Chassis Number/Vehicle Identification Number


Open the cover shown in the figure to check the chassis number.



#### ▼ Tyre Pressure Label



#### ▼ Engine Number



#### ▼ Built Date (Australia)

The “Built Date” is the calendar month and the year in which the body shell and power train sub-assemblies are conjoined and the vehicle is driven or moved from the production line.

| mazda                                                                     |       |       |      |
|---------------------------------------------------------------------------|-------|-------|------|
| MODEL                                                                     | PAINT | BUILT | DATE |
| <div style="background-color: #cccccc; height: 15px; width: 100%;"></div> |       |       |      |
| <div style="background-color: #cccccc; height: 15px; width: 100%;"></div> |       |       |      |
| VEHICLE ID. NO                                                            |       |       |      |
| <div style="background-color: #cccccc; height: 15px; width: 100%;"></div> |       |       |      |
| Mazda Motor Corporation                                                   |       |       |      |

## Specifications

### ▼ Engine

| Item              | Specification                   |             |
|-------------------|---------------------------------|-------------|
|                   | Without i-stop                  | With i-stop |
| Type              | DOHC-16V in-line, 4-cylinder    |             |
| Bore × Stroke     | 74.5 × 85.8 mm (2.93 × 3.38 in) |             |
| Displacement      | 1,496 ml (1,496 cc)             |             |
| Compression ratio | 12.0                            | 13.0        |

### ▼ Electrical System

| Item              |                            | Specification              |
|-------------------|----------------------------|----------------------------|
| Battery           | With i-stop                | Q-85*1                     |
|                   | Without i-stop             | 12V-60Ah/20HR              |
| Spark-plug number | Mazda Genuine spark plug*2 | PE5R-18-110 or PE5S-18-110 |

\*1 Q-85 is designed for i-stop system (FOR STOP & START). Only Q-85 should be used to ensure correct operation of i-stop system (FOR STOP & START). Consult an expert repairer (we recommend an Authorised Mazda Repairer) for details.

\*2 The spark plugs provide the SKYACTIV-G its optimum performance. Consult an expert repairer (we recommend an Authorised Mazda Repairer) for details.

### CAUTION

*When cleaning the iridium plugs, do not use a wire brush. The fine particulate coating on the iridium alloy and platinum tips could be damaged.*

### ▼ Lubricant Quality

| Lubricant    | Classification                          |
|--------------|-----------------------------------------|
| Engine oil*1 | API SL/SM/SN or ILSAC GF-III/GF-IV/GF-V |

\*1 Refer to the recommended SAE viscosity numbers on page 6-14.

| Lubricant                 | Classification                       |
|---------------------------|--------------------------------------|
| Coolant                   | FL-22 type                           |
| Manual transaxle oil      | Mazda Long Life Gear Oil G7*1        |
| Automatic transaxle fluid | Mazda Genuine special fluid (ATF FZ) |
| Brake/Clutch fluid        | SAE J1703 or FMVSS116 DOT-3 or DOT-4 |

## Specifications

# Specifications

\*1 Mazda Long Life Gear Oil G7 is superior oil for low fuel cost and optimum shift-feel. Using Mazda Long Life Gear Oil G7 is recommended.

If Mazda Long Life Gear Oil G7 cannot be obtained, use standard oil (API Service GL-4 (SAE 75W-80)).

## ▼ Capacities

### (Approximate Quantities)

| Item                      |                                | Capacity                           |
|---------------------------|--------------------------------|------------------------------------|
| Engine oil                | With oil filter replacement    | 4.2 L (4.4 US qt, 3.7 Imp qt)      |
|                           | Without oil filter replacement | 3.9 L (4.1 US qt, 3.4 Imp qt)      |
| Coolant                   | Manual transaxle               | 5.0 L (5.3 US qt, 4.4 Imp qt)      |
|                           | Automatic transaxle            | 5.2 L (5.5 US qt, 4.6 Imp qt)      |
| Manual transaxle oil      |                                | 1.59 L (1.68 US qt, 1.40 Imp qt)   |
| Automatic transaxle fluid |                                | 7.2 L (7.6 US qt, 6.3 Imp qt)      |
| Fuel tank                 |                                | 44.0 L (11.6 US gal, 9.68 Imp gal) |

Check oil and fluid levels with dipsticks or reservoir gauges.

## ▼ Dimensions

### Saloon

| Item           | Vehicle specification |
|----------------|-----------------------|
| Overall length | 4,340 mm (170.9 in)   |
| Overall width  | 1,695 mm (66.7 in)    |
| Overall height | 1,470 mm (57.9 in)    |
| Front tread    | 1,495 mm (58.9 in)    |
| Rear tread     | 1,485 mm (58.5 in)    |
| Wheelbase      | 2,570 mm (101.2 in)   |

### Hatchback


| Item                         |        | Vehicle specification |
|------------------------------|--------|-----------------------|
| Overall length               |        | 4,065 mm (160.0 in)   |
| Overall width                |        | 1,695 mm (66.7 in)    |
| Overall height* <sup>1</sup> | Type A | 1,515 mm (59.7 in)    |
|                              | Type B | 1,495 mm (58.9 in)    |
| Front tread                  |        | 1,495 mm (58.9 in)    |
| Rear tread                   |        | 1,485 mm (58.5 in)    |
| Wheelbase                    |        | 2,570 mm (101.2 in)   |

\*1 The overall height is categorized according to the aerial type as follows:


## 9-4



**Type A**



**Type B**



**▼ Light Bulbs**

**Exterior light**

| Light bulb                       |           | Category |                |
|----------------------------------|-----------|----------|----------------|
|                                  |           | Wattage  | UN-R*1 (SAE)   |
| Headlights                       |           | LED*2    | — (—)          |
| Running lights*                  |           | LED*2    | — (—)          |
| Position lights                  | LED type  | LED*2    | — (—)          |
|                                  | Bulb type | 5        | W5W (—)        |
| Front direction indicator lights |           | 21       | WY21W (7443NA) |
| Side direction indicator lights  |           | LED*2    | — (—)          |
| High-mount brake light           |           | LED*2    | — (—)          |
| Rear direction indicator lights  |           | 21       | WY21W (7443NA) |
| Tail lights/Brake lights         |           | 21/5     | W21/5W (7443)  |
| Reverse lights                   | Saloon    | 16       | W16W (921)     |
|                                  | Hatchback | LED*2    | — (—)          |
| Number plate lights              |           | 5        | W5W (—)        |

\*1 UN-R stands for United Nations Regulation.

\*2 LED is the abbreviation for Light Emitting Diode.

\*Some models.

## Specifications

# Specifications

### Interior light

| Light bulb                            | Category |              |
|---------------------------------------|----------|--------------|
|                                       | Wattage  | UN-R*1 (SAE) |
| Boot light (Saloon)                   | 3        | —            |
| Luggage compartment light (Hatchback) | 5        | —            |
| Overhead lights/Map lights            | 8        | —            |

\*1 UN-R stands for United Nations Regulation.

### ▼ Tyres

#### Sample tyre mark and its meaning

Nominal section width 175 / 70 R 14 94 H M+S  
 Nominal aspect ratio in %  
 Construction code  
 Nominal rim diameter in inches  
 Load index (not on ZR tyres)  
 Speed symbol  
 Mud and snow

### Tyre mark information

Choose the proper tyres for your vehicle using the following tyre mark information.

| Speed symbol | Maximum permissible speed |
|--------------|---------------------------|
| Q            | Up to 160 km/h (99 mph)   |
| R            | Up to 170 km/h (105 mph)  |
| S            | Up to 180 km/h (111 mph)  |
| T            | Up to 190 km/h (118 mph)  |
| U            | Up to 200 km/h (124 mph)  |
| H            | Up to 210 km/h (130 mph)  |
| V            | Up to 240 km/h (149 mph)  |
| W            | Up to 270 km/h (167 mph)  |
| Y            | Up to 300 km/h (186 mph)  |
| ZR           | Over 240 km/h (149 mph)   |

### **Tyre and inflation pressure**

#### ***NOTE***

*The tyres have been optimally matched with the chassis of your vehicle.*

*When replacing tyres, Mazda recommends that you replace tyres of the same type originally fitted to your vehicle. For details, contact an expert repairer (we recommend an Authorised Mazda Repairer).*

Check the tyre pressure label for tyre size and inflation pressure (page 6-27).

After adjusting the tyre pressure, initialization of the tyre pressure monitoring system is necessary to make the system operate normally.

Refer to Tyre Pressure Monitoring System Initialization on page 4-193.

### **Standard tyre**

| Tyre size     |       | Inflation pressure        |                           |
|---------------|-------|---------------------------|---------------------------|
|               |       | Up to 3 persons           | — Full load               |
| 185/65R15 88T | Front | 250 kPa (2.5 bar, 36 psi) | 270 kPa (2.7 bar, 39 psi) |
|               | Rear  | 230 kPa (2.3 bar, 33 psi) | 320 kPa (3.2 bar, 46 psi) |
| 185/60R16 86H | Front | 250 kPa (2.5 bar, 36 psi) | 260 kPa (2.6 bar, 38 psi) |
|               | Rear  | 230 kPa (2.3 bar, 33 psi) | 330 kPa (3.3 bar, 48 psi) |

1 person's weight: About 75 kg

### **Temporary spare tyre**

| Tyre size      | Inflation pressure |
|----------------|--------------------|
| T125/70D15 95M | 420 kPa (60 psi)   |

### **Wheel nut tightening torque**

When installing a tyre, tighten the wheel nut to the following torque.

108—147 N·m (12—14 kgf·m, 80—108 ft·lbf)

#### **▼ Fuses**

Refer to Fuses on page 6-37.

#### **▼ Brakes**

If you require information regarding the wear limit specification for the brake disc plates and drums, or the measurement method, please contact an expert repairer (we recommend an Authorised Mazda Repairer). The information is made freely available.

## Personalisation Features

### Personalisation Features

The following personalisation features can be set or changed by the customer or an Authorised Mazda Repairer. Consult an Authorised Mazda Repairer for details.

Additionally, some of the personalisation features can be changed by the customer depending on the feature.

Personalisation features and settings which can be changed differ depending on the market and specification.

#### Settings Change Method

##### ① Settings can be changed by operating the centre display screen.

A: Refer to Settings on page 5-122.

B: Refer to Fuel Economy Monitor on page 4-69.

C: Refer to Active Driving Display on page 4-26.

##### ② Settings can be changed by operating the vehicle switches.

D: Refer to Auto Lock/Unlock Function on page 3-10.

E: Refer to Transmitter on page 3-4.

F: Refer to Locking, Unlocking with Request Switch (With the advanced keyless function) on page 3-10.

##### ③ Settings can be changed by an Authorised Mazda Repairer.

| Item                                                                                                                                                                 | Feature                                                                                                         | Factory Setting | Available Settings | Settings Change Method |   |   |
|----------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------|-----------------|--------------------|------------------------|---|---|
|                                                                                                                                                                      |                                                                                                                 |                 |                    | ①                      | ② | ③ |
| Safety                                                                                                                                                               |                                                                                                                 |                 |                    |                        |   |   |
| Advanced Smart City Brake Support (Advanced SCBS) (page 4-136)<br>Smart City Brake Support [Reverse] (SCBS R) (page 4-140)<br>Smart Brake Support (SBS) (page 4-144) | The system can be changed so that Smart City Brake Support (SCBS)/Smart Brake Support (SBS) does not operate.*1 | On              | On/Off             | A                      |   | ✕ |
|                                                                                                                                                                      | The distance at which the collision warning activates can be changed.                                           | Med.            | Near/<br>Med./Far  | A                      |   | ✕ |
|                                                                                                                                                                      | The volume of the collision warning can be changed.                                                             | High            | High/Low/Off       | A                      |   | ✕ |
| Lane-keep Assist System (LAS) & Lane Departure Warning System                                                                                                        | The system can be changed so that the steering wheel assist does not operate.                                   | On              | On/Off             | A                      |   | ✕ |

## Personalisation Features

| Item                          | Feature                                                                                                                         |                                                                                                                                                                                        | Factory Setting | Available Settings                  | Settings Change Method |   |   |
|-------------------------------|---------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------|-------------------------------------|------------------------|---|---|
|                               |                                                                                                                                 |                                                                                                                                                                                        |                 |                                     | ①                      | ② | ③ |
| (LDWS) (page 4-117)           | When the steering wheel operation assistance is turned on                                                                       | The timing at which the steering wheel operation assist of the Lane-keep Assist System (LAS) & Lane Departure Warning System (LDWS) operates can be changed.                           | Late            | Early/Late                          | A                      | — | × |
|                               |                                                                                                                                 | The cancel sensitivity of the steering assistance for the Lane-keep Assist System (LAS) & Lane Departure Warning System (LDWS) can be changed.                                         | High            | High/Med/Low                        | A                      | — | × |
|                               |                                                                                                                                 | The system can be changed so that the Lane Departure Warning does not activate.                                                                                                        | On              | On/Off                              | A                      | — | × |
|                               | When the steering wheel operation assistance is turned off                                                                      | The warning timing in which the Lane-keep Assist System (LAS) & Lane Departure Warning System (LDWS) system determines that the vehicle may be deviating from its lane can be changed. | Med             | Adaptive/<br>Early/<br>Med/<br>Late | A                      | — | × |
|                               |                                                                                                                                 | The sensitivity of the warning for the Lane-keep Assist System (LAS) & Lane Departure Warning System (LDWS) can be changed.                                                            | Med             | Often/Med/<br>Rare                  | A                      | — | × |
|                               | The type of Lane-keep Assist System (LAS) & Lane Departure Warning System (LDWS) warning can be changed.                        |                                                                                                                                                                                        | Vibration       | Vibration/<br>Beep/<br>Rumbl.       | A                      | — | × |
|                               | The warning intensity/volume of the Lane-keep Assist System (LAS) & Lane Departure Warning System (LDWS) system can be changed. | Vibration                                                                                                                                                                              | Low             | High/Low                            | A                      | — | × |
|                               |                                                                                                                                 | Rumbl.                                                                                                                                                                                 | Low             | High/Mid/Low                        | A                      | — | × |
|                               |                                                                                                                                 | Beep                                                                                                                                                                                   | Low             | High/Low                            | A                      | — | × |
| Lane Departure Warning System | The warning sound for the Lane Departure Warning System (LDWS) can be changed.*2                                                |                                                                                                                                                                                        | Beep            | Beep/<br>Rumble<br>Strip            | A                      | — | × |

Specifications

## Personalisation Features

| Item                                                   | Feature                                                                                                                                         |        | Factory Setting | Available Settings        | Settings Change Method |   |   |
|--------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------|--------|-----------------|---------------------------|------------------------|---|---|
|                                                        |                                                                                                                                                 |        |                 |                           | ①                      | ② | ③ |
| (LDWS) (page 4-82)                                     | The volume of the warning sound for the Lane Departure Warning System (LDWS) can be changed.                                                    | Rumble | Low             | High/Mid/Low              | A                      | — | × |
|                                                        |                                                                                                                                                 | Beep   | Low             | High/Low                  | A                      | — | × |
|                                                        | The warning timing in which the Lane Departure Warning System (LDWS) determines that the vehicle may be deviating from its lane can be changed. |        | Adaptive        | Adaptive/Early/Med/Late   | A                      | — | × |
|                                                        | The sensitivity of the warning for the Lane Departure Warning System (LDWS) can be changed.                                                     |        | Med             | Often/Med/Rare            | A                      | — | × |
| Blind Spot Monitoring (BSM) (page 4-89)                | The system can be changed so that Blind Spot Monitoring (BSM) does not operate.*1                                                               |        | On              | On/Off                    | A                      | — | × |
|                                                        | Warning beep volume*3                                                                                                                           |        | High            | High/Low/Off              | A                      | — | × |
| Driver Attention Alert (DAA) (page 4-101)              | The system can be changed so that Driver Attention Alert (DAA) does not operate.*1                                                              |        | On              | On/Off                    | A                      | — | × |
| Distance Recognition Support System (DRSS) (page 4-87) | The system can be changed so that Distance Recognition Support System (DRSS) does not operate.*1                                                |        | On              | On/Off                    | A                      | — | × |
|                                                        | The distance at which the vehicle ahead and your vehicle indicated in the display flashes in white can be changed.                              |        | Near            | Far/Med/Near              | A                      | — | × |
| Traffic Sign Recognition System (TSR)*4 (page 4-95)    | The Traffic Sign Recognition System (TSR) can be set to inoperable.*1                                                                           |        | On              | On/Off                    | A                      | — | × |
|                                                        | The warning pattern of the excessive speed warning can be changed.                                                                              |        | Off             | Off/Visual/Audio & Visual | A                      | — | × |
|                                                        | The activation timing for the excessive speed warning can be changed.                                                                           |        | +0              | +0/+5/+10                 | A                      | — | × |

## 9-10

## Personalisation Features

| Item                                     | Feature                                                                                                                                                 | Factory Setting                     | Available Settings                                                                                                                   | Settings Change Method |   |   |
|------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------|------------------------|---|---|
|                                          |                                                                                                                                                         |                                     |                                                                                                                                      | ①                      | ② | ③ |
| 360° View Monitor (page 4-147)           | Setting can be changed so that the 360° view monitor is automatically displayed when the ignition is switched to ON.                                    | Off                                 | On/Off                                                                                                                               | A                      | — | × |
|                                          | Setting can be changed so that the display of the estimated forward line of progress is not displayed.                                                  | On                                  | On/Off                                                                                                                               | A                      | — | × |
|                                          | Setting can be changed so that the top view/front view displayed while the vehicle is moving in the forward direction after reversing is not displayed. | On                                  | On/Off                                                                                                                               | A                      | — | × |
| Parking sensor system (page 4-206)       | Display*5/non-display                                                                                                                                   | On                                  | On/Off                                                                                                                               | A                      | — | × |
| <b>Vehicle</b>                           |                                                                                                                                                         |                                     |                                                                                                                                      |                        |   |   |
| Door locks (page 3-10)                   | Operation condition of auto lock/unlock function                                                                                                        | Lock: When Driving Un-lock: IGN Off | Lock: Out of Park Un-lock: In Park/<br>Lock: Shifting Out of Park/<br>Lock: When Driving Un-lock: IGN Off/<br>Lock: When Driving/OFF | A                      | D | × |
| Keyless entry system (page 3-3)          | Time for locking door automatically                                                                                                                     | 30 seconds                          | 90 seconds/<br>60 seconds/<br>30 seconds                                                                                             | A                      | — | × |
| Advanced keyless entry system (page 3-7) | Time for locking door automatically                                                                                                                     | 30 seconds                          | 90 seconds/<br>60 seconds/<br>30 seconds                                                                                             | A                      | — | × |
|                                          | Auto-lock function operation/non-operational                                                                                                            | Off                                 | On/Off                                                                                                                               | A                      | — | × |
|                                          | Beep volume when locking/unlocking                                                                                                                      | Medium                              | High/<br>Medium/<br>Low/<br>Off                                                                                                      | A, E, F                | — | × |

Specifications

## Personalisation Features

| Item                                       | Feature                                                                                  | Factory Setting | Available Settings                                               | Settings Change Method |   |   |
|--------------------------------------------|------------------------------------------------------------------------------------------|-----------------|------------------------------------------------------------------|------------------------|---|---|
|                                            |                                                                                          |                 |                                                                  | ①                      | ② | ③ |
| Illuminated entry system (page 5-143)      | Time until interior lights turn off after closing door                                   | 15 seconds      | 60 seconds/<br>30 seconds/<br>15 seconds/<br>7.5 seconds         | A                      | — | × |
|                                            | Time until interior lights turn off automatically when any door is not closed completely | 30 minutes      | 60 minutes/<br>30 minutes/<br>10 minutes                         | A                      | — | × |
| Auto-wiper control (page 4-53)             | Operational/non-operational                                                              | On              | On/Off*6                                                         | A                      | — | × |
| Running lights (page 4-51)                 | Operational/non-operational                                                              | On              | On/Off                                                           | —                      | — | × |
| Auto-light control (page 4-47)             | Timing by which lights turn on                                                           | Medium          | High/<br>Med. High/<br>Medium/<br>Med. Low/<br>Low               | A                      | — | × |
| High Beam Control System (HBC) (page 4-77) | Operational/non-operational*1                                                            | On              | On/Off                                                           | A                      | — | × |
| Adaptive LED Headlights (ALH) (page 4-79)  | Operational/non-operational*1                                                            | On              | On/Off                                                           | A                      | — | × |
| Lights-on reminder (page 7-37)             | Warning beep volume                                                                      | High            | High/Low/Off                                                     | A                      | — | × |
| Coming home light (page 4-50)              | Time until headlights turn off                                                           | 30 seconds      | 120 seconds/<br>90 seconds/<br>60 seconds/<br>30 seconds/<br>Off | A                      | — | × |
| Leaving home light (page 4-51)             | Operational/non-operational                                                              | Off             | On/Off                                                           | A                      | — | × |
| Direction indicator (page 4-52)            | Beep volume                                                                              | High            | High/Low                                                         | A                      | — | × |
| Three-flash turn signal (page 4-52)        | Operational/non-operational                                                              | On or Off       | On/Off                                                           | A                      | — | × |

## 9-12



## Personalisation Features

| Item                                      | Feature                                                                                                        | Factory Setting | Available Settings                                      | Settings Change Method |   |   |
|-------------------------------------------|----------------------------------------------------------------------------------------------------------------|-----------------|---------------------------------------------------------|------------------------|---|---|
|                                           |                                                                                                                |                 |                                                         | ①                      | ② | ③ |
| Rear window defogger (page 4-57)          | The operation time for the rear window defogger can be changed.                                                | 15 minutes      | 15 minutes/Continuous*7                                 |                        |   | × |
| <b>System</b>                             |                                                                                                                |                 |                                                         |                        |   |   |
| Language                                  | Language indicated in display                                                                                  | English         | Depends on market*8                                     | A                      |   | × |
| Temperature                               | Temperature unit indicated in display                                                                          | °C              | °F/°C                                                   | A                      |   | × |
| Distance                                  | Distance unit indicated in display                                                                             | km              | mi/km                                                   | A                      |   | × |
| <b>Fuel Economy Monitor</b> (page 4-69)   |                                                                                                                |                 |                                                         |                        |   |   |
| Ending display                            | Display/non-display                                                                                            | Off             | On/Off                                                  | B                      |   | × |
| Fuel economy re-setting procedure         | Linkage/non-linkage with fuel economy reset and trip meter reset                                               | Off             | On/Off                                                  | B                      |   | × |
| <b>Active Driving Display</b> (page 4-26) |                                                                                                                |                 |                                                         |                        |   |   |
| Display                                   | Setting can be changed so that the Active Driving Display is not displayed.                                    | On              | On/Off                                                  | C                      |   | × |
|                                           | The display height (up/down position) can be changed.                                                          | 0               | 13 steps up/down from initial setting (total: 27 steps) | C                      |   | × |
|                                           | The method for adjusting the display brightness (automatically/manually) can be changed.                       | AUTO            | AUTO/MANUAL                                             | C                      |   | × |
|                                           | The standard brightness while automatic adjustment is selected can be changed using the brightness adjustment. | 0               | 2 steps up/down from initial setting (total: 5 steps)   | C                      |   | × |
|                                           | The standard brightness while manual adjustment is selected can be changed using the brightness adjustment.    | 0               | 20 steps up/down from initial setting (total: 41 steps) | C                      |   | × |
| Navigation guidance                       | Display/non-display                                                                                            | OFF             | On/Off                                                  | C                      |   | × |

\*1 Though these systems can be turned Off, doing so will defeat the purpose of the system and Mazda recommends that these systems remain On.

## Specifications

# Personalisation Features

---

- \*2 For vehicles with an audio system other than the on-screen function type, the warning sound cannot be changed. The warning sound is only a beep.
- \*3 Only the volume of the warning beep during Blind Spot Monitoring (BSM) operation can be changed. The volume of the warning beep during Rear Cross Traffic Alert (RCTA) operation cannot be changed.
- \*4 This system functions only when the navigation system is functioning.
- \*5 When the ultrasonic sensors detect an obstruction, the contents indicated on the centre display switches to the 360°View Monitor. (Vehicles with 360°View Monitor)
- \*6 If the auto-wiper control is set to Off, the wiper lever **AUTO** position is set to intermittent operation.
- \*7 The operation may stop in 15 minutes due to the effect of the outside temperature even if the operation time of the rear window defogger has been changed to Continuous.
- \*8 Available only in display from the centre display.

# 10 Index



## Index

---

### A

Accessory Socket..... 5-143  
Active Driving Display..... 4-26  
Adaptive LED Headlights (ALH)..... 4-79  
Add-On Non-Genuine Parts and  
Accessories..... 8-3  
Adjustable Speed Limiter (ASL).... 4-129  
    Activation/deactivation..... 4-132  
    Adjustable Speed Limiter (ASL)  
    display..... 4-129  
    Adjustable Speed Limiter (ASL)  
    main indication (white)..... 4-131  
    Adjustable Speed Limiter (ASL) set  
    indication (white)/indicator light  
    (green)..... 4-131  
    Setting the system..... 4-134  
    Speed limiter warning beep..... 4-131  
    Temporarily cancelling the  
    system..... 4-135  
Advanced Key  
    Advanced keyless entry system..... 3-7  
    Operational range..... 3-8  
Advanced Smart City Brake Support  
(Advanced SCBS)..... 4-136  
    Collision warning..... 4-138  
    Smart City Brake Support (SCBS)  
    Indicator Light (Red)..... 4-138  
    Stopping the Advanced Smart City  
    Brake Support (Advanced SCBS)  
    system operation..... 4-138  
Air Bag Systems..... 2-43  
Air Bag/Seat Belt Pretensioner System  
Warning Beep..... 7-37  
Air-Conditioning System..... 5-4  
    Fully Automatic Type..... 5-11  
    Manual Type..... 5-7  
    Operating Tips..... 5-4  
    Vent Operation..... 5-5  
Ambient Temperature Display..... 4-23  
Antilock Brake System (ABS)..... 4-65

#### Audio Control Switch

    Adjusting the Volume..... 5-14  
    Seek Switch..... 5-14

#### Audio Set [Type A (non-touchscreen)]

    AUX..... 5-28  
    Bluetooth®..... 5-35  
    CD Player..... 5-25  
    Clock..... 5-22  
    Error Indications..... 5-34  
    iPod mode..... 5-32  
    Power/Volume/Sound Controls... 5-20  
    Radio..... 5-23  
    Troubleshooting..... 5-63  
    USB..... 5-29  
    Voice Recognition..... 5-59

#### Audio Set [Type B (touchscreen)]

    Android Auto™..... 5-92  
    Apple CarPlay..... 5-89  
    Applications..... 5-125  
    AUX..... 5-82  
    Bluetooth®..... 5-96  
    CD Player..... 5-79  
    Digital Audio Broadcasting (DAB)  
    Radio..... 5-77  
    Radio..... 5-74  
    Radio (RDS)..... 5-74  
    Settings..... 5-122  
    Troubleshooting..... 5-126  
    USB..... 5-83  
    Voice Recognition..... 5-119  
    Volume/Display/Sound  
    Controls..... 5-72

#### Audio System

    Aerial..... 5-19  
    Appendix..... 5-132  
    Audio Control Switch..... 5-14  
    Audio Set [Type A (non-  
    touchscreen)]..... 5-20  
    Audio Set [Type B  
    (touchscreen)]..... 5-67  
    AUX/USB mode..... 5-15

## Index

Before Using the Audio System..... 5-14  
Automatic Transaxle..... 4-38  
    Active Adaptive Shift (AAS)..... 4-41  
    Automatic transaxle controls..... 4-38  
    Driving tips..... 4-46  
    Manual shift mode..... 4-42  
    Shift-lock system..... 4-39  
    Transaxle ranges..... 4-40

## B

Battery..... 6-22  
    Inspecting Electrolyte Level..... 6-24  
    Maintenance..... 6-23  
    Recharging..... 6-24  
    Replacement..... 6-24  
    Specifications..... 9-3  
Battery runs out..... 7-14  
    Jump-Starting..... 7-14  
Blind Spot Monitoring (BSM)..... 4-89  
    Cancelling operation of Blind Spot Monitoring (BSM)..... 4-94  
Blind Spot Monitoring (BSM) System warning beep..... 7-39  
Bluetooth® [Type A (non-touchscreen)]  
    Bluetooth® Audio..... 5-50  
    Bluetooth® Hands-Free..... 5-52  
    Bluetooth® Preparation..... 5-38  
Bluetooth® [Type B (touchscreen)]  
    Bluetooth® Audio..... 5-102  
    Bluetooth® Hands-Free..... 5-110  
    Bluetooth® Preparation..... 5-99  
Body Lubrication..... 6-18  
Bonnet Release..... 6-11  
Bottle Holder..... 5-145  
Brakes  
    Brakes assist..... 4-62  
    Foot brake..... 4-60  
    Pad wear indicator..... 4-62  
    Parking brake..... 4-61

Warning light..... 4-61

## C

Capacities..... 9-4  
Carbon Monoxide..... 3-19  
Cell Phones..... 8-4  
Child Restraint  
    Categories of child-restraint systems..... 2-28  
    Child-restraint precautions..... 2-24  
    Child-restraint system installation..... 2-28  
    Child-restraint system suitability for various seat positions table..... 2-32  
    Installing child-restraint systems..... 2-35  
Child Safety Locks for Rear Doors... 3-12  
Collision warning..... 7-41  
Coming Home Light..... 4-50  
Control Status Display..... 4-70  
Cruise Control..... 4-186  
    Cruise Control Switch..... 4-186  
    Cruise main indication (white)..... 4-187  
    Cruise set indication (white)/indicator light (green)..... 4-187  
Cruise Control Set Vehicle Speed Display..... 4-23  
Cup Holder..... 5-144

## D

Defogger  
    Rear window..... 4-57  
Dimensions..... 9-4  
Direction Indicators..... 4-52  
Distance Recognition Support System (DRSS)..... 4-87  
    Indication on display..... 4-87  
Door Locks..... 3-9  
Driver Attention Alert (DAA)..... 4-101

## Index

---

|                                                    |      |
|----------------------------------------------------|------|
| Drive selection.....                               | 4-72 |
| Driving In Flooded Area.....                       | 3-35 |
| Driving Tips                                       |      |
| Automatic transaxle.....                           | 4-46 |
| Driving in flooded area.....                       | 3-35 |
| Floor mat.....                                     | 3-32 |
| Hazardous driving.....                             | 3-32 |
| Rocking the vehicle.....                           | 3-33 |
| Running-in period.....                             | 3-31 |
| Saving fuel and protection of the environment..... | 3-31 |
| Winter driving.....                                | 3-34 |
| Dynamic Stability Control (DSC).....               | 4-67 |
| DSC OFF Indicator Light.....                       | 4-68 |
| DSC OFF Switch.....                                | 4-68 |
| TCS/DSC Indicator Light.....                       | 4-67 |

## E

|                                            |      |
|--------------------------------------------|------|
| Effectiveness Display.....                 | 4-71 |
| Electronic steering lock warning beep..... | 7-39 |
| Emergency Starting                         |      |
| Push-Starting.....                         | 7-17 |
| Starting a Flooded Engine.....             | 7-17 |
| Emergency Stop Signal System.....          | 4-63 |
| Emergency Towing                           |      |
| Towing Description.....                    | 7-20 |
| Towing/Tiedown Hooks.....                  | 7-21 |
| Emission Control Maintenance.....          | 6-42 |
| Air-intake control system.....             | 6-42 |
| Engine.....                                | 6-42 |
| Evaporative emission control system.....   | 6-43 |
| Fuel system.....                           | 6-42 |
| Ignition system.....                       | 6-43 |
| Emission Control System.....               | 3-18 |
| Ending Screen Display.....                 | 4-71 |
| Engine                                     |      |
| Bonnet release.....                        | 6-11 |
| Coolant.....                               | 6-16 |

|                               |      |
|-------------------------------|------|
| Engine Compartment            |      |
| Overview.....                 | 6-13 |
| Exhaust gas.....              | 3-19 |
| Oil.....                      | 6-14 |
| Starting.....                 | 4-5  |
| Essential information.....    | 6-2  |
| Exhaust Gas.....              | 3-19 |
| Exterior Care.....            | 6-44 |
| Aluminium Wheel               |      |
| Maintenance.....              | 6-48 |
| Bright-Metal Maintenance..... | 6-48 |
| Cavity Protection.....        | 6-48 |
| Maintaining the Finish.....   | 6-45 |
| Paint Damage Touch-up.....    | 6-48 |
| Plastic Part Maintenance..... | 6-49 |
| Undercoating.....             | 6-48 |

## F

|                                      |       |
|--------------------------------------|-------|
| Flasher                              |       |
| Hazard warning.....                  | 4-58  |
| Headlights.....                      | 4-47  |
| Flat Tyre.....                       | 7-3   |
| Mounting the Spare Tyre.....         | 7-11  |
| Removing a Flat Tyre.....            | 7-8   |
| Floor Mat.....                       | 3-32  |
| Fluid                                |       |
| Brake/Clutch.....                    | 6-17  |
| Washer.....                          | 6-18  |
| Fluids                               |       |
| Classification.....                  | 9-3   |
| Foot Brake.....                      | 4-60  |
| Forward Sensing Camera (FSC).....    | 4-174 |
| Front Seat.....                      | 2-5   |
| Fuel                                 |       |
| Filler flap and cap.....             | 3-21  |
| Gauge.....                           | 4-21  |
| Requirements (Australia).....        | 3-17  |
| Requirements (Except Australia)..... | 3-18  |
| Tank capacity.....                   | 9-4   |

## Index

- Fuel Consumption Display..... 4-70  
Fuel Economy Monitor..... 4-69  
    Control status display..... 4-70  
    Effectiveness display..... 4-71  
    Ending Screen Display..... 4-71  
    Fuel consumption display..... 4-70  
Fuses..... 6-37  
    Panel description..... 6-39  
    Replacement..... 6-37
- G**
- Gauges..... 4-19  
Glove Compartment..... 5-145
- H**
- Hazardous Driving..... 3-32  
Hazard Warning Flasher..... 4-58  
Headlights  
    Coming home light..... 4-50  
    Control..... 4-47  
    Flashing..... 4-50  
    High-low beam..... 4-50  
    Leaving home light..... 4-51  
    Levelling..... 4-51  
    Running lights..... 4-51  
Head Restraint..... 2-14  
High Beam Control System  
(HBC)..... 4-77  
Hill Launch Assist (HLA)..... 4-63  
Horn..... 4-58
- I**
- If a Warning Light Turns On or  
Flashes..... 7-23  
If the Active Driving Display Does Not  
Operate..... 7-44  
Ignition  
    Switch..... 4-4  
Ignition not switched off (STOP)  
warning beep..... 7-38
- Illuminated Entry System..... 5-143  
Immobilizer System..... 3-29  
Indicator Lights..... 4-31  
    Low engine coolant  
    temperature..... 4-35  
    Wrench..... 4-35  
Inspecting Brake/Clutch Fluid  
Level..... 6-17  
Inspecting Coolant Level..... 6-16  
Inspecting Engine Oil Level..... 6-15  
Inspecting Washer Fluid Level..... 6-18  
Instrument Cluster..... 4-19  
Instrument Panel Illumination..... 4-22  
Interior Care..... 6-50  
    Active driving display  
    maintenance..... 6-52  
    Cleaning the window interiors..... 6-52  
    Instrument panel top  
    maintenance..... 6-51  
    Leather upholstery  
    maintenance..... 6-51  
    Panel maintenance..... 6-52  
    Plastic part maintenance..... 6-51  
    Seat belt maintenance..... 6-50  
    Upholstery maintenance..... 6-51  
    Vinyl upholstery maintenance..... 6-50  
Interior Lights..... 5-141  
    Luggage Compartment Light..... 5-141  
    Map Lights..... 5-141  
    Overhead Lights..... 5-141  
i-ACTIVSENSE..... 4-74  
    Active Safety Technology..... 4-74  
    Adaptive LED Headlights  
    (ALH)..... 4-79  
    Adjustable Speed Limiter  
    (ASL)..... 4-129  
    Advanced Smart City Brake Support  
    (Advanced SCBS)..... 4-136  
    Blind Spot Monitoring (BSM)..... 4-89  
    Detection Devices..... 4-75

## Index

Distance Recognition Support System (DRSS).....4-87  
Driver Attention Alert (DAA)... 4-101  
Forward Sensing Camera (FSC)..... 4-174  
High Beam Control System (HBC)..... 4-77  
Lane Departure Warning System (LDWS)..... 4-82  
Lane-keep Assist System (LAS) & Lane Departure Warning System (LDWS)..... 4-117  
Mazda Radar Cruise Control (MRCC)..... 4-107  
Pre-Crash Safety Technology..... 4-75  
Radar Sensors (Rear).....4-182  
Radar sensor (front).....4-179  
Rear Cross Traffic Alert (RCTA)..... 4-103  
Smart Brake Support (SBS)..... 4-144  
Smart City Brake Support [Reverse] (SCBS R).....4-140  
Traffic Sign Recognition System (TSR)..... 4-95  
Ultrasonic sensor (rear)..... 4-184  
360°View Monitor.....4-147  
i-stop.....4-11  
    Indicator light (Green).....4-15  
    i-stop OFF switch.....4-16  
    Vehicle roll prevention function.....4-17  
    Warning light (Amber).....4-15  
i-stop warning beep.....7-39

## J

Jack.....7-4  
Jump-Starting..... 7-14

## K

Keyless Entry System..... 3-3

## 10-6

Keys.....3-2  
    Key suspend function.....3-6  
    Transmitter.....3-4  
Key left-in-luggage compartment warning beep (With the advanced keyless function)..... 7-39  
Key left-in-vehicle warning beep (With the advanced keyless function)..... 7-39  
Key removed from vehicle warning beep..... 7-38  
Key Suspend Function.....3-6

## L

Label Information..... 9-2  
Lane Departure Warning sound..... 7-40  
Lane Departure Warning System (LDWS).....4-82  
    LDWS switch.....4-84  
Lane-Change Signals.....4-52  
Lane-keep Assist System (LAS) & Lane Departure Warning System (LDWS).....4-117  
Leaving Home Light.....4-51  
Liftgate.....3-13  
    Luggage compartment.....3-16  
    When Liftgate Cannot be Opened.....7-42  
Lighting Control.....4-47  
Lights-on reminder.....7-37  
Light Bulbs  
    Replacement..... 6-30  
    Specifications.....9-5  
Lubricant Quality.....9-3  
Luggage Compartment.....5-147  
    Cargo sub-compartment..... 5-147  
Luggage Compartment Light.....5-141

## M

Maintenance  
    Information..... 6-2



## Index

Scheduled.....6-3  
Maintenance Monitor.....6-8  
Manual Transaxle Operation.....4-36  
Map Lights.....5-141  
Mazda Radar Cruise Control  
(MRCC).....4-107  
    Close proximity warning.....4-109  
    Cruise control function.....4-114  
    Display indication.....4-109  
    Setting the system.....4-110  
    Shift-up/shift-down request  
    display.....4-114  
Mazda Radar Cruise Control (MRCC)  
System warnings.....7-40  
Message Indicated on Display.....7-35  
Meters and Gauges.....4-19  
Mirrors  
    Outside mirrors.....3-23  
    Rearview mirror.....3-24

## O

Odometer and Trip Meter.....4-20  
Outside Mirrors.....3-23  
Outside Temperature Display.....4-23  
Overhead Lights.....5-141  
Overheating.....7-18  
Owner Maintenance  
    Closing the Bonnet.....6-11  
    Engine Compartment  
    Overview.....6-13  
    Key battery replacement.....6-25  
    Opening the Bonnet.....6-11  
    Owner Maintenance Precautions...6-9

## P

Parking Brake.....4-61  
Parking Sensor System.....4-202  
    Park assist sensor system  
    operation.....4-206  
    Sensor detection range.....4-204

Personalisation Features.....9-8  
Power Steering.....4-73  
Power steering warning buzzer.....7-39  
Power Windows.....3-26

## R

Radar Sensors (Rear).....4-182  
Radar Sensor (Front).....4-179  
Rearview Mirror.....3-24  
Rear Coat Hooks.....5-148  
Rear Cross Traffic Alert (RCTA)....4-103  
Rear Door Child Safety Locks.....3-12  
Rear Seat.....2-11  
Rear View Monitor.....4-194  
    Displayable range on the  
    screen.....4-196  
    Picture quality adjustment.....4-201  
    Rear view monitor operation....4-197  
    Rear view parking camera  
    location.....4-195  
    Switching to the rear view monitor  
    display.....4-195  
    Variance between actual road  
    conditions and displayed  
    Image.....4-199  
    Viewing the display.....4-197  
Rear Window Defogger.....4-57  
Rear Window Washer.....4-56  
Rear Window Wiper.....4-56  
Recommended Oil.....6-14  
Recording of Vehicle Data.....8-5  
Registering Your Vehicle in A Foreign  
Country.....8-2  
Replacement  
    Fuse.....6-37  
    Key battery.....6-25  
    Light Bulbs.....6-30  
    Tyres.....6-28  
    Wheel.....6-29  
    Wiper.....6-19

## Index

---

Request switch inoperable warning beep  
(With the advanced keyless  
function)..... 7-38  
Rocking the Vehicle..... 3-33  
Running-In Period..... 3-31

## S

Saving Fuel and Protection of the  
Environment..... 3-31  
Scheduled Maintenance..... 6-3  
Seats..... 2-5  
    Driver's seat..... 2-5  
    Front passenger's seat..... 2-10  
    Front seat..... 2-5  
    Head restraint..... 2-14  
    Rear seat..... 2-11  
Seat Belt System  
    Automatic locking..... 2-19  
    Emergency locking..... 2-19  
    Pregnant women..... 2-18  
    Seat belt precautions..... 2-16  
    3-point type..... 2-20  
Seat belt warning beep..... 7-37  
Security System  
    Immobilizer system..... 3-29  
Smart Brake Support (SBS)..... 4-144  
    Collision warning..... 4-146  
    Smart Brake Support (SBS) indicator  
    light (red)..... 4-146  
    Stopping the Smart Brake Support  
    (SBS) system operation..... 4-146  
Smart City Brake Support [Reverse]  
(SCBS R)..... 4-140  
    Smart City Brake Support (SCBS)  
    Indicator Light (Red)..... 4-143  
    Stopping the Smart City Brake  
    Support [Reverse] (SCBS R) system  
    operation..... 4-143  
Spare Tyre..... 7-5  
Specifications..... 9-3

Speedometer..... 4-20  
SRS Air Bags  
    How the SRS air bags work..... 2-49  
    Limitations to SRS air bag..... 2-53  
    Monitoring..... 2-55  
    SRS air bag deployment  
    criteria..... 2-52  
    Supplementary restraint system  
    components..... 2-48  
Starting the Engine..... 4-5  
Steering Wheel  
    Horn..... 4-58  
Storage Compartments..... 5-145  
    Glove compartment..... 5-145  
    Luggage compartment..... 5-147  
    Rear coat hooks..... 5-148  
Sunvisors..... 5-141

## T

Tachometer..... 4-21  
Towing  
    Towing Caravans and Trailers..... 3-36  
Towing Description..... 7-20  
Towing/Tiedown  
    Hook..... 7-21  
Traction Control System (TCS)..... 4-66  
    TCS/DSC Indicator Light..... 4-66  
Traffic Sign Recognition System  
(TSR)..... 4-95  
Transmitter..... 3-4  
Trip Computer..... 4-23  
Trip Meter..... 4-20  
Trouble  
    Battery runs out..... 7-14  
    Emergency Starting..... 7-17  
    Emergency Towing..... 7-20  
    Flat Tyre..... 7-3  
    Overheating..... 7-18  
    Parking in an Emergency..... 7-2

## Index

When Liftgate Cannot be  
Opened..... 7-42  
Tyres..... 6-27  
    Flat Tyre..... 7-3  
    Replacing a Tyre..... 6-28  
    Replacing a Wheel..... 6-29  
    Snow tyres..... 3-34  
    Specifications..... 9-6  
    Temporary Spare Tyre..... 6-29  
    Tyre chains..... 3-34  
    Tyre Inflation Pressure..... 6-27  
    Tyre Rotation..... 6-28  
Tyre Inflation Pressure Warning  
Beep..... 7-39  
Tyre Pressure Monitoring System... 4-191

## U

Ultrasonic Sensor (Rear)..... 4-184

## V

Vanity Mirrors..... 5-141  
Vehicle Information Labels..... 9-2  
Vehicle speed alarm..... 7-39

## W

Warning Lights..... 4-29  
Warning Sound is Activated..... 7-37  
    Air Bag/Seat Belt Pretensioner  
    System Warning Beep..... 7-37  
    Blind Spot Monitoring (BSM)  
    System warning beep..... 7-39  
    Collision warning..... 7-41  
    Electronic steering lock warning  
    beep..... 7-39  
    Ignition not switched off (STOP)  
    warning beep..... 7-38  
    i-stop warning beep..... 7-39  
    Key left-in-luggage compartment  
    warning beep (With the advanced  
    keyless function)..... 7-39

Key left-in-vehicle warning beep  
(With the advanced keyless  
function)..... 7-39  
Key removed from vehicle warning  
beep..... 7-38  
Lane Departure Warning sound... 7-40  
Lights-on reminder..... 7-37  
Mazda Radar Cruise Control  
(MRCC) System warnings..... 7-40  
Power steering warning buzzer.... 7-39  
Request switch inoperable warning  
beep (With the advanced keyless  
function)..... 7-38  
Seat belt warning beep..... 7-37  
Tyre inflation pressure warning  
beep..... 7-39  
Vehicle speed alarm..... 7-39  
Warranty..... 8-2  
Windows  
    Power windows..... 3-26  
Windscreen Washer..... 4-56  
Windscreen Wipers..... 4-53  
Winter Driving..... 3-34  
Wiper  
    Replacing Rear Window Wiper Blade  
    (Hatchback)..... 6-20  
    Replacing Windscreen Wiper  
    Blades..... 6-19

## 0-9

360°View Monitor..... 4-147  
    Front wide view..... 4-160  
    How to use the system..... 4-153  
    Margin of error between road surface  
    on screen and actual road  
    surface..... 4-170  
    Rear wide view..... 4-168  
    Side view..... 4-162  
    Top view/front view..... 4-158  
    Top view/rear view..... 4-165

## 10-9

Index

|                                              |       |
|----------------------------------------------|-------|
| Types of images displayed on the screen..... | 4-151 |
|----------------------------------------------|-------|

