

# MAZDA BT-50 GPS AND INFOTAINMENT MAP UPDATE GUIDE



In this guide are step-by-step instructions to update the maps and get the most from your BT-50 GPS and infotainment system.

Map updates are usually released once a year and as a Mazda owner, you are entitled to 3 complimentary updates.

To perform the map update, you will require a USB stick and a Windows PC with internet access.

Map updates for your Mazda BT-50 are accessed from the iAuto website—<https://mazda.aus.iauto.com>. For further information, please refer to the vehicle Owner's Manual.

## PREPARE THE USB MEMORY DRIVE


Format a USB memory stick (8GB or larger) using your Windows PC. The file system format must be FAT32



In your car, connect the USB memory stick to the USB port located below the multimedia system



Touch the following icons to access the system settings menu.



Touch "About" then "System Information".

Touch "Export to USB" to export the Auth code. Once complete, remove the USB flash drive from the car.

## DOWNLOAD THE UPDATED MAP PACKAGE

Connect the prepared USB flash drive to your Windows PC. Navigate to the iAuto website (<https://mazda.aus.iauto.com>) and click "Import AuthCode" then click the search icon.

The website will display any available map packages, your remaining free downloads and the free map expiry date.



Download the three listed files to your USB flash drive to obtain the updated map package.



## UPDATE THE NAVIGATION SYSTEM

In your car, connect the USB flash drive containing the map update package. An update icon will be displayed on the status bar when the USB drive is detected

Drag the status bar downwards to display the information screen. Touch the "System & Data Update" option then touch "OK" to begin the update

Once the update is complete, a message will appear advising that the system will restart. When the system restart is complete, the USB flash drive can be removed and the map update is complete.